

FS SERIES C FUNCTION LIST (SOFTWARE VER. XWF)

C FUNCTION	SETTING	COMMENT
C 1 Capacity	0 1 2 3 4 5 6	6kg 15kg 30kg internal count 60kg 150kg 300kg
C 2 Metric/Non Metric	0 1	ALL KA and KL series for Aust Non Metric (non NSC approved)
C 3 International/Domestic	0 1 2	ALL KA and KL series for Aust Japanese approval Tare at lower range only
C 4 Normal/NTEO (USA approval model)	0 1	ALL KA and KL series for Aust.
C 5 Resolution	0 1	1/3000 dual range (KA series) 1/3000 single range (KL series)
C 6 Miscellaneous	0 1 9	KL 30kg (RS232 decimal point fix) KA series KL 60/150kg

PROCEDURE TO ENTER C SETTING

1. Press Calibration key.
2. When display shows C kg press the CLEAR key.
3. Press 5 0 3 then the ENTER key.
4. Display will show the C 1 setting.
5. Press ENTER key to accept the setting or enter the correct value using the numeric keys, then press the ENTER key.
6. Continue until display show C END.
7. Press the ENTER key to display C kg.
8. Press the ENTER key to resume weighing.
9. Turn indicator off then on again to enable any changes to C settings.