

SK Model Setting Procedure

1. Press and hold the **Zero** key, press the **centre** hidden key and the **On** key.
2. Keep the **Zero** key pressed, release the **On** key and the **Centre** key then immediately press the **Centre** key twice. Release the **Zero** key.
3. The display will show the software version number i.e. **P-3.0**.
4. Press the Centre key, the display will show **CAL**.
5. Press the Centre key, the display will show **Adj**.
6. Press and hold the **Zero** key and momentarily press the **Centre** key.
7. **0030** or similar appears depending on the model as shown below.
8. Press the **Zero** key, the decimal point appears.
9. Increase the value of the digit to the right of the decimal point with the **Zero** key.
10. Move the decimal point to the left using hidden key, e.g. **00.30**
11. Use combination of the **Centre** and **Zero** keys to set the capacity.

e.g.

SETTING	MODEL/CAPACITY
0000	SK 1000g
0010	SK 2000g
0020	SK 5000g
0021	SK 5001g
0030	SK 10K
0040	SK 20K
0050	SK 30K

12. Press and hold the **Centre** key and press **Zero** key simultaneously.
13. **20** appears, press the **Centre** key **-t-** appears, then press the **Centre** key again.
14. **CAL t** appears. Press **Zero** key.
15. **CAL 0** appears. Press **Zero** key.
16. **CAL F** appears. Place capacity mass on scale and press **Zero** key,
e.g. SK 2000=2 kg.
17. **CAL End**: Turn scale off then on, scale will be weighing normally.