

HX SERIES

MAINTENANCE MANUAL

Maintenance-HX-series-v.1.a 92.09.28.

ELECTRONIC BALANCES

MODELS

HX-100

HX-400

HX-3000

HX-6000



CONTENTS

COMPLIANCE WITH FCC RULES ...	Page 1
1. INTRODUCTION	Page 2
1.1 Equipment and Tools Required	Page 2
1.2 Corrective Maintenance Outline	Page 3
2. PERFORMANCE TEST	Page 4
2.1 Performance Test Procedure	Page 4
2.2 Test Details	Page 5
3. CORRECTIVE MAINTENANCE	Page 8
3.1 Troubleshooting Table	Page 8
3.2 HX Maintenance Flowchart	Page 12
4. DISASSEMBLY AND REASSEMBLY OF MECHANICAL UNIT	Page 21
4.1 Disassembly	Page 22
4.2 Cleaning of Bobbin	Page 25
4.3 Reassembly	Page 26
5. ADJUSTMENT	Page 31
5.1 HX Series Adjustment Specifications	Page 31
5.2 Reassembly and Adjustment Flowchart	Page 32
5.3 General Precautions	Page 33
5.4 Check Mode	Page 36
5.5 Initial Setting	Page 37
5.6 Initialization	Page 37

5.7	Unit Type Setting	Page 38
5.8	Rough Operation Check	Page 39
5.9	Rough Adjustment.....	Page 40
5.10	Temperature Adjustment	Page 42
5.11	Fine Adjustment	Page 44
5.12	Adjustment Specifications	Page 49
6.	BLOCK DIAGRAM.....	Page 53
7.	ELECTRONIC PARTS LIST	Page 55
	PZ:2497 Logic Board (ver. 2.xx).....	Page 57
	PZ:2498 Power Supply Board.....	Page 59
	PZ:2499 Interface Board.....	Page 61
	PZ:2501 Display Board.....	Page 63
	PZ:2503 HX-04.....	Page 65
	PZ:2513 Motor Board.....	Page 67
	PZ:2598 Logic Board (ver.1.xx).....	Page 69
	PZ:2636 HX-05.....	Page 71
	PZ:2645 HX-06.....	Page 73
8.	CIRCUIT DIAGRAMS.....	Page 75
	PZ:2498 Power Supply Board.....	Page 77
	PZ:2499 Interface Board.....	Page 79
	PZ:2501 Display Board.....	Page 81
	PZ:2503 HX-04.....	Page 83
	PZ:2513 Motor Board.....	Page 85
	PZ:2598 Logic Board (ver.1.xx).....	Page 87
	PZ:2636 HX-05.....	Page 89
	PZ:2645 HX-06.....	Page 91

9. PARTS LAYOUT	Page 93
PZ:2497 Logic Board (ver.2.xx).....	Page 95
PZ:2498 Power Supply Board.....	Page 97
PZ:2499 Interface Board.....	Page 99
PZ:2501 Display Board.....	Page 101
PZ:2503 HX-04.....	Page 103
PZ:2513 Motor Board.....	Page 105
PZ:2598 Logic Board (ver.1.xx).....	Page 107
PZ:2636 HX-05.....	Page 109
PZ:2645 HX-06.....	Page 111
 10. EXPLODED VIEWS.....	 Page 113
Screws List	Page 115
HX100.....	Page 119
Breeze break (OP-10, OP-11).....	Page 133
HX400.....	Page 137
HX3000	Page 149
HX6000	Page 163



Compliance with FCC Rules

Please note that this equipment generates, uses and can radiate radio frequency energy. This equipment has been tested and has been found to comply with the limits of a Class A computing device pursuant to Subpart J of Part 15 of FCC rules. These rules are designed to provide reasonable protection against interference when equipment is operated in a commercial environment. If this unit is operated in a residential area it might cause some interference and under these circumstances the user would be required to take, at his own expense, whatever measures are necessary to eliminate the interference.

(FCC = Federal Communications Commission in the U.S.A.)



1. INTRODUCTION

For smooth maintenance, the products must be technically understood, and the required equipment and tools must be prepared. Since the HX series electronic balance is a precision balance, the proper operation cannot be guaranteed if the maintenance is performed under the unsatisfactory conditions.



1.1 Equipment and Tools Required

Standard	Description
Phillips screwdriver 3 mm	For disassembly and reassembly
Posidrive screwdriver	For adjusting the counter weight
Flat bladed screwdriver	For disassembly and reassembly
Adhesive tape 8 mm	For cleaning
Mechanical alignment fixture	For disassembly and reassembly of the mechanical unit
Wrench (spanner), 8 mm	For cornerload adjustment
Wrench (spanner), 13 mm	For installation of the pan support leg
Wrench (spanner), 5.5 mm	For counter weight adjustment
Allen wrench, 3 mm	For mechanical unit repair
Allen wrench, 2.5 mm	For internal weight stopper installation
Allen wrench, 2 mm	For installation of the weld nut (motor unit)
Allen wrench, 2.5 mm	For repairing the cam and cam shaft (motor unit)
Round-nose chain pliers	For installing the lower case post & bottom parts
Soldering iron (25-40 W)	For soldering
Screw lock	For pan support receiver installation (HX400/3000/6000)
Weights	HX100: two 50 g, one 100 g (calibrated weight with correction factor) HX400: two 200 g, one 400 g (calibrated weight with correction factor) HX3000: one 1 kg, one 2 kg, one 2 kg (calibrated weight with correction factor) HX6000: three 2 kg, one 5 kg
AC adapter	The adapter will be dependent on the area of use. See the Parts List for the proper adapter.
Multimeter	
Oscilloscope	
Temperature Controlled Room	A room where the temperature can be maintained at $10 \pm 1^{\circ}\text{C}$ and $30 \pm 1^{\circ}\text{C}$ for 8 hours or more.



1.2 Corrective Maintenance Outline

Test to locate defects

To perform the corrective maintenance, defects must be located and their cause determined.

One of the easiest ways to locate a defect is to perform an operation check replacing suspected components.

Corrective maintenance procedure

The corrective maintenance procedure is described by a flowchart.

With the flowchart and the trouble-shooting table, corrective maintenance activities can be performed.

Adjustment details

An adjustment procedure is described for each unit.



2. PERFORMANCE TEST

Allow 8 hours warm-up prior to conducting the performance test.



2.1 Performance Test Procedure

Verify the following:

- External view (is the unit properly assembled and clean)
The balance has been leveled using the bubble spirit level.
The pan is level. (check for correct assembly)
- Functions
 1. Verify that each key functions correctly:
 - a) ON/OFF key
 - b) PRINT key
 - c) SAMPLE key
 - d) MODE key
 - e) CAL key
 2. Verify that the following function correctly:
 - a) The plus and minus indicators
 - b) The decimal point indicators
 - c) That a stable display is obtained.
 - d) That the motor is driving smoothly and not making abnormal noise.
 - e) External key inputs
 - f) The RS-232C interface
 - g) Selection of the weighing units
 - h) Selection of four TAEI units

Obtain the coefficient k by using a 100.000 g weight.

Example:

If 2.64557TL is displayed, obtain the coefficient by the following formula;

$$k = \frac{\text{g indication}}{\text{TL indication}} = \frac{100.000}{2.64557} = 37.799$$

	Weight												Tails	Tolerance of k
Domestic	g		%											
Export, general	g	cnt	%	lb	oz	LO	Ozt	dwt	ct	mm	GN	t		
Metric	g	cnt	%											
U.S.A.	g	cnt	%	lb	oz	LO	Ozt	dwt	ct	mm	GN			
Netherlands	g	cnt	%	lb	oz	LO	Ozt	dwt	ct	mm	GN			
Hong Kong, general	g	cnt	%	lb	oz	LO	Ozt	dwt	ct	mm	GN		TG	37.798~37.800
Hong Kong, jewelry	g	cnt	%	lb	oz	LO	Ozt	dwt	ct	mm	GN		TN	37.491~37.429
Singapore	g	cnt	%	lb	oz	LO	Ozt	dwt	ct	mm	GN		TS	37.792~37.794
Taiwan	g	cnt	%	lb	oz	LO	Ozt	dwt	ct	mm	GN		TT	37.499~37.501
Iran	g	cnt	%						ct			t	M	
India	g	cnt	%	lb	oz	LO	Ozt	dwt	ct	mm	GN	t		
Europe	g	cnt	%	lb	oz	LO	Ozt	dwt	ct	mm	GN			
Australia	g	cnt	%	lb	oz	LO	Ozt	dwt	ct	mm	GN			
U.K.	g	cnt	%	lb	oz	LO	Ozt	dwt	ct	mm	GN			



2.2 Test Details

Internal weight repeatability

After automatic calibration, put the specified calibration mass on the pan and read the displayed value.

Repeat the test five times. If the difference between the values of all five tests and the true value are within the specifications, the tested balance passes the internal weight repeatability test.

Unit type	Calibration mass used	Specifications
HX100	100g	Within ± 0.2 mg
HX400	400g	Within ± 2 mg
HX3000	3kg	Within ± 20 mg (one ± 30 mg error allowed)
HX6000	6kg	Within ± 200 mg

Repeatability


Alternately place and remove the calibration mass specified in the table below on the center of the pan and check the displayed values of the weight and zero point.

Perform three sets of tests consisting of five repetitions. If two of the test results are within specifications, the balance passes the repeatability test.

Unit type	Calibration mass used	Specifications
HX100	100g	Difference between highest and lowest values: within 0.3 mg
HX400	400g	Difference between highest and lowest values: within 2 mg
HX3000	3kg	Difference between highest and lowest values: within 20 mg
HX6000	6kg	Difference between highest and lowest values: within 200 mg

Cornerload error

Place the specified calibration mass at the center of the pan and record the displayed value. Then place the calibration mass, at positions 4, 5, 3, and 2. Check the difference between the values at the center and the four corners.



Unit type	Calibration mass used	Specifications
HX100	50g	Difference between the values at the center and the four corners; within ± 0.3 mg
HX400	200g	Difference between the values at the center and the four corners; within ± 2 mg
HX3000	2kg	Difference between the values at the center and the four corners; within ± 20 mg
HX6000	4kg	Difference between the values at the center and the four corners; within ± 200 mg

Linearity / hysteresis for HX100

After calibration, place the calibration mass on the pan and gradually add more weight until the weighing limit is reached, as specified in the table below. Check the difference between the displayed value and the true value for each weight. Remove the calibration masses one at a time after the weighing limit was reached and check the difference for each weight.

Unit type	Linearity Calibration mass used					Specifications (mg)	
						Addition	Exclusion
HX100	0g	20g	40g	60g	100g	±2	±3

Hysteresis

The Difference between increasing and decreasing at 50g to be within ±3.

Linearity / hysteresis for HX400, HX3000 & HX6000

After calibration, place the calibration mass on the pan and gradually add more weight until the weighing limit is reached, as specified in the table below. Check the difference between the displayed value and the true value for each weight. Remove the calibration masses one at a time after the weighing limit was reached and check the difference for each weight.

Unit type	Calibration mass used					Specifications (mg)	
						Addition	Exclusion
HX400	0g	100g	200g	300g	400g	±2	±3
HX3000	0g	1kg	2kg	3kg		±20	±30
HX6000	0g	2kg	4kg	6kg		±200	±200



3. CORRECTIVE MAINTENANCE

Perform corrective maintenance for the HX series by referring to the HX maintenance flowchart and the troubleshooting table. The flowchart shows the corrective maintenance procedure and the relationship between steps. The troubleshooting table describes the possible cause and solution to facilitate corrective maintenance.

Nodes in the HX maintenance flowchart

Perform corrective maintenance from the following node character according to the error:

- A: Replacing, disassembling, or assembling mechanical unit.
- B: Replacing or adjusting electrical parts.
- C: Initializing a board and inputting specific data.
- D: Adjusting the characteristics of the mechanical unit.
- E: Inputting temperature data.
- F: Performing function tests.
- G: Performing drift check.



3.1 Troubleshooting Table

The following troubleshooting table describes the possible cause of and the solution to problems. A through G in the table indicate the nodes to go to in the flowchart.

Troubleshooting Table


Problem	Location	Check	Solution
No display (position beam is not balanced)	AC adapter	Check if the correct adapter is used.	Replace with the correct adapter.
	Fuse blown	Check the fuse	Replace the fuse
	Trouble related to a cable	Check if the cable on the board PZ:2499 has been caught by the rear panel	Route the cable correctly
	Trouble related to a connector	Check the power supply board (PZ:2498) connection	Insert the connector firmly
	Board contact	Check if J16 of the motor board (PZ:2513) touches the weight handling mechanism.	Mount the board PZ:2513 as high as possible. Make terminal treatment of J16.
	Insulation error	Check the voltage on the test pin of PZ:2498.	Locate the defective board and replace with a normal one.
No display (position beam is balanced)	Display cable	Check if the display cable is disconnected.	Connect the display cable firmly.
	FFC	Check if the flat flexible cable (FFC) is disconnected.	Connect the FFC firmly.
	ROM	Check if the correct ROM is installed.	Check the ROM.
Unstable display	Parameter setting	Check if there is only one setting monitor ▲.	Press and hold the MODE key to set ▲▲▲.
	Pan and surroundings	Check if the pan and pan support are installed correctly.	Install them correctly.
	Display cable	Check if the main body is resting on the cable.	Put the display cable into the groove correctly.
	Foreign matter	Check for foreign matter in the main body.	Remove any foreign matter.
	Inside contact	Check if the cable for the analog board (PZ:2500) touches the flexible bearing assy.	Move the cable so that they will not touch the flexible bearing assy.
		Check if the FFC touches the mechanical unit.	Set the FFC so that it will not touch the mechanical unit.
		Check if the counter weight touches the flexible bearing assy.	Set the counter weight so that it will not touch the flexible bearing assy.
		Check if there is dust in the force motor magnet assy.	Disassemble the force motor, remove the dust and reassemble.
	Weight handling mechanism	Check if the internal weight touches the mechanical unit.	Adjust the weight handling mechanism.
		Check if the internal weight and weight handling mechanism are installed correctly	Adjust the weight handling mechanism position.
Unstable display	Trouble related to temperature A/D	Check if the display of T1 in the check mode is stable.	Insert J8 of the analog board (PZ:2500) firmly.
	Broken bearing	Check the flexible bearing assy. and tension bearing.	Replace any broken parts.

Problem	Location	Check	Solution
E or - E indication	Calibration error	Perform calibration.	Test the repeatability.
	Broken bearing	Check the value of D0 in the check mode.	Disassemble and reassemble the mechanical unit.
Error 0	Temp. A/D count T0 Error (8000<T0<15000)	Connecting Error	Check PZ:2500 J6/J8
		Analog board error	Change PZ:2500
		Temp. Sensor error	Change temp. Sensor of PZ:2500
Error 1	Unstable measurement using the RE-ZERO key. (more than 15 sec.	Unstable measurement display	Protect from drafts and vibration
			Check around weighing pan
Error 2 Not used	N/A	N/A	N/A
Error 3	Irregular data from AD-1652	Irregular operation.	Refer to manual.
Error 4	Error of CAL weight	Around weighing pan	Replace weighing pan
		Shipping screws installed in unit.	Remove shipping screws
		Weight A/D conversion process.	Change parts & units.
		CAL weight system.	Check CAL weight system.
Error 5	Motor error		
Error 6	RAM read / write error	defective solder joint.	Check logic board.
		Defective CPU.	Replace CPU
Error 7	Product type setting error	Product type not set.	Set product type.
		Bad connection or solder joint.	Check signal J5 of logic board.
		EEPROM error.	Change analog board.
Error 8 Not used	N/A	N/A	N/A
Abnormal repeatability	Foreign matter or broken bearing	See "Unstable display"	Disassemble and reassemble the mechanical unit.
Large cornerload error	Erroneous level adjustment	Check if the bubble is centered in the bubble spirit level.	Adjust the level.
	Erroneous cornerload adjustment	Retry cornerload adjustment	Replace flexible bearing assemblies, tension and fulcrum bearings, if error is not corrected by readjustment.
Abnormal linearity	Linearity changes after the balance has been in operation for a period of time	Input the linearity data again.	
	Abnormal position sensor	Check the value of D0 and the response speed.	Adjust the position sensor.
	Broken flexible bearing	Check the flexible bearing assy. and tension bearing.	Replace any broken parts.

Internal weight error	Erroneous weight set value entry	Retry the internal weight set value entry (CAL SET).	Test weight repeatability.
	Abnormal repeatability	Test weight repeatability of the balance.	Disassemble and reassemble the mechanical unit.
		Test the internal weight repeatability.	Check the weight handling mechanism.
	Abnormal linearity	Test the linearity.	Input the linearity data again then perform the internal weight-set value entry.
Large repeatability error	Broken flexible bearing	Check upper and lower flexible bearing assemblies, tension and fulcrum bearings.	Replace any broken parts.
Large inclination error (HX100)	counter weight out of adjustment	Adjust the counter weight.	Refer to the adjustment procedure.
Inaccurate clock	Lithium battery	Check the battery voltage.	Replace the battery.



3.2 HX Maintenance Flowchart



↑ Type

S/N _____ Checked date ____ Year__Month__Day__ Inspector

1. External views

No scratches or dust on the case and filter	OK/NG
No scratches on the weighing pan (omitted when pan for inspection is used)	OK/NG
Two level feet (rear) are installed.	OK/NG
Underhook cap is installed on the lower case.	OK/NG
Two leg caps (one each for right and left) are installed on the upper case.	OK/NG
Correct filters and key switches are installed.	OK/NG
Screws are tightened on the rear and lower cases.	OK/NG
Blank panel is installed on the rear case (omitted when optional unit is installed).	OK/NG
Name plates are correctly attached (according to the modification code table for export versions).	OK/NG
Weighing pan is level.	OK/NG
The proper level is provided by the bubble spirit level.	OK/NG

2. Functions

The ON/OFF key functions correctly	OK/NG
The RE-ZERO key functions correctly	OK/NG
The MODE key functions correctly	OK/NG
The SAMPLE key functions correctly	OK/NG
The CAL key functions correctly	OK/NG
The PRINT key functions correctly	OK/NG
Uniform brightness is obtained on the display.	OK/NG
All segments (except 'NET' and 'ANIMAL') are displayed when the display is turned on.	OK/NG
The decimal point is displayed (according to the modification code table for export versions).	OK/NG
The stabilization mark is displayed.	OK/NG
Correct remote key entry is obtained.	OK/NG
Correct RS-232C interface is obtained.	OK/NG
Correct remote control operation is obtained.	OK/NG
Correct OP- () operation is obtained.	OK/NG
Correct OP- () operation is obtained.	OK/NG

3. Performance

Error is within 1 count.																		
Stability is within 1 count.																		
Internal weight repeatability (checked with 100 g calibration mass) Specifications: within ± 2 counts			OK/NG															
1		4																
2		5																
3																		
Repeatability Specifications: within 3 counts for the difference between the highest and lowest values			OK/NG															
Repetitions	0 g	100 g																
1																		
2																		
3																		
4																		
5																		
Cornerload error (checked with 50 g mass) Specifications: within ± 3 counts for the difference between the values at the center and the four corners			OK/NG															
<table border="1" style="margin: auto;"> <tr> <td>4</td> <td>()</td> <td>()</td> <td>5</td> </tr> <tr> <td></td> <td></td> <td>6</td> <td>()</td> </tr> <tr> <td></td> <td></td> <td>1</td> <td>()</td> </tr> <tr> <td>3</td> <td>()</td> <td>()</td> <td>2</td> </tr> </table>				4	()	()	5			6	()			1	()	3	()	()
4	()	()	5															
		6	()															
		1	()															
3	()	()	2															
Linearity Specifications: within ± 2 counts			OK/NG															
Calibration mass used	Weight values																	
0g																		
20g																		
40g																		
60g																		
80g																		
100g																		

4. Storage and Shipping

The two screws for transportation are tightened on the lower case.	OK/NG
--	-------

↑ Type

S/N _____ Checked date ____ Year__Month__Day__ Inspector

1. External views

No scratches or dust on the case and filter	OK/NG
No scratches on the weighing pan (omitted when pan for inspection is used)	OK/NG
Two level feet (rear) are installed.	OK/NG
Underhook cap is installed on the lower case.	OK/NG
Two leg caps (one each for right and left) are installed on the upper case.	OK/NG
Correct filters and key switches are installed.	OK/NG
Screws are tightened on the rear and lower cases.	OK/NG
Blank panel is installed on the rear case (omitted when optional unit is installed).	OK/NG
Name plates are correctly attached (according to the modification code table for export versions).	OK/NG
Weighing pan is level.	OK/NG
The proper level is provided by the bubble spirit level.	OK/NG

2. Functions

The ON/OFF key functions correctly	OK/NG
The RE-ZERO key functions correctly	OK/NG
The MODE key functions correctly	OK/NG
The SAMPLE key functions correctly	OK/NG
The CAL key functions correctly	OK/NG
The PRINT key functions correctly	OK/NG
Uniform brightness is obtained on the display.	OK/NG
All segments (except 'NET' and 'ANIMAL') are displayed when the display is turned on.	OK/NG
The decimal point is displayed (according to the modification code table for export versions).	OK/NG
Correct remote key entry is obtained.	OK/NG
Correct RS-232C interface is obtained.	OK/NG
Correct remote control operation is obtained.	OK/NG
Correct OP- () operation is obtained.	OK/NG
Correct OP- () operation is obtained.	OK/NG

3. Performance

Error is within 1 count.																		
Stability is within 1 count.																		
Internal weight repeatability (checked with 400 g calibration mass) Specifications: within ± 2 counts			OK/NG															
1		4																
2		5																
3																		
Repeatability Specifications: within 2 counts for the difference between the highest and lowest values			OK/NG															
Repetitions	0 g	400 g																
1																		
2																		
3																		
4																		
5																		
Cornerload error (checked with 200 g mass) Specifications: within ± 2 counts for the difference between the values at the center and the four corners			OK/NG															
<table border="1" style="margin: auto;"> <tr> <td>4</td> <td>()</td> <td>()</td> <td>5</td> </tr> <tr> <td></td> <td></td> <td>6 ()</td> <td></td> </tr> <tr> <td></td> <td></td> <td>1 ()</td> <td></td> </tr> <tr> <td>3</td> <td>()</td> <td>()</td> <td>2</td> </tr> </table>				4	()	()	5			6 ()				1 ()		3	()	()
4	()	()	5															
		6 ()																
		1 ()																
3	()	()	2															
Linearity Specifications: within ± 2 counts for addition within ± 3 counts for exclusion			OK/NG															
Calibration mass used	Increase	Decrease																
0g																		
100g																		
200g																		
300g																		
400g																		

4. Storage and Shipping

The two screws for transportation are tightened on the lower case.	OK/NG
--	-------

↑ Type

S/N _____ Checked date ____ Year__Month__Day__ Inspector

1. External views

No scratches or dust on the case and filter	OK/NG
No scratches on the weighing pan (omitted when pan for inspection is used)	OK/NG
Two level feet (rear) are installed.	OK/NG
Underhook cap is installed on the lower case.	OK/NG
Two leg caps (one each for right and left) are installed on the upper case.	OK/NG
Correct filters and key switches are installed.	OK/NG
Screws are tightened on the rear and lower cases.	OK/NG
Blank panel is installed on the rear case (omitted when optional unit is installed).	OK/NG
Name plates are correctly attached (according to the modification code table for export versions).	OK/NG
Weighing pan is level.	OK/NG
The proper level is provided by the bubble spirit level.	OK/NG

2. Functions

The ON/OFF key functions correctly	OK/NG
The RE-ZERO key functions correctly	OK/NG
The MODE key functions correctly	OK/NG
The SAMPLE key functions correctly	OK/NG
The CAL key functions correctly	OK/NG
The PRINT key functions correctly	OK/NG
Uniform brightness is obtained on the display.	OK/NG
All segments (except 'NET' and 'ANIMAL') are displayed when the display is turned on.	OK/NG
The decimal point is displayed (according to the modification code table for export versions).	OK/NG
Correct remote key entry is obtained.	OK/NG
Correct RS-232C interface is obtained.	OK/NG
Correct remote control operation is obtained.	OK/NG
Correct OP- () operation is obtained.	OK/NG
Correct OP- () operation is obtained.	OK/NG

3. Performance

Error is within 1 count.																			
Stability is within 1 count.																			
Internal weight repeatability (checked with 3 kg calibration mass) Specifications: within ± 2 counts (± 3 counts allowed only for once)				OK/NG															
1		4																	
2		5																	
3																			
Repeatability Specifications: within 2 counts for the difference between the highest and lowest values				OK/NG															
Repetitions	0 g	3000 g																	
1																			
2																			
3																			
4																			
5																			
Cornerload error (checked with 2 kg mass) Specifications: within ± 2 counts for the difference between the values at the center and the four corners				OK/NG															
<table border="1" style="margin: auto;"> <tr> <td>4</td> <td>()</td> <td>()</td> <td>5</td> </tr> <tr> <td></td> <td></td> <td>6 ()</td> <td></td> </tr> <tr> <td></td> <td></td> <td>1 ()</td> <td></td> </tr> <tr> <td>3</td> <td>()</td> <td>()</td> <td>2</td> </tr> </table>					4	()	()	5			6 ()				1 ()		3	()	()
4	()	()	5																
		6 ()																	
		1 ()																	
3	()	()	2																
Linearity Specifications: within ± 2 counts for addition within ± 3 counts for exclusion				OK/NG															
Calibration mass used	Increase	Decrease																	
0g																			
1000g																			
2000g																			
3000g																			

4. Storage and Shipping

The two screws for transportation are tightened on the lower case.	OK/NG
--	-------

↑ Type

S/N _____ Checked date ____ Year__Month__Day__ Inspector

1. External views

No scratches or dust on the case and filter	OK/NG
No scratches on the weighing pan (omitted when pan for inspection is used)	OK/NG
Two level feet (rear) are installed.	OK/NG
Underhook cap is installed on the lower case.	OK/NG
Two leg caps (one each for right and left) are installed on the upper case.	OK/NG
Correct filters and key switches are installed.	OK/NG
Screws are tightened on the rear and lower cases.	OK/NG
Blank panel is installed on the rear case (omitted when optional unit is installed).	OK/NG
Name plates are correctly attached (according to the modification code table for export versions).	OK/NG
Weighing pan is level.	OK/NG
The proper level is provided by the bubble spirit level.	OK/NG

2. Functions

The ON/OFF key functions correctly	OK/NG
The RE-ZERO key functions correctly	OK/NG
The MODE key functions correctly	OK/NG
The SAMPLE key functions correctly	OK/NG
The CAL key functions correctly	OK/NG
The PRINT key functions correctly	OK/NG
Uniform brightness is obtained on the display.	OK/NG
All segments (except 'NET' and 'ANIMAL') are displayed when the display is turned on.	OK/NG
The decimal point is displayed (according to the modification code table for export versions).	OK/NG
Correct remote key entry is obtained.	OK/NG
Correct RS-232C interface is obtained.	OK/NG
Correct remote control operation is obtained.	OK/NG
Correct OP- () operation is obtained.	OK/NG
Correct OP- () operation is obtained.	OK/NG

3. Performance

Error is within 1 count.																	
Stability is within 1 count.																	
Internal weight repeatability (checked with 6 kg calibration mass) Specifications: within ± 2 counts		OK/NG															
1	4																
2	5																
3																	
Repeatability Specifications: within 2 counts for the difference between the highest and lowest values		OK/NG															
Repetitions	0 g		6000 g														
1																	
2																	
3																	
4																	
5																	
Cornerload error (checked with 4 kg mass) Specifications: within ± 2 counts for the difference between the values at the center and the four corners		OK/NG															
<table border="1" style="margin: auto;"> <tr> <td>4</td> <td>()</td> <td>()</td> <td>5</td> </tr> <tr> <td></td> <td></td> <td>6 ()</td> <td></td> </tr> <tr> <td></td> <td></td> <td>1 ()</td> <td></td> </tr> <tr> <td>3</td> <td>()</td> <td>()</td> <td>2</td> </tr> </table>			4	()	()	5			6 ()				1 ()		3	()	()
4	()	()	5														
		6 ()															
		1 ()															
3	()	()	2														
Linearity Specifications: within ± 1 count for addition within ± 2 counts for exclusion		OK/NG															
Calibration mass used	Increase		Decrease														
0g																	
2000g																	
4000g																	
6000g																	

4. Storage and Shipping

The two screws for transportation are tightened on the lower case.	OK/NG
--	-------



4. DISASSEMBLY AND REASSEMBLY OF MECHANICAL UNIT


This chapter describes the procedures and notes for the flexible bearing assy. replacement, bobbin cleaning, and adjustment after reassembly of the mechanical unit.

Notes: Use a dust free environment for disassembly and reassembly.

Adjustments are needed after reassembly for linearity, repeatability, and cornerload error.

Temperature adjustment is also needed since the balance is affected by tightening torque or stress. Do not disassemble and reassemble where the temperature adjustment cannot be performed.

Mechanical alignment fixture:



Other tools required:

Phillips screwdriver, 3mm
Allen wrench, 4mm



4.1 Disassembly

This section describes the disassembly procedure using the HX-400 as an example.

- Step 1** Remove the upper case
- Step 2** Remove the rear panel, avoid damaging the cable. (Fig. 2)
- Step 3** Remove the weight stopper. (Fig. 3)
- Step 4** Remove the mechanical unit from the lower case. (Fig. 4)
- Step 5** Remove the weight arm. (Fig. 5)




Fig.2




Fig.4




Fig.5

(This operation does not apply to HX-3000 and HX-6000)

- Step 6** Remove the pan support receiver. (Fig. 5)
- Step 7** Attach the mechanical unit to the main fixture (four screws in front and four on the bottom). (Fig. 6 & 7)





Fig.6



Step 8 Remove the upper flexible bearing assy. (Fig. 8)

Step 9 Place the unit upside-down and remove the lower flexible bearing assy. (Fig. 9)




Fig.8




Fig.9

Step 10 Remove the tension bearing while holding the beam. (Fig. 10 & 11)




Fig.11




Fig.10

Step 11 Remove the mechanical unit from the main fixture. Then remove the suspension guide from the mechanical unit. (Fig. 12)




Fig.12

- Step 12** Attach the mechanical unit to the main fixture with seven screws (four in the front and three on the bottom).




Fig.13

- Step 13** Remove the fulcrum bearings.




Fig.14

- Step 14** Remove the wire using the soldering iron.

- Step 15** Remove the shield plate, the position beam and bobbin, taking care not to damage them.

- Step 16** Place the flexible bearing assy. and the fulcrum bearing on a level surface and check their flatness. Replace them if they are bent or broken.




Fig.15




Fig.16



4.2 Cleaning the Bobbin

To clean the mechanical unit, the bobbin and the magnet must be cleaned, by the following procedure:

Step 1 Prepare a 5 cm length of adhesive tape for cleaning.

Notes: Do not use compressed air as there may be metal particles blown loose from around the magnet base.

Do not smoke during the operation.

Step 2 Disassemble the mechanical unit then remove the bobbin from the magnet.


Step 3 Remove dust from the inside of the magnet using the Adhesive tape under a bright light. Use new tape whenever the Adhesive of the current tape stops sticking.

Step 4 Clean the wire around the bobbin with adhesive tape.

Step 5 Use a bright light to confirm that no dust is remains.

Step 6 Insert the bobbin into the magnet.

Step 7 Reassemble the mechanical unit.





4.3 Reassembly

Step 1

Insert the position beam with the bobbin into the magnet taking care to avoid damage, then fasten with screws.

Step 2

Attach the mechanical unit to the main fixture (at fulcrum bearing side) then install the fulcrum bearings. (Fig. 19, 20 & 21)

Screws




Fig.18




Fig.20




Fig.19

Step 3

Adjust the bobbin position then tighten the screws. (Caution, do not scratch the bobbin.)

Step 4

Install the shield plate and H stopper. (Fig. 22)

Step 5

Solder the wire using a soldering iron.




Fig.22




Fig.21

Step 6

Replace the lower flexible bearing assy. and the suspension guide then replace the mechanical unit carefully.




Fig.23




Fig.24

Step 7

Attach the mechanical unit at the tension bearing side.




Fig.25




Fig.28

Step 8

Attach the upper flexible bearing assy. ensuring correct position and avoiding inclination.




Fig.26

Upper flexible bearing assy.
Lower flexible bearing assy.




Fig.27

Step 9

Attach the lower flexible bearing assy. ensuring correct position and avoiding inclination.

Step 10 Tighten the tension bearing lightly.




Fig.29

Step 11 Adjust the position beam with the position spacer then fasten the tension bearing firmly.




Fig.30

Step 12 Remove the mechanical unit from the main fixture then install the weight arm.




Fig.31

Weight arm

Step 13 Install the position sensor board.




Fig.32

- Step 14** Adjust the mechanical unit position with the internal weight frame then fasten it to the lower case.




Fig.33




Fig.34

- Step 15** Install the rear panel avoiding damage to the wiring.




Fig.35




Fig.36

Step 16 Replace the internal weight.




Fig.37

Step 17 Supply power for lifting the internal weight then install the internal weight stopper.




Fig.38

Step 18 Install the pan support receiver.




Fig.39

Step 19 Check the assembly performance. Refer to the ADJUSTMENTS for details.

- (1) Press the CAL key in the check mode with D6 displayed and check to see that the internal weight does not touch anything. (Repeatability check)
- (2) Adjust the cornerload error to be within ± 2 counts.
Calibration mass: 5 kg for HX-6000
2 kg for HX-3000
200 g for HX-400
50 g for HX-100
- (3) Check the linearity.
- (4) Input the internal weight error data.

If any results of performance checks are incorrect, reassemble the mechanical unit.



5. Adjustments




5.1 HX Series Adjustment Specifications

Item	HX100	HX400	HX3000	HX6000
Repeatability (five times)	$\pm 1/10\text{g}$ (D6 display)	$\pm 1/400\text{g}$ (D6 display)	$\pm 2/3\text{kg}$ (D5 display)	$\pm 2/6\text{kg}$ (D5 display)
Cornerload error				
Value difference from the center	$\pm 2/50\text{g}$	$\pm 2/200\text{g}$	$\pm 2/2\text{kg}$	$\pm 2/4\text{kg}$
Diagonal-corner error	—	—	—	2/4kg
Linearity	± 2	± 2	± 2	± 1
Hysteresis	± 3	± 3	± 3	± 2
Temperature drift				
Zero point	± 50	± 20	± 20	± 20
Span (calibration mass) (internal weight)	$\pm 30/100\text{g}$	$\pm 16/400\text{g}$	$\pm 10/3\text{kg}$	$\pm 3/5\text{kg}$
Internal weight repeatability (five times)	$\pm 1/100\text{g}$	$\pm 1/400\text{g}$	$\pm 1/3\text{kg}$	$\pm 1/6\text{kg}$
Creep (five minutes)	$\pm 3/100\text{g}$	$\pm 3/400\text{g}$	$\pm 3/3\text{kg}$	$\pm 3/6\text{kg}$
Inclination error (up to 1mm at the rear)	± 10			




5.2 Reassembly and Adjustment Flowchart



5.3 General Precautions

The data structure of the HX series is shown below. Functions listed nearer to the bottom are more basic. If any data is adjusted, the data listed above the adjusted data must also be adjusted.



PZ: 2500A/B/C/D (Analog board)

<Board type>

Unit type	PZ No.	R6	R7
HX100	PZ:2500D	200R00	None
HX400	PZ:2500A	200R00	200R00
HX3000	PZ:2500B	200R00	100R3A
HX6000	PZ:2500C	60R	None

PZ: 2481/A/B/C/D (Position sensor board)

<Board type>

Unit type	PZ No.	R13
HX100	PZ:2481D	120K
HX400	PZ:2481A	82K
HX3000	PZ:2481B	56K
HX6000	PZ:2481C	68K

PZ: 2598, PZ:2497 (Logic board) – Common to all units

<Equipment required>

- Voltmeter, capable of measuring down to 1 mV

1. Battery voltage check

- 1 Measure the voltage across the lithium battery.
→ The voltage must be 3.0 V or higher.
- 2 Measure the voltage across R1 (2.2 K).
→ The voltage must be within 3 mV to 5 mV.

PZ:2498 (Power board) - Common to all units

<Equipment required>

- Interface board PZ:2499 (normal board)
- AC adapter (see parts list for the correct adapter)
- Voltmeter, capable of measuring down to 0.1 V

1. Output voltage check

- 1 Connect the PZ:2499 2P connector to the PZ:2498/2497.
- 2 Connect the AC adapter to the PZ:2499.
- 3 Measure the voltage between test pins LG and VDD.
The voltage must be between 4.7 V and 5.3 V.
Measure the voltage between test pins LG and VEE.
The voltage must be between -9.7 V and -10.3 V.

PZ:2501 (Display board) - Common to all units

<Equipment required>

- Normal HX
- Normal key switch

1. Operation check

- 1 Connect the HX to the display board.
 - 2 Turn the power on.
 - 3 Check that [] or [P-FAIL] is displayed.
 - 4 Check that BEEP sounds when any key is pressed and no abnormal sound is heard.
 - 5 Press and hold the RE-ZERO key and press the ON/OFF key, and check that all segments are displayed.
- * The key switch may be damaged if it is connected and disconnected repeatedly. Use a new key switch if the board is replaced.




5.4 Check Mode

1. Entering check mode

- 1 Verify that the display is off.
- 2 Press and hold the RE-ZERO and MODE keys and momentarily press the ON/OFF key. Release the MODE and ON/OFF keys while holding the RE-ZERO key. Immediately press the MODE key twice. This must be done quickly (If the time is displayed in the standby mode, press and hold the RE-ZERO key and then the MODE key. Wait for about two seconds while the date is displayed, the balance enters the check mode only when the time is displayed again).
- 3 The ROM version and type are displayed as [1.00 XXXX HX]. (XXXX represents 100, 400, 3000, or 6000.)

2. Check mode menu

C-0 is displayed when the RE-ZERO key is pressed.



In the period from D0 to T1, the internal weight goes downward when the CAL key is pressed. It goes upward when the CAL key is pressed again.



5.5 Initial Setting

1. Check that all the cables are correctly installed.
 2. Connect the AC adapter.
 3. One of the following is displayed at this time:
 - 1) A decimal point (Power indicator)
 - 2) [P-FAIL]
 - 3) Time such as [12:34 AM]

The following may be displayed at this time, but they are not abnormal.

 - 1 A false time such as [0A:0F]
 - 2 Time display alters quickly.
 - 4) After all segments are displayed for several seconds, the weight value or E will be displayed. In this case, press the ON/OFF key to display 1) or 3) above.
- * 1) to 3) are defined as the display off-state.
4. Perform the initialization. (See Initialization.)
 5. Perform the unit type setting. (See Unit type setting.)
 6. Disconnect the AC adapter then reconnect it. Enter the check mode again and check that the unit type setting is correct.



5.6 Initialization

<Caution>

This operation initializes all the following data. The adjustments are also required.

- Unit type setting (set to HX-6000)
- Temperature data (cleared)
- Linearity data (cleared)
- Internal weight value (set to default)
- Time/date (set to default)
- Internal parameter setting (set to manufactures setting)

1. Entering check mode

- 1 Verify that the display is off.
- 2 Press the RE-ZERO and MODE keys.
Wait for two seconds if time is displayed. The balance enters the check mode only when time is displayed.
- 3 Press and hold the RE-ZERO and MODE keys and press the ON/OFF key. Press and hold the RE-ZERO key and immediately press the MODE key twice.
- 4 The ROM version and type are displayed such as [1.00 XXXX HX].
(XXXX is undefined.)

2. Initialization

- 1 Press and hold the MODE and SAMPLE keys and press the PRINT key. [init] will be displayed.
- 2 Press and hold the CAL key and press the RE-ZERO key. [----] will be displayed for two seconds then return to [init] display.

3. End

If the unit type setting is to be performed, proceed to the unit type setting procedure.

If the unit type is HX-6000, press the ON/OFF key to turn the display off.



5.7 Unit Type Setting

<Caution> This operation alternates the unit type setting while at the same time the default value is set to the internal weight. Internal weight-set value entry is required after this operation.

Temperature and linearity data are not affected.

- 1 Verify that the display is off.
- 2 Press and hold the RE-ZERO and MODE keys and momentarily press the ON/OFF key. Release the MODE and ON/OFF keys while holding the RE-ZERO key. Immediately press the MODE key twice.
- 3 Check that the unit type is displayed, for example, [1.00 6000 HX].
- 4 Press and hold the MODE and SAMPLE key and press the PRINT key. [init] will be displayed.
- 5 Press the MODE key. [type] will be displayed.

- 6 Press the RE-ZERO key. [X.XX 6000 HX] will be displayed.
- 7 Pressing the RE-ZERO key alternates the unit type from 6000, 3000, 400, 100, then 6000. Select the desired unit type.
- 8 Press the PRINT key. [----] will be displayed for about two seconds then return to [init] display.
- 9 Press the ON/OFF key to turn the display off and end the unit type setting.

5.8 Rough Operation Check

1. A/D count check in the check mode
 - 1 Verify that the display is off.
 - 2 Press and hold the RE-ZERO and MODE keys and momentarily press the ON/OFF key. Release the MODE and ON/OFF keys while holding the RE-ZERO key. Immediately press the MODE key twice.
 - 3 Check that the unit type is displayed, for example [1.00 3000 HX].
 - 4 Press the RE-ZERO key. [C-0] will be displayed.
 - 5 Press the RE-ZERO key. [XXX D0] will be displayed. (Weight A/D count display)
 - 6 Install the weighing pan and pan support correctly and check that the counted values are within the range mentioned in the table below.
 - 7 Press the SAMPLE key seven times. [XXXX T0] will be displayed. (Temperature A/D count display)

Check that the counted values for the room temperature between 15 and 25°C are within the range mentioned in the table below.

Unit type	D0 (Weight A/D)	T0 (Temperature A/D)
HX100	500~2500	10000±2000
HX400	500~2000	10000±2000
HX3000	500~1500	10000±2000
HX6000	500~2000	10000±2000

2. Motor operation check

- 1 Check that D0 is displayed (weight A/D count display) and press the SAMPLE key five times.
- 2 Motor rotates whenever the CAL key is pressed. Check the following points:
 - Operation the internal weight is smoothly performed.
 - No abnormal sound is heard during the weight handling.
- 3 When D5 is displayed, check the internal weight repeatability.

Unit type	Repeatability specifications (D5 display)
HX100	±2
HX400	±2
HX3000	±2
HX6000	±2

5.9 Rough Adjustment

1. Calibration

- 1 Verify that the display is on.
- 2 Check that nothing is on the weighing pan.
- 3 Press the CAL key. Automatic calibration will be performed.
- 4 After [CAL END] display, [0.00 g] will be displayed.

2. Cornerload adjustment

Perform the cornerload adjustment in the check mode with D6 displayed.

- 1 Verify that the display is on.
- 2 Press and hold the RE-ZERO and MODE keys and momentarily press the ON/OFF key. Release the MODE and ON/OFF keys while holding the RE-ZERO key. Immediately press the MODE key twice.
- 3 Check that the unit type is displayed, for example [1.00 3000 HX].
- 4 Press the RE-ZERO key. [C-0] will be displayed.
- 5 Press the RE-ZERO key. [XXXX D0] will be displayed.

- 6 Press the SAMPLE key six times. [XXXX D6] will be displayed.
- 7 Perform the cornerload adjustment. The difference between the values at the center and the four corners must be within the range given in the table below.

Unit type	Calibration mass used	Rough adjustment specifications
HX100	50g	± 5 counts
HX400	200g	± 5 counts
HX3000	2kg	± 5 counts
HX6000	4kg	± 5 counts

3. Counter weight check (for HX-100 only)

Perform the counter weight check in the check mode with D6 displayed. Refer to 2. Cornerload adjustment, for entering the check mode.

- 1 Press the RE-ZERO for zero indication.
- 2 Elevate the front with the 1mm thick spacer and read the changed value (inclination error) at the zero point.
- 3 Adjust the counter weight position and repeat the test until the inclination error is within the range given in the table below.

Unit type	Inclination error (D6 display)
HX100	± 10
HX400	
HX3000	
HX6000	



5.10 Temperature Adjustment

Input the high temperature data at 30°C and low temperature data at 10°C. Do this four hours after the temperature stabilizes.

First input the high temperature data then the low temperature data.

Then return to the high temperature again to check the drift value between the zero point and the temperature span.

1. Input of temperature data

- 1 Verify that the display is off.
- 2 Press and hold the RE-ZERO and MODE keys and momentarily press the ON/OFF key. Release the MODE and ON/OFF keys while holding the RE-ZERO key. Immediately press the MODE key twice.
- 3 Check that the unit type is displayed, for example [1.00 3000 HX]
- 4 Press and hold the MODE and SAMPLE keys and press the PRINT key. [init] will be displayed.
- 5 Press the MODE key twice to initiate [tH] display and press MODE key again to display [tL]. Input the high temperature data when [tH] is displayed, and low temperature with [tL].
- 6 Press the RE-ZERO key. The motor drives and internal weight position adjustments will be performed. [tH 0]/[tL 0] will be displayed.
- 7 Press the RE-ZERO key with nothing placed on the pan. The weight mark will be displayed.
- 8 Check that [tH F]/[tL F] is displayed after the display stabilizes.
- 9 Place the calibration mass of the weight specified in the table below on the pan and press the RE-ZERO key. The weight mark will be displayed. (HX-100/400 press the RE-ZERO key then the CAL key, to lower the internal weight)
- 10 Check that [init] is displayed after the display stabilizes.

A Remove the calibration mass.

Unit type	Mass used
HX100	100g (or internal weight)
HX400	400g (or internal weight)
HX3000	3kg
HX6000	5kg

2. Temperature check

- 1 After inputting the low temperature data, enter the check mode with D6 displayed.
- 2 Press the RE-ZERO key for 0 indication then place the calibration mass on the pan and record the range value. Remove the calibration mass.
- 3 Change the temperature to high and leave for four hours.
- 4 Read the value at the zero point.
- 5 Press the RE-ZERO key again for 0 indication.
- 6 Place the calibration mass on the pan and read the range value.
- 7 Check that the values at zero point and the span are within the range given in the table below.

Unit type	Zero point	Span	
		Calibration mass	Internal weight
HX100	±50 counts	±30/100g	±30
HX400	±20 counts	±16/400g	±16
HX3000	±20 counts	±10/3kg	
HX6000	±20 counts	±3/5kg	



5.11 Fine Adjustment

Cornerload Adjustment

Perform the cornerload fine adjustment in the check mode with D6 displayed.

- 1 Verify that the display is off.
- 2 Press and hold the RE-ZERO and MODE keys and press the ON/OFF key.
- 3 Check that the unit type is displayed. e.g. [1.00 3000 HX]
- 4 Press the RE-ZERO key. [C-0] will be displayed.
- 5 Press the RE-ZERO key. [XXXX D0] will be displayed.
- 6 Press the SAMPLE key six times. [XXXX D6] will be displayed.
- 7 Perform the cornerload fine adjustment. The difference between the center and four corners must be within the range mentioned in the table below.
- 8 Check that the difference between the two diagonal corners are within 2 counts. (HX-6000 only)

Unit type	Calibration mass used	Fine adjustment specifications
HX100	50g	± 2 counts
HX400	200g	± 2 counts
HX3000	2kg	± 2 counts
HX6000	5kg	± 2 counts

Linearity Data Input

1. Warm-up and pre-weighing
 - 1 The power must be on for at least one hour.
 - 2 Place a full-scale-weight calibration mass on the pan then remove it. Repeat this two or three times.
2. Input of linearity data input
 - 1 Verify that the display is off.
 - 2 Press and hold the RE-ZERO and MODE keys and momentarily press the ON/OFF key. Release the MODE and ON/OFF keys while holding the RE-ZERO key. Immediately press the MODE key twice.
 - 3 Check that the unit type is displayed. e.g. [1.00 3000 HX]
 - 4 Press the RE-ZERO key. [C-0] will be displayed.
 - 5 Press the MODE key twice. [Lnr] will be displayed.
 - 6 Press the RE-ZERO key. [Lnr 0] will be displayed.
 - 7 Press the RE-ZERO key with nothing placed on the pan.
 - 8 After the display stabilizes, check that [Lnr 1] is displayed.
 - 9 Place calibration mass A then press the RE-ZERO key.
 - 10 After the display got stable, check that [Lnr 2] is displayed.
 - 11 Place calibration mass B on the pan then press the RE-ZERO key.
 - 12 After the display stabilizes, check that [Lnr F] is displayed.
 - 13 Place calibration masses A and B on the pan then press the RE-ZERO key.
 - 14 After the display stabilizes, check that [C-0] is displayed.

Unit type	Calibration mass A	Calibration mass B
HX100	50g	50g
HX400	200g	200g
HX3000	1kg	2kg
HX6000	2kg	4kg
	or (3kg)	(3kg)
	or (1kg)	(5kg)

Internal Weight Set Value Entry

1. Warm-up and pre-weighing
 - 1 The power must be on for at least one hour.
 - 2 Place a full-scale-weight calibration mass on the pan then remove it. Repeat this two or three times.
2. Entering check mode and performing weight set value entry
 - 1 Check that [C-0] is displayed and press the MODE key five times.
 - 2 Check that [CAL SEt] is displayed.
 - 3 Press the RE-ZERO key. Wait for a few seconds while the motor rotates and pre-weighing of the internal weight is performed.
 - 4 Check that the value of the calibration mass in use is displayed. e.g. [2000.00 g]. If the displayed value is other than that listed in the table below, change the value with the MODE key.
 - 5 Press the RE-ZERO key with the pan empty.
 - 6 Check that [CAL 0] is displayed. After the display stabilizes, [CAL F] will be displayed and the weight mark will blink.
 - 7 Place the calibration mass with the weight displayed in step 4, on the pan.
 - 8 After the display stabilizes, check that [CAL End] is displayed and the weight mark blinks.
 - 9 Remove the calibration mass. The blinking of the weight mark stops.
 - 10 Press the RE-ZERO key. [----] will be displayed.
Weight handling will be performed automatically afterwards.
Zero point reading → weight down → weight up
 - 11 ROM version 2.01, repeat steps 5 ~ 10 four times
 - 12 End when [C-0] is displayed.

Unit type	Calibration mass used
HX100	100g
HX400	400g
HX3000	2kg
HX6000	5kg

Export Setting

1. Unit of weight registration

Register the unit of weight in the check mode by referring to the modification code table.

- 1 Have the display off.
- 2 Press and hold the RE-ZERO and MODE keys and momentarily press the ON/OFF key. Release the MODE and ON/OFF keys while holding the RE-ZERO key. Immediately press the MODE key twice.
- 3 Check that the unit type is displayed. e.g. [1.00 3000 HX]
- 4 Press the RE-ZERO key. [C-0] will be displayed.
- 5 Press the MODE key six times. [Unit] will be displayed.
- 6 Press the RE-ZERO key. [Unit g] will be displayed.
- 7 Register the desired weight unit as follows:
 - Press the SAMPLE key to register the displayed unit of weight.
 - Press the MODE key to display the next unit of weight.
- 8 Press the PRINT key when the registration is completed.
- 9 End when [C-0] is displayed. Turn the display off.

2. Date setting

Change the internal parameter setting for the date display order (YMD/MDY/DMY). If the specification in the modification code table is [YMD], the same as the manufactures setting, it does not need to be changed.

- 1 Verify that the display is off.
- 2 Press and hold the RE-ZERO and MODE keys, press the ON/OFF key.
- 3 Press the MODE key. [Stb-b 0] will be displayed.
- 4 Press the MODE key twice. [Print 0] will be displayed.
- 5 Press the SAMPLE key seven times. [dAtE 0] will be displayed.
- 6 Change the date display order as follows:
 - YMD: Leave as is. [dAtE 0]
 - MDY: Press the RE-ZERO key once. [dAtE 1]
 - DMY: Press the RE-ZERO key twice. [dAtE 2]
- 7 Press the PRINT key.
- 8 Turn the display off.

Upgrade the ROM

1. Open the upper case and replace the ROM on the logic board.
2. Perform the adjustment as required.
3. If "initialization" is specified, perform the initialization as follows:
 - 1 Verify that the display is off.
 - 2 Press and hold the RE-ZERO and MODE keys and momentarily press the ON/OFF key. Release the MODE and ON/OFF keys while holding the RE-ZERO key. Immediately press the MODE key twice.
 - 3 Check that the unit type is displayed. e.g. [1.00 3000 HX]
 - 4 Press the RE-ZERO key. [C-0] will be displayed.
 - 5 Press the MODE key seven times. [init-HF] will be displayed.
 - 6 Press the RE-ZERO key. [----] will be displayed for a few seconds.
 - 7 Check that the display returns to [C-0].
 - 8 Turn the display off.

Adjustment after Logic Board Replacement

1. PZ:2598 → PZ:2598 (early version replaced by same version)

The clock IC must be initialized after the logic board replacement.

This is normally done by the initial setting. If the logic board is replaced after the adjustment has started, perform the initialization as follows:

- 1 Verify that the display is off.
 - 2 Press and hold the RE-ZERO and MODE keys and momentarily press the ON/OFF key. Release the MODE and ON/OFF keys while holding the RE-ZERO key. Immediately press the MODE key twice.
 - 3 Check that the unit type is displayed. e.g. [1.00 3000 HX]
 - 4 Press the RE-ZERO key. [C-0] will be displayed.
 - 5 Press the MODE key eight times. [init-CL] will be displayed.
 - 6 Press the RE-ZERO key. [----] will be displayed for a few seconds.
 - 7 Check that the display returns to [C-0]
 - 8 Turn the display off.
 2. PZ:2598 → PZ:2497 (early version replaced by later version).
- The A/D count for the later version is not the same as the early version.

Setup procedure is as follows:

- 1 Linearity setting.
- 2 Auto CAL.

After changing from a PZ:2598 to a PZ:2497, Set the linearity and perform calibration. Do a complete performance check.



5.12 Adjustment Specifications

Repeatability

Perform the repeatability check in the check mode.

Perform it with D6 displayed for HX-100 and HX-400, and with D5 displayed for HX-3000 and HX-6000.

- 1 Place the calibration mass on the pan then remove it. Repeat this five times.
- 2 The difference between the values at the zero point and with calibration mass placed on the pan (lowest and highest values) must be within the specifications.

Unit type	Calibration mass used	Specifications
HX100	100g	2 counts
HX400	400g	2 counts
HX3000	3kg	4 counts
HX6000	6kg	4 counts

Linearity/Hysteresis

Perform the linearity and hysteresis check in the check mode with D6 displayed.

- 1 Add and remove the calibration masses specified in the following table and check the linearity and hysteresis.

Unit type	Calibration mass used				Specifications	
					Linearity	Hysteresis
HX100	0g	50g	100g		±2	±3
HX400	0g	200g	400g		±2	±3
HX3000	0kg	1kg	2kg	3kg	±2	±3
HX6000	0kg	2kg	4kg	6kg	±1	±2

Internal Weight Repeatability

Perform the internal weight repeatability check in the normal weighing mode.

- 1 Press the CAL key to perform internal weight calibration.
- 2 Place the calibration mass specified in the table below on the pan and record the displayed value.
- 3 Repeat steps 1 and 2 five times.
- 4 All five of the differences between the displayed values and the true values must be within the specifications.

Absolute value (displayed value - true value) \leq D represents the following specifications:

Unit type	Calibration mass used	Specifications
HX100	100g	± 1 count
HX400	400g	± 1 count
HX3000	3kg	± 1 count
HX6000	6kg	± 1 count

Creep Characteristics

Perform the creep characteristics check in the check mode with D6 displayed.

- 1 Press the RE-ZERO key to display 0.
- 2 Place the calibration mass specified in the table below on the pan and record the displayed value. This value is to be the initial value.
- 3 Leave the calibration mass for five minutes, then read the displayed value.
- 4 The difference between the initial value and the value after five minutes must be within the specifications.


Unit type	Calibration mass used	Specifications
HX100	100g	± 3 counts
HX400	400g	± 3 counts
HX3000	3kg	± 3 counts
HX6000	6kg	± 3 counts

Cornerload Error

The difference between the values at the center and the four corners must be within the specifications.

The difference between the diagonal corners must be within 2 counts for HX-6000.

Unit type	Calibration mass used	Specifications
HX100	50g	± 2 counts
HX400	200g	± 2 counts
HX3000	2kg	± 2 counts
HX6000	5kg	± 2 counts



PZ:2598 IS EXCHANGED TO PZ:2497 FOR IMPROVEMENT

HX Series		Block Diagram	
Model	Description	Stock No.	Drwg No.

ELECTRONIC PARTS LIST

P Z : 2 4 9 7

CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q' TY
C4, 7, 8	CC:100P	CAPACITOR 100pF 50V	3
C1, 2, 6	CC:FK16Y5V1H104	CAPACITOR 0.1 μ F	3
C3, 5	CT:1A4R7	CAPACITOR 4.7uF/10V	2
D2	DI:1SS53	DIODE	1
D1	DI:1SS97	DIODE	1
	EB:CR2032-WT12	BATTERY	1
J5, 9	JI:HLEM20R-1	FPC CONECTOR	2
U2	JS:10328-01-445	IC SOCKET	1
J3	KO:974-9-5	CABLE	1
	PC:2497A	PRINTED CIRCUIT BOARD	1
R4, 7	RC:NAT1.2K	CARBON RESISTOR 1.2K Ω 1/4W	2
R2, 13, 14	RC:NAT100K	CARBON RESISTOR 100K Ω 1/4W	3
R1	RC:NAT2.2K	CARBON RESISTOR 2.2K Ω 1/4W	1
R3, 5, 6, 8, 9, 10, 11, 12	RC:NAT22K	CARBON RESISTOR 22K Ω 1/4W	8
R15, 16, 17, 18	RN:IHR-8-223MA	RESISTOR ARRAY 22K Ω	4
S1	SS:2NB2X2AG	SLIDE SWITCH	1
U3	UC:62421A	CLOCK IC	1
U1	UC:D95017GF-3BA	CMOS CPU	1
U4	UC:HC125F	CMOS IC	1
	XT:C4SB-12M-K02	RESONATOR 12MHz	1

P Z : 2 4 9 8

CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q' TY
	04:B48713	HEAT SINK	1
	07:B49887	ISOLATION SHEET	1
C5	CC:470P	CAPACITOR 470PF 50V	1
C1, 2, 3, 7, 10, 12, 13, 14	CC:FK16Y5V1H104	CAPACITOR 0.1 μ F	8
C6	CK:SM50VB3R3	CAPACITOR 3.3 μ F 50V	1
C8, 11	CK:SME16VB220	CAPACITOR 220 μ F 16V	2
C4, 15	CK:SME25VB470	CAPACITOR 470 μ F 25V	2
D4	DF:PS2501-1L/K	PHOTO COUPLER	1
D2	DI:1S1588	DIODE	1
D3	DI:SB10-03A2	DIODE	1
D1	DZ:05Z13	ZENER DIODE	1
J16	JI:05P-S2T2-EF	PIN HEADER	1
J3	JI:09P-S2T2-EF	PIN HEADER	1
J2	JI:2P-S2T2-EF	PIN HEADER	1
	PC:2498B	PRINTED CIRCUIT BOARD	1
	QA:AC256-1674	RADIATOR	1
	QA:AC316A	WASHER	1
Q5	QT:A1015Y	TRANSISTOR	1
Q2	QT:C1173	TRANSISTOR	1
Q1, 3, 4	QT:C1815Y	TRANSISTOR	3
R5, 6	RC:NAT1.2K	CARBON RESISTOR 1/4W 1.2K Ω	2
R10	RC:NAT1.8K	CARBON RESISTOR 1.8K Ω 1/4W	1
R11	RC:NAT10K	CARBON RESISTOR 10K Ω 1/4W	1
R8	RC:NAT2.2K	CARBON RESISTOR 2.2K Ω 1/4W	1
R4, 7	RC:NAT22K	CARBON RESISTOR 22K Ω 1/4W	2
R2, 3	RC:NAT270R	CARBON RESISTOR 270 Ω 1/4W	2
R1	RC:NAT33K	CARBON RESISTOR 33K Ω 1/4W	1
R12	RC:NAT8.2K	CARBON RESISTOR 8.2K Ω 1/4W	1
R9	RC:NAT820R	CARBON RESISTOR 820 Ω 1/4W	1
	TF:407	TRANSFORMER	1
TP	TM:LC-2-G-0	TEST PIN	3
U2	UR:2410HF	REGURATOR	1
U1	UR:PQ05RR1	REGURATOR	1

P Z : 2 4 9 9

CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q' TY
	04:A39220A	REAR PANEL	1
	07:B48667B	OPTION BOARD GUIDE A	1
	07:B49158A	OPTION BOARD GUIDE B	1
C3	CC:0.001U	CAPACITOR 0.001uF 50V	1
C7, 8, 9, 15, 16	CC:0.022U	CAPACITOR 0.01 μ F 500V	5
C6	CC:0.1U25V	CAPACITOR 0.1 μ F 25V	1
C4	CC:68P	CAPACITOR 68PF 50V	1
C14	CK:SME35VB47	CAPACITOR 47 μ F 35V	1
C10, 11, 12, 13	CK:SRA16VB-47	CAPACITOR 47 μ F 16V	4
C1, 2	CM:E1106KN	CAPACITOR 10 μ F 50V	2
C5	CT:1D2R2	CAPACITOR 2.2 μ F 20V	1
D5	DF:PS2501-1L/K	PHOTO DIODE	1
D1, 2, 3, 4	DI:1S1588	DIODE	4
J1	EJ:0470-01-230	CONNECTOR	1
	FH:F-105	FUSE HOLDER	1
FUSE	FS:EAWK-500MA	FUSE 500mA	1
J13	JA:17LE-13250	CONNECTOR	1
J12	JA:TCS5076-18	CONNECTOR	1
J10	JA:TCS7930	CONNECTOR	1
J6	JI:543-0522-5	CONNECTOR	1
J14	JI:BS10P-SHF1AA	CONNECTOR	1
J5, 9	JI:HLEM20S-1	CONNECTOR	2
J2	KO:974-2-30	CABLE	1
J4	KO:974-5-10	CABLE	1
L1, 2	LL:LHLC06NB470K	COIL	2
L4	NF:D-42C	COIL	1
L3, 5	NF:D-58C	COIL	2
	PC:2499B	PRINTED CIRCUIT BOARD	1
Q4	QF:K30ATM-GR	FET TRANSISTOR	1
Q3	QF:K701	POWER MOS FET	1
Q1	QT:A1153	TRANSISTOR	1
Q2	QT:C2901	TRANSISTOR	1
R7	RC:NAT10K	CARBON RESISTOR 10K Ω 1/4W	1
R1, 2	RC:NAT1K	CARBON RESISTOR 1K Ω 1/4W	2
R6, 9	RC:NAT2.2K	CARBON RESISTOR 2.2K Ω 1/4W	2
R8	RC:NAT3.3K	CARBON RESISTOR 3.3K Ω 1/4W	1
R3, 4	RC:NAT4.7K	CARBON RESISTOR 4.7K Ω 1/4W	2
R5	RC:NAT470R	CARBON RESISTOR 470 Ω 1/4W	1
U1	UC:MAX232CPE	PS-232C DRIVER/RECEIVER	1

P Z : 2 5 0 1

CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q'TY
	04:B48727	HEAT SINK	1
	06:B41182A	DISPLAY CUSHION SHEET	2
C5	CC:470P	CAPACITOR 470PF 50V	1
C1, 3, 4, 7, 9, 11, 12, 13	CC:FK16Y5V1H104	CAPACITOR 0.1 μ F	8
C8, 14	CK:SRA16VB100	CAPACITOR 100 μ F 16V	2
C2	CK:SRA35VB-47	CAPACITOR 47 μ 35V	1
C10	CK:SRA50VB-22	CAPACITOR 22 μ F 50V	1
C6	CK:SRA50VB-3.3	CAPACITOR 3.3 μ F 50V	1
D2, 4	DI:1S1588	DIODE	2
D3	DI:1SS131	DIODE	1
D1	DZ:05Z9.1	ZENOR DIODE	1
D5	DZ:RD3.6EB	ZENOR DIODE	1
VFD	ED:FIP10BM11	FLUORESCENT DISPLAY	1
U1	ET:IS1U60L	REMOTE SENSOR	1
BZ	ET:MEB-12C-5	BUZZER	1
J10	JI:543-0519-0	CABLE	1
J11	JI:HLEM7R-1	FPC CONNECTOR	1
L1	NF:D-58C	COIL	1
	PC:2501B	PRINTED CIRCUIT BOARD	1
Q3	QT:BA1A4P	TRANSISTOR	1
Q2	QT:C1173	TRANSISTOR	1
Q1	QT:C1815Y	TRANSISTOR	1
R7, 8	RC:NAT1K	CARBON RESISTOR 1K Ω 1/4W	2
R2, 3	RC:NAT22K	CARBON RESISTOR 22K Ω 1/4W	2
R5, 6	RC:NAT270R	CARBON RESISTOR 270 Ω 1/4W	2
R4	RC:NAT33K	CARBON RESISTOR 33K Ω 1/4W	1
R10	RC:NAT5.6K	CARBON RESISTOR 5.6K Ω 1/4W	1
R9	RC:NAT560R	CARBON RESISTOR 560K Ω 1/4W	1
	TF:407	TRANSFORMER	1
TM VH, VDD, GND	TM:LC-2-G-0	TEST PIN	3
U2	UA:S-8054ALR	VOLTAGE COMPARATOR	1
U3	UC:75004GB-726	MICRO PROCESSOR	1
U4, 5	UC:MSC1164GS	20BIT VFD DRIVER	2
XT	XT:KBR4.0MKSTR	RESONATOR 4.0MHz	1

HX-04

P Z : 2 5 0 3

CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q'TY
	04:B48691	OPTION-04 PLATE	1
	05:B49548	OPTION HANDLE	
U1, 2, 3	DF:AQV253	PHOTO MOS RELAY	3
D1	DF:PS2403-1	PHOTO COUPLER	1
D2	DI:1B4B42	DIODE BRIDGE	1
J15	JA:TCS5076-17	CONNECTOR DIN	1
J14	JS:F10P-SHVQ	IC SOCKET	1
PC	PC:2503A	PRINTED CIRCUIT BOARD	1
Q1	QT:BA1A4P	TRANSISTOR	1
Q2	QT:C1815Y	TRANSISTOR	1
R5	RC:NAT1K	CARBON RESISTOR 1K Ω 1/4W	1
R1, 2, 3	RC:NAT3.3K	CARBON RESISTOR 3.3K Ω 1/4W	3
R4	RC:NAT5.6K	CARBON RESISTOR 5.6K Ω 1/4W	1

P Z : 2 5 1 3

CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q' TY
	04:B40464	SHAFT STOP	1
	04:B48672	MOTOR HOLDER SUPPORT	1
	05:B46148	CAM SHAFT	1
	05:B47178	BLIND NUT STOPPER	3
	07:B40278	SHAFT HOLDER SUPPORT	1
	07:B47133A	LEVER ASSY, STOP	1
	09:B40470C	SWITCHING CAM	1
	10:A35234	GEARED MOTOR	1
	10:C-330L	BLIND NUT	3
C1	CC:0.01U	CAPACITOR 0.01 μ F	1
D2	DF:TLP809	PHOTO INTERRUPTER	1
D1	DI:1S1588	DIODE	1
	KO:974-5-10	CABLE	1
	PC:2513A	PRINTED CIRCUIT BOARD	1
Q1	QT:C1815Y	TRANSISTOR	1
R1, 2	RC:NAT2.2K	RESISTOR 2.2K Ω 1/4W	2

P Z : 2 5 9 8

CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q' TY
C1, 2, 3	CC:100P	CERAMIC CAPACITOR 100pF 50V	3
C4~12	CC:FK16Y5V1H104	CERAMIC CAPACITOR 0.1 μ F	9
C13	CT:1A4R7	TANTALUM CAPACITOR 4.7 μ F	1
D2	DI:1SS53	DIODE	1
D1	DI:1SS97	DIODE	1
BATT	EB:CR2032-WT12	LITHIUM BATTERY	1
J5, 9	J1:HLEM20R-1	FPC CONECTOR	2
U6	JS:10328-01-445	IC SOCKET	1
J3	KO:964-09S005		1
R2, 3, 4	RC:NAT100K	CARBON RESISTOR 100K Ω 1/4W	3
R8	RC:NAT2.2K	CARBON RESISTOR 2.2K Ω 1/4W	1
R6	RC:NAT220R	CARBON RESISTOR 220 Ω 1/4W	1
R5, 9~16	RC:NAT22K	CARBON RESISTOR 220K Ω 1/4W	9
R1, 7	RN:IHR-8-223MA	RESISTOR NETWORK 22K Ω \times 8	2
U5	UC:5518CFL	CMOS TC5518CFL-15	1
U7	UC:62421A	CLOCK IC	1
U2, 3	UC:D65013GC-388	GATE ARRAY	2
U1	UC:D78C10G-1B	CPU	1
U8	UC:HC125F	CMOS IC	1
U4	UC:HC573F	CMOS IC	1
U9	UC:HC74F	CMOS IC	1
	XT:C4SB-12M-K02	RESONATOR 12MHz	1

P Z : 2 6 3 6


CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q'TY
	04:C40731A	OPTION PLATE	1
	05:B49548	OPTION HANDLE	1
C1, 2	CC:0.01U	CAPACITOR 0.01 μ F	2
C3	CT:1A4R7	TANTALUM CAPACITOR 4.7 μ F 10V	1
D5	DF:PS-2403-1	PHOTO COUPLER	1
D3, 4	DF:PS2501-1L/K	PHOTO DIODE	2
D6	DI:1B4B42	DIODE BRIDGE	1
D1, 2	DI:1S1588	DIODE	2
	JA:TCP0576	CONNETTOR, DIN	1
J19	JA:TCS5076-17	CONNECTOR, DIN	1
J18	JE:HSJ0916-01	CONNECTOR	1
	JE:T-314A	PLUG, 3 PIN	1
J14	JS:F10P-SHVQ	IC SOCKET	1
L2	NF:D-42C	COIL	1
L1	NF:ZBF253D-01	FERRITE BEADS	1
	PC:2636A	PRINTED CIRUCIT BOARD	1
Q1, 5	QT:BA1A4P	TRANSISTOR	2
Q2, 3, 4, 6	QT:C1815Y	TRANSISTOR	4
R7, 8, 11	RC:NAT1K	CARBON RESISTOR 1K Ω 1/4W	3
R4, 6, 9	RC:NAT2.2K	CARBON RESISTOR 2.2K Ω 1/4W	3
R5	RC:NAT2.7K	CARBON RESISTOR 2.7K Ω 1/4W	1
R3, 12	RC:NAT3.3K	CARBON RESISTOR 3.3K Ω 1/4W	2
R10	RC:NAT5.6K	CARBON RESISTOR 5.6K Ω 1/4W	1
R1	RM:RNM10KF	METAL FILEM RESISTOR 10K Ω 1/4W	1
R2	RM:RNM2.2KF	METAL FILEM RESISTOR 2.2K Ω 1/4W	1

P Z : 2 6 4 5


CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q' TY
	04:B49889A	OPTION PLATE	1
	05:B49548	OPTION HANDLE	1
	10:NO1900PA50L	SCREW DRIVER	1
C5	CC:0.01U	CAPACITOR 0.01 μ F	1
C3	CC:470P	CAPACITOR 470PF 50V	1
C1, 2, 6, 7, 8	CC:FK16Y5V1H104	CAPACITOR 0.1 μ F	5
C4	CT:1VR33	TANTALUM CAPACITOR 0.33 μ F 35V	1
D1	DZ:RD2.7EB1	ZENER DIODE	1
	JA:TCP0576	CONNECTOR DIN	1
J17	JA:TCS5076-17	CONNECTOR DIN	1
	JE:66464-102	CONNECTOR, JUMPER	2
J14	JS:F10P-SHVQ	IC SOCKET	1
JP1, 2	JT:65507-406	CONNECTOR, PIN HEAD	1
	PC:2645	PRINTED CIRCUIT BOARD	1
Q1	QT:A1015Y	TRANSISTOR	1
Q2	QT:C1815Y	TRANSISTOR	1
R9, 10	RC:NAT100K	CARBON RESISTOR 100K Ω 1/4W	2
R16	RC:NAT10K	CARBON RESISTOR 10K Ω 1/4W	1
R14	RC:NAT10R	CARBON RESISTOR 10 Ω 1/4W	1
R8	RC:NAT15K	CARBON RESISTOR 15K Ω 1/4W	1
R2, 4	RC:NAT22K	CARBON RESISTOR 22K Ω 1/4W	2
R12	RC:NAT2K	CARBON RESISTOR 2K Ω 1/4W	1
R15	RC:NAT3.3K	CARBON RESISTOR 3.3K Ω 1/4W	1
R18	RC:NAT3.9K	CARBON RESISTOR 3.9K Ω 1/4W	1
R1, 7	RC:NAT47K	CARBON RESISTOR 470K Ω 1/4W	2
R6	RC:NAT56K	CARBON RESISTOR 56K Ω 1/4W	1
R5	RC:NAT6.8K	CARBON RESISTOR 6.8K Ω 1/4W	1
R11	RC:NAT7.5K	CARBON RESISTOR 7.5K Ω 1/4W	1
R3	RC:NAT82K	CARBON RESISTOR 82K Ω 1/4W	1
R19	RM:RNM10KF	METAL FILM RESISTOR 10K Ω 1/4W	1
R20	RM:RNM3.9KF	METAL FILM RESISTOR 3.9K Ω 1/4W	1
R13	RV:V102	POTENTIOMETER 100 Ω	1
R17	RV:V103	POTENTIOMETER 10K Ω	1
U3	UA:C4072C	OP AMP	1
U2	UC:4016	CMOS	1
U1	UR:TL431CLPB	SWITCHING REGULATOR	1


CIRCUIT DIAGRAMS


A B C D E F G




Symbol	Date	By	Revision No.	Model	HX Series
				Description	Interface board
				Stock No.	PZ : 2499
				Drwg. No.	









				Model	HX-05
Symbol	Date	By	Revision No.	Description	Feeder output
				Stock No.	PZ:2636
				Drwg. No.	




PARTS LAYOUT




LOGIC BOARD




POWER SUPPLY BOARD




PZ:2499
INTERFACE BOARD




DISPLAY BOARD




COMPARATOR BOARD




MOTOR BOARD




LOGIC BOARD





PCB Assembly				Model	HX-06
Symbol	Date	By	Revision No.	Description	Analog output
				Stock No.	PZ:2645
				Drwg. No.	



PCB Assembly				Model	HX-05
Symbol	Date	By	Revision No.	Description	Feeder output
				Stock No.	PZ:2636
				Drwg. No.	

EXPLODED VIEW

SCREW LIST

3000/6000

USED SECTION	USED POSITION	HEAD TYPE	SIZE	Q' TY
POSITION BEAM	BOBBIN	PAN HEAD WITH SPRING AND PLAIN WASHER	M3X8	2
POSITION BEAM	FULCRUM BEARING	PAN HEAD	M4X8	4
POSITION BEAM	GRAVITY WEIGHT STOP (100/400)	NUT	M3	2
FLEXIBLE ASSEMBLY	ASSEMBLY SIDE	PAN HEAD	M4X5	8
FLEXIBLE ASSEMBLY	MAIN FRAME SIDE	PAN HEAD	M4X8	8
SUSPENSION	TENSION BEARING	PAN HEAD	M4X8	2
PAN SUPPORT	RECEIVER BLOCK SIDE (400)	FLAT HEAD	M3X6	4
PAN SUPPORT	SUSPENSION SIDE (400)	PAN HEAD	M4X6	2
PAN SUPPORT	RECEIVER BLOCK SIDE (3000/6000)	FLAT HEAD	M3X6	4
PAN SUPPORT	SUSPENSION SIDE (3000/6000)	ALLEN HEAD BOLT	M4X8	3
PAN SUPPORT	SHOCK ABSORBER (3000/6000)	ALLEN HEAD BOLT	M4X12	4
FRAME	FOUR CORNER	HEXAGON HEAD WITH HOLE	M5X30	2
FRAME	MAGNET HOLDER	ALLEN HEAD BOLT	M4X20	2
FRAME	MAGNET HOLDER	ALLEN HEAD BOLT	M4X25	2
FRAME	ANALOG BOARD	PAN HEAD WITH SPRING AND PLAIN WASHER	M3X8	3
FRAME	FLEXIBLE BEARING	PARALLEL PIN	Ø 5X10	2
MAGNET	SHIELD	PAN HEAD WITH SPRING WASHER	M3X6	3
MAGNET	BEAM STOP	PAN HEAD WITH SPRING WASHER	M3X6	1
MAGNET	POSITION SENSOR	PAN HEAD WITH SPRING AND FLAT WASHER	M3X6	2
MAGNET	YOKE	PAN HEAD	M4X10	3
CALIBRATION WEIGHT	LEVER ASSEMBLY	PAN HEAD WITH SPRING AND PLAIN WASHER	M3X6	8
CALIBRATION WEIGHT	SHAFT	PAN HEAD WITH SPRING AND PLAIN WASHER	M3X6	1
CALIBRATION WEIGHT	MOTOR BOARD	PAN HEAD WITH SPRING AND PLAIN WASHER	M3X6	2
CALIBRATION WEIGHT	MOTOR SUPPORT STOP	FLAT HEAD ALLEN BOLT	M3X15	3
CALIBRATION WEIGHT	MOTOR SUPPORT STOP	NUT	M3	3
CALIBRATION WEIGHT	MOTOR	PAN HEAD	M1.4X4	2
CALIBRATION WEIGHT	WEIGHT LEVER ASSEMBLY (100/400)	PAN HEAD WITH SPRING AND PLAIN WASHER	M3X5	4
CALIBRATION WEIGHT	WEIGHT LEVER ASSEMBLY (100/400)	PAN HEAD WITH SPRING AND PLAIN WASHER	M3X8	4
CALIBRATION WEIGHT	WEIGHT LEVER ASSEMBLY (3000/6000)	ALLEN HEAD BOLT	M3X10	4

SCREW LIST

3000/6000

USED SECTION	USED POSITION	HEAD TYPE	SIZE	Q'TY
CALIBRATION WEIGHT	WEIGHT STOP	FLAT HEAD ALLEN BOLT	M4X8	2
CALIBRATION WEIGHT	WEIGHT LEVER ASSEMBLY	KNURLED HEAD	M4X10	2
CALIBRATION WEIGHT	CAM	ALLEN HEAD WITH HOLE	M3X6	1
CALIBRATION WEIGHT	SWITCH CAM	ALLEN HEAD WITH HOLE	M3X3	1
CALIBRATION WEIGHT	CAM DRIVING LEVER ASSEMBLY	ALLEN HEAD WITH HOLE	M3X3	1
UPPER CASE	DUST COVER (100/400/3000)	BINDING HEAD	M4X4	2
UPPER CASE	CONDUCTING SPRING	LOCK NUT	M8	1
UPPER CASE	CONDUCTING SPRING	PAN HEAD WITH SPRING AND PLAIN WASHER	M3X5	1
LOWER CASE	FRAME	ALLEN HEAD BOLT	M4X10	3
LOWER CASE	HOLE PLUG	BINDING HEAD	M4X4	2
LOWER CASE	PLUNGER	ALLEN HEAD WITH HOLE	M6X10	2
LOWER CASE	DISPLAY CASE)	PAN HEAD WITH SPRING AND PLAIN WASHER	M4X8	2
LOWER CASE	OPTION GUIDE	TAPPING	M3X6	4
LOWER CASE	POWER BOARD	PAN HEAD WITH SPRING AND PLAIN WASHER	M3X8	2
LOWER CASE	LOGIC BOARD	PAN HEAD WITH SPRING AND PLAIN WASHER	M3X6	2
REAR PANEL	INTERFACE BOARD	PAN HEAD WITH SPRING AND PLAIN WASHER	M3X8	3
REAR PANEL	REAR PANEL	PAN HEAD WITH SPRING WASHER	M4X6	4
REAR PANEL	BLANK PANEL	BINDING HEAD	M3X6	2
REAR PANEL	GROUND	BINDING HEAD	M4X4	1
REAR PANEL	GROUND	TOOTHED WASHER	M4	1
DISPLAY CASE	CASE CONNECTOR	PAN HEAD WITH SPRING AND PLAIN WASHER	M4X8	2
DISPLAY CASE	DISPLAY UPPER CASE	PAN HEAD WITH SPRING AND PLAIN WASHER	M3X8	3
DISPLAY CASE	DISPLAY LEG STOPPER	PAN HEAD WITH SPRING AND PLAIN WASHER	M3X8	1
DISPLAY CASE	DISPLAY BOARD	PAN HEAD WITH SPRING AND PLAIN WASHER	M3X8	2
DISPLAY CASE	GROUND	PAN HEAD WITH SPRING AND PLAIN WASHER	M3X8	1
DISPLAY CASE	DISPLAY SUPPORT	ROLL SPRING PIN	Ø 3X12	4

EXPLODED VIEW 1

NO.	PARTS NAME	DESCRIPTION
1		BINDING HEAD M4×4
2	07:B49002-1	LEFT SUPPORT CAP
3	PM:HX100-5	BREEZE BREAK UNIT
4	09:B30261	UPPER CASE SET, INCLUDING NO. 5~8
5	04:B48993	CONDUCTING LEAF SPRING
6	04:B48993	CONDUCTING LEAF SPRING
7		PAN HEAD WITH SPRING AND PLAIN WASHER M3×5
8	04:B48994	CONDUCTING SPRING PLATE
9	07:B49002-2	RIGHT SUPPORT CAP
10	04:A39220A	REAR PANEL
11		PAN HEAD WITH SPRING WASHER M4×6
12	KO:914-53	CABLE
13		PAN HEAD WITH SPRING WASHER M4×6
14		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
15	PZ:2499	INTERFACE BOARD
16		PAN HEAD SPRING AND PLAIN WASHER M3×8
17		PAN HEAD SPRING AND PLAIN WASHER M3×8
18	05:B47177	WEIGHT 50g
19	05:B47177	WEIGHT 50g
20		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
21	04:B47132	WEIGHT SEESAW L
22		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
23	04:B47131	WEIGHT SEESAW R
24		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
25	04:B47134	UPPER SEESAW STOP
26	04:B47136B	LEAF SPRING FOR LEVER ASSEMBLY
27	04:B47135	LOWER SEESAW STOP
28		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
29	07:B40278	SHAFT BRACKET
30	05:B49005A	PC GUIDE
31		BINDING HEAD M4×4
32	00:B46916	BUBBLE SPIRIT LEVEL
32	05:B49003A	BUBBLE LEVEL HOLDER
33		BINDING HEAD M3×6
34	02:B48692	BLANK PANEL
35	03:A10186A	LOWER CASE
36	07:A46735A	LEVELING FOOT
37	05:B49004A	CABLE GUIDE
38		LOCK NUT M10
39		FLAT HEAD ALLEN SCREW M4×8
40	04:B48709A	WEIGHT STOP
41		SHIPPING BOLT M4×10
42	05:B49004A	CABLE GUIDE
43	07:A46735A	LEVEL FOOT
44	07:A46858	UNDER HOOK COVER FR
45		PAN HEAD WITH SPRING AND PLAIN WASHER M4×8
46	PZ:2498	POWER SUPPLY BOARD
47		PAN HEAD WITH SPRING AND PLAIN WASHER M4×8
48		SHIPPING BOLT M4×10
49		FLAT HEAD ALLEN SCREW M3×15
50	05:B47178	WELLNUT BUSHING STOP
51	10:C-330L	WELLNUT BUSHING
52	05:B48938A	SUPPORT FOR LOGIC BOARD
53		PAN HEAD WITH SPRING AND PLAIN WASHER M4×8
54		PAN HEAD WITH SPRING AND PLAIN WASHER M4×8

EXPLODED VIEW 1

NO.	PARTS NAME	DESCRIPTION
55	03:B48654-1	CASE CONNECTOR R
56	10:P3×12	ROLL SPRING PIN $\phi 3 \times 12$
57	07:B49032	DISPLAY SUPPORT
58	03:A21398	DISPLAY LOWER CASE
59	10:SJ-5012	RUBBER FOOT
60	07:B48923	DISPLAY SUPPORT STOP
61		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
62	10:SJ-5012	RUBBER FOOT
63		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
64	03:B48654-2	CASE CONNECTOR L
65		PAN HEAD WITH SPRING AND PLAIN WASHER M4×8
66		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
67		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
68	PZ:2501	DISPLAY BOARD
69		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
70	07:A21399	DISPLAY UPPER CASE
71	09:A39217	SILICON SWITCH COVER SHEET
72	01:A39658	DISPLAY FILTER
73	10:A35234	GEARED MOTOR
74		NUT M3
75	04:B48672	MOTOR SUPPORT
76		PAN HEAD M1.4×M4
77	07:B47133A	CAM DRIVING SEESAW
78		ALLEN HEAD WITH HOLE M3×3 AND M3×6
79	09:B40470C	SWITCH CAM
80	04:B40464	COAXIAL BRACKET
81		ALLEN HEAD WITH HOLE M6×10
82	00:B47414	PLUNGER
83	10:3/16	STEEL BALL
84		FLAT HEAD ALLEN SCREW M4×8
85	05:B49004A	CABLE GUIDE
86	05:B49004A	CABLE GUIDE
87	05:B48938A	SUPPORT FOR LOGIC BOARD
88	04:B48709A	WEIGHT STOP
89	10:3/16	STEEL BALL
90	00:B47414	PLUNGER
91		ALLEN HEAD WITH HOLE M6×10
92	04:B47135	LOWER SEESAW STOP
93	04:B47135	LOWER SEESAW STOP
94		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
95	05:B46148	CAM SHAFT
96		ALLEN HEAD WITH HOLE M3×3
97	PZ:2513	MOTOR BOARD
98		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
99	PZ:2497	LOGIC BOARD
100		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
201	04:B47118A	WEIGHT PAN
202	00:B49220-1	SHOCK ABSORBER
203		"E" RING
204	05:C40516	WEIGHT PAN RECEPTOR CONE
204	04:B47119	WEIGHT PAN RECEPTOR PLATE
206	04:B49016	BREEZE BREAK RING
207		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
208	05:C40515	DUST RING
209	04:C40309	DUST PLATE

HX-100

EXPLODED VIEW 1


NO.	PARTS NAME	DESCRIPTION
210		BINDING HEAD M4×4
211	04:B30073	FLOOR PLATE

EXPLODED VIEW - 1

HX - 100

maintenance-HX-series-v. 1.a

Page 125



EXPLODED VIEW 2

NO.	PARTS NAME	DESCRIPTION
101	05:C40517	WEIGHT PAN RECEPTER CONE HOLDER
102		PAN HEAD WITH SPRING AND PLAIN WASHER M3×5
103	04:B47491	WEIGHT ARM PLATE
104		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
105	04:B48995	WEIGHT ARM
106	03:A39174D-2	SUSPENSION GUIDE
107	04:B48995	WEIGHT ARM
108		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
109	04:B47491	WEIGHT ARM PLATE
110		PAN HEAD WITH SPRING AND PLAIN WASHER M3×5
111	04:A48929;B	FLEXIBLE BEARING
112	05:B49476	FLEXIBLE BEARING WASHER
113	10:S-NO-1-SUS	CONICAL SPRING WASHER
114		PAN HEAD M4×8
115	05:B49476	FLEXIBLE BEARING WASHER
116	10:S-NO-1-SUS	CONICAL SPRING WASHER
117		PAN HEAD M4×8
118	05:A46919	UNDERHOOK
119	10:P1.5×6	ROLL SPRING PIN
120	10:P1.5×6	ROLL SPRING PIN
121	04:B47108	LOWER TENSION BEARING HOLDER
122	10:S-NO-1-SUS	CONICAL SPRING WASHER
123		PAN HEAD M4×8
124	04:B47103	UPPER FLEXIBLE BEARING ASSY
125		PAN HEAD M4×8
126	10:S-NO-1-SUS	CONICAL SPRING WASHER
127	05:B49476	FLEXIBLE BEARING WASHER
128	04:A46360;B	FLEXIBLE BEARING
129	05:B49476	FLEXIBLE BEARING WASHER
130	10:S-NO-1-SUS	CONICAL SPRING WASHER
131		PAN HEAD M4×5
132		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
133	04:B47740-2	STOP PLATE
134		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
135	04:B47737A	SHIELD PLATE
136	05:B47106	STOP PIN
137		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
138		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
139	03:A39136E-1	BEAM
140		
141	PC:2546	RELAY BOARD
142	10:P1.5×6	ROLL SPRING PIN
143	10:P1.5×6	ROLL SPRING PIN
144	05:B47111	SPRING GUIDE
145	10:C-207	TRIMMING WEIGHT SPRING
146		
147	05:B47113	TRIMMING WEIGHT B
148	05:B47112	TRIMMING WEIGHT A
149	05:B47110	TRIMMING WEIGHT SCREW
150	09:A39083C	BOBBIN
151	05:B46880-1	POLE PIECE
152	00:B44509A	MAGNET
153	05:B48233B	YOKE
154	PZ:2481D	POSITION SENSER BOARD
155		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6

EXPLODED VIEW 2


NO.	PARTS NAME	DESCRIPTION
156		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
157	PZ:2500D	ANALOG BOARD
158		ALLEN HEAD BOLT M4×10
159	10:S-NO-1-SUS	CONICAL SPRING WASHER
160		ALLEN HEAD BOLT M4×10
161	10:S-NO-1-SUS	CONICAL SPRING WASHER
162		ALLEN HEAD WITH HOLE M5×30
163	00:B49401	FOUR CORNER ADJUSTMENT
164	03:A21386E-1	MAIN MECHANICAL FRAME
165	10:P5×10	PARALEL PIN ϕ 5×10
166	00:A47004	FOUR CORNER SPRING
167	05:B48675A	MAGNET HOLDER BASE
168	10:S-NO-1-SUS	CONICAL SPRING WASHER
169		PAN HEAD M4×10
170		PAN HEAD M4×5
171	10:S-NO-1-SUS	CONICAL SPRING WASHER
172	05:B49476	FLEXIBLE BEARING WASHER
173	04:A46360;B	FREXIBLE BEARING
174	04:B47104	LOWER FLEXIBLE BEARING ASSY
175	05:B49476	FLEXIBLE BEARING WASHER
176	10:S-NO-1-SUS	CONICAL SPRING WASHER
177		PAN HEAD M4×8
178	03:A10186A	LOWER CASE
179	10:S-NO-1-SUS	CONICAL SPRING WASHER
180		ALLEN HEAD BOLT M4×10
181		PAN HEAD M4×8
182	10:S-NO-1-SUS	CONICAL SPRING WASHER
183	05:B49476	FLEXIBLE BEARING WASHER
184	04:A46360;B	FLEXIBLE BEARING
185	05:B49476	FLEXIBLE BEARING WASHER
186	10:S-NO-1-SUS	CONICAL SPRING WASHER
187		
188	04:B48932	TENSION BEARING
189	04:B47107	UPPER TENSION BEARING HOLDER
190	10:S-NO-1-SUS	CONICAL SPRING WASHER
191		PAN HEAD M4×8
192		TRAS
193	10:S-NO-1-SUS	CONICAL SPRING WASHER
194	05:B49476	FLEXIBLE BEARING WASHER
195	04:B46360;B	FLEXIBLE BEARING
196	05:B49476	FLEXIBLE BEARING WASHER
197	10:S-NO-1-SUS	CONICAL SPRING WASHER
198		PAN HEAD M4×8
199		PAN HEAD M4×5

EXPLODED VIEW -2

HX - 100


maintenance-HX-series-v.1.1.a

Page 131



BREEZE BREAK FOR HX

NO.	PARTS NAME	DESCRIPTION
1	07:C40061-1	SIDE KNOB L
2	07:B49806	SIDE KNOB SHEET
3	00:B49326	SIDE GLASS
4		BUSHING
5		TRUSS HEAD M3×8
6	07:B49801-3	CUSHION STRIP
7	07:B49800-2	DOOR SUPPORT STRIP L
8	00:B49323	FRONT GLASS
9	07:B49841	ADHESIVE STRIP
10	07:B49842	ADHESIVE STRIP
11	07:B49801-1	CUSHION STRIP
12	04:A21433A	BREEZE BREAK CASE
13	07:B49801-2	CUSHION STRIP
14	07:B49841	ADHESIVE STRIP
15	07:B49801-3	CUSHION STRIP
16	07:B49800-1	DOOR SUPPORT STRIP R
17		TRUSS HEAD M3×8
18		BUSHING
19	00:B49326	SIDE GLASS
20	07:B49806	SIDE KNOB SHEET
21	07:C40061-2	SIDE KNOB R
22		FLAT HEAD M3×4
23	04:B49377A	REAR STOP PLATE
24	07:B49378-1	GUIDE RAIL R
25		TRUSS HEAD M3×8
26		BUSHING
27	00:B49325	TOP GLASS
28	07:B49807	TOP KNOB SHEET
29	07:B49390A	TOP KNOB
30	00:B49324	REAR GLASS
31	07:B49378-2	GUIDE RAIL L
32	04:A39554A	SLIDE PLATE
33	07:B49374	KNOB SLIDER
34	07:B49374	KNOB SLIDER
35	07:A21435A	HANDLE
36	07:B49375	SLIDER COVER
37	07:B49375	SLIDER COVER
38	07:B49374	KNOB SLIDER
39	07:B49375	SLIDER COVER




EXPLODED VIEW BREEZE BREAK

EXPLODED VIEW 1

NO.	PARTS NAME	DESCRIPTION
1	04:A39326	WEIGHING PAN
2		FLAT HEAD M3×6
3	05:B43841A	WASHER RING
4	04:A39327	PAN SUPPORT
5	05:B48934	PAN SUPPORT BUSHING
6		
7	04:A39339	DUST COVER
8		BINDING HEAD M4×4
9		BINDING HEAD M4×4
10	04:A39220A	REAR PANEL
11		PAN HEAD WITH SPRING WASHER M4×6
12	KO:914-53	CABLE
13		PAN HEAD WITH SPRING WASHER M4×6
14		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
15	PZ:2499	INTERFACE BOARD
16		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
17		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
18	05:B47129A	WEIGHT
19	05:B47129A	WEIGHT
20		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
21	04:B47132	WEIGHT SEESAW L
22		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
23	04:B47131	WEIGHT SEESAW R
24		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
25	04:B47134	UPPER SIDE SEESAW STOP
26	04:B47136B	LEAF SPRING FOR SEESAW
27	04:B47135	LOWER SIDE SEESAW STOP
28		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
29	07:B40278	SHAFT BRACKET
30	05:B49005A	PC GUIDE
31		BINDING HEAD M4×4
32	00:A46916	LEVEL VIAL
32	05:B49003A	BUBBLE LEVEL HOLDER
33		BINDING HEAD M3×6
34	02:B48692	BLANK PANEL
35	03:A10186A	LOWER CASE
36	07:A46735A	LEVEL FOOT
37	05:B49004A	CABLE GUIDE
38		LOCK NUT M10
39		FLAT HEAD ALLEN HEAD BOLT M4×8
40	04:B48708A-2	WEIGHT STOP
41		KNURELED HEAD BOLT M4×10
42	05:B49004A	CABLE GUIDE
43	07:A46735A	LEVELING FOOT
44	07:B46858	UNDERHOOK CAP
45		PAN HEAD WITH SPRING AND PLAIN WASHER M4×8
46	PZ:2498	POWER SUPPLY BOARD
47		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
48		SHIPPING BOLT M4×10
49		FLAT HEAD ALLEN HEAD BOLT M3×15
50	05:B47178	WELLNUT BUSHING STOP
51	10:C-330L	WELLNUT BUSHING
52	05:B48938A	SUPPORT FOR LOGIC BOARD
53		PAN HEAD WITH SPRING AND PLAIN WASHER M4×8
54		PAN HEAD WITH SPRING AND PLAIN WASHER M4×8

EXPLODED VIEW 1

NO.	PARTS NAME	DESCRIPTION
55	03:B48654-1	CASE CONNECTOR R
56		ROLL SPRING PIN $\phi 3 \times 12$
57	07:B49032	DISPLAY SUPPORT
58	03:A21398	DISPLAY LOWER CASE
59	10:SJ-5012	RUBBER FOOT
60	07:B49023	DISPLAY SUPPORT STOP
61		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 8$
62	10:SJ-5012	RUBBER FOOT
63		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 8$
64	03:B48654-2	CASE CONNECTOR L
65		PAN HEAD WITH SPRING AND PLAIN WASHER $M4 \times 8$
66		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 8$
67		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 8$
68	PZ:2501	DISPLAY BOARD
69		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 8$
70	07:A21399	DISPLAY UPPER CASE
71	09:A39217	SILICON SWITCH COVER SHEET
72	01:A39659	DISPLAY FILTER
73	10:A35234	GEARED MOTOR
74		NUT $M3$
75	04:B48672	MOTOR SUPPORT
76		PAN HEAD $M1.4 \times 4$
77	07:B47133A	CAM DRIVING SEESAW
78		HEXAGON HEAD WITH HOLE $M3 \times 3$ AND $M3 \times 6$
79	09:B40470C	SWITCH CAM
80	04:B40464	COAXIAL BRACKET
81		ALLEN HEAD WITH HOLE $M6 \times 10$
82	00:B47414	PLUNGER
83	10:3/16	STEEL BALL
84		FLAT HEAD ALLEN HEAD BOLT $M4 \times 8$
85	05:B49004A	CABLE GUIDE
86	05:B49004A	CABLE GUIDE
87	05:B48938A	SUPPORT FOR LOGIC BOARD
88	04:B48708A-2	WEIGHT STOP
89	10:3/16	STEEL BALL
90	00:B47414	PLUNGER
91		ALLEN HEAD WITH HOLE $M6 \times 10$
92	04:B47135	LOWER SEESAW STOP
93	04:B47134	UPPER SEESAW STOP
94		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 6$
95	05:B46148	CAM SHAFT
96		ALLEN HEAD WITH HOLE $M3 \times 3$
97	PZ:2513	MOTOR BOARD
98		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 6$
99	PZ:2497	LOGIC BOARD
100		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 6$
300	07:A10191	UPPER CASE
301	04:B48993	CONDUCTING LEAF SPRING
302		LOCK NUT $M8$
303		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 5$
304	04:B48994	CONDUCTING SPRING PLATE
305	07:B49002-2	RIGHT SUPPORT CAP
306	07:B49002-1	LEFT SUPPORT CAP




EXPLODED VIEW 2

NO.	PARTS NAME	DESCRIPTION
101		
102	09:B49985	PAN SUPPORT RECEIVER BLOCK
103	10:C-166	SHOCK OBSORBER SPRING
104	03:A39175D	PAN SUPORT RECEIVER
105		
106		PAN HEAD M4×6
107	10:S-NO-1-SUS	CONICAL SPRING WASHER
108		PAN SPRING M3×6
109	04:B47740-2	STOP PLATE
110		PAN HEAD SPRING WASHER M3×6
111	04:B47737A	SHIELD PLATE
112	05:B47106	STOP PIN
113		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
114		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
115	03:A39136E-2	POSITION BEAM
116		NUT M3
117	PZ:2546	RELAY BOARD
118		
119		
120		NUT M3
121	05:B47113	TRIMMING WEIGHT B
122	05:B47112	TRIMMING WEIGHT A
123		PAN HEAD M3×20
124	04:B47105	UPPER FLEXIBLE BEARING ASSY
125		PAN HEAD M4×8
126	10:S-NO-1-SUS	CONICAL SPRING WASHER
127	05:B49476	FLEXIBLE BEARING WASHER
128	04:A46361;B	FLEXIBLE BEARING
129	05:B49476	FLEXIBLE BEARING WASHER
130	10:S-NO-1-SUS	CONICAL SPRING WASHER
131		PAN HEAD M4×5
132		PAN HEAD WITH SPRING AND PLAIN WASHER M3×5
133	04:B47491	WEIGHT STOPPER PLATE
134		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
135	04:B48995	WEIGHT ARM
136	03:A39174D-1	SUSPENSION GUIDE
137	04:B48995	WEIGHT ARM
138		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
139	04:B47491	WEIGHT STOP PLATE
140		PAN HEAD WITH SPRING AND PLAIN WASHER M3×5
141	10:P1.5×6	ROLL SPRING PIN
142	10:P1.5×6	ROLL SPRING PIN
143	04:A47793;B	FLEXIBLE BEARING
144	05:B49476	FLEXIBLE BEARING WASHER
145	10:S-NO-1-SUS	CONICAL SPRING WASHER
146		PAN HEAD M4×8
147	05:B49476	FLEXIBLE BEARING WASHER
148	10:S-NO-1-SUS	CONICAL SPRING WASHER
149		PAN HEAD M4×8
150	09:A39083C	BOBBIN
151	05:B46880-1	POLE PIECE
152	00:B44509A	MAGNET
153	05:B48233B	YOKE
154	PZ:2481A	POSITION SENSER BOARD
155		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6

EXPLODED VIEW 2

NO.	PARTS NAME	DESCRIPTION
156		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
157	PZ:2500A	ANALOG BOARD
158		ALLEN HEAD BOLT M4×20
159	10:S-NO-1-SUS	CONICAL SPRING WASHER
160		ALLEN HEAD BOLT M4×25
161	10:S-NO-1-SUS	CONICAL SPRING WASHER
162		ALLEN HEAD WITH HOLE M5×30
163	05:A46369	FOUR CORNER ADJUSTMENT SCREW
164	03:A21386D-1	MAIN MECHANICAL FRAME
165		PARALLEL PIN ϕ 5×10
166	00:A47004	FOUR CORNER SPRING
167	05:B48675A	MAGNET HOLDER BASE
168	10:S-NO-1-SUS	CONICAL SPRING WASHER
169		PAN HEAD M4×10
170		PAN HEAD M4×5
171	10:S-NO-1-SUS	CONICAL SPRING WASHER
172	05:B49476	FLEXIBLE BEARING WASHER
173	04:A46361;B	FLEXIBLE BEARING
174	04:B47104	LOWER FLEXIBLE BEARING ASSY
175	05:B49476	FLEXIBLE BEARING WASHER
176	10:S-NO-1-SUS	CONICAL SPRING WASHER
177		PAN HEAD M4×8
178	03:A10186A	LOWER CASE
178		
179	10:S-NO-1-SUS	CONICAL SPRING WASHER
180		ALLEN HEAD BOLT M4×10
181		PAN HEAD M4×8
182	10:S-NO-1-SUS	CONICAL SPRING WASHER
183	05:B49476	FLEXIBLE BEARING WASHER
184	04:A46361;B	FLEXIBLE BEARING
185	05:B49476	FLEXIBLE BEARING WASHER
186	10:S-NO-1-SUS	CONICAL SPRING WASHER
187		PAN HEAD M4×5
188	04:B48931	TENSION BEARING
189	04:B47107	UPPER TENSION BEARING HOLDER
190	10:S-NO-1-SUS	CONICAL SPRING WASHER
191		PAN HEAD M4×8
192		PAN HEAD M4×5
193	10:S-NO-1-SUS	CONICAL SPRING WASHER
194	05:B49476	FLEXIBLE BEARING WASHER
195	04:B48933	FLEXIBLE BEARING
196	05:B49476	FLEXIBLE BEARING WASHER
197	10:S-NO-1-SUS	CONICAL SPRING WASHER
198		PAN HEAD M4×8
199	05:A46919	UNDERHOOK
200	10:P1.5×6	ROLL SPRING PIN
201	10:P1.5×6	ROLL SPRING PIN
202	04:B47108	LOWER TENSION BEARING HOLDER
203	10:S-NO-1-SUS	CONICAL SPRING WASHER
204		PAN M4×8



EXPLODED VIEW -2
HX - 400

EXPLODED VIEW 1

NO.	PARTS NAME	DESCRIPTION
1	04:A39254	WEIGHTING PAN
2		FLAT HEAD M3×6
3	05:B43841A	WASHER RING
4	04:A39255	PAN SUPPORT
5	09:B49984	PAN SUPPORT BUSHING
6		
7	04:A39340	DUST COVER
8		BINDING HEAD M4×4
9		BINDING HEAD M4×4
10	04:A39220A	REAR PANEL
11		PAN HEAD WITH SPRING WASHER M4×6
12	K0:914-53	CABLE
13		PAN HEAD WITH SPRING WASHER M4×6
14		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
15	PZ:2499	INTERFACE BOARD
16		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
17		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
18	05:B47130A	WEIGHT FOR HX3000
19	05:B47130A	WEIGHT FOR HX3000
20		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
21	04:B47132	WEIGHT SEESAW L
22		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
23	04:B47131	WEIGHT SEESAW R
24		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
25	04:B47134	UPPER SIDE SEESAW STOP
26	04:B47136B	LEAF SPRING FOR SEESAW
27	04:B47135	LOWER SIDE SEESAW STOP
28		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
29	07:B40278	SHAFT BRACKET
30	05:B49005A	PC GUIDE
31		BINDING HEAD M4×4
32	00:B46916	BUBBLE SPIRIT LEVEL
32	05:B49003A	BUBBLE LEVEL HOLDER
33		BINDING HEAD M3×6
34	02:B48692	BLANK PANEL
35	03:A10186A	LOWER CASE
36	07:76735A	LEVELING FOOT
37	05:B49004A	CABLE GUIDE
38		LOCK NUT M10
39		FLAT HEAD ALLEN HEAD BOLT M4×8
40	04:B48708A-1	WEIGHT STOP
41		KNURELED HEAD BOLT M4×10
42	05:B49004A	CABLE GUIDE
43	07:A46735A	LEVELING FOOT
44	07:B46858	UNDERHOOK CAP
45		PAN HEAD WITH SPRING AND PLAIN WASHER M4×8
46	PZ:2498	POWER SUPPLY BOARD
47		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
48		SHIPPING BOLT M4×10
49		FLAT HEAD ALLEN HEAD BOLT M3×15
50	05:B47178	WELLNUT BUSHING STOP
51	10:C-330L	WELLNUT BUSHING
52	05:B48938A	SUPPORT FOR LOGIC BOARD
53		PAN HEAD WITH SPRING AND PLAIN WASHER M4×8
54		PAN HEAD WITH SPRING AND PLAIN WASHER M4×8

EXPLODED VIEW 1

NO.	PARTS NAME	DESCRIPTION
55	03:B48654-1	CASE CONNECTOR R
56		ROLL SPRING PIN $\phi 3 \times 12$
57	07:B49032	DISPLAY SUPPORT
58	03:A21398	DISPLAY LOWER CASE
59	10:SJ-5012	RUBBER FOOT
60	07:B48923	DISPLAY SUPPORT STOP
61		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 8$
62	10:SJ-5012	RUBBER FOOT
63		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 8$
64	03:B48654-2	CASE CONNECTOR L
65		PAN HEAD WITH SPRING AND PLAIN WASHER $M4 \times 8$
66		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 8$
67		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 8$
68	PZ:2501	DISPLAY BOARD
69		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 8$
70	07:A21399	DISPLAY UPPER CASE
71	09:A39217	SILICON SWITCH COVER SHEET
72	01:A39660	DISPLAY FILTER
73	10:A35234	GEARED MOTOR
74		NUT $M3$
75	04:B48672	MOTOR SUPPORT
76		PAN HEAD $M1.4 \times 4$
77	07:B47133A	CAM DRIVING SEESAW
78		ALLEN HEAD WITH HOLE $M3 \times 3$ AND $M3 \times 6$
79	09:B40470B	SWITCH CAM
80	04:B40464	COAXIAL BRACKET
81		ALLEN HEAD WITH HOLE $M6 \times 10$
82	00:B47414	PLUNGER
83	10:3/16	STEEL BALL
84		FLAT HEAD ALLEN HEAD BOLT $M4 \times 8$
85	05:B49004A	CABLE GUIDE
86	05:B49004A	CABLE GUIDE
87	05:B48938A	SUPPORT FOR LOGIC BOARD
88	04:B48708A-1	WEIGHT STOP
89	10:3/16	STEEL BALL
90	00:B47414	PLUNGER
91		ALLEN HEAD WITH HOLE $M6 \times 10$
92	04:B47135	LOWER SEESAW STOP
93	04:B47134	UPPER SEESAW STOP
94		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 6$
95	05:B46148	CAM SHAFT
96		ALLEN HEAD WITH HOLE $M3 \times 3$
97	PZ:2513	MOTOR BOARD
98		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 6$
99	PZ:2597	LOGIC BOARD
100		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 6$
300	07:A10187	UPPER CASE
301	04:B48993	CONDUCTING LEAF SPRING
302		LOCK NUT $M8$
303		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 5$
304	04:B48994	CONDUCTING SPRING PLATE
305	07:B49002-2	RIGHT SUPPORT CAP
306	07:B49002-1	LEFT SUPPORT CAP


EXPLODED VIEW - 1

HX - 3000

maintenance-HX-series-v.1.a

Page 153

from No.1 to No.100
from No.300 to No.306



EXPLODED VIEW 2

NO.	PARTS NAME	DESCRIPTION
101		ALLEN HEAD BOLT M4×8
102	10:S-NO-1-SUS	CONICAL SPRING WASHER
103	03:A21391C	PAN SUPPORT RECEIVER
104	05:B48937	PAN SUPPORT RECEIVER BLOCK
105	04:B47116A	SHOCK ABSORBER LEAF SPRING
106	04:B43841A	WASHER M3
107		FLAT HEAD M3×6
108	05:B47120A	SHOCK ABSORBER BLOCK
109		ALLEN HEAD BOLT M4×12
110		ALLEN HEAD BOLT M4×12
111	05:B48937	PAN SUPPORT RECEIVER BLOCK
112	04:B43841A	WASHER M3
113		FLAT HEAD M3×6
114	05:B48937	PAN SUPPORT RECEIVER BLOCK
115	04:B47116A	SHOCK ABSORBER LEAF SPRING
116	04:B43841A	WASHER M3
117		PAN HEAD M3×6
118	05:B47120A	SHOCK ABSORBER BLOCK
119		ALLEN HEAD BOLT M4×12
120		ALLEN HEAD BOLT M4×12
121	05:B48937	PAN SUPPORT RECEIVER BLOCK
122	04:B43841A	WASHER M3
123		FLAT HEAD M3×6
124	04:B47103	UPPER FLEXIBLE BEARING ASSY
125		PAN HEAD M4×8
126	10:S-NO-1-SUS	CONICAL SPRING WASHER
127	05:B49476	FLEXIBLE BEARING WASHER
128	04:B48933	FLEXIBLE BEARING
129	05:B49476	FLEXIBLE BEARING WASHER
130	10:S-NO-1-SUS	CONICAL SPRING WASHER
131		PAN HEAD M4×5
132		PAN HEAD WITH SPRING WASHER M3×6
133	04:B47740-1	STOP PLATE
134		PAN HEAD WITH SPRING WASHER M3×6
135	04:B47737	SHIELD PLATE
136	05:B47106	STOP PIN
137		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
138		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
139	PZ:2546	RELAY BOARD
140	03:A39135E-2	POSITION BEAM
141	10:101801-15006	ROLL SPRING PIN
142	10:101801-15006	ROLL SPRING PIN
143	04:A47644A;B	FLEXIBLE BEARING
144	05:B49476	FLEXIBLE BEARING WASHER
145	10:S-NO-1-SUS	CONICAL SPRING WASHER
146		FLAT HEAD M4×8
147	05:B49476	FLEXIBLE BEARING WASHER
148	10:S-NO-1-SUS	CONICAL SPRING WASHER
149		PAN HEAD M4×8
150	09:A39083C	BOBBIN
151	05:B46880	POLE PIECE
152	00:B44509	MAGNET
153	05:B48233B	YOKE
154	PZ:2481	POSITION SENSOR BOARD
155		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6

EXPLODED VIEW 2

NO.	PARTS NAME	DESCRIPTION
156		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
157	PZ:2500B	ANALOG BOARD
158		ALLEN HEAD BOLT M4×20
159	10:S-NO-1-SUS	CONICAL SPRING WASHER
160		ALLEN HEAD BOLT M4×25
161	10:S-NO-1-SUS	CONICAL SPRING WASHER
162		ALLEN HEAD WITH HOLE M5×30
163	05:A46369	FOUR CORNER ADJUSTMENT SCREW
164	03:A21386D-2	MAIN MECHANICAL FRAME
165		PARALEL PIN ϕ 5×10
166	00:A47004	FOUR CORNER SPRING
167	05:B48675	MAGNET HOLDER BASE
168	10:S-NO-1-SUS	CONICAL SPRING WASHER
169		PAN HEAD M4×10
170		PAN HEAD M4×5
171	10:S-NO-1-SUS	CONICAL SPRING WASHER
172	05:B49476	FLEXIBLE BEARING WASHER
173	04:B47127	FLEXIBLE BEARING
174	04:B47104	LOWER FEXIBLE ASSY
175	05:B49476	FLEXIBLE BEARING WASHER
176	10:S-NO-1-SUS	CONICAL SPRING WASHER
177		PAN HEAD M4×8
178	03:A10186B	LOWER CASE
179	10:S-NO-1-SUS	CONICAL SPRING WASHER
180		ALLEN HEAD BOLT M4×10
181		PAN HEAD M4×8
182	10:S-NO-1-SUS	CONICAL SPRING WASHER
183	05:B49476	FLEXIBLE BEARING WASHER
184	04:B48933	FLEXIBLE BEARING
185	05:B49476	FLEXIBLE BEARING WASHER
186	10:S-NO-1-SUS	CONICAL SPRING WASHER
187		PAN HEAD M4×5
188	03:A38507E	SUSPENSION GUIDE
189	04:B48690A	WEIGHT ARM
190		SPRING WASHER M3
191		ALLEN HEAD BOLT M3×10
192		PAN HEAD M4×5
193	10:S-NO-1-SUS	CONICAL SPRING WASHER
194	05:B49476	FLEXIBLE BEARING WASHER
195	04:B48933	FLEXIBLE BEARING
196	05:B49476	FLEXIBLE BEARING WASHER
197	10:S-NO-1-SUS	CONICAL SPRING WASHER
198		PAN HEAD M4×8
199	05:A46919	UNDERHOOK
200	10:1010801-15006	ROLL SPRING PIN
201	10:1010801-15006	ROLL SPRING PIN
202	04:B48930	TENSION BEARING
203	04:B47108	LOWER TENSION BEARING HOLDER
204	10:S-NO-1-SUS	CONICAL SPRING WASHER
205		PAN HEAD M4×8
206		PAN HEAD M4×8
207	10:S-NO-1-SUS	CONICAL SPRING WASHER
208	04:B47107	UPPER TENSION BEARING HOLDER
209	04:B48690A	WEIGHT ARM
210		SPRING WASHER M3

HX-3000

EXPLODED VIEW 2


NO.	PARTS NAME	DESCRIPTION
211		ALLEN HEAD BOLT M3×10

EXPLODED VIEW - 2

HX - 3000

maintenance-HX-series-v.1.a

Page 161




EXPLODED VIEW 1

NO.	PARTS NAME	DESCRIPTION
1	04:A39256	WEIGHTING PAN
2		FLAT HEAD M3×6
3	05:B43841A	WASHER RING
4	04:A39328	PAN SUPPORT
5	09:B49984	PAN SUPPORT BUSHING
6		
7	07:A10192	UPPER CASE
8	07:B49002-2	LEFT SUPPORT CAP
9	07:B49002-1	RIGHT SUPPORT CAP
10	04:A39220A	REAR PANEL
11		PAN HEAD WITH SPRING WASHER M4×6
12	KO:914-53	CABLE
13		PAN HEAD WITH SPRING WASHER M4×6
114		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
15	PZ:2499	INTERFACE BOARD
16		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
17		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
18	05:B47130A	WEIGHT FOR HX3000
19	05:B47130A	WEIGHT FOR HX3000
20		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
21	04:B47132	WEIGHT SEESAW L
22		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
23	04:B47131	WEIGHT SEESAW R
24		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
25	04:B47134	UPPER SEESAW STOP
26	04:B47136B	LEAF SPRING FOR SEESAW
27	04:B47135	LOWER SEESAW STOP
28		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6
29	07:B40278	SHAFT BRACKET
30	05:B49005A	PC GUIDE
31		BINDING HEAD M4×4
32	00:B46916	BUBBLE SPIRIT LEVEL
32	05:B49003A	BUBBLE LEVEL HOLDER
33		BINDING HEAD M3×6
34	02:B48692	BLANK PANEL
35	03:A10186A	LOWER CASE
36	07:76735A	LEVELING FOOT
37	05:B49004A	CABLE GUIDE
38		LOCK NUT M10
39		FLAT HEAD ALLEN SCREW M4×8
40	04:B48708A-1	WEIGHT STOP
41		KNURELED HEAD BOLT M4×10
42	05:B49004A	CABLE GUIDE
43	07:A46735A	LEVELING FOOT
44	07:B46858	UNDERHOOK CAP
45		PAN HEAD WITH SPRING AND PLAIN WASHER M4×8
46	PZ:2498	POWER SUPPLY BOARD
47		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
48		KNURELED HEAD BOLT M4×10
49		FLAT HEAD ALLEN SCREW M3×15
50	05:B47178	WELLNUT BUSHING STOP
51	10:C-330L	WELLNUT BUSHING
52	05:B48938A	SUPPORT FOR LOGIC BOARD
53		PAN HEAD WITH SPRING AND PLAIN WASHER M4×8
54		PAN HEAD WITH SPRING AND PLAIN WASHER M4×8

EXPLODED VIEW 1

NO.	PARTS NAME	DESCRIPTION
55	03:B48654-1	CASE CONNECTOR R
56		ROLL SPRING PIN $\phi 3 \times 12$
57	07:B49032	DISPLAY SUPPORT
58	03:A21398	DISPLAY LOWER CASE
59	10:SJ-5012	RUBBER FOOT
60	07:B49023	DISPLAY SUPPORT STOP
61		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 8$
62	10:SJ-5012	RUBBER FOOT
63		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 8$
64	03:B48654-2	CASE CONNECTOR L
65		PAN HEAD WITH SPRING AND PLAIN WASHER $M4 \times 8$
66		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 8$
67		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 8$
68	PZ:2501	DISPLAY BOARD
69		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 8$
70	07:A21399	DISPLAY UPPER CASE
71	09:A39217	SILICON SWITCH COVER SHEET
72	01:A39661	DISPLAY FILTER
73	10:A35234	GEARED MOTOR
74		NUT $M3$
75	04:B48672	MOTOR SUPPORT
76		PAN HEAD $M1.4 \times 4$
77	07:B47133A	CAM DRIVING SEESAW
78		ALLEN HEAD WITH HOLE $M3 \times 3$ AND $M3 \times 6$
79	09:B40470C	SWITCH CAM
80	04:B40464	COAXIAL BRACKET
81		ALLEN HEAD WITH HOLE $M6 \times 10$
82	00:B47414	PLUNGER
83	10:3/16	STEEL BALL
84		FLAT HEAD ALLEN SCREW BOLT $M4 \times 8$
85	05:B49004A	CABLE GUIDE
86	05:B49004A	CABLE GUIDE
87	05:B48938A	SUPPORT FOR LOGIC BOARD
88	04:B48708A-1	WEIGHT STOP
89	10:3/16	STEEL BALL
90	00:B47414	PLUNGER
91		ALLEN HEAD WITH HOLE $M6 \times 10$
92	04:B47135	LOWER SEESAW STOPPER
93	04:B47134	UPPER SEESAW STOPPER
94		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 6$
95	05:B46148	CAM SHAFT
96		ALLEN HEAD WITH HOLE $M3 \times 3$
97	PZ:2513	MOTOR BOARD
98		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 6$
99	PZ:2497	LOGIC BOARD
100		PAN HEAD WITH SPRING AND PLAIN WASHER $M3 \times 6$



EXPLODED VIEW - 1 HX - 6000

EXPLODED VIEW 2

NO.	PARTS NAME	DESCRIPTION
101		ALLEN HEAD BOLT M4×8
102	10:S-NO-1-SUS	CONICAL SPRING WASHER
103	03:A21391C	PAN SUPPORT RECEIVER
104	05:B48937	PAN SUPPORT RECEIVER BLOCK
105	04:B47912A-2	SHOCK ABSORBER LEAF SPRING
106	04:B43841A	WASHER M3
107		FLAT HEAD M3×6
108	05:B47120A	SHOCK ABSORBER BLOCK
109		ALLEN HEAD BOLT M4×12
110		ALLEN HEAD BOLT M4×12
111	05:B48937	PAN SUPPORT RECEIVER BLOCK
112	04:B43841A	WASHER M3
113		FLAT HEAD M3×6
114	05:B48937	PAN SUPPORT RECEIVER BLOCK
115	04:B47912A-1	SHOCK ABSORBER LEAF SPRING
116	04:B43841A	WASHER M3
117		PAN HEAD M3×6
118	05:B47120A	SHOCK ABSORBER BLOCK
119		ALLEN HEAD BOLT M4×12
120		ALLEN HEAD BOLT M4×12
121	05:B48937	PAN SUPPORT RECEIVER BLOCK
122	04:B43841A	WASHER M3
123		FLAT HEAD M3×6
124	04:B47103	UPPER FLEXIBLE BEARING ASSY
125		PAN HEAD M4×8
126	10:S-NO-1-SUS	CONICAL SPRING WASHER
127	05:B49476	FLEXIBLE BEARING WASHER
128	04:B48933	FLEXIBLE BEARING
129	05:B49476	FLEXIBLE BEARING WASHER
130	10:S-NO-1-SUS	CONICAL SPRING WASHER
131		PAN HEAD M4×5
132		PAN HEAD WITH SPRING WASHER M3×6
133	04:B47740-1	STOP PLATE
134		PAN HEAD WITH SPRING WASHER M3×6
135	04:B47737	SHIELD PLATE
136	05:B47106	STOP PIN
137		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
138		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
139	PZ:2546	RELAY BOARD
140	03:A39135F-2	POSITION BEAM
141	10:P1.5×6	ROLL SPRING PIN
142	10:P1.5×6	ROLL SPRING PIN
143	04:A47644A	FLEXIBLE BEARING
144	05:B49476	FLEXIBLE BEARING WASHER
145	10:S-NO-1-SUS	CONICAL SPRING WASHER
146		FLAT HEAD M4×8
147	05:B49476	FLEXIBLE BEARING WASHER
148	10:S-NO-1-SUS	CONICAL SPRING WASHER
149		PAN HEAD M4×8
150	09:A39083C	BOBBIN
151	05:B46880-1	POLE PIECE
152	00:B44509A	MAGNET
153	05:B48233B	YOKE
154	PZ:2481C	POSITION SENSOR BOARD
155		PAN HEAD WITH SPRING AND PLAIN WASHER M3×6

EXPLODED VIEW 2

NO.	PARTS NAME	DESCRIPTION
156		PAN HEAD WITH SPRING AND PLAIN WASHER M3×8
157	PZ:2500C	ANALOG BOARD
158		ALLEN HEAD BOLT M4×20
159	10:S-NO-1-SUS	CONICAL SPRING WASHER
160		ALLEN HEAD BOLT M4×25
161	10:S-NO-1-SUS	CONICAL SPRING WASHER
162		ALLEN HEAD WITH HOLE M5×30
163	05:A49401	FOUR CORNER ADJUSTMENT SCREW
164	03:A21386D-2	MAIN MECHANICAL FRAME
165	10:P5×10	PARALEL PIN ϕ 5×10
166	00:A47004	FOUR CORNER SPRING
167	05:B48675A	MAGNET HOLDER BASE
168	10:S-NO-1-SUS	CONICAL SPRING WASHER
169		PAN HEAD M4×10
170		PAN HEAD M4×5
171	10:S-NO-1-SUS	CONICAL SPRING WASHER
172	05:B49476	FLEXIBLE BEARING WASHER
173	04:B48933	FLEXIBLE BEARING
174	04:B47104	LOWER FLEXIBLE BEARING ASSY
175	05:B49476	FLEXIBLE BEARING WASHER
176	10:S-NO-1-SUS	CONICAL SPRING WASHER
177		PAN HEAD M4×8
178	03:A10186B	LOWER CASE
179	10:S-NO-1-SUS	CONICAL SPRING WASHER
180		ALLEN HEAD BOLT M4×10
181		PAN HEAD M4×8
182	10:S-NO-1-SUS	CONICAL SPRING WASHER
183	05:B49476	FLEXIBLE BEARING WASHER
184	04:B48933	FLEXIBLE BEARING
185	05:B49476	FLEXIBLE BEARING WASHER
186	10:S-NO-1-SUS	CONICAL SPRING WASHER
187		PAN HEAD M4×5
188	03:A38507E	SUSPENSION GUIDE
189	04:B48690A	WEIGHT ARM
190		SPRING WASHER M3
191		ALLEN HEAD BOLT M3×10
192		PAN HEAD M4×5
193	10:S-NO-1-SUS	CONICAL SPRING WASHER
194	05:B49476	FLEXIBLE BEARING WASHER
195	04:B48933	FLEXIBLE BEARING
196	05:B49476	FLEXIBLE BEARING WASHER
197	10:S-NO-1-SUS	CONICAL SPRING WASHER
198		PAN HEAD M4×8
199	05:A46919	UNDERHOOK
200	10:P1.5×6	ROLL SPRING PIN
201	10:P1.5×6	ROLL SPRING PIN
202	04:B48930	TENSION BEARING
203	04:B47108	LOWER TENSION BEARING HOLDER
204	10:S-NO-1-SUS	CONICAL SPRING WASHER
205		PAN HEAD M4×8
206		PAN HEAD M4×8
207	10:S-NO-1-SUS	CONICAL SPRING WASHER
208	04:B47107	UPPER TENSION BEARING HOLDER
209	04:B48690A	WEIGHT ARM
210		SPRING WASHER M3

HX-6000

EXPLODED VIEW 2


NO.	PARTS NAME	DESCRIPTION
211		ALLEN HEAD BOLT M3×10

EXPLODED VIEW - 2
HX - 6000

maintenance-HX-series-v.1.a

Page 175

from No.101 to No.211





A&D Company, Limited

3-23-14 Higashi-Ikebukuro, Toshima-ku, Tokyo-170 Japan
Telephone: [81] (03) 5391-6132 Fax: [81] (03) 5391-6148 Telex: 2422816 AANDD J

A&D ENGINEERING, INC.

1555 McCandless Drive, Milpitas, CA. 95035 U.S.A.
Telephone: [1] (408) 263-5333 Fax: [1] (408) 263-0119

A&D INSTRUMENTS LTD.

Abingdon Science Park, Abingdon, Oxford OX14 3YS England
Telephone: [44] (0235) 550420 Fax: [44] (0235) 550485

A&D MERCURY PTY. LTD.

32 Dew Street, Thebarton, South Australia 5031 Australia
Telephone: [61] (08) 352-3033 Fax: [61] (08) 352-7409

A&D KOREA Limited

3rd Floor Hanam Bldg 44-27 Yoido-dong Youngdeungpo-ku Seoul, Korea
Telephone: [82] (02) 784-4264 Fax: [82] (02) 784-6557