

AD4407 Set up & Calibration Procedure

KEY OPERATIO N	DESCRIPTION	DISPLAY
<CAL>		CAL 0
<MODE> 3 times		CAL SEt
< ENTER>	For single range	SiNGL
<MODE>	Toggles between kg & tonnes	Kg or g or t
<ZERO>	Toggles between Single & Dual Range	Single or Dual
< ENTER>		D 0000
<ZERO>	Selects the resolution size	
<+/->	Toggles decimal point format between decimal point & coma	
<MODE>	Selects decimal position	0.000
< ENTER>	Capacity setting	CAP -XXXX
<0-9 KEYS>	Set capacity	
< ENTER>	Enters ZERO setting	CAL O
< ENTER>		CAL F then xxxxx Full load
	Place calibration mass on scale	
<0-9 KEYS>	Set display to equal calibration mass	
< ENTER>	Enters CAPCITY setting	CAL END
<CAL>	Exit CAL mode	CAL OFF
<ON/OFF>	Returns to normal weighing	