



HVW-G Initialisation Procedure

- 1) With the display off, hold the <CAL> & <ZERO> keys, press the <ON> key.
“F1- x ” displayed.
- 2) Press the <F> key 4 times. “init” displayed.
- 3) Press the <MODE> key 2 times. The indicator now performs a display check, when the display check is completed turn the unit off & on. The initialization is now complete.
- 4) CF & F functions will need to be re-entered.

HVW-G CF FUNCTION SETTINGS

With the display turned off

Press & Hold <Cal> & <Zero> Keys

Press <On/Off> Key

F1 – will be displayed

Press three times <F> Key

CF – will be displayed

Press <Mode > Key

CF1 – will be displayed

	Type	HV 15	HV 60	HV 200	HW 10	HW 60	HW 100	HW 200	300 x 0.05	600 x 0.1	1200
CF 2	Triple	1	1	1	0	0	0	0	0	0	0
CF 3	Capacity	0	1	2	0	1	2	3	6	7	8

CF 1	1	
CF 4	0 (kg)	1 (lbs, oz)
CF 5	0	1 (lbs, oz, lbs & oz)
CF 6	1	
CF 7	1	
CF 8	1	
CF 9	1	
CF 10	0	
CF 11	0	
CF 12	1	
CF 13	1	
CF14	1	0 for HV NSC
CF15	0	

Press <Mode> key to move from CF1 to CF15

Press < Sample> key to change CF value

Press <Mode> key until “END” is displayed.

Press <On/Off> key twice.