

AD-4325A/V

MAINTENANCE MANUAL

Maintenance-AD-4325A/V.v.1.b 911017 OGA

WEIGHING INDICATOR



CONTENTS

Outline.....Page 2

Description of Functions

1. Principles of Functions.....Page 3

2. Block Diagram.....Page 4

3. Flow Chart.....Page 6

Troubleshooting using Check Software

1. Check Mode
(Refer to Section E in the instruction manual.) Page 25

2. Test Mode.....Page 26

AD-4325A

1. Parts List.....Page 35

2. Schematics.....Page 45

3. Parts Location.....Page 55

4. Exploded View.....Page 63

AD-4325V

1. Parts List.....Page 69

2. Schematics.....Page 79

3. Parts Location.....Page 89

4. Exploded View.....Page 93



Outline

The AD4325A/V is an indexing control indicator and can store 100 kinds of different set values (such as final weight, free fall, preliminary, over, and under).

High-speed A/D conversion is provided by the same hardware and software as those for the AD4323 with 70 sampling times and resolution of 1/10,000. It has been provided with six types of comparators in order to cope with various applications.

Calibration and function data are stored in an EEPROM, and various set and accumulated values such as final weight, free fall, etc. are stored in the CMOS RAM backed up by batteries.

The A/D, OP-01, OP-04, and OP-07 boards are the same as those for the AD4323. The OP-02 and OP-03 boards are used only for the AD-4325A/V.

A watchdog timer is provided to prevent the CPU from running away.



Description of Functions


1. Principles of Functions

• Load Cell and Indicator

The strain gauge style load cell has strain gauges attached to the elastic body designed to be strained in proportion to a load and has those gauges wired to form a Wheatstone bridge.

A voltage of about 12V DC is applied to this Wheatstone bridge from the indicator. The output from the bridge is connected to the input of the indicator.

If a load is applied to the load cell, the elastic body is deformed as shown in the figure below and the gauges A and A' change in the elongating direction, and those B and B' in the contracting direction. Since the strain gauge increases a resistance in proportion to its elongation and decreases it in proportion to compression, a voltage proportional to the load is generated at the output of the Wheatstone bridge.



The indicator converts this signal from analog into digital and displays it as a weight value.

Since the resistance between the input terminals(+EXC and -EXC) of the load cell is as low as about 350Ω, if it is installed in the place away from the indicator, a cable resistance will change due to a temperature change and the actual voltage applied to the load cell will change. A change of this applied voltage affects the output and results in an weighing error. In order to avoid such a phenomenon, sensing cables are connected in parallel with +EXC and -EXC to monitor a voltage change between them on the part of the indicator. If the voltage between them falls, the A/D unit internally compensates for error due to a resistance change between the cables.

• A/D Converter


The weight indicator converts the analog signal from the load cell into digital data proportional to the weight value. The A/D converter is the same as that used in the AD4323.

- **Data Processing after A/D Conversion**

A/D conversion is of double integrating type of system. It applies zero span obtained by calibration to an A/D-converted count as a weight value and uses it as display and output data.

However, output timing depends on the operation mode. For example, the stop mode rewrites the data at any time(8times/second), but the operation mode rewrites it at judgement completion time and holds it until next judgment.

2. Block Diagram



[PZ: 2323A] Main Board

This board is similar to those for the AD4324 and AD4323TK. The Watchdog circuit monitors the power-on reset and CPU. The CLK has a speed of 12 MHz and used as a clock for the CPU and A/D counter. The RAM 5564 (U8) is backed up by the lithium battery. Various set and accumulated values such as final weight, free fall, etc. are stored in the RAM. Calibration and function data are stored in an EEPROM. Display data is parallel/serial-converted by the 66300 (U1) and sent to the display board. For the I/O, key, etc., data is exchanged by a latch and buffer over the data bus, but there were some cases where different parts had been used in transistors specifying addresses. When key input is abnormal, check the type numbers of these transistors with built-in resistor. The slide switch is set to IN and JP1 to 2.

[PZ-2324] Power Board

This board may be the same as those for the AD4324 and AD4323TK. No fuse is needed. The F terminal (12 V) may be connected to the F terminal on the relay board (OP-2) and used for 12 V for relay drive.

[PZ: 2330] Display Board

This board converts serial data sent from the main board into parallel data. It is of dynamic drive and data is sent from the main board every 0.832 ms. The six keys on the left (K1 through K2) read data in the serial mode and may be software switched for selection of digits indicated by LEDs. The four slide switches (S1 through S4) read data in parallel mode.

[PZ:2077B] A/D Board

This board is similar to the AD4323 A/D board except that the connector has been replaced by a terminal strip.

[PZ:2361] Terminal Board (Standard)

The control I/O connector for the AD4325A is a terminal strip, which is mounted on the substrate. COM1 and COM2 are common.

[PZ: 2331] Relay Board (OP-02)

The input of this board is the same as that for the terminal board and its output is converted into a relay contact output. Power supply is required to drive this relay board. The power is obtained by connecting the F terminal (12 V) on the power board to the F terminal on the relay board (OP-02).

[PZ: 2079] BCD Output Board (OP-01)

This board is the same as that for the AD4323.

[PZ: 2078] Serial I/O Board (OP-04)

This board is the same as that for the AD4323.


[PZ: 2080] Analog Output Board (OP-07)


This board is the same as that for the AD4323.


[PZ: 2089] RS-422 Board (OP-03)


This board is used only with the AD4325A. In this board, RS-232C is used as the RS-422 level (without address or in the command mode with address).

3. Flow Chart









```

***** INITIALIZE DISPLAY DRIVER and CONTROL I/O OUTPUT *****

INIT16:  CALL DSPICL                      Clear Display Buffer for WREEPR, RDEEPR
        Clear M66300 to Blank Display
        EEPRM ← EEPDT                    8600H- (FUNC, CAL BUFFER) → INIT DATA
        TMO = 13                        TM1'S CLOCK is 12/(384 * 13) MHz
        MVI TMM, 01100101B              TM1'S CK = TMO OUT, TMO'CK = 384.
        MVI MKL, 11111101B              ENABLE INT TIMER 0.
        OFF OUT PUT CONTROL I/O
        EI

SDIND4:  IF: Pressed k2 and K3, OR Pressed k2 and k4?
        then
        CALL OPRT1                      to ON ALL SEGMENT
        else
        CALL OPRT2                      to OFF ALL SEGMENT


SDIND2:  CALL M66300
        Clear DAREG0                    D/A OUTPUT ZERO
        OFF OUTPUT CONTROL I/O

SDIND3:  MVIW FLGS16, 00001111B
        SET CONTROL I/O OUTPUT


        ***** SEND DISP & D/A DATA *****


        (RET)


```





***** READ KEYSW *****


















— CALL SUBP0
 — CALL ZRTRCK
 — CALL GRNTIN
 — CALL DIV3
 — CALL DIVSON
 — CALL GRSNET
 — CALL COMP
 — CALL HOLDB
 — CALL SIEVRY
 — CALL RDANIN
 — CALL RDEXIN
 — CALL RDSWIN
 (GJMP ENDTMI)

MINS CAP OVER CHECK AND SUB PUSH ZERO.
 ZERO TRACKING.
 $(INTNET) \leftarrow (INTGRS) - (INTTAR)$
 $(PGRS) \leftarrow (INTGRS) / 3$
 $(GROSS) \leftarrow (PGRS) * (MINDIV)$
 $(NET) \leftarrow (GROSS) - (TARE)$
 A/D OVER, NEAR ZERO, +- OVER, FLOW
 Hold process (expect the comparator)
 SERIAL INTERFACE.
 READ AN7-0.
 READ EXIN RISE UP.
 READ DIGISW (,KSW ...NEXT TIME !)

to RETI



END 2ND INTERRUPT ROUTINE

```


— ORI MKL, 01001000B      DISABLE INT1 AND INTE1
— EI
— DMOV EA, ECNT
— MOV A, PA                A ← EXCNT
— ANI A, 00000111B


— UNLESS:OFF PC, 00100000B
  then
    ADI A, 00001000B


— ANI PC, 10111111B      STOP 2ND AND AUTO ZERO
— ANI PB, 01111111B      CLEAR EXT. COUNTER
— MVI A, 11001000B
— MOV ETMM, A            ECNT CLOCK      CI INPUT ( TO = "H" )
                        CLEAR ECNT      'TO' DOWN
— MVI EOM, 01000000B      LV1 RESET, INV DI
— MVI EOM, 01010000B      CO1 = "L"
— ORI MKL, 01001000B      MASK INTE1 & INT1.
— ANIW ADFLAG, 11111011B; CLEAR A/D OVER FLAG
— LXI H, AVTOP and CONNECT ECNT AND EXCNT

— UNLESS:A/D MINUS OVER ?
  then
    RESET A/D MINUS OVER CHECK FLAG

```









Troubleshooting Using Check Software

There are two kinds of check software which are incorporated in the standard ROM.

- (1) Turning on the slide switch S1 with power on causes the system to enter the Check mode. In this mode, key and external inputs are checked.
- (2) With the ON/OFF and " * " keys held down, turning on the power causes the system to enter the Test mode. When the ENTER key is pressed (within 2 seconds) after version and country displays, the system makes a check by items, following a display segment check. In this mode, it is possible to make individual checks on key input, control I/O input, current loop input, code input, connector J5/J6, A/D, EEPROM, OP-01, and OP-03/OP-04.

1. Check Mode (Refer to Section E in the instruction manual.)

In the Check mode, only inputs are checked with all outputs turned off. Therefore, the user can make checks during operation.

[Entering the Check Mode]

Turn on the power switch on the rear panel. When the display is off, press the ON/OFF key to turn it on.

Remove the blind cover on the lower right of the front panel and turn on the slide switch S1. This causes the system to enter the Check mode. Make sure that all the displays are turned on. Since in the Check mode inputs are checked by displaying the status, no check can be made unless the display is normal. When it is doubtful whether the display is normal, make a segment check in the Test mode beforehand.

<<RAM Check>>

When "CHEC rA" is displayed on the upper right, following all displays on, a RAM R/W check is started. Write 55H and AAH in 8000H - 87FFH and read. If it is OK, "GOOD" will be displayed on the lower right.

<<Code Input>>

When the ENTER key is pressed, "CHEC Cd" is displayed on the upper right and the BCD code input is displayed in decimal on the lower right.

<<Control I/O Input>>

When the ENTER key is pressed, "CHEC io" is displayed on the upper right and the status of control I/O input is displayed in "oooooo". The left digit of the display indicates whether an option is attached. It goes "1" when the OP-03 and OP-04 boards are connected and "0" otherwise.

The remaining 6 digits correspond to inputs 1 to 6. When an input is on, the digit goes "1".

Options are checked only at power on.

<<Key Switches>>

When the ENTER key is pressed, "Loooooo" is displayed on the upper right LEDs and "roooooo" on the lower right LEDs of the front panel. The upper digits correspond to the "ON/OFF" to "" keys and the lower to "CODE", "<", ">", "+", "-", and "ENTER" keys. Pressing a key causes the digit to go "1".

The right 6 keys ("CODE", "<", ">", "+", "-", "ENTER") are dynamically read by using display digit select signals.

There is something wrong with a data line in cases where pressing any keys shows no reactions or where pressing only one key causes all 6 digits to go "1".

If the system enters the Check mode even with the slide switch S1 off, a contact failure may occur in the cable connected between J2 of the main board and J3 of the display board. The slide switch is turned on when open.

<<A/D>>

When the S1 is pressed, "CHEC Ad" is displayed on the upper right and the internal count of the A/D converter is simply averaged and displayed on the lower right, and then returned to the normal condition. If unnecessary, pressing the "CODE" key returns the count to the normal condition.

2. Test Mode

The Test mode is not open to the user (not described in the instruction manual) and is used mainly for output check.

[Entering the Test Mode]

With the slide switches S1 through S4 off, turning on the power with the ON/OFF and "" keys held down causes the system to enter the Test mode. When the ENTER key is pressed (within 2 seconds) after version and country displays, the system makes a check by items, following low battery and display segment checks. If all the displays are turned on without entering the Test mode, it is conceivable that a failure occurs in the keys or switches or the keys has not been pressed properly.

<<Lower Battery Check>>

Check if proper data (AAH) has been written in the specified addresses (85FFH and 8780H). If illegal data has been written, "Lo bAtt" appears on the upper right. This message indicates that the lithium batteries or

RAM itself may be defective. If no error is detected, the system will go to the next check without display. The message "Lo bAtt" is sometimes not displayed, even if the power is turned on again after the message appeared because of battery failure. This is because the electric charge remains in the capacitor on the board to back up the RAM. Leave the power turned off for about one hour. However, when the ROM has been replaced with another version, the message "Lo bAtt" may appear even if no failure is detected in hardware.

Following the lower battery check, the check by items is started. The message "tEst" appears on the left in cases other than No. 01 and 02. Pressing the ENTER key starts checking. In cases other than the next No., as soon as the CODE key is pressed, followed by either one key of "ON/OFF" (K1) to "-" (K10), the corresponding check will be made. (No check can be made for No. 02.) When the ENTER key (K12) is pressed, the message "END" is displayed, returning to the state immediately after power on.

No. 01 <<Segment Check>>

After all the display tubes and LEDs displayed "0" to "9" and ".", ",", is displayed on the left LED, while the right is blanked. "" is displayed on the left LED, "01 CHEC SEG" is displayed on the upper right LEDs, while the lower right is blanked, and the upper unit LED is also turned on. "▼" is displayed on the left LED, "01 CHEC SEG" is displayed on the upper right LEDs, while the lower right is blanked, and the lower unit LED is also turned on.

If the unnecessary segments are turned on or some segments are not turned on, an open or short circuit may have occurred. Check the segments from the display tubes or LEDs to the display drivers. When the ENTER key is pressed, the next test is started.

No. 02

<<Keyswitch, Control I/O Output, Standard Current Loop Output>>

<<Key Switches>>

"Soooo" is displayed on the left LEDs, "Loooooo" on the upper right LEDs, and "roooooo" on the lower right LEDs.

When the slide switches are pressed, the left LEDs go "1". They correspond to S1 to S4. The upper right LEDs correspond to "ON/OFF" to "" keys and the lower right to "CODE", "<", ">", "+", "-", and "ENTER" keys. Pressing the keys cause the LEDs to go "1". When the ENTER key is pressed, the next test is started.

The right 6 keys ("CODE", "<", ">", "+", "-", "ENTER") are dynamically read by using display digit select signals.

There is something wrong with a data line in cases where pressing any keys shows no reactions or where pressing only one key causes all 6 digits to go "1". The slide switch is turned on when open.

<<Control I/O Output>>

When the "ON/OFF" key (K1) to ">" key (K9) are pressed with the "-" key (K11) held down, the corresponding outputs 9 to 1 are output.

<<Standard Current Loop Output>>

When the "+" key (K10) is pressed with the "-" key (K11) held down, 1234567890ABCDEF<CR><LF> and <CR><LF> are output at intervals of 1.5 seconds. The baud rate is 2,400 baud.

No. 03 <<Control I/O Input>>

"03 CHEC io" is displayed on the upper right. Turn on control I/O outputs 9 to 1 one by one. At the same time, the input status "000000" is displayed on the lower right. The left digit of the display indicates whether an option is attached. It goes "1" when the OP-03 and OP-04 boards are connected and "0" otherwise. The remaining 6 digits correspond to inputs 1 to 6. When an input is on, the digit goes "1". Options are checked only at power on.

When the ENTER key is pressed, the next test is started.

No. 04 <<Code Input>>

"04 CHEC Cd" is displayed on the upper right and the BCD code input is displayed in decimal on the lower right.

When the ENTER key is pressed, the next test is started.

No. 05 <<Connector J5>>

"05 CHEC J5" is displayed on the upper right.

Connector J5 is used for OP-01, OP-03, and OP-04 boards. If there is no optional board, only the connector is checked. In this case, a special jig is needed.

"0000" is displayed on the lower right. It corresponds to SW1 to SW4. When the jig switch is pressed, "1" is displayed.

When the ENTER key is pressed, the next test is started.

If "1" is not displayed, a pattern disconnection may occur and if multiple numbers are displayed, solder bridging may occur.

PIN No.	1	2	3	4	5	6
Signal name	SW4 input	SW3 input	SW2 input	SW2 output	SW1 input	SW1 output

PIN No.	1	2	3	4	5	6
Signal name	+5V	GND	+5VE	GNDE	SW3 output	SW4 output

No. 06 <<Connector J6>>

"06 CHEC J6" is displayed on the upper right.

Connector J6 is used for the OP-07 board. If there is no board, only the connector is checked. In this case, a special jig is needed.

"0" to "9" are displayed in order on the lower right. If the jig display is the same, it is O.K. "6" is displayed as "b".

When the ENTER key is pressed, the next test is started.

No. 07 <<A/D>>

"07 CHEC AdC" is displayed on the upper right.

The internal count of the A/D converter is simply averaged and displayed on the lower right. Since deep averaging is being applied, a display response to an input change is delayed.

When the ENTER key is pressed, the next test is started.

No. 08 <<EEPROM>>

"08 CHEC EEP" is displayed on the upper right.

Data is written into and read from the all areas of the EEPROM, and checked and displayed on the lower right.

(00H, 55H, AAH, FFH) displayed are data. It is O.K if "Good" is displayed.

When the ENTER key is pressed, the next test is started.

"no Good" is displayed if NG. Since the CPU is online to the EEPROM, the pattern or board contributes to this failure. The EEPROM contains the calibration and function data. Therefore, when it is replaced, resetting is needed.

* Never turn off power while checking the EEPROM, otherwise its contents will be destroyed.

No. 09 <<OP-01>>

"09 CHEC OP1" is displayed on the upper right and "0" on the lower right. Outputs are turned on (with output transistors off) one by one. When Hold is input, "1" is displayed on the lower right and the outputs are held, displaying "Hold". A special jig is needed.

When the ON/OFF key is pressed, the jig "/PC" LED is turned off in an instant. When the 0 key is pressed, the jig "/PC" LED is turned on in an instant. When the TARE key is pressed, both LEDs are turned off.

This test is ineffective when the OP-01 is not connected and when the OP-03 and OP-04 are connected.

When the ENTER key is pressed, the next test is started.

No. 10 <<OP-03/OP-04>>

<<OP-03>>

"10 CHEC.OP3" is displayed on the upper right, followed by "2400 bPS".

It is necessary to short-circuit the output and input of either connector (connectors 1 and 5 or 4 and 9). Make sure that the output data and input data are the same. The data is @0?n<CR><LF>. It is O.K if "0" to "9" are displayed in order on the lower right.

<<OP-04>>

"10 CHEC OP4" is displayed on the upper right, followed by "2400 bPS".

It is necessary to short-circuit the output and input of the D-sub connector (connectors 2 and 3). Make sure that the output data and input data are the same. The data is n<CR><LF>. Output by changing n (= 0 - 9) every about 1.5 seconds. It is O.K if "0" to "9" are displayed in order on the lower right. For the current loop output, "0" to "9" can be printed in the dump mode with the printers (AD8117A, AD8118, etc.) connected. (Only 600/2,400bps)

<<Common to OP-03/OP-04>>

When changing the baud rate, press the corresponding key according to the following table. The specified baud rate is displayed on the upper right.

Key Name	ON/OFF	0	TARE	TARE CLEAR	CROSS/NET
bps	600	1,200	2,400	4,800	9,600

If "0" - "9" and "no Good" are alternately displayed on the lower right, an output or input IC failure or solder bridging may occur. If only "no Good" is displayed, a clock IC failure or solder bridging may occur. Note that "no Good" is sometimes displayed in an instant immediately after the baud rate was changed.

This test is ineffective when the OP-03 and OP-04 are connected or when the OP-01 is not connected.

When the ENTER key is pressed, "END" is displayed on the upper right, returning the state immediately after power on.

A D - 4 3 2 5 A

A D - 4 3 2 5 A

PARTS LIST

AD4325A MAIN BOARD -1/2

90.08.31

CIRCUIT SYMBOL or DRWG. NO.	PARTS NAME	DESCRIPTION	Q'TY
	7PZ:2323A	MAIN BOARD AD4325A	1
C4,11~26	CC:0.022U	CERAMIC CAPACITOR 0.022 μ F 80V	17
C6	CC:100P	CERAMIC CAPACITOR 100pF 50V	1
C5	CM:V1H474JZ	FILM CAPACITOR 0.47 μ F	1
C1,7	CT:1A4R7	TANTALUM CAPACITOR 4.7 μ F 10V	2
C2,3	CT:1D2R2	TANTALUM CAPACITOR 2.2 μ F 20V	2
PC5,8	DF:PS-2403-2	PHOTO COUPLER	2
PC1~4,6,7	DF:PS-2403-4	PHOTO COUPLER	6
D3	DI:A54H	DIODE ARRAY	1
DB1	DI:1B4B42	BRIDGE DIODE	1
D1,2	DI:1SS97	DIODE	2
BAT	EB:CR2032-WT12	LITHIUM BATTERY	1
J9	JA:4470-01-1111	CONNECTOR	1
J7	JI:364P024-AG	CONNECTOR	1
J8	JI:16PA-2.54DSA	CONNECTOR	1
(U7)	JS:10328-01-445	IC SOCKET	1
JP1	JS:14120-01	IC SOCKET	1
J1	JT:1-171825-0	CONNECTOR	1
J3,4	JT:1-171825-2	CONNECTOR	2
J2,5	JT:1-172429-2	CONNECTOR	2
J10,11	JT:171825-7	CONNECTOR	2
J6	JT:172429-8	CONNECTOR	1
	PC:2323	PC BOARD	1
Q2,3,4	QT:BA1A4P	TRANSISTOR	3
Q1,5	QT:C1815Y	TRANSISTOR	2
R5~9,11,16~21 23	RC:NAT1K	CARBON RESISTOR 1K Ω 1/4W	13
R25	RC:NAT1M	CARBON RESISTOR 1M Ω 1/4W	1
R1,4	RC:NAT10K	CARBON RESISTOR 10K Ω 1/4W	2
R3,12	RC:NAT22K	CARBON RESISTOR 22K Ω 1/4W	2
R14	RC:NAT27R	CARBON RESISTOR 27 Ω 1/4W	1
R22	RC:NAT3.9K	CARBON RESISTOR 3.9K Ω 1/4W	1
R24	RC:NAT330R	CARBON RESISTOR 330 Ω 1/4W	1
R2,15	RC:NAT4.7K	CARBON RESISTOR 4.7K Ω 1/4W	1
R13	RC:NAT470R	CARBON RESISTOR 470 Ω 1/4W	1
R10	RC:NAT680R	CARBON RESISTOR 680 Ω 1/4W	1
RA3,4	RN:IHR-4-102KA	RESISTOR NETWORK 1.0K Ω \times 4	2

PARTS LIST

AD4325A MAIN BOARD -2/2

90.08.31

CIRCUIT SYMBOL or DRWG. NO.	PARTS NAME	DESCRIPTION	Q'TY
	7PZ:2323A	MAIN BOARD AD4325A	1
RA1	RN:IHR-4-182KA	RESISTOR NETWORK $1.8K\Omega \times 4$	1
RA8	RN:IHR-4-223MA	RESISTOR NETWORK $22K\Omega \times 4$	1
RA2,6,7	RN:IHR-4-472MA	RESISTOR NETWORK $4.7K\Omega \times 4$	3
RA5,9	RN:IHR-8-223MA	RESISTOR NETWORK $22K\Omega \times 8$	2
RA10	RN:IHR-8-392JA	RESISTOR NETWORK $3.9K\Omega \times 8$	1
SW1	SS:SSS022	SWITCH	1
TP1,2,3	TM:CP-10	TEST PIN	3
U11	UA:MB3773PS-G	VOLTAGE COMPARATOR	1
	UA:TD62503BP	TRANSISTOR ARRAY	2
U12	UC:D78C10G-1B	CMOS CPU	1
U19	UC:HCU04	CMOS IC	1
U10,18	UC:HC00	CMOS IC	2
U2	UC:HC02	CMOS IC	1
U4	UC:HC08	CMOS IC	1
U5,22	UC:HC32	CMOS IC	1
U17	UC:HC4520	CMOS IC	1
U15	UC:HC540	CMOS IC	1
U14,16	UC:HC573	CMOS IC	2
U9	UC:RP93C46	EEPROM	1
U8	UC:5564AFL-15	CMOS SRAM	1
U1,6	UN:M66300FP	PISO DATA BUFFER IC	2
	UN:27C256	EPROM	1
U3	UT:LS06	TTL	1
U13	UT:159	TTL	1
X1	XT:C4SB-12M-K02	CRYSTAL 12MHz	1
	04:B42944A		2
	05:A40702	SPACER 16mm	1
	05:B43312	SPACER M2.6×8	2

AD4325A POWER BOARD -1

90.08.31

[illegible]

PARTS LIST
AD4325A DISPLAY BOARD -1

90.08.31

[illegible]


PARTS LIST

AD4325A TERMINAL BOARD -1

90.08.31


[illegible]

A B C D E F G H I J






Symbol	Date	By	Revision No.	Model
				AD4325A
Description	Stock No.	Drw. No.		
Main Board 1/2	PZ:2323A	318606		

A B C D E F G H I J




Symbol	Date	By	Revision No.	Model	Description	2/2
				AD1323A	Main Board	
					Stock No.	PZ : 2323A
					Draw No.	


TF 378




Symbol	Date	By	Revision No.	Model	AD4325A
				Description	Power Supply Board
				Stock No.	PZ : 2324/CK
				Draw No.	EC3-01325




Symbol	Date	By	Revision No.	Model	Description	Stock No.	Drwg.No.
				AD4325A	DISPLAY BOARD	PZ : 2330	EC3-01438



				Model	AD4325A
Symbol	Date	By	Revision No.	Description	TERMINAL BOARD
				Stock No.	PZ:2361
				Drwg. No.	




Model	AD4325A		
	Revision No.	MAIN BOARD	
		Stock No.	
		PZ:2323A	
Symbol	Date	By	
		Description	
		Stock No.	
		Drwg. No.	




					Model	AD4325A
					Description	POWER BOARD
					Stock No.	PZ-2324
					Drawg. No.	KZ3-00875

PC2330



Symbol	Date	By	Revision No.	Description	Model
				Display Board	AD4325A
				Stock No.	PZ:2330
				Draw No.	




Symbol	Date	By	Revision No.	Model	AD4325A
				Description	Terminal Board
				Stock No.	PZ: 2361
				Drwg. No.	

EXPLODED VIEW AD4325A

PAGE 1
9. 4.1990

DRWG.NO.	PARTS NAME	DESCRIPTION	QTY
1	02:A37030	COVER	2
2	04:B43493	SLIDE RAIL	2
3	01:A37028	REAR PANEL	1
4	05:B43490	SIDE FRAME	2
5	02:A48921	ANALOG BLANK PANEL	1
6	04:A49263	BCD OUT BLANK PANEL	1
7	01:B43496	PANEL	1
8	04:B43492	SUB FRAME	1
9	04:B43491		2
10	07:A10144-1	FRONT FRAME	1
11	01:A37032	KEY SHEET A (JPN)	1
(11)	01:A37689	KEY SHEET A (INT'L)	1
12	07:B43495A	FILTER B	1
13	07:B43494	FILTER A	1
14	07:B43488-1	BLANK COVER	1
15	05:B44283	M3 SEALING BOLT	2
16	07:A45440	SEALING SCREW WITH HOLE	2
A		M3 WASHER	
B		M3X8 W SEMUSE	
C		M4X6 W SEMUSE	
D		M3X6 W SEMUSE	
E		M4 NYLON WASHER	
F		M4X10 TRUSS SCREW	
G		M3 NUT	
H		M4X8 W SEMUSE SCREW	
I		2.5 E RING	

EXPLODED VIEW



A D - 4 3 2 5 V

7 P Z : 2 3 2 3 P A R T S L I S T

CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q'TY
C4, 11~26	CC:0.022U	CAPACITOR 0.01 μ F 500V	17
C6	CC:100P	CAPACITOR 100PF 50V	1
C5	CM:V1H474JZ	CAPACITOR 0.47 μ F	1
C1, 7	CT:1A4R7	CAPACITOR 4.7 μ F 10V	2
C2, 3	CT:1D2R2	CAPACITOR 2.2 μ F 20V	2
PC5, 8	DF:PS-2403-2	PHOTO COUPLER	2
PC1~4, 6, 7	DF:PS-2403-4	PHOTO COUPLER	6
DB1	DI:1B4B42	BRIDGE DIODE	1
D1, 2	DI:1SS97	DOIDE	2
D3	DI:A54H	DIODE ARRAY	1
BAT	EB:CR2032-WT12	LITHIUM BATTERY	1
J9	JA:4470-01-1111	DIN CONNECTOR	1
J8	J1:16PA-2.54DSA	CONNECTOR	1
J7	J1:364P024-AG	CONNECTOR	1
U7	JS:10328-01-445	IC SOCKET	1
JP1	JS:14120-01	IC SOCKET	1
J1	JT:1-171825-0	POST HEADER	1
J3, 4	JT:1-171825-2	POST HEADER	2
J2, 5	JT:1-172429-2	POST HEADER	2
J10, 11	JT:171825-7	POST HEADER	2
J6	JT:172429-8	POST HEADER	1
	PC:2323	PRITED CIRCUIT BOARD	1
Q2, 3, 4	QT:BA1A4P	TRANSISTOR	3
Q1, 5	QT:C1815Y	TRANSISTOR	2
R1, 4	RC:NAT10K	RESISTOR 10K Ω 1/4W	2
R5~9, 11, 23	RC:NAT1K	RESISTOR 1K Ω 1/4W	7
R25	RC:NAT1M	RESISTOR 1M Ω 1/4W	1
R3, 12	RC:NAT22K	RESISTOR 22K Ω 1/4W	2
R14	RC:NAT27R	RESISTOR 27 Ω 1/4W	2
R22, 16~21	RC:NAT3.9K	RESISTOR 3.9K Ω 1/4W	7
R24	RC:NAT330R	RESISTOR 330 Ω 1/4W	1
R2, 15	RC:NAT4.7K	RESISTOR 4.7K Ω 1/4W	2
R13	RC:NAT470R	RESISTOR 470 Ω 1/4W	1
R10	RC:NAT680R	RESISTOR 680 Ω 1/4W	1
RA3, 4	RN:1HR-4-102MA	RESISTOR NETWORK 1K \times 4, 1/8W	2
RA1	RN:1HR-4-182KA	RESISTOR NETWORK	1
RA8	RN:1HR-4-223MA	RESISTOR NETWORK 22K \times 4, 1/8W	1
RA2, 6, 7	RN:1HR-4-472MA	RESISTOR NETWORK 4.7 \times 4, 1/8W	3
RA5, 9	RN:1HR-8-223MA	RESISTOR NETWORK 22K Ω \times 8	2
RA10	RN:1HR-8-392JA	RESISTOR NETWORK 3.9K Ω \times 8	1
SW1	SS:SSS022	SLIDE SWITCH	1
TP1, 2, 3	TM:CP-10	TEST PIN	3
U11	UA:MB3773PS-G	VOLTAGE COMPARATOR	1
U20, 21	UA:TD62503BP	TRANSISTOR ARRAY	2
U8	UC:5564AFL-15	RAM	1
U12	UC:D78C10G-1B	CPU	1
U10, 18	UC:HC00	CMOS IC	2
U2	UC:HC02	CMOS IC	1
U4	UC:HC08	CMOS IC	1
U5, 22	UC:HC32	CMOS IC	2
U17	UC:HC4520	CMOS IC	1
U15	UC:HC540	CMOS IC	1
U14, 16	UC:HC573	CMOS IC	2
U19	UC:HCU04	CMOS IC	1
U9	UC:RP93C46	EEPROM	1
U1, 6	UN:M66300FP	DATA BUFFER IC	2

7 P Z : 2 3 2 3 P A R T S L I S T

CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q' TY
U13	UT:159	TTL	1
U3	UT:LS06	TTL	1
X1	XT:C4SB-12M-K02	RESONATOR 12MHz	1

7 P Z : 2 3 2 4 P A R T S L I S T



CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q' TY
	04:B42955	HEAT SINK	1
C1, 2	CC:0.01U500V	CAPACITOR 0.01 μ F 500V	2
C11~16	CC:0.1U25V	CAPACITOR 0.1 μ F 25V	6
C6	CK:9117	CAPACITOR 4700 μ F 35V	1
C17	CK:SM50VB10	CAPACITOR 10 μ F 50V	1
C5, 7, 9	CK:SME25VB22	CAPACITOR 22 μ F 25V	3
C8	CK:SME25VB2200	CAPACITOR 2200 μ F 25V	1
C4	CK:SMG25VB4700	CAPACITOR 4700 μ F 25V	1
C10	CK:SXE35VB1000	CAPACITOR 1000 μ F 25V	1
C3	CM:E6104KZ	FILM CAPACITOR	1
D4, 5	DI:1B4B42	DIODE BRIDGE	2
D1, 2, 3	DI:W02	DIODE BRIDGE	3
DZ1	DZ:05Z5.6	ZENER DIODE	1
	FH:85PN0819	FUSE HOLDER	2
J2	JT:1-171825-2	CONNECTOR	1
J3	JT:171825-3	CONNECTOR	1
J1	JT:172369-3	CONNECTOR	1
	JT:61134-1	CONNECTOR	2
	KO:280A-08BR	CONNECTOR CABLE	2
L1, 2	LL:SF-T8-40S	COIL	2
	PC:2324A	PRINTED CIRCUIT BOARD	1
R1	RC:NAT22K	RESISTOR 22K Ω 1/4W	1
R2, 3	RC:NAT82R	RESISTOR 82 Ω 1/4W	2
	TF:378	TRANSFORMER	1
U2	UR:7805HF	REGURATOR	2
U1, 3	UR:78M12HF	REGURATOR	1

7 P Z : 2 4 8 8 P A R T S L I S T



CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q' TY
C3~8	CC:FK16Y5V1H104	CAPACITOR 0.1 μ F	6
C2	CK:SXE25VB10	CAPACITOR 10 μ F/25V	1
C1	CT:1A4R7	CAPACITOR 4.7 μ F/10V	1
D1~12	DI:1S1588	DIODE	12
D13	DI:1SS97	DIODE	1
LED3~20	DL:TLS347T-AAD	LED	18
D1, 2	DL:TLUG144	LED	2
	ED:FIP7E13	DISPLAY TUBE	1
J1	JT:1-171825-0	POST HEADER	1
J3	JT:1-172429-2	POST HEADER	1
J2	JT:171825-3	POST HEADER	1
	PC:2488A	PRINTED CIRCUIT BOARD	1
Q1, 2, 3	QT:BA1L4Z	TRANSISTOR	3
R2	RC:NAT1.2K	RESISTOR 1.2K Ω 1/4W	1
R5, 6	RC:NAT22K	RESISTOR 22K Ω 1/4W	2
R1	RC:NAT4.7K	RESISTOR 4.7K Ω 1/4W	1
R3, 4	RC:NAT470R	RESISTOR 470 Ω 1/4W	2
K1~12	SK:TM1-01/0010	SWITCH	12
S1~4	SS:2NB2X2AG	KEY SWITCH	4
T1~3	TM:LC-2-G-0	TEST PIN	3
U3	UA:TD62783AP	TRANSISTOR ARRAY	1
U4	UC:HC595	CMOS IC	1
U1	UC:MSC1164GS	FLUORESCENCE DISPLAY DRIVER	1
U2, 5	UC:TD62C850N	LATCH DRIVER	2

7 P Z : 2 3 6 1 P A R T S L I S T


CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q' TY
	01:B43496	PANNEL	1
	05:B43835	TERMINAL SPACER	2
	J1:CL616-0023-0	CONNECTOR	1
	PC:2361	PRINTED CIRCUIT BOARD	1
	TM:40S1CXS17P11	TERMINAL BASE	1




Symbol	Date	By	Revision No.	Description	Model
			318606	Stock No.	AC4325A/V
				Drwg. No.	
				Main Board	2/2
				PZ : 2323A	



Symbol	Date	By	Revision No.	Model	AD4325A/V
				Description	Power Supply Board
				Stock No.	PZ : 2324
				Drwg. No.	EC3 - 01325




Symbol	Date	By	Revision No.	Model	Description	Stock No.	Drwg. No.
				AD4325V	DISPLAY BOARD	PZ:2488	



				Model	AD4325A/V
Symbol	Date	By	Revision No.	Description	TERMINAL BOARD
				Stock No.	PZ:2361
				Drawn No.	

EXPLODED VIEW

DRWG. NO.	PARTS NAME	DESCRIPTION	Q' TY
1	01:A38510A	KEY SHEET (ENGLISH)	1
(1)	01:A39292	KEY SHEET (MARCURY)	1
(1)	01:A38502	KEY SHEET (JAPANESE)	1
2	07:A45440	CAL LOCK SCREW	1
3	07:B47081-1A	BLANK PANEL	1
4	07:B42936	FILTER	1
5	07:B47082	FILTER B	1
6	07:A10171-1	FRONT FRAME	1
7	04:B47626	FRONT SETTER	1
8	04:B47080	SUB FRAME	2
9	05:B43490	SIDE FRAME	2
10	02:A38500	SIDE COVER	2
11	05:B44285	HEXAGON SCREW	2
12	04:A49263	BCD BLANK PANEL	1
13	02:A48921	ANALOG BLANK PANEL	1
14	04:A38498	REAR PANAL	1
15	04:B43493A	SLIDE RAIL	2
16	PZ:2488	DISPLAY BOARD	1
17	PZ:2323	MAIN BOARD	1
18	PZ:2077	ANALOG BOARD	1
19	PZ:2324	POWER SOURCE BOARD	1
20	PZ:2361	TERMINAL BOARD	1
21	J1:360A1	CONNECTER	1
22		M2.6 NUT	2
23	ST:T-881SBSS	POWER SWITCH	1
24	TM:40S1AX3P	TERMINAL BASE	1
25	05:43835	TERMINAL SPACE SCREW	2
26	FH:FH-B02	FUSE FOLDER	1
a		M3×6 PAN HEAD SCREW	4
b		M3×8 PAN HEAD SCREW	8
c		M4×8 PAN HEAD SCREW	8
d		M2.6×10 PAN HEAD SCREW	2
e		M4×10 TRUSS HEAD SCREW	1
f		M3×6 PAN HEAD SCREW	1
g		M2.6 E TYPE STOPPER	1
h		M3 WASHER	2
i		M3 CLAW WASHER	2
j		M2.6 WASHER	2
k		M3 NUT	8
l		M4 CLAW WASHER	4
m		M4 NYLON WASHER	1



MEMORANDA

[illegible]

We hope that you have found this Instruction Manual useful and informative. If you have any suggestions for product improvement, found an error in this manual, or if you would like more information concerning this product, please don't hesitate to contact your nearest A&D office, or:

A&D Company, Limited
Daihatsu-Nissay Ikebukuro Bldg. 5F,3-23-14 Higashi-Ikebukuro,Toshima-ku,
Tokyo 170 Japan
TEL: (03) 5391-6123 FAX: (03) 5391-6129 Telex: 02422816AANDDJ

A&D Engineering, INC.
1555 McCandless Drive / Milpitas, CA 95035 U.S.A.
TEL: (408) 263-5333 FAX: (408) 263-0119

A&D Instruments GmbH
 Lyoner Straße 36, D-6000 Frankfurt/Main 71, F.R. Germany
 TEL: (069) 666-7006 FAX: (069) 666-6831

A&D Mercury PTY. LTD.
32 Dew Street, Thebarton, South Australia 5031 Australia
TEL: (08) 352-3033 FAX: (08) 352-7409

A&D KOREA LIMITED
3rd Floor Hanam Bldg 44-27 Yoido-dong Yungdeungpo-ku Seoul, Korea
TEL: (02) 784-4264 FAX: (02) 784-6557