

A&D Model 4329

Check Mode / “AD1” Display Internal Count

Entering the check mode

1. With the display in the off state, hold down the <MODE> key, press the <OPR/STB> key. “F-00” appears.
2. Press <MODE> key, “R102” appears.
3. Press <PRESET TARE> & <M+> keys, “CHECK” appears.
4. Press <MODE> key, 3 times, “AD1” appears.
5. Press <PRINT> key, internal counts now displayed.
6. Press the <OPR/STB> key, to exit Check Mode.