

SKWP Initialization Procedure

1. Press and hold the **Zero** key, press the **centre** hidden key, Cal key and the **On** key.
2. Keep the **Zero** key pressed, release the **On** key and the **Centre** key then immediately press the **Centre** key twice. Release the **Zero** key.
3. The display will show the software version number i.e. *P-3.0*.
4. Press the Centre key, the display will show *CAL*.
5. Press the Centre key, the display will show *Adj*.
6. Press the Centre key, the display will show *in it*.
7. Hold zero key and press hidden key twice. *P-3.0* appears.
8. Turn scale off and then on *P-3.0* appears then
9. *0030* or similar appears depending on the model as shown below.
10. Press the **Zero** key, the decimal point appears.
11. Increase the value of the digit to the right of the decimal point with the **Zero** key.
12. Move the decimal point to the left using hidden key, e.g. *00.30*
13. Use combination of the **Centre** and **Zero** keys to set the capacity.

e.g.

SETTING	MODEL/CAPACITY
<i>0000</i>	SK 1000g
<i>0010</i>	SK 2000g
<i>0020</i>	SK 5000g
<i>0021</i>	SK 5001g
<i>0030</i>	SK 10K
<i>0040</i>	SK 20K
<i>0050</i>	SK 30K

14. Press and hold the **Centre** key and press **Zero** key simultaneously.
15. *20* appears, press the **Centre** key *-t-* appears, then press the **Centre** key again.
16. *CAL t* appears. Press **Zero** key.
17. *CAL 0* appears. Press **Zero** key.
18. *CAL F* appears. Place capacity mass on scale and press **Zero** key,
e.g. SK 2000=2 kg.
19. *CAL End*: Turn scale off then on, scale will be weighing normally.