

AD4406 Single Range
Calibration Procedure

	<u>QUICK CALIBRATION</u>	
<u>KEY OPERATION</u>	<u>DESCRIPTION</u>	<u>DISPLAY</u>
<CAL>		CAL 0
	With zero load	
<F2 ENTER>		CAL F then xxxxx Full load
	Place test masses on scale	
	Set indicator to = test masses applied	Eg 179
<F2 ENTER>		CAL END
<CAL>		END
<On/OFF>	Exit CAL mode	
<On/OFF>	Returns to normal weighing	