



FC COUNTING SCALE
SETTING SCALE CAPACITY

1. With the scale in standby mode, and the Calibration switch on.
2. Press ENTER, ZERO & STANDBY at the same time.
The top display will show a 2 digit number.
3. Enter the code as per the table below.

CODE	CAPACITY
10	500g
20	1kg
30	2kg
40	5kg
50	10kg
60	20kg
70	31kg
80	50kg

4. Press the ENTER key to store the capacity then conduct a calibration sequence as normal.