

EK/EW-G SERIES

COMPACT BALANCES

MAINTENANCE MANUAL

MODELS:	EK-120G	EW-60G
	EK-200G	EW-300G
	EK-600G	EW-600G
	EK-1200G	EW-3000G
	EK-2000G	
	EK-6000G	
	EK-12KG	



Contents

I. GENERAL DESCRIPTION	2
II. DESCRIPTION OF SOFTWARE	4
1. Outline of Operations	4
2. Start-up Sequence after Turning on the Power	5
3. Normal Operation	8
4. Calibration	12
III. DESCRIPTION OF CIRCUITS	14
1. Block Diagram	14
2. Power Circuit	15
3. A/D Circuit	17
4. External Memory	18
5. Serial Data Output	19
6. Display Circuit	20
7. Battery Option Charging Circuit	21
8. Load Cell	22
IV. CHECK MODE	23
1. Entering the Check Mode	23
2. Software Version Display	23
3. LCD & Input/Output Check	23
4. Display Pattern Check	23
5. A/D Count Display	24
6. Internal Count Display	24
V. MAIN BOARD INITIALIZATION	25
1. Initial Values	25
2. Initialization Method	25
3. Optional Connecting Cable Shorting Jig	25
VI. ADJUSTMENT OF THE PRODUCT	26
1. Internal Setting	26
2. Calibration	28
3. Four-corner Error	29
VII. TROUBLESHOOTING	30
1. Flow Chart	30
2. Check Items	32
VIII. ASSEMBLY PROCEDURES / Docking of Cell	33
APPENDIX A: ELECTRONIC PART	A1
A-1. PARTS LIST	A2
A-2. CIRCUIT DIAGRAMS	A8
A-3. PARTS LAYOUT	A13
APPENDIX B. MECHANICAL PART	B1
B-1. EXPLODED VIEW & PARTS LIST	B2

I. GENERAL DESCRIPTION

1. This document applies to the following models:

1. EK120G
2. EK200G
3. EK600G
4. EK1200G
5. EK2000G
6. EK6000G
7. EK12KG
8. EW60G
9. EW300G
10. EW600G
11. EW3000G

2. The EK-G and EW-G series are electronic balances using load cells as weight sensors.

3. The EK-G series and EW-G series have been differentiated by resolution. The EW-G series has a resolution of 1/3,000 and the EK-G series has a greater resolution.

The following lists the models and their displays and pan shape:

- | | | | |
|-------------|---|-----------------|---------------------|
| 1. EK120G | : | 120 g x 0.01 g | Round weighing pan |
| 2. EK200G | : | 200 g x 0.01 g | Round weighing pan |
| 3. EK600G | : | 600 g x 0.1 g | Square weighing pan |
| 4. EK1200G | : | 1,200 g x 0.1 g | Square weighing pan |
| 5. EK2000G | : | 2,000 g x 0.1 g | Square weighing pan |
| 6. EK6000G | : | 6,000 g x 1 g | Square weighing pan |
| 7. EK12KG | : | 12,000 g x 1 g | Square weighing pan |
| 8. EW60G | : | 60 g x 0.02 g | Round weighing pan |
| 9. EW300G | : | 300 g x 0.1 g | Square weighing pan |
| 10. EW600G | : | 600 g x 0.2 g | Square weighing pan |
| 11. EW3000G | : | 3,000 g x 1 g | Square weighing pan |

4. The EK-G and EW-G have the same specifications except resolution.
5. There are 13 weighing units available so that a relevant one can be selected .

1. Gram(g)
2. No. of pieces(pcs.)
3. Percent(%)
4. Ounce(oz) = 28.34952313 g
5. Pound(lb) = 453.59237 g
6. Troy ounce(ozt) = 31.1034768 g : Gold
7. Carat(ct) = 0.2 g : Jewels
8. Momme = 3.75 g : Pearl
9. Pennyweight(dwt) = 1.55517384 g : Precious metals
10. Grain(GN) = 0.06479891g : Powder
11. Singapore and Hong Kong (general) tael(tl-S) = 37.7994 g
12. Hong Kong(jewels) tael(tl-H) = 37.429 g
13. Taiwan tael(tl-T) = 37.5 g

* For tael, select either one of them.

6. The following are available as options:

1. OP-03 : RS-232C interface
2. OP-04 : Comparator output
3. OP-05 : Current loop interface
4. OP-07 : Underhook weighing fitting (EK6000G and EK12KG only)
5. OP-09 : Rechargeable battery pack (NiCd)
6. OP-11 : Carrying case

7. Differences between the EK/EW-A and the EK/EW-G

1. The display has been made larger; the character height has been enlarged from 11.5 mm to 15.8 mm.
2. A print switch has been added.
3. The key switch response has been improved.
4. Sampling speed has been increased from 3 times/second to 5 times/second.
5. Single weight registration has been enabled even if it is negative. Pcs., %
6. An automatic power-off function has been added.
7. The RS-232C has been made bidirectional.Q, U, Z
8. An automatic printing function has been added.
9. A comparator function (HI, OK, LO) has been added.
10. The options can be now installed more easily. OP-03, -04, -05, -09

II. DESCRIPTION OF SOFTWARE

1. Outline of Operations


A weight is detected with a sensor called a load cell. An output signal from the load cell(voltage change) is converted from an analog voltage to digital data by a hybrid module(AMZ21). The A/D-converted data (double integration) is processed by a microcomputer (CPU). Control signals for the operation of the A/D converter are sent by the CPU.


The CPU used in the EK-G/EW-G is a 4-bit microcomputer. This IC alone controls the A/D conversion, reads the key switches, controls the LCD, transmits and receives the serial data.

The software resides in a mask ROM and has been incorporated during manufacture of the microcomputer. Therefore, it cannot be modified. Two power systems are internally used; 10V for the analog system and 5V for the logic system.

2. Start-up sequence after Turning on the Power

2-1 Flow Chart





2-2 Description of the Start-up Sequence


- (1) The CPU is initially set while the [ON/OFF] switch is pressed.
- (2) Pin No. 11 (of the CPU) is set to the Low level so that you can release the [ON/OFF] switch.
- (3) The data is read from the EEPROM(U5).
- (4) An LCD check pattern is displayed depending on the specifications.
- (5) Performing A/D conversion, the instrument waits for the data to stabilize, that is, both A/D raw data and display data should stabilize.
- (6) When the data has stabilized, the power-on zero point is established and the weight display procedure starts. The power-on zero point can be established within $\pm 10\%$ of the weighing capacity from the zero point value established during calibration. A dash display (- - - -) appears when this range is exceeded.
- (7) When the [MODE] switch is pressed here, the weight display procedure starts without waiting for stabilization or assuming the power-on zero point.




This is used to display a weight value when the weight display procedure does not readily start or the dash display appears. It is also used to determine how much the zero point has deviated.

3. Normal Operation

3-1 Flow Chart





3-2 Description of Normal Operations


- (1) Analog to digital conversion (A/D).
 - 1) A voltage input from the load cell is converted to digital data.
- (2) Reading the key switch
 - 1) The key switch input is directly read at a CPU port.
 - 2) The key switch read timing is about 6 times for each sampling at adequate intervals.
 - 3) Whether the key switch is pressed or not is determined when 2 read time states are the same.
- (3) Averaging the A/D raw data
 - 1) Once within the average width, moving average is implemented up to 16 times (about 3.2 seconds¹⁾). When beyond the average width, the moving average is re-implemented, starting with the first average width.
- (4) Low battery level detection.
 - 1) Pin No. 24 of the CPU is monitored for a Low level.
- (5) Establishing the internal count
 - 1) The following calculations are made to establish an internal count.
$$(\text{Internal count}) = [(\text{Averaged A/D raw data}) - (\text{Calibration zero point})] \times (\text{Calibration span})$$
 - 2) Thus the computed internal count is a value 5 times greater than a displayed one.
 - 3) With this 5-fold value, the following processing is done.
- (6) Determining stabilization of the display
 - 1) The display should be within ± 0.5 graduation during 5 samples (about 1 second).
- (7) Selecting the unit
 - 1) When the [MODE] switch is pressed, the displayed weighing unit is changed.
- (8) Zeroing and subtracting the tare
 - 1) Pressing the [ZERO] switch when the display is stable, clears the display to zero by zeroing or subtracting the tare. If the display is not stable, pressing the [ZERO] switch is ignored.
 - 2) Zeroing is done when within $\pm 2\%$ of the weighting capacity from the power-on zero established value, and the tare is subtracted when beyond this range. Which has been selected is shown by the "◀" mark displayed on the left side in the LCD.
- (9) Zero track
 - 1) This function pursues slow deviation of the zero point so that weighing can always start at zero accurately.
 - 2) To actuate the zero track function, the display should be within ± 0.5 graduation during 5 samplings.
 - 3) The zero track effective range is the same as the zero point range (weighing capacity $\pm 2\%$).

- (10) Checking over-range.
 - 1) "E" is displayed when a weight value exceeds the weighing capacity + 9th graduation.
 - 2) "-E" is displayed when the weight value is negative more than 2 % of the weighing capacity.
- (11) Changing the weighing unit.
 - 1) The weighing unit is changed to the one determined in (7) Selecting the unit.
 - 2) The units include ounce(oz), pound(lb), troy ounce(ozt), carat(ct), momme, pennyweight(dwt), grain(GN), Singapore and Hong Kong (general) tael(tl), Hong Kong(jewels) tael(tl), Taiwan tael(tl), don, and Chinese tael(tl).
- (12) Creating the display data
 - 1) A unit changed value is given a determined software jump number and decimal place to display a weight.
- (13) Comparator output
 - 1) When comparator output has been selected by the function, the display data and upper-/lower-limit value are compared and the results are displayed.
 - 2) When an optional interface(EKW-04G) is attached, it is possible to output the comparison result and sound a buzzer.
- (14) Data conversion
 - 1) The data has been treated as binary(BIN) numbers so far. Now, they are converted into decimal(DEC) numbers.
- (15) Serial data input check
 - 1) When the RS-232C is set to the command mode, the CPU checks whether a command has been input. When it has been input, it is implemented.
 - 2) When the [PRINT/ENTER] switch is pressed, the CPU will output the serial data.
- (16) Display
 - 1) The data to be displayed on the LCD is assembled by the CPU. To display 10 g, for example, "1" is illuminated in the 2nd digit of the LCD, "0" in the 1st digit, followed by "g" as a unit.
- (17) Serial data output
 - 1) The RS-232C data is output at all times when the stream mode is selected. If the command mode is selected, the data is only output if a command is received to output the data, or the print button is pressed.
- (18) Auto power-off
 - 1) When the auto power-off function has been selected, auto power-off will operate.
 - 2) When "0" is continuously displayed for approximately 5 minutes¹, the power goes off automatically.
 - 3) When the low battery level is indicated, auto power-off operates.

*1: Differs slightly depending on the magnitude of load cell output.

4. Calibration

4-1 Flow Chart




4-2 Description of the Calibration Sequence


- (1) When the [CAL] switch is pressed while in the weighing mode, the calibration mode is selected. During a display check at power-on time, the calibration mode is not entered even if the [CAL] switch is pressed.
- (2) Once in the calibration mode, no serial or comparator data is output.
- (3) First, gravity acceleration is displayed. Enter the gravity acceleration for the area where the calibration will be performed (where you are now). Based on the value entered here, the zero point and span are compensated. If you enter the correct value, for the area of use, you do not have to recalibrate the zero point or span when using the instrument in a different district, simply adjust setting of the gravity acceleration. When an incorrect value is entered, you have to readjust the zero point or span.
- (4) Since the gravity acceleration, zero point, and span are stored when the [PRINT/ENTER] switch is pressed, they are not lost even if you turn off the power after the display is changed.
- (5) Although a weight value can be altered during span adjustment, it should equal to the weighing capacity or a minimum of two thirds of the weighing capacity. If lower than two thirds of the weighing capacity is used, the error becomes larger near the maximum weighing capacity. If greater than the weighing capacity, a load cell stopper may come into contact, causing an incorrect value to be stored as the span value. It could also cause damage to the load cell.
- (6) The span is calculated as follows:
$$\text{Span} = \text{Internal counts} \div (\text{A/D raw data with the weight placed} - \text{Zero point raw data})$$

III. DESCRIPTION OF CIRCUITS

1. Block Diagram



2-2 CPU Power Timing Chart



2-3 Description of CPU Timing

- (1) Press the [ON/OFF] switch.
- (2) A bias current starts flowing to Q1, and U1 and U2 are actuated to supply current throughout the circuit.
- (3) The CPU(U3) starts conducting and sets pin No. 11(of the CPU) to the Low level.
- (4) Q3 starts conducting and continues to supply the bias current to Q1.
- (5) Since Q3 is conducting, the current flows even if the [ON/OFF] switch is released.
- (6) When turning off the power, the CPU detects that the [ON/OFF] switch is pressed again, and sets pin No. 11 of the CPU to the High level.
- (7) Although Q3 stops conducting, the power has not been turned off yet while the [ON/OFF] switch is being pressed, because Q1 is still conducting.
- (8) Releasing the [ON/OFF] switch stops Q1 conduction and turns off the power.
- (9) The RESET circuit uses a function built into U2. When the input voltage to U2 is lowered to about 4.7V, a reset signal is applied to the CPU.
- (10) When an input voltage is 10.7 V or less, Q2 stops conducting, the current does not flow through R3 and R4, and pin No. 24 of the CPU is set to the Low level.

3-1 Circuit Diagram

The diagram illustrates the electrical connection between a Load Cell and the CPU board. The Load Cell is connected to a 5-pin connector J6. The pins are labeled as follows: Pin 1 is +10V, Pin 2 is Hi, Pin 3 is +V, Pin 4 is Lo, and Pin 5 is -V. The +10V supply is connected to a 10V regulator (U4, AMZ21). The Hi, +V, Lo, and -V signals are connected to the input of a 10V to 5V converter (U7). The output of the converter is connected to the CPU (U3) pins 43, 42, 41, and 38. The 4.91MHz XTAL oscillator is connected to the CPU pin 38.

Timing diagram showing the sequence of signals for the counter operation:


- PULSE CPU PIN 39:** A series of pulses with a width of $3.3\mu\text{sec}$.
- 1ST CPU PIN 43:** A pulse with a duration of 100msec , labeled **START** and **END**.
- 2nd CPU PIN 41:** A pulse labeled **START**.
- CMP CPU PIN 29:** A pulse labeled **2nd END**.
- AZ CPU PIN 42:** A pulse with a duration of 80msec , labeled **START** and **END**.
- COUNTER CPU PIN 38:** A pulse labeled **COUNT UP**.

3-3 Description of Analog to Digital Circuit Operation.

- (1) The 1st signal is input. The CPU's pin No. 43 is set to the Low level.
- (2) The time of the 1st signal is measured. Pulses are output from the CPU's pin No. 39 and input into pin No. 30. The number of pulses are counted and the CPU counter is set so that the time will be 100 msec.
- (3) When the CPU counter overcounts and is finished with the 1st signal, the 2nd signal is input. The CPU's No. 43 and 41 pins are set to the High level.
- (4) The gate(U6) is opened and a signal from a ceramic oscillator is input to the CPU's pin No. 38. The time of the 2nd signal ranges from 0 to 107 msec depending on the voltage input from the load cell.
- (5) When the 2nd signal is finished, pin No. 5 (2nd terminal) of the AMZ21 is set to the Low level, an external interrupt is input to the CPU, and the gate is closed to stop the signal input from the ceramic oscillator.
- (6) When an interrupt is input to the CPU, the 2nd signal is stopped and an AZ signal is input. Pins No. 41 and 42 are set to the Low level.
- (7) The time of AZ is measured. Set 80 msec in the same manner as in (2).

4. External Memory

4-1 Timing Chart (Read-out)




4-2 Description of External Memory Operation

- (1) An EEPROM is used as the external storage device. The storage capacity is 1 kilo bit.
- (2) The data stored includes the following:
 1. Gravity acceleration value
 2. Calibration zero point
 3. Calibration span
 4. User functions(F1 to F5)
 5. Factory settings(CF1 to CF5)
 6. Unit assumed at power-on time
 7. Unit used
 8. Upper- and lower-limit values of the comparator
 9. The number of sample pieces and sample weight registered
 10. 100% weight registered
- (3) If the EEPROM(U5) is replaced at repair time, it is necessary to redo all of the settings.
- (4) When the [PRINT/ENTER] switch is pressed during each setting, that value is entered. To confirm whether the data is correctly entered, read it out immediately after entering it to compare. When the compared data does not match, "Err 8" is displayed.
- (5) When you want to read out the data, turn on the power and do so before a display check is effected.

5. Serial Data Output

5-1 Timing Chart (Transmission)



5-2 Description of the Serial Data Output.

The serial data is transmitted when an A/D converted AZ signal is input.

6. Display Circuit

6-1 Description of the Display Circuit Operation

- (1) The display on the LCD is directly controlled by the CPU.
- (2) The LCD is a custom product of A & D.
- (3) The display specifications are 1/3 duty and 1/3 bias.
- (4) The following table shows the display segments.

Pin No.	1	2	3	4	5	6	7	8	9	10	11
COM3	COM3			○			-	(-
COM2		COM2		-	◀ T)	-	(ACAI)	-
COM1			COM1	◀ B	◀ M)	-	.	,)	-
digit				11		10			1	9	
CPU	7	6	5	4	3	2	1	80	53	79	78


Pin No.	12	13	14	15	16	17	18	19	20	21	22
COM3	(-	(-	(
COM2	(*)	-	(HI	(-	(OK	(
COM1	.	,)	-	.	,	(-	.	,	(
digit	9	1	8			1	7			2	6
CPU	77	54	76	75	74	55	73	72	71	56	70

Pin No.	23	24	25	26	27	28	29	30	31	32	33
COM3	-	(-	(oz	t	l	pcs
COM2	-	(LO	(-	(「	lb	%	dwt	GN
COM1	-	.	,	(-	.	」	k	g	ct	mom
digit	6		2	5			2	4		3	
CPU	69	68	57	67	66	65	58	63	62	60	59

Pin No.	34	35	36
COM3			COM3
COM2		COM2	
COM1	COM1		
digit			
CPU	5	6	7

7. Battery Option Charging Circuit

7-1 Circuit Diagram




7-2 Description of the Battery Charging Circuit Operation

- (1) When the main board has been turned on, most the current from AC adapter is taken by the main board.
- (2) When the main board is turned off, the current flows to the battery to charge it.
- (3) When the AC adapter is not attached, power is supplied from the battery to the main board via J1.

8. Load Cell

8-1 Circuit Diagram



8-2 Specifications(LC116 Series load cells)

- 1) Zero : 0 mV/V + 20 % (When the weighing pan is installed)
- 2) Span : 1 mV/V ± 10 %
- 3) Impedance : 350Ω
- 4) Pin connection :
 - 1 = No connection (NC)
 - 2 = Plus side of the load cell output (HI)
 - 3 = Plus side(10 V) of the applied voltage (+V)
 - 4 = Minus side of the load cell output (Lo)
 - 5 = Minus side(GND) of the applied voltage (-V)

8-3 Mounting of Load Cell

Model	Type of cell / Capacity	Tightening torque (kg)	Stopper adjustment (mm)
EK	120G	10	0.8
	200G		
	600G		1.0
	1200G	28	1.2
	2000G		
	6000G		1.3
EW	60G	10	0.8
	300G		
	600G		1.0
	3000G	28	1.3
	6000G		

IV. CHECK MODE

1. Entering the Check Mode

- (1) Holding down the [CAL] switch, press the [ON/OFF] switch to turn on the power.
- (2) "P-X.XX" is displayed to indicate that you have entered the check mode.

2. Software Version Display

- (1) What is displayed upon entering the check mode is a software version;
"P-2.00"etc.
- (2) When terminating, turn off the power. To make an LCD & input/output check, press the [MODE] switch.

3. LCD & Input/Output Check

- (1) After entering the check mode, press the [MODE] switch again. All the segments are turned on.
- (2) The display changes only when a switch is pressed (see below).



Display	Switch	Comparator Output
7	[SAMPLE]	HI
b	[PRINT/ENTER]	OK
d	[MODE]	LO
-	[ZERO]	Buzzer sounds
7	[CAL]	Stable
b	[ON/OFF]	
0	Parts SCK, S0 and Si are shorted	
1	Parts SCK, S0 are shorted	
2	Parts SCK, Si are shorted	
4	Parts S0 and Si are shorted	
1	The low battery detecting circuit is at the Low level.	

- (3) When terminating, turn off the power. To make a display pattern check, press the [MODE] switch.

4. Display Pattern Check

- (1) After entering the check mode, press the [MODE] switch twice.
- (2) All the display digits sequentially repeat the following display pattern at the same time at intervals of about 0.8 second."0 →1 →2 →3 →4 →5 →6 →7 →8 →9 →A →b →C →d →→,"
- (3) When terminating, turn off the power. To view the A/D count, press the [MODE] switch.

5. A/D Count Display

- (1) After entering the check mode, press the [MODE] switch three times.
- (2) A numerical value is displayed, where the 1st-digit number is enclosed by the parentheses. (Counts up to about 200,000 with 1 mV/V input)
- (3) When moving average is implemented 16 times, the stabilization mark "O" is displayed.
- (4) When the [ZERO] switch is pressed, the display is cleared to 0. However, it is reset when the internal count display is selected.
- (5) The RS-232C output is made.
- (6) When terminating, turn off the power. To view the internal count, press the [MODE] switch.

6. Internal Count Display

- (1) After entering the check mode, press the [MODE] switch four times.
- (2) A numerical value is displayed, where the 1st-digit number is not enclosed by the parentheses. (5 times larger than the display)
- (3) When moving average is implemented 16 times, the stabilization mark "O" is displayed.
- (4) When the [ZERO] switch is pressed, the display is cleared to 0. However, it is reset when the A/D count display is selected.
- (5) The RS-232C output is made.
- (6) When terminating, turn off the power.

Pressing the [MODE] switch again takes you to the A/D count display.

V. MAIN BOARD INITIALIZATION

1. Initial Values

When the board is initialized;

CF1=0	F1=0
CF2=1	F2=1
CF3=0	F3=0
CF4=0	F4=0
CF5=0	F5=0
* F6=0	


** F6 is only available for the P-2.00 version ROM.*

F6 is the function for factory use. Do not change the data.

2. Initialization Method

- (1) Connect the No. 3 and No. 4 pins of the option connecting cable by means of a 1 k Ω resistance.
- (2) Holding down the [CAL], [ZERO], and [PRINT/ENTER] switches, press the [ON/OFF] switch to turn on the power.
- (3) "init" is displayed for a moment then replaced by "End." When "Err 8" is displayed, it indicates that the data was not correctly written into the EEPROM.
- (4) Turn off the power to terminate.

3. Optional Connecting Cable Shorting Jig



VI. ADJUSTMENT OF THE PRODUCT

1. Internal Setting

Functions of Switches

- [CAL] : Proceeds to the next function, leaving a set values as it is.
- [PRINT/ENTER] : Stores a new set value and proceeds to the next function.
- [SAMPLE] : Increments the set value by 1.
- [MODE] : Decrements the set value by 1.
- [ZERO] : Clears the set value to zero(0).

- (1) Connect the No. 3 and No. 4 pins of the option connecting cable using a 1 k Ω resistor.
- (2) Holding down the [CAL] and [ZERO] switches, press the [ON/OFF] switch to turn on the power. "CF1 ?" is displayed.
- (3) When you want to leave the set value as it is, press the [CAL] switch to proceed to the next function.
- (4) When you want to alter the set value, use the [SAMPLE], [MODE], and [ZERO] switches to set the value shown in Table 1. When here is a remodeling code, remodel as shown in Table 2.
- (5) Press the [PRINT/ENTER] switch to store. When "Err 8" is displayed, it indicates that the data was not correctly stored in the EEPROM.
- (6) When all settings are completed, "End" is displayed.
- (7) Turn off the power to terminate.

Table 1

EK-G/EW-G Internal Settings														
ROM Version P-1.10, p-2.00 * F6 is only available for P-2.00 ROM														
	C F 1	C F 2	C F 3	C F 4	C F 5	F 1	F 2	F 3	F 4	F 5	* F 6	Remarks		
EK120G	0	1	2	0	2	0	1	0	0	0	0			
200G					3									
600G					1							1		
1200G												2		
2000G												3		
6000G			0	1										
12KG				2										
EW60G				2	1							0		
300G			1										0	
600G			1											
3000G	0	0												

Table 2

Alterations of Internal Settings by Remodeling Codes														
ROM Version P-1.10, P-2.00														
Remodeling Code	Model	Function Altered	EK						EW				Remarks	
			1	2	6	1	2	6	1	6	3	6		3
			2	0	0	2	0	0	2	0	0	0		0
			0	0	0	0	0	0	K	G	0	0		0
			G	G	G	0	0	0	G		G	G		0
			G	G	G	G	G	G				G		
*0001	None	As per Table 1										g,pcs,%, " . "		
*0002	CF3	A	9			8		A	9		8	g,pcs,%, " , "		
*0003	CF2	4										g,pcs,%,oz,lb,ozt,ct, mom,dwt,GN, " . "		
*0004	CF2	4										g,pcs,%,oz,lb,ozt,ct, mom,dwt,GN, " . "		
*0005	CF2	5										g,pcs,%,oz,lb,ozt,ct, mom,dwt,GN,t11, " . "		
*0006	CF2	6										g,pcs,%,oz,lb,ozt,ct, mom,dwt,GN,t12, " . "		
*0007	CF2	N/A	7	N/A		7	N/A		7			g,pcs,%,oz,lb,ozt,ct, mom,dwt,GN,t13, " . "		
*0008	CF2	4										g,pcs,%,oz,lb,ozt,ct, mom,dwt,GN, " , "		
	CF3	A	9			8		A	9		8			

t11=Hong Kong (general)/Singapore tael

t12=Hong Kong (jewelry) tael

t13=Taiwan tael

N/A=Not applied

2. Calibration


Functions of Switches


- [CAL] : Proceeds to the next without changing the setting.
- [PRINT/ENTER] : Stores a new value and proceeds to the next.
- [SAMPLE] : Increments a blinking value.
- [MODE] : Shifts a blinking digit to the right by one digit.
- [ZERO] : None

- (1) Press the [ON/OFF] switch to turn on the power. After two seconds, press the [MODE] switch to select the weight display mode.
- (2) Apply a preliminary load, using a weight about twice larger than the weighing capacity. (This weight will be removed in step 5)
- (3) In this state, warm up the instrument for 10 minutes. This should be done carefully for the EK120G and EK200G.
- (4) Press the [CAL] switch to enter the calibration mode. "9. XXX" is displayed.
- (5) Enter the gravity acceleration value of where you are now. If you enter the correct value for your location, you do not have to readjust the zero point or span when using the instrument in a different location, simply alter the gravity acceleration to the correct value for that location.
- (6) Proceed to the zero point. "CAL 0" is displayed.
- (7) With nothing on the weighing pan, press the [PRINT/ENTER] switch to set the zero point when the stabilization mark appears.
- (8) Proceed to span. The calibration weight is displayed.
- (9) Put the weight which equals a displayed value(g). When the stabilization mark is displayed, press the [PRINT/ENTER] switch to assume the span. Although the weight value can be altered, use it as it is as much as possible.
- (10) End of calibration. When "End" is displayed, press the [CAL] switch to terminate calibration.

VII. TROUBLESHOOTING

1. Flow Chart





2. Check Items

If possible enter the check mode to perform these checks.

2-1 Power Check

(1) +10 V(U1)

1) Input voltage = Output voltage + 0.7 V or more. Otherwise, low battery.

2) Output voltage = 10 V \pm 1 V

(2) + 5 V(U2)

1) Input voltage = 10 V \pm 1 V

2) Output voltage = 5 V \pm 0.3 V

(3) Current

12 V DC, 51 mA for the main body only. When the current has a difference of \pm 10 mA or more, it is considered abnormal.

(4) Reset output = 5 V

(5) What happens if the [ON/OFF] switch is held down ?

2-2 CPU Check

(1) Power : 5 V at pin No. 33.

(2) Reset : Normally, 5 V at pin No. 24.

(3) Clock : 4.91 MHz for XT

(4) A/D control : Waveform in the A/D circuit timing chart

2-3 LCD and Switches

(1) Since the LCD and switches are directly connected to the CPU ports, make sure that they are free from contact or soldering failure.

(2) Since the [ON/OFF] switch(SW5) is connected to the power circuit, pay attention to the transistors Q3 and Q4 as well.

2-4 A/D

(1) 10 V at the No. 3 pin.

(2) The waveform shown in the timing chart for the A/D circuit is input at 10 V. The AZ waveform is reversed.

2-5 Load Cell

(1) Input voltage(between 5 and 3) = 10 V

(2) Output voltage(between 2 and 4) : Zero = 0 V + 2 mV (with the weighing pan)
Full scale = Zero + 10 mV \pm 1 mV

CAUTION : For the next check, remove all power from the circuit (disconnect the AC adapter and battery option (if used)).

(3) Resistance value = About 410 Ω for the input side, About 350 Ω for the output side.

VIII. ASSEMBLY PROCEDURES


/ Docking of Cell

- (1) Affix a load angle to the load cell temporarily. (Screw at 2 places) (3 places for the EW3000, EK6000, and 12K). The screw (1) and washer (2) differ depending on the model used. (Refer to the figure below)

Model	EW60G EK120G EK200G	EW300G EW600G	EK600G EK1200G EK2000G	EW3000G EK6000G EK12KG
Screw	Truss M4 x 8	Pan head screw M4 x 10		Hexagon socket head bolt M4 x 10
Washer	Plain washer (Nylon, M4)			Plain washer(M4) Spring washer(M4)

*The load angle differs depending on the model used.(Refer to the figure below)


Model	EW60G EK120G EK200G	EW300G EW600G	EK600G EK1200G EK2000G	EW3000G EK6000G EK12KG
Name	Load angle	Load angle		Load angle B
Standard	04:A46310	04:A46311		04:3000117



(2) Attach the load cell to the lower case.(Refer to the figure below)

1) For the EW60G, EK120/200G

- Attach the main board to the lower case. (Align the projections with the holes in the main board and fit in.)
- Place a spacer between the load cell and the load cell mounting section of the lower case(left side of the cell) and attach with two pan head screws M4 x 10. (Make sure that the cell is perpendicular (if not perpendicular, it can cause a 4 corner problem), and tighten with a torque of 10 kgf-cm). Attach the grounding terminal together with the upper screw (closer to the main board).
- The grounding terminal attached to the tip should also be screwed to a 3 mm tap on the left rear of the cell mounting section.
- Insert a 0.8 mm spacer jig under the temporarily mounted load angle and tighten with the proper torque(Refer to Figure on the next page). Push down on the load angle from above and tighten the screws. The angle should be parallel to the guide (if not straight, it can cause a 4 corner problem).
- Attach the upper stopper on the right side of the load cell. When this is done, put a nylon washer(s) in between the upper stopper and mounting section.(One or two depending on the height). Pull up the cell to confirm that it moves.




2) For the EW300/600G, EK600/1200/2000G. (Refer to the Load Cell Mounting Drawing on the previous page)

- Attach the main board to the lower case. (Align the projections with the holes in the main board and fit in.)
- Install the stopper plate below the load cell mounting section . (shaped like a round circle with sticky tape on the back).
- Set the load cell in the load cell mounting section, attach the load cell supporters from the front side, and attach with screws. Two pan head screws M4 x 12, tightening torque of 7.10 kgf-cm. Attach the grounding terminal to the upper screw (closer to the main board) and tighten.
- The grounding terminal attached to the tip should be also screwed to a 3 mm tap on the left rear of the cell mounting section.
- Insert a 1.1 or 1.2 mm spacer jig under the temporarily mounted load angle and tighten with a torque(tightening torque of 10 kgf-cm), while pushing on the load angle from above (refer to the drawing below). Use the 1.1 mm spacer jig for the EW300/600G and EK600G, and 1.2 mm spacer jig for the EK1200/2000G.
- Screw the upper stopper to the right side of the load cell (tap M3 x 8). After attaching the upper stopper, pull up on the cell to confirm that it moves.

3) For the EW3000, EK6000G/12KG. (Same procedure except the following)

- The load cell supporters used for attaching the load cell should have 3 holes. To attach them, use a hexagon socket head bolt(M4 x 12) together with a spring washer and plain washer (Screw at 3 places). Attach the grounding terminal to the top one (tightening torque of 28 kgf-cm)
- When tightening the load angle with a torque, use the 1.3 mm spacer jig (tightening torque of 28 kgf-cm).
- The upper stopper is not required.



APPENDIX:A ELECTRONIC PART

PARTS LIST

7 P Z : 2 7 7 3 - M A I N			
CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q' TY
C2, 13, 14, 16~20, 30~34 .36~39 C40, 42 C6 C1	PC : 2 7 7 3 B CC : 0. 1 U 2 5 V T CC : 4 7 P T CK : S M E 1 6 V B 1 0 0 CK : S M E 3 5 V B 4 7 0	PRINTED CIRCUIT BOARD CAPACITOR 0.1 μ F 25V CAPACITOR 47pF CAPACITOR 100 μ F 16V CAPACITOR 470 μ F 35V	1 17 2 1 1
C3, 5, 7, 9, 24, 29, 35 D1 D2, 6~12 LCD J6	CT : 1 V 0 1 0 T DI : S B 1 0 - 0 3 A 2 - T DI : 1 S S 2 7 0 T ED : E - 7 3 3 9 JE : H B L B 5 S - 5 J	CAPACITOR 1 μ F 35V DIODE DIODE LCD FPC CONNECTOR	7 1 8 1 1
J5 J4 JPC JPB JPA	JI : 0 9 P - S 2 T 2 - E F JT : 1 7 1 8 2 5 - 3 KB : 1 2 6 0 0 6 B K 7 7 KB : 1 2 6 0 0 8 B K 7 7 KB : 1 2 6 0 1 3 B K 7 7	CONNECTOR CONNECTOR WIRE WIRE WIRE	1 1 1 1 1
U4 Q2 Q1 Q3, 4	KO : 1 2 5 7 - 0 0 5 - 0 6 MF : A M Z 2 1 QT : A 1 0 1 5 Y T QT : A 1 0 2 0 Y T QT : B A 1 A 4 P T	EARTH CABLE ANALOG MODULE TRANSISTOR 2SA1015Y TRANSISTOR 2SA1020Y TRANSISTOR BA1A4PT	1 1 1 1 2
R29, 34 R1, 31, 33, 39 R5, 6, 10~16, 38 R32 R27, 28	RC : N A T 1. 5 K J T RC : N A T 1 0 K J T RC : N A T 1 0 0 R J T RC : N A T 1 5 K J T RC : N A T 2 2 K J T	RESISTOR 1.5K Ω 1/4W RESISTOR 10K Ω 1/4W RESISTOR 100 Ω 1/4W RESISTOR 15K Ω 1/4W RESISTOR 22K Ω 1/4W	2 4 10 1 2
R3, 7, 8, 21, 42 R2, 4 R18~20, 22, 25, 35~37 R30 R17, 23, 24	RC : N A T 3. 3 K J T RC : N A T 3 3 K J T RC : N A T 5 6 K J T RN : I H R - 4 - 1 0 3 M A RN : I H R - 4 - 2 2 3 M A	RESISTOR 3.3K Ω 1/4W RESISTOR 33K Ω 1/4W RESISTOR 56K Ω 1/4W RESISTOR NETWORK RESISTOR NETWORK	5 2 8 1 3
R9 SW1~5 U7 U6 U5	RN : I H R - 8 - 5 6 3 J A SK : S K H H A K UA : C 3 3 9 C UC : H C 0 8 UC : R P 9 3 C 4 6	RESISTOR NETWORK TACT SWITCH COMPARATOR HCMOS IC EEPROM	1 5 1 1 1
U3 U1 U2 XT1	UC : 4 7 C 8 2 0 Z - N A 1 5 UR : C 2 2 5 5 H UR : T A 7 8 D L 1 0 S XT : K B R 4. 9 1 M K S T F 0 7 : 4 0 0 0 3 2 3	CPU VOLTAGE REGULATOR VOLTAGE REGULATOR CERAMIC OSC DISPLAY HOLDER	1 1 1 1 1
	1 7 : 1 3 - N 3 \times 6 B 1	TAPPING SCREW	2

- A 3 -


7 P Z : 2 7 7 4			
CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q' TY
D1	PC : 2 7 7 4 DI : F 1 4 A EB : 1 0 A A 6 0 0 - 1 0 5 3 FH : 8 5 P N 0 8 1 9 FS : E A W K - 3 1 5 M A	PRINTED CIRCUIT BOARD DIODE Nlcd BATTERY FUSE HOLDER FUSE 315mA	1 1 1 2 1
J1 R2 R1 S1	KO : 1 0 2 - 3 S 2 0 RC : 1 / 2 1 0 0 R RE : M O R 2 B 1 5 R J SS : S S X - 4 5 9	CABLE 3P 20cm RESISTOR 100Ω 1/2W RESISTOR 15Ω 2W SLIDE SWITCH	1 1 1 1

7 P Z : 2 7 7 5			
CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q' TY
C2,7 C3,4,5,6 C1 J2	PC : 2 7 7 5 CC : 0. 1 U 2 5 V CK : SME 2 5 VB 1 0 CK : SME 2 5 VB 2 2 JA : 1 7 LE - 1 3 2 5 0	PRINTED CIRCUIT BOARD CAPACITOR 0.1 μ F 25V CAPACITOR 10 μ F 25V CAPACITOR 22 μ F 25V CONNECTOR	1 2 4 1 1
J1 NF1 R1 U1	JI : 0 9 P - S 2 T 2 - E F NF : D - 4 2 C RC : NAT 3. 3 K UC : MAX 2 3 2 C P E 0 7 : 3 0 0 0 1 1 9	CONNECTOR NOISE FILTER RESISTOR 3.3K Ω 1/4W RS232C PANNEL	1 1 1 1 1
	0 8 : C 4 0 9 2 7 - 1	SEAL	1

7 P Z : 2 7 7 6			
CIRCUIT SYMBOL	PARTS NAME	DESCRIPTION	Q' TY
C2 C1 PHC1 D1	PC : 2 7 7 6 CC : 0. 1 U 2 5 V CK : SME 2 5 V B 2 2 DF : PS 2 5 0 1 - 1 L / K DI : 1 B 4 B 4 2	PRINTED CIRCUIT BOARD CAPACITOR 0.1 μ F 25V CAPACITOR 22 μ F 25V PHOTO CUPPLER BRIDGE DIODE	1 1 1 1 1
J2 J1 Q1 Q2 R2	JA : TCS 5 0 7 6 - 1 7 JI : 0 9 P - S 2 T 2 - E F QT : BA 1 A 4 P QT : C 1 8 1 5 Y RC : NAT 1 K	CONNECTOR CONNECTOR TRANSISTOR BA1A4P TRANSISTOR 2SC1815Y RESISTOR 1K Ω 1/4W	1 1 1 1 1
R1	RC : NAT 5. 6 K 0 7 : 3 0 0 0 1 1 8 0 8 : 4 0 0 1 0 5 9	RESISTOR 5.6K Ω 1/4W PANNEL SEAL	1 1 1


7 P Z : 2 7 7 7

- A 7 -




Model	EK/EW-G
Description	
Stock No	PZ:2773
Drwg. No	QD-EC3-000063


A&D CO., LTD.




Model	EKW-Ø9G
Description	
Stock No	PZ:2774
Drwg. No	QD-EC4-ØØØØ25




Model	EKW-03G
Description	
Stock No	PZ:2775
Drwg. No	QD-EC4-000022



Model	EKW-05G
Description	
Stock No	PZ:2776
Drwg. No	QD-EC4-000024




Model	EKW-04G
Description	
Stock No.	PZ:2777
Drwg. No.	QD-EC4-000023




Model	EK-G series
Description	
Stock No.	PZ:2773-MAIN
Dwg. No.	QD-KZ2-000005


A&D CO., LTD.




Model	EK-G series
Description	
Stock No	PZ:2773-PS
Drwg. No	QD-KZ2-000005




Model	EKW-09G
Description	
Stock No	PZ 2774
Drwg. No	QD-KZ4-000010



Model	EKW-03G
Description	
Stock No	PZ 2775
Drwg. No	QD-KZ4-000011




Model	EKW-05G
Description	
Stock No	PZ:2776
Drwg. No	QD-KZ4-000012



Model	EKW-04G
Description	
Stock No	PZ:2777
Drwg. No	QD-KZ4-000013

APPENDIX:B MECHANICAL PART


EXPLODED VIEW-1
EK-120G/200G



E K - 1 2 0 G / 2 0 0 G

NO.	PARTS NAME	DESCRIPTION
1	04:A46385	PAN
2	07:A44236	PAN SUPPORT
3	07:1000007	UPPER CASE
4	08:3000113	SWITCH
5	07:4000316	DISPLAY FILTER
6	07:1000008	LOWER CASE
7	07:3000116	OPTION BLANK PANEL
8	07:3000115	CAL SWITCH COVER
9	00:4000879	LEVEL VIAL HOLDER
10	04:4000321	UPPER STOP
11	04:A46955	SPACER
12	LC:116-300	LOAD CELL
13	04:A46310	LOAD ANGLE
14	07:4000317	CAP A
15	07:4000318	CAP B
16	07:4000319	CAP.C
17	07:A46041A	FOOT
18	07:2000025	BATTERY COVER
19	PZ:2773	MAIN BOARD
20	PZ:2773	BATTERY BOARD
A		PAN HEAD TAPPING SCREW M3×10
B		PAN HEAD TAPPING SCREW M3×8
C		PAN HEAD WITH WASHER AND SPRING WASHER M3×6
D		PAN HEAD WITH WASHER AND SPRING WASHER M4×10
E		TRUSS HEAD M4×8
F		WASHER M4

EXPLODED VIEW
EK-600G/1200G/2000G




E K - 6 0 0 G

NO.	PARTS NAME	DESCRIPTION
1	04:A44255	PAN
2	09:A33750	PAN SUPPORT
3	07:1000007	UPPER CASE
4	08:3000113	SWITCH
5	07:4000316	DISPLAY FILTER
6	07:1000008	LOWER CASE
7	07:3000116	OPTION BLANK PANEL
8	07:3000115	CAL SWITCH COVER
9	00:4000879	LEVEL VIAL HOLDER
10	04:A44251	STOP PLATE
11	04:4000321	UPPER STOP
12	LC:116-600	LOAD CELL
13	04:A46311	LOAD ANGLE
14	04:A44250	LOAD CELL SUPPORT
15	07:4000317	CAP A
16	07:4000318	CAP B
17	07:4000319	CAP C
18	07:A46041A	FOOT
19	07:2000025	BATTERY COVER
20	PZ:2773	MAIN BOARD
21	PZ:2773	BATTERY BOARD
A		PAN HEAD TAPPING SCREW M3×10
B		PAN HEAD TAPPING SCREW M3×8
C		PAN HEAD WITH WASHER AND SPRING WASHER M3×6
D		PAN HEAD WITH WASHER AND SPRING WASHER M4×12
E		PAN HEAD WITH WASHER AND SPRING WASHER M4×10
F		PAN HEAD WITH WASHER AND SPRING WASHER M4×10

E K - 1 2 0 0 G / 2 0 0 0 G

NO.	PARTS NAME	DESCRIPTION
1	04:A44255	PAN
2	04:A32888	PAN SUPPORT
3	07:1000007	UPPER CASE
4	08:3000113	SWITCH
5	07:4000316	DISPLAY FILTER
6	07:1000008	LOWER CASE
7	07:3000116	OPTION BLANK PANEL
8	07:3000115	CAL SWITCH COVER
9	00:4000879	LEVEL VIAL HOLDER
10	04:A44251	STOP PLATE
11	04:4000321	UPPER STOP
12	LC:116-2K	LOAD CELL
13	04:A46311	LOAD ANGLE
14	04:A44250	LOAD CELL SUPPORT
15	07:4000317	CAP A
16	07:4000318	CAP B
17	07:4000319	CAP C
18	07:A46041A	FOOT
19	07:2000025	BATTERY COVER
20	PZ:2773	MAIN BOARD
21	PZ:2773	BATTERY BOARD
21		PAN HEAD TAPPING SCREW M3×10
B		PAN HEAD TAPPING SCREW M3×8
C		PAN HEAD WITH WASHER AND SPRING WASHER M3×6
D		PAN HEAD WITH WASHER AND SPRING WASHER M4×12
E		PAN HEAD WITH WASHER AND SPRING WASHER M4×10
F		PAN HEAD WITH WASHER AND SPRING WASHER M4×10

EXPLODED VIEW
EK-6000G/12KG




E K - 6 0 0 0 G

NO.	PARTS NAME	DESCRIPTION
1	04:A44255	PAN
2	04:A32889	PAN SUPPORT
3	07:1000007	UPPER CASE
4	08:3000113	SWITCH
5	07:4000316	DISPLAY FILTER
6	07:4000322	LOWER CASE
7	07:3000116	OPTION BLANK PANEL
8	07:3000115	CAL SWITCH COVER
9	00:4000879	LEVEL GUIDE HOLDER
10	04:A44251	STOP PLATE
11	LC:116-6K	LOAD CELL
12	04:3000117	LOAD ANGLE
13	04:4000320	LOAD SUPPORT
14	07:4000317	CAP A
15	07:4000318	CAP B
16	07:4000319	CAP C
17	07:A46041A	FOOT
18	07:2000025	BATTERY COVER
19	PZ:2773	MAIN BOARD
20	PZ:2773	BATTERY BOARD
A		PAN HEAD TAPPING SCREW M3×10
B		PAN HEAD WITH WASHER AND SPRING WASHER M3×6
C		HEXAGON BOLT M4×12
D		HEXAGON BOLT M4×10
E		PAN HEAD WITH WASHER AND SPRING WASHER M5×10
F		SPRING WASHER M4
G		WASHER M4

E K - 1 2 K G

NO.	PARTS NAME	DESCRIPTION
1	04:A44255	PAN
2	04:A32889	PAN SUPPORT
3	07:1000007	UPPER CASE
4	08:3000113	SWITCH
5	07:4000316	DISPLAY FILTER
6	07:4000322	LOWER CASE
7	07:3000116	OPTION BLANK PANEL
8	07:3000115	CAL SWITCH COVER
9	00:4000879	LEVEL GUIDE HOLDER
10	04:A44251	STOP PLATE
11	LC:116-12	LOAD CELL
12	04:3000117	LOAD ANGLE
13	04:4000320	LOAD SUPPORT
14	07:4000317	CAP A
15	07:4000318	CAP B
16	07:4000319	CAP C
17	07:A46041A	FOOT
18	07:2000025	BATTERY COVER
19	PZ:2773	MAIN BOARD
20	PZ:2773	BATTERY BOARD
A		PAN HEAD TAPPING SCREW M3×10
B		PAN HEAD WITH WASHER AND SPRING WASHER M3×6
C		HEXAGON BOLT M4×12
D		HEXAGON BOLT M4×10
E		PAN HEAD WITH WASHER AND SPRING WASHER M5×10
F		SPRING WASHER M4
G		WASHER M4




EXPLODED VIEW
EW-60G

E W — 6 0 G

NO.	PARTS NAME	DESCRIPTION
1	04:A46385	PAN
2	07:A44236	PAN SUPPORT
3	07:1000007	UPPER CASE
4	08:3000114	SWITCH
5	07:4000316	DISPLAY FILTER
6	07:1000008	LOWER CASE
7	07:3000116	OPTION BLANK PANEL
8	07:3000115	CAL SWITCH COVER
9	00:4000879	LEVEL VIAL HOLDER
10	04:4000321	UPPRE STOP
11	04:A46955	SPACER
12	LC:116-300	LOAD CELL
13	04:A46310	LOAD ANGLE
14	07:4000317	CAP A
15	07:4000318	CAP B
16	07:4000319	CAP C
17	07:A46041A	FOOT
18	07:2000025	BATTERY COVER
19	PZ:2773	MAIN BOARD
20	PZ:2773	BATTERY BOARD
A		PAN HEAD TAPPING SCREW M3×10
B		PAN HEAD TAPPING SCREW M3×8
C		PAN HEAD WITH WASHER AND SPRING WASHER M3×6
D		PAN HEAD WITH WASHER AND SPRING WASHER M4×10
E		TRUSS HEAD M4×8
F		WASHER M4


EXPLODED VIEW
EW-300G/600G



EW - 300G / 600G

NO.	PARTS NAME	DESCRIPTION
1	04:A44255	PAN
2	04:A33750	PAN SUPPORT
3	07:1000007	UPPER CASE
4	08:3000114	SWITCH
5	07:4000316	DISPLAY FILTER
6	07:1000008	LOWER CASE
7	07:3000116	OPTION BLANK PANEL
8	07:3000115	CAL SWITCH COVER
9	00:4000879	LEVEL VIAL HOLDER
10	04:A44251	STOP PLATE
11	04:4000321	UPPER STOP
12	LC:116-600	LOAD CELL
13	04:A46311	LOAD ANGLE
14	04:A44250	LOAD CELL SUPPORT
15	07:4000317	CAP A
16	07:4000318	CAP B
17	07:4000319	CAP C
18	07:A46041A	FOOT
19	07:2000025	BATTERY COVER
20	PZ:2773	MAIN BOARD
21	PZ:2773	BATTERY BOARD
A		PAN HEAD TAPPING SCREW M3×10
B		PAN HEAD TAPPING SCREW M3×8
C		PAN HEAD WITH WASHER AND SPRING WASHER M3×6
D		PAN HEAD WITH WASHER AND SPRING WASHER M4×12
E		PAN HEAD WITH WASHER AND SPRING WASHER M4×10
F		PAN HEAD WITH WASHER AND SPRING WASHER M4×10

EXPLODED VIEW
EW-3000G



EW - 3000G

NO.	PARTS NAME	DESCRIPTION
1	04:A44255	PAN
2	07:A32889	PAN SUPPORT
3	07:1000007	UPPER CASE
4	08:3000114	SWITCH
5	07:4000316	DISPLAY FILTER
6	07:4000322	LOWER CASE
7	07:3000116	OPTION BLANK PANEL
8	07:3000115	CAL SWITCH COVER
9	00:4000879	LEVEL VIAL HOLDER
10	04:A44251	STOP PLATE
11	LC:116-6K	LOAD CELL
12	04:3000117	LOAD ANGLE
13	04:4000320	LOAD CELL SUPPORT
14	07:4000317	CAP A
15	07:4000318	CAP B
16	07:4000319	CAP C
17	07:A46041A	FOOT
18	07:2000025	BATTERY COVER
19	PZ:2773	MAIN BOARD
20	PZ:2773	BATTERY BOARD
A		PAN HEAD TAPPING SCREW M3×10
B		PAN HEAD WITH WASHER AND SPRING WASHER M3×6
C		HEXAGON BOLT M4×12
D		HEXAGON BOLT M4×10
E		PAN HEAD WITH WASHER AND SPRING WASHER M5×10
F		SPRING WASHER M4
G		WASHER M4

MEMORANDA

[illegible]



A&D Company, Limited

3-23-14 Higashi-Ikebukuro, Toshima-ku, Tokyo 170 JAPAN
Telephone: [81] (03) 5391-6132 Fax: [81] (03) 5391-6148

A&D ENGINEERING, INC.

1555 McCandless Drive, Milpitas, CA. 95035 U.S.A.
Telephone: [1] (408) 263-5333 Fax: [1] (408) 263-0119

A&D INSTRUMENTS LTD.

Abingdon Science Park, Abingdon, Oxford OX14 3YS ENGLAND
Telephone: [44] (0235) 550420 Fax: [44] (0235) 550485

<German Sales Office>

Genfer Strasse 6, Niedereschbach 60437 Frankfurt Main 50 GERMANY
Telephone: [49] (069) 507-1017 Fax: [49] (069) 507-2054

A&D MERCURY PTY. LTD.

32 Dew Street, Thebarton, South Australia 5031 AUSTRALIA
Telephone: [61] (08) 352-3033 Fax: [61] (08) 352-7409

A&D KOREA Limited

Han Bldg. 277-21, Nonhyun-Dong, Kangnam-Gu, Seoul, KOREA
Telephone: [82] (02) 517-4101 Fax: [82] (02) 546-4264