



RS232 connection to AD-8920 Remote Display

25 pin connector
Balance/Scale

9 pin connector
Balance/Scale

Phone connector
AD-8920

Pin no.	Pin No.	Description	Pin no.
1		Frame ground	
2 Receive	3		
3 Transmit	2	Data	2 Receive
6	6		
7	5	Signal ground	3
8 – 25		-	