

AD4406 lb / kg **Setup Procedure**

KEY OPERATION	DESCRIPTION	DISPLAY
	With the display off	
<Net Gross> / <On/OFF>	Release On/OFF key	
When “FOO” <Cal>	Release keys	C00
<F2 ENTER>	C00 to 0	C0-0
<F2 ENTER>	C01 to 1	C1-1
<F2 ENTER>	C02 – C09 to 0	CX-0
<On/OFF>	Returns to normal weighing	

KEY OPERATION	DESCRIPTION	DISPLAY
	With the display on	
<CAL>		CAL 0
<ZERO→> 3 times		CAL SEt
<F2 ENTER>	For single range	SiNGL
<ZERO→>	Toggles between kg & tonnes	kg / t / lb / lb kg.
<F2 ENTER>		d xx
<CAL>		Cal off
<On/OFF>	Returns to normal weighing	