

**AD4407 Single Range  
Calibration Procedure**

	<b><u>QUICK CALIBRATION</u></b>	
<b><u>KEY OPERATION</u></b>	<b><u>DESCRIPTION</u></b>	<b><u>DISPLAY</u></b>
<CAL>		CAL 0
	With zero load	
<ENTER>		CAL F then xxxxx Full load
	Place test masses on scale	
	Set indicator to = test masses applied	Eg 500.00
< ENTER>		CAL END
<CAL>		END
<On/OFF>	Exit CAL mode	
<On/OFF>	Returns to normal weighing	