



AD-4406 SETUP FOR ADA LED DOT REMOTE DISPLAY

REMOTE DISPLAY

1. Ensure DIP switch setting on the PCB inside the remote display is set to RS232 position if using the RS232 option in the AD-4406. Otherwise set it to the RS485 position if using the RS485 option in the AD-4406.

AD-4406

1. Enter the Function settings when in weighing mode by pressing the **F1** and **F2** keys at the same time. The display will show *F00*.
2. Set function F30=*2* or *3*.
3. Set function F40=*0*.
4. Set function F34=*00 1 A, 002 F, E003 0*. Change the factory default settings as follows;
When entering F34 the display shows *00 1 9*. Change the flashing *9* to *A* using the **^** key.
Press the **>** key to display *002 E*. Change the flashing *E* to *F* using the **^** key.
Press the **>** key to display *003 A*. Change the flashing *A* to *0* using the **^** key.
Press the **NET/GROSS** key to display *E003 0*.
Press the **F2** key to save the settings.
5. Press **F1** key to return to weighing mode.