

HL Model Calibration Procedure

1. Press and hold the **Zero** key, press the **centre** hidden key and the **On** key.
2. **[AL** appears. Press **Zero** key.
3. **[AL 0** appears. Press **Zero** key.
4. **[AL F** appears. Place capacity mass on scale and press **Zero** key,
e.g. HL 200=200 g.
5. **[AL End**: Turn scale off then on, scale will be weighing normally.