

GR Series – Internal Calibration Mass Adjustment Procedure

1. Verify that the display is off.
2. Press and hold the ZERO & MODE keys & press the ON/OFF key.
Release the MODE & ON/OFF keys while still holding the ZERO keys.
Immediately press the MODE key twice.
3. The software version will be displayed for approx. one second, followed by the balance type. All display segments will then turn on.
4. Press MODE key → “d-dsp” displayed.
5. Press MODE 3 times → “CAL out “ displayed.
6. Press PRINT key → “CAL 0” displayed.
7. Press MODE key → full calibration capacity displayed.
8. Press MODE / REZERO key → to alter full calibration capacity.
9. Press PRINT to enter setting → “CAL 0” displayed
10. With nothing on the weigh pan, press PRINT → full calibration load displayed.
11. Place test mass onto weigh pan. → Press PRINT, “end” displayed.
12. Remove test mass → “CAL in” displayed
13. Press MODE key → “CAL SET” displayed.
14. Press PRINT → “cc” displayed. Internal calibration is performed.
15. “CP in” is displayed.
16. Press ON/OFF key twice to return to normal weighing.