

AD4406 Single Range Calibration Procedure

KEY OPERATION	DESCRIPTION	DISPLAY
<CAL>		CAL 0
<ZERO→> 3 times		CAL SEt
<F2 ENTER>	For single range	SiNGL
<ZERO→>	Toggles between g or kg & tonnes	kg or t
<F2 ENTER>		D 0000
<TARE↑>	Selects the resolution size	
<ZERO→>	Selects decimal position	
<F2 ENTER>	Capacity setting	CAP -XXXX
<ZERO→>/<TARE↑>	Set capacity	
<F2 ENTER>	Enters ZERO setting	CAL O
<F2 ENTER>		CAL F XXXX
	Place calibration mass on scale	
<TARE↑>/<ZERO→>	Set display to equal calibration mass	
<F2 ENTER>	Enters CAPCITY setting	CAL END
<On/OFF>	Exit CAL mode	END
<On/OFF>	Returns to normal weighing	