

TOOL MANAGEMENT

0 6000 N00200

SPDL 5 TCMD 0

POT NO: 0 POT TYPE: STANDARD >

ATC MAGAZINE POT

01	3	16	16
02	2	17	17
03	0	18	18
04	6	19	19
05	10	20	20
06	4	21	21
07	7	22	22
08	8	23	23
09	9	24	24
10	14	25	25
11	11	26	26
12	12	27	27
13	13	28	28
14	1	29	29
15	15	30	30

PTN: 5 ORD: 0 KIND: STANDARD >
FTN: 0 SIZE: STANDARD >

ALM

WRN

ALARM
RESET

TEACH
RESET

UP
DOWN



TOOL
CALL

OPTIONS

ROTATION PROHIBIT: NO >
TS ENABLE: ENABLED >
TOOL CHANGE PROHIBIT: NO >
FIXED POT: NO >
SLOW TOOL CHANGE: NO >
IGNORE BROKEN CHECK: NO >
IGNORE VERIFICATION: NO >
TOOL RUNOUT TEACH: NO >

A>

POS PRGM FUNC TOOL OFFSET WORK COORD INPUT MODE PREV PAGE NEXT PAGE MAG DATA RESET ALL

JOG *** --EMG-- ALM 08:44