

Create wireless network on Raspberry Pi 4

Follow the tutorial on the website of Raspberry Pi :

- [setting-up-a-routed-wireless-access-point](#)

SD card & boot details

Use Raspberry Pi Imager to create your bootable sd card :

- [Raspberry Imager](#)

Add the following line to the boot/config.txt file : `enable_uart=1`

For help, try :

- [setting-up-your-raspberry-pi](#)

Connect to your Rpi using uart

Connect your Raspberry Pi with a USB <-> UART cable, like this :

