

OSD SETTING

In this menu, you can configure the OSD (On Screen Display) settings.

- **Camera ID :**

Displays or hides Camera ID in the upper left of the screen.

- **Camera Name :**

Add a name to the camera. (see the top note on page 78 for more information.)

- **Preset Number :**

Displays or hides Preset Numbers on the screen.

- **Preset Name :**

Add names to preset locations. (see the top note on page 78 for more information.)

- **Seq. Status :**

Displays or hides the status of a sequence action that is in progress.

- **Area Name :**

Displays or hides the Area Name for the Area Settings on the screen.

- **PTZ Position :**

Displays or hides the status of the Pan, Tilt, and Zoom operation that is in progress.

Main Menu

Camera Setting ↵

Sequence Setting ↵

P/T Setting ↵

OSD Setting ↵

Alarm Setting ↵

Initialize ↵

Password Setting ↵

Status ↵



OSD Setting

Camera ID ON

Camera Name ↵

Preset Number ON

Preset Name ↵

Seq. Status ON

Area Name OFF

PTZ Position ON

● Language :

Enables changing the system language. This camera supports ENGLISH, FRENCH, GERMAN, SPANISH, ITALIAN, PORTUGUES, POLISH, RUSSIAN, CZECH, TURKISH, KOREAN, JAPANESE.

● Others

- Direction : Indicates the current angle of the camera:
East, West, South, North, Southeast, Southwest, Northeast, or Northwest.
 - Set North Dir. : Specify the azimuth of the north manually.
- Clock Setting: You can specify the time information manually that will be displayed on the screen. This will synchronize with Sequence so that you can set it to activate on a specific time and date.
 - Display: Specify the use of time display on the screen.
 - Date Format: Specify the date format. (DD/MM/YYYY, MM/DD/YYYY)
 - Set Date: Enter a desired date manually.
 - Time Format: Specify the time format. (24hr / 12hr)
 - Set Time: Specify the time manually.

English - 77

XXX Name

[]

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

a

b

c

d

e

f

g

h

i

j

k

l

m

n

o

p

q

r

s

t

u

v

w

x

y

z

1

2

3

4

5

6

7

8

9

0

()

[]

- /

*

!

?

,

.

BACK

SPACE

CLR

SET

- When selecting the Camera Name and Preset Name, the screen displays the Left keypad.
- Names can be up to 12 characters and can be entered via the joystick and the Enter key. Once a name is entered, use the joystick and the Enter key to perform the Set command and save the name.