

Special

OSD

Focus

IR

Camera title

☒ Enable

Add

Delete

Preview

Title overlay  
[A~Z,a~z,0~9,Space,.. -  
#\*+/( )\_,]

X

Y

I85 Westbo

↑

↓

←

→

-



+

1

-



+

18

Date &amp; Time

☐ Enable

Weekday  
overlay

Format

X

Y



MM-DD-YYY ▼

-



+

1

-



+

3

Size

Medium ▼

Color

Green ▼

Transparency

Solid ▼

Overlay

☒ PTZ position☒ Preset name☐ Camera ID☒ Azimuth

Apply

Cancel

## OSD

Display the camera title or the date and time, and set the location, size, color and transparency of the characters.

### Camera title

Sets whether or not to display the camera title. When **[Enable]** is selected, the **[Add]**/**[Delete]** buttons will be activated.

When you click the **[Add]** button, a field where a camera title can be entered will be added to the list. Enter the title of your camera, and move the cursor to set its location. Up to 5 camera titles can be added.

To delete a camera title, select the title to delete and click the **[Delete]** button. To preview how the camera title is displayed on the screen after entering it, enter the camera title and click the **[Preview]** button.

### Date & Time

To display the date and time on the screen, select **[Enable]**. Select the date display type and set the position to display the date and time by moving the cursor.

### Size

Adjust the size of OSD.

### Color

Set the color of OSD.

### Transparency

Set the transparency of OSD.

### Overlay

Display the camera's PTZ coordinates, or preset names on the screen.

- **PTZ position:** Sets whether to display the PTZ location on the screen or not.
- **Preset name:** Sets whether to display the preset name on the screen or not.
- **Camera ID:** Sets whether to display the camera number on the screen or not.
- **Azimuth:** The function is used to display the azimuth of the area that you are looking at on the screen currently. When the function is enabled, the 8 directions of E(East)/W(West)/S(South)/N(North)/NE(Northeast)/NW(Northwest)/SE(Southeast)/SW(Southwest) are displayed at the bottom right of the screen.

#### Note

- In case of the item with a location that can be adjusted (camera title, date & time, overlay image, and system info), if it overlaps with other fixed OSD items, the screen may fail to display it properly. (Some cameras do not support [Overlay image] or [System info] option.)
- The 'camera ID' in [Overlay] is displayed at the left top of screen while the 'PTZ position' is displayed at the left bottom of screen; The locations cannot be changed.