

CONTROLLED COPY



PT. SINKO PRIMA ALLOY

Alamat : Jl. Tambak Osowilangun Permai No. 61,
pergudangan osowilangun permai Blok E7-E8,
Surabaya-Indonesia (60191)

Telepon : 031-7482816

Fax. : 031-7482815

Aftersale (WA) : 0821-4281-7085

Email : aftersales@elitech.co.id
sinkoprime@gmail.com

Website : www.elitech.id

SPA-BM/PROD-162. 15 Oktober 2024. Rev01

Chapter 1 Main Technical Specifications Operating Light LED

1.1 Normal working environment

Operating environment

- a) Temperature : 15°C ~ 30°C
- b) Relative humidity: 40% ~ 60 %RH
- c) Atmospheric pressure: 860~1060 hpa

Storage and Transfer

- a) Ambient temperature : 15°C ~ 30°C
- b) Relative humidity: 40%~60 %RH
- c) Atmospheric pressure: 500~1060 hpa

FULL SPECIFICATION Operating Light LED

| | | |
|-------------------------------|--------|-----------------------------------------------|
| Model | | MOL-02 (2 LAMPU) |
| Lamp dimensions | | 500 (Ø) mm, 135 (T) mm |
| Material | | Aluminium alloy dan PC |
| Weight | | ± 68 kg |
| Power | | ± 102 W |
| Life time | | 30000 hours |
| LED Lamp Quantity | Lamp 1 | 54 pcs |
| | Lamp 2 | 54 pcs |
| Lamp Radiation Exposure Ratio | Lamp 1 | ± 296 mW/m ² |
| | Lamp 2 | ± 296 mW/m ² |
| Lamp Color Temperature | Lamp 1 | 3500-5000K |
| | Lamp 2 | 3500-5000K |
| Lamp Light Intensity | Lamp 1 | > 40.000 Lux (100 cm) - > 160.000 Lux (60 cm) |
| | Lamp 2 | > 40.000 Lux (100 cm) - > 160.000 Lux (60 cm) |
| Light Spot Diameter | Lamp 1 | 300 mm (1m) |

| | | |
|--|--------|-------------|
| | Lamp 2 | 300 mm (1m) |
|--|--------|-------------|

| | | |
|----------------------------|----------------------|-----------------------------------|
| Lamp Illumination Depth | Lamp 1 | 130 mm |
| | Lamp 2 | 130 mm |
| Color Rendering Index (Ra) | Lamp 1 | Ra:91.5 ; R9:81 ; R13:95 : R14:92 |
| | Lamp 2 | Ra:91.5 ; R9:81 ; R13:95 : R14:92 |
| Normal Usage Condition | Temperature | 15~30°C |
| | Relative Humidity | 40%~60% RH |
| | Atmospheric Pressure | 860 ~ 1060hpa |
| Transport and Storage | Temperature | 15~30°C |
| | Relative Humidity | 40%~60% RH |
| | Atmospheric Pressure | 500 ~ 1060hpa |

Chapter 2 Security Warning

- 2.1 This tool is recommended for use by adults and children.
- 2.2 Please read this guide carefully before operating unit and operate the tool in accordance with the operating regulations.
- 2.3 Unit need to be cleaned after use with aerosol treatment.
- 2.4 Cleanup needs to be done once in a day.
- 2.5 It should not be used to process anesthetic and the use of a viscous fluid.
- 2.6 Please do turn off and unplug the power cord supply before cleaning and wipe dry.
- 2.7 Do not use while bathing.
- 2.8 Turn off the unit first before refilling.
- 2.9 Keep the unit out of the fire.

Chapter 3 Rules of Maintenance

1. Under normal conditions use according to this unit Use Directive, if this unit has some problems please contact our customer service. The company has sales records and customer records for each unit that received a one-year service warranty from the date of initial purchase depending on the conditions and time.
2. Although in the free maintenance period, we charge for repairs for the following reasons:
3. Errors on use caused by operation outside of the instructions for the use of the unit.
4. (Damaged by knocks, falls or other errors, non-working of the unit due to exposure to water or other faults)
5. The error caused by the fall when the user has left the purchase location.

6. Mistakes on preparation, reconstruction, decomposition and others beyond the standard of our company.
7. Damage caused by natural disasters such as fire, flood, earthquake and others.

Chapter 4 Notice before Operation

1. Read these instructions carefully before operating to ensure that the unit can be used safely and effectively.
2. Installation and maintenance of the equipment shall be carried out in accordance with these instructions.
3. This unit should be placed in a flat place. Put it in a bright spot when it is moved. Avoid shock vibrations and shocks.
4. AC frequency and voltage value shall be in accordance with the requirement, and have sufficient current capacity.
5. Please put this unit in an easy place for earthing.
6. Check all equipment, whether installed properly and correctly and in accordance with the place

Chapter 5 Grounding and Electrical Connections to the Operating Light LED

Earthing:

- 5.1 Connect the unit to the ground and the power source outlet via a three-way power cord (3-wire plug). The three-wire plug must be inserted into the three-wire cable outlet correctly.
- 5.2 If a three-wire outlet is not available, an eligible electrician shall install one unit in accordance with CONSILER or AUTHENTIC rules in Indonesia.
- 5.3 Under no circumstances do not discharge the grounding conductor of the electric steaker.
- 5.4 Do not use any connection cable or adapter. The power cord and the steaker must be intact and undamaged.
- 5.5 Do not use pipelines and others as grounding.
- 5.6 Proper grounding can ensure safety and guard against interference of AC power and electromagnetic waves.

Electrical Connections to Operating Light LED :

- 5.7 Make sure the AC power supply complies with the following specifications.
- 5.8 Connect the power supply / steaker cable from the unit to the socket that has been grounded / grounded properly and correctly.
- 5.9 Make sure the power indicator light on the unit is on.
- 5.10 If the power cord is not connected properly before operating the unit, it is possible that the unit is not working perfectly due to inefficient power input.

Chapter 6 Operation of the Operating Light LED

1. Connect the power cord to the power socket
2. Turn on the ON button
3. Put the check lamp in the desired position
4. Focus the LED light on the patient / object
5. Adjust the lighting buttons as desired
6. Perform an Operating
7. Done check OFF OFF button
8. Disconnect the power cord from the electrical socket
9. Keep the check lamp in place

Chapter 7 Troubleshooting Troubleshooting on Users

| No | Problem | Solution |
|----|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 | Off total | <ul style="list-style-type: none">• Check power connection to power source• Check the power cable socket connection with the avometer• Check the fuse cable connection with avometer |
| 2 | Not working | <ul style="list-style-type: none">• Check the power indicator indicator is not on• Check the normal voltage is not |

Chapter 8 Care and Maintenance

1. The buyer is not permitted to open or disassemble the contents in the unit. Any maintenance or renewal shall be performed by an authorized person and an authorized professional of PT. Sinko Prima Alloy. Maintenance must be done with original components from PT. Sinko Prima Alloy.
2. Please apply to withdraw the steaker power supply when the electric power is about to be switched off. If the unit is not used for long periods of time, please draw the steaker power supply from the power source, then place the unit in a cool, cool and dry place.
3. Then unit should be maintained and cleaned regularly.

How to clean Elitech Operating Light LED as follows :

1. Firstly the power cord must be removed from the power source.
2. Prepare a cloth containing clean water without cleaning material and then rub it evenly over the entire unit.
3. Use a clean, dry cloth to dry, until the entire unit is completely dry and clean

Surgical Lamp

MOL-02

(2 Lamp)

Manual Book

CONTROL

CONTROLLED COPY

CONTROLLED COPY