

NLS-EM1300

1D Barcode Scanning Engine

Integration Guide



© 1999-2008 by Newland Auto-ID Tech. Co., Ltd, All rights reserved.

No part of this publication may be reproduced, transmitted, or used in any form or by any means, electrical or mechanical, without prior written permission from Newland Auto-ID. The material in this manual is subject to change without notice.

All software, including firmware, is provided strictly on an “as is” basis and is provided without further warranty. Newland Auto-ID grants to the user a non-transferable and non-exclusive license to use each software or firmware program delivered hereunder (licensed program). Except as noted below, such license may not be assigned, sublicensed, or otherwise transferred by the user without prior written consent of Newland Auto-ID. No right to copy a licensed program in whole or in part is granted except as permitted under copyright law or as hereinafter expressly provided. The user agrees to maintain Newland Auto-ID’s copyright notice on the licensed programs delivered hereunder, and to include the same on any authorized copies it makes in whole or in part. The user agrees not to decompile, disassemble, decode, or reverse engineer any licensed program or product delivered to the user or any portion thereof.

Newland Auto-ID reserves the right to make changes and improvements to any software or product for reliability, function, or design.

Newland Auto-ID does not assume any responsibility or liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein.

No license is granted, either expressly or implicitly, estoppels, or otherwise under any Newland Auto-ID intellectual property rights. An implied license only exists for equipment, circuits, and subsystems contained in Newland Auto-ID products.

Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation. All other product or service names are the property of their respective owners.

Newland Auto-ID Tech. Co., Ltd,



Content

About this guide

Introduction	1
Chapter Description	1
Graphic Notations	1
Newland Auto-ID Support Center	2

About EM1300

Introduction.....	3
Highlights of the EM1300	3
Get Familiar With EM1300	4
Unpacking.....	4
Outline of EM1300	4
EM1300 Decode Zone	5
Decode Distances.....	5
EM1300 Overall Specifications.....	6

Mechanical Interface

Introduction.....	7
Dimensions of EM1300 Unit.....	8
EM1300 Front View	8
EM1300 Right Side View	8
EM1300 Bottom View	8
Interface Socket	9
Interface Socket Pin Assignment and Definitions	9
Housing Design Considerations.....	10
Housing Structure	10
Scan Window	10
Temperature	10

Electrical Interface

Introduction.....	11
Interface Signal levels.....	12
Input signals.....	13
Trigger Input	13
A Sample Schematic of Trigger Input Circuit	13
Output Signals.....	14
LED Output	14
Beeper Output.....	14
A Sample Schematic of LED Circuit:	15
A Sample Schematic of Beeper Circuit:	15





Software Interface

Introduction.....	16
Trigger EM1300 for a Reading.....	17
Hard Trigger.....	17
Auto Scan.....	17
Continuous Scan Mode.....	17
Serial Port Communication	18
EM1300 Initiated Data Upload.....	18
Barcode Message	19

EM1300 Development Tools

Introduction.....	20
EM1300 Evaluation Kit, EVK1300.....	21
Software Development Kit	22

Overall Setup

Introduction.....	23
Code Programming	23
Command Programming.....	23
Programming Notation	24
Code Programming On/Off.....	25
Code Programming	25
Programming Outline	26
Command Programming.....	26
Default	27
Factory Default	27
Working Mode	28
Mode Select	28
Working Mode Parameters	29
For all modes	29
For Interval Mode Only	29
For Sensor Mode Only.....	29
For Auto Mode Only.....	29
Security Level	30
Security Level.....	30
Beeper	31
Beeper	31

Query Command

Introduction.....	32
-------------------	----

RS232 Interface

Introduction.....	33
-------------------	----





Serial Port Programming	34
Check	35
Stop Digit	35
Flow Controlling.....	35
KBW Programming	36
Keyboard Layout	36
Inter-character Delay	37
Characters Transformation.....	37
CapsLock	37

Data Format

Introduction.....	38
Prefix Sequences.....	39
User Prefix	40
Disable or Enable User Prefix	40
Program User Prefix	40
AIM Prefix.....	41
AIM Prefix definitions.....	41
Code ID Prefix	42
User Suffix	43
Disable or Enable User Suffix	43
Program User Suffix	43
Stop Suffix	44
Disable or Enable Stop Suffix	44
Program Stop Suffix	44

Symbols

Introduction.....	45
Symbols Available	45
Code 128.....	46
Load Factory Default.....	46
Enable/Disable Code 128	46
Code 128 Code ID	46
Select Message Length	47
Check Digit	48
UCC/EAN-128.....	49
Load Factory Default.....	49
Enable/Disable UCC/EAN-128	49
UCC/EAN-128 Code ID	49
Select Message Length	50
Check Digit	51
AIM 128.....	52
Load Factory Default.....	52
Enable/Disable AIM 128	52
AIM 128 Code ID	52
Select Message Length	53





ISBT 128	54
Load Factory Default	54
Enable/Disable ISBT 128	54
ISBT 128 Code ID	54
EAN-8	55
Load Factory Default	55
Enable/Disable EAN-8	55
EAN-8 Code ID	55
2 Digits Addenda Code	56
5 Digits Addenda Code	56
EAN-8 expand to EAN-13	57
Check Digit	57
EAN-13	58
Load Factory Default	58
Disable/Enable EAN-13	58
Check Digit	59
EAN-13 Code ID	59
2 Digits Addenda Code	60
5 Digits Addenda Code	60
ISSN	61
Load Factory Default	61
Enable/Disable ISSN	61
ISSN Code ID	61
ISBN	62
Load Factory Default	62
Enable/Disable ISBN	62
ISBN Digits	63
ISBN Code ID	63
UPC-E	64
Load Factory Default	64
Disable/Enable UPC-E	64
Check Digit	65
UPC-E Code ID	65
2 Digits Addenda Code	66
5 Digits Addenda Code	66
Transmit Default "0"	67
UPC-E Expand to UPC-A	67
UPC-A	68
Load Factory Default	68
Disable/Enable UPC-A	68
UPC-A Code ID	68
Check Digit	69
Transmit Default "0"	69
2 Digits Addenda Code	70
5 Digits Addenda Code	70
Interleaved 2 of 5	71
Load Factory Default	71
Disable/Enable Interleaved 2 of 5	71
Interleaved 2 of 5 Code ID	71





Check Digit	72
Select Message Length	73
ITF-6	74
ITF-6 Code ID	74
ITF-14	75
ITF-14 Code ID	75
Deutsche14	76
Load Factory Default	76
Disable/Enable Deutsche14	76
Deutsche14 Code ID	76
Deutsche12	77
Load Factory Default	77
Disable/Enable Deutsche12	77
Deutsche12 Code ID	77
COOP25 (Japanese Matrix 25)	78
Load Factory Default	78
Enable/ Disable COOP25	78
COOP25 (Japanese Matrix 25) Code ID	78
Check Digit	79
Select Message Length	80
Matrix 25(Europe Matrix 25)	81
Load Factory Default	81
Enable/ Disable Matrix 25	81
Matrix 25 Code ID	81
Check Digit	82
Select Message Length	83
Industrial 25	84
Load Factory Default	84
Enable/ Disable Industrial 25	84
Industrial 25 Code ID	84
Check Digit	85
Select Message Length	86
Standard 25	87
Load Factory Default	87
Enable/ Disable Standard 25	87
Standard 25 Code ID	87
Check Digit	88
Select Message Length	89
Code 39	90
Load Factory Default	90
Enable/Disable Code 39	90
Code 39 Code ID	90
Check Digit	91
Transmit Start & Stop Character	92
Decode ASCII	92
Select Message Length	93
Codabar	94
Load Factory Default	94





Enable/Disable Codabar	94
Codabar Code ID	94
Check Digit	95
Transmit Start & Stop Character.....	96
Select Message Length	97
Code 93	98
Load Factory Default	98
Enable /Disable Code 93	98
Code 93 Code ID	98
Check Digit	99
Select Message Length	100
Code 11	101
Load Factory Default	101
Enable/ Disable Code 11.....	101
Code 11 Code ID	101
Check Digit	102
Select Message Length	103
Plessey	104
Load Factory Default	104
Enable/ Disable Plessey	104
Plessey Code ID.....	104
Check Digit	105
Select Message Length	106
MSI-Plessey	107
Load Factory Default	107
Enable/ Disable MSI-Plessey	107
MSI-Plessey Code ID	107
Check Digit	108
Select Message Length	109
RSS	110
Load Factory Default	110
Enable/ Disable RSS.....	110
RSS Code ID.....	110

Appendix

Digit Code.....	111
Save and Abort.....	113





About this guide

Introduction

This NLS-EM1300 (“EM1300”) Scan Engine Integration Guide provides general instructions for OEM integration.

Chapter Description

About EM1300: The chapter of About EM1300 gives a brief description of the EM1300. It covers the general, overall specifications of the EM1300.

Mechanical Interface: The chapter of Mechanical Interface describes the mechanical interface of the EM1300. It includes the dimensions and locations of EM1300 mechanical components.

Electrical Interface: The chapter of Electrical Interface describes the electrical interface of the EM1300. It mainly explains the EM1300 interface socket and flexible cable. Samples of schematics are also included.

Software Interface: The chapter of Software Interface describes the software interface of EM1300.

EM1300 Development Tools: The chapter of EM1300 Development Tools lists the development tools and brief descriptions of the tools.

Programming the Engine: The chapter of Configuration lists all the configurations of EM1300. The configuration can be done through pre-printed configuration barcodes, serial port commands, and/or Quickset, a Newland software package.

Graphic Notations



Tool – Handy item for a task.



Attention – Important subject to be aware of or to avoid.



Tips – Helpful information about a topic or a feature.



Example – Illustration of how to use a feature.



About this guide

Newland Auto-ID Support Center

If you have a problem with your equipment, contact the Newland Support Center in your region. Before calling, have the model number, serial number, and several of your barcodes at hand.

Call the support Center from a phone near the scanning equipment so that the service person can try to talk you through your problem. If the equipment is found to be working properly and the problem is barcode readability, the Support Center will request samples of your bar codes for analysis at our plant.

If your problem cannot be solved over the phone, you may need to return your equipment for servicing. If that is necessary, you will be given specific directions.

Note: Newland Auto-ID Tech. is not responsible for any damages incurred during shipment.

For service information, warranty information or technical assistance contact or call the Support Center listed below. For the latest service information go to <http://www.nlscan.com>





About EM1300

Introduction

EM1300 is an embedded barcode reading engine. Its gray scale CCD image capturer and the Newland patented UIMG, a Computerized Image Recognition System, ensure the fast scanning and decoding accuracy on different barcode media such as paper, plastic card, and metal surface. It can be easily integrated into OEM equipments or systems (hand-held, portable, and mounted) to provide solutions for image capture, barcode reading, and barcode message processing.

EM1300 Software Development Kit is provided for easy and quick development of OEM applications.

Highlights of the EM1300

- » Compact design allowing easy integration into OEM equipments and systems.
- » Outstanding decoding performance for major 1D barcodes.
- » High performance CPU ensuring fast and accurate scans.
- » Easy OEM software development and firmware upgrade.





Unpacking

Remove EM1300 and accessories from the package. Check for missing parts and inspect for damage. EM1300 is packed in anti-static bag. Please handle accordingly.



If there is any damage or missing parts, please contact your supplier at once. Keep the original package for return services, if necessary.

Outline of EM1300

The outline of EM1300 is shown in Figure 1. The topside has the electrical control components, including a flexible cable socket, Interface Socket, through which EM1300 interfaces with external device.

The front side has the optical components, such as Image Lens, through which EM1300 captures image, Aiming Light, which sends a rectangular, green light beam for aiming, and, illumination lights, which illuminates the barcode.

The bracket covers the sides and bottom of the Engine. Two mounting holes on the bottom side are available for mounting the Engine to external device.

The back side is CCD circuit for image capture.





Figure 1. EM1300 Outline



Here is the EM1300 Decode Zone.

The view angle of the camera is 42° . Following figure shows the decode zone of the engine.



L: The minimum window of OEM device
D: The distance of the engine scan window to the OEM device window

Decode Distances

Following table lists the decode ranges of EM1300 for different barcode types and densities.

Barcode	Density (mil)	Near (mm)	Far (mm)
1D Code	5	40	90
*PDF417	5	40	90
*PDF417	10	30	180

*: In order to read PDF417, EM1300 needs a module which customers ordered specially.



Performance

CPU	72M
Memory	SRAM: 20K , Flash 128K
Interface	TTL232
Image Sensor	CCD
Resolving	2500
Decode rate	200 decodes/sec (default) , 500 decodes/sec (MAX)
Symbologies	Code128, EAN-13, EAN-8, Code39, UPC-A, UPC-E, Codabar, China post 25, Interleaved 2 of 5, ISBN/ISSN, Code 93, etc.
Precision	≥ 4mil
Light Source	LED(622 nm - 628 nm)
Light Intensity	265 LUX (130 mm)
Depth of Scan Field	20 mm ~ 500 mm
Print Contrast Signal	≥ 25%
Pitch	30°
Yaw	45°
Illumination	0 ~ 100,000 LUX

Mechanical/ Electrical

Power Consumption	0.2 W
Voltage	DC 3.3 V
Current	Max 62 mA
	Working 33 mA
	Idle 1 μ A
Weight	18g

Environment

Operate Temperature	-5℃ - +45℃
Storage Temperature	-40℃ - +60℃
Humidity	5% - 95% (non-condensing)
Certificates	FCC Part15 Class B, CE EMC Class B



Mechanical Interface

Introduction

This section describes the Mechanical Interface.





EM1300 Front View

Following figures show the dimensions of EM1300. The figure 2 EM1300 Front View has the width and height dimensions. The height of the EM1300 is from the bottom of EM1300 to the top of highest component on the topside.




Figure 2. EM1300 Front View

EM1300 Right Side View

The Figure 3 EM1300 Right Side View has the length dimensions.




Figure 3. EM1300 Right Side View

EM1300 Bottom View

The figure 4 EM1300 Bottom View has the mounting screw specifications. The mounting screw is M1.4, 1.4mm screw. The length of the screw into EM1300 must be less than 3 mm.




Figure 4. EM1300 Bottom View



EM1300 uses a 12-pins flex cable socket to interface with external device (Host), such as EVK1300, the EM1300 Evaluation Kit. Figure 5 below shows the socket. For reference purpose, the EM1300 Evaluation Kit uses a connector, part number MOLEX 527451296, to connect the flex cable.




Figure 5. Interface Socket

Interface Socket Pin Assignment and Definitions

Pin	Signal Name	Type*	Description
PIN 1	Flash Download	I	Operation Mode Control: » Flash Download Mode – Level Low when engine is powered on; » Normal Mode – otherwise.
Pin 2	VCC	P	DC 3.3 ± 0.3V
Pin 3	Ground	P	Ground
Pin 4	RXD	I	RS233 Receiving, TTL
Pin 5	TXD	O	RS232 Transmission, TTL
Pin 6	Reserved for CTS	I	Reserved for CTS, not implemented
Pin 7	Reserved for RTS	O	Reserved for RTS, not implemented
Pin 8	N/C	I	Not connected
Pin 9	Beeper	O	Beeper output, low current output
Pin 10	DLED	O	Decode LED, low current output
Pin 11	N/C		Not connected
Pin 12	Trigger	I	Trigger read and decode

* Pin Type Definitions: I – Input, O – Output, and P – Power.





Housing Structure

The housing for the Engine should make sure that no pressure should be put on the Engine. There should have sufficient space for the flexible cable and stress release of the cable should also be considered.

Scan Window

A scan window is needed to protect camera lens, aiming light, and illumination lights. This scan window design should follow:

- » Housing must not block or shade illumination LED' s aiming light, and camera lens.
- » Use high transparent and scratch resistant material. Please refer to following specifications:

Total light transmittance (%)	≥90% (ASTM D 1008)
haze (%)	<1.0% (ASTM D 1008)
Stylus	≥4H (JIS K 5400)

- » The gap between housing window and illumination LED (highest point) should be less than 5 mm.
 - » The window must be perpendicular to the surface of the front plate of the EM1300.
-

Temperature

Electrical and other components generate heat. Especially under continuous operation, the temperature of the Engine will be high. The methods below are for heat concerns:

- » A radiator on top of the engine is recommended
- » Do not surround or wrap the Engine by rubber or any material that obstruct the heat dissipation.





Electrical Interface

Introduction

This section describes the electrical specifications of the interface signals.





The table below lists the interface input and output level voltage ranges

Signal Type	Voltage Level	Voltage Range
Input	High	2.0V - 3.6V
	Low	-0.3V - 0.6V
Output	High	2.4V - 3.3V
	Low	0V - 0.4V
Serial Input		3.3V
Serial Output		3.3V





Electrical Interface


Input signals

Trigger Input

When the Trigger line is pull low for 10 ms, the Engine starts a read. The Engine keeps reading until a successful reading or the line is high. After a successful reading, the line must go high in order to make another read.

A Sample Schematic of Trigger Input Circuit

Here is a schematic from the evaluation board, EVK1300. The signal can connect to external device's output port.





Here are the descriptions of the output signals, beeper and LED. They can be used to detect the status of the scanning and the state of the Engine.

LED Output

When the Engine completes the initialization, the LED line is high. The LED line goes low for 50 ms twice with 50 ms in between after a successful reading and, if programmed, transmission of the code message.

Beeper Output

Table below is the definitions of the beeper outputs:


Beep Pattern	Definition
Low-higher-higher-higher	Power ON completed
1 beep	Successful reading of an ordinary barcode
2 beeps	Successful reading of a programming barcode
3 short low-2 high	Reading failure
1 long low	Unknown Character, Virtual Keypad (USB connection)






A Sample Schematic of LED Circuit:

Here is the LED circuit used in the evaluation board, EVK1300.



A Sample Schematic of Beeper Circuit:

Here is a beeper circuit used in the evaluation board, EVK1300.





Software Interface

Introduction

The simplest way to interface with EM1300 is to just listen to the serial output from the Engine. Leave the trigger, reset, beeper, and LED signals to the hardware. With proper configuration, the default firmware will send the decoded barcode messages through the serial output. However, if more controls of the Engine are required, the rest of this section describes the software interface with the Engine.





EM1300 will start a reading when the trigger pin of the flex cable is pulled low (hard trigger) or when EM1300 is configured in the sensor mode and it senses the trigger condition is met (auto scan).

Hard Trigger

If the trigger line is connected to an output port of external device, the control software of the external device (Host) can pull the line low. The Engine will start to read barcode after 10 ms. The engine will keep reading until it acquired a barcode image that has a recognized barcode, valid or not.

If a valid reading is found, the default function is that the beeper line will send a 1-beep pattern and the decoded barcode message will be sent through the serial out line.

Auto Scan

The Engine can be in sensor mode (or auto scan mode.) (See Configuration section for detail.) When the ambient light changes, the Engine will automatically make a read. If a valid read is found, the default function is to send the decoded barcode messages.

Continuous Scan Mode

Another scan mode is continuous scan mode. When the Engine is in this mode it will keep acquiring images and trying to read a code. When it reads a code it sends the code to the serial port.





This section introduces the serial communication. The default serial port configuration is baud rate of 9600, 8 data bits, no parity bit, and 1 stop bit. It is important to match the serial port configuration between EM1300 and the Host. Both EM1300 and Host can initiate communication.

EM1300 Initiated Data Upload

EM1300 initiates communication only to send system information on power on, when enabled, and barcode messages. No reply from Host is expected.

System Information

Name	Description
Dev	Device type
Ver	BIOS version
Date	BIOS version establishing time
S/N	Device serial number
ESN	User-defined device serial number
Interface	1 types of communication interfaces:RS232, baud rate, parity check, data bits, stop bit
1D	List of enabled 1D symbols. Each code is divided by comma. Additional features of the code are appended as: 1. “+” connects features 2. Min Message Length -> Max Message Length 3. “No Check Digit” or “Check Digit” 4. “Fixed Lengths: 2~64, even value” in the form of 2 4 6 8 10 12...
Scan Mode	Scan Mode: 1. Manual Scan = “Hand-held Mode” 2. Auto Scan = “Continuous Mode” 3. Induced Scan = “Sensor(smart) Mode”





The message upload format is in binary. It is the binary value of the decoded barcode value including prefix, suffix, and so on.

There are two methods to determine the end of barcode message.

Method 1: LED Signal

At end of the data upload, the Engine will set the LED line low for 150 ms.

Host can read the LED line input to detect the end of data upload, if the line is connected to the input port.

Method 2: Inter-Character Timeout

Host could use inter-character timeout to determine the end of data upload. An inter-character timeout means the longest delay time between 2 consecutive (binary) characters in a sequence of (binary) characters sent over serial line. It is usually enabled only after the first character is received to avoid unwanted timeout events during the waiting of a message.

The inter-character timeout value should be set to about 5 times of a character's transmission time. When the inter-character timeout occurs, it is the end of data upload. For example, 5 ms can be used as an inter-character timeout for the baud rate of 9600, 8 data bit, no parity bit, and one stop bit.





EM1300 Development Tools


Introduction

Sections below list some EM1300 development tools. A brief introduction to each tool is included.





Here is a brief introduction to the EM1300 Evaluation Kit, EKV3000. The layout of the EVK1300 circuit board is shown in figure below. The board contains beeper, LED, trigger button, and reset button. A USB connector is for the power and communication. An alternative RS232 is for communication. The J1 connector is where the EM1300 flex cable connects to.





A software development kit is available for all EM series embedded engines. It allows Customers to develop their applications in EM series engines.





Overall Setup

Introduction

There are 2 ways to program (configure) the Engine, Code Programming and Command Programming.

Code Programming

The Engine reads a set of specially encoded barcodes to program options and features. In the following sections, we will explain the options and features available and provide the barcodes to program them.

This method of programming the Engine is most straight forward. However, it requires manually readings of each barcode. As all manual operations, errors are more likely to occur.

Command Programming

The Host can send the Pro CMD strings to program the Engine. In the following sections, the Pro CMD strings will be included with the barcodes for Code Programming.

This method of programming the Engine could be automated. A software program can be developed to download all the configuration data to the Engine. The program can also verify the download.

Note: The programming results are restored in non-volatile memory. They will not be lost when the Engine is powered off.





** Code Programming Off
【Pro CMD: 99900032】

Code Programming ON



Code Programming OFF



This is the notation to disable the Code Programming.

There are 3 parts of a notation:

- » The first part of the notation is the barcode for Code Programming
- » The second part of the notation is the name of the options or features, such as Disable Code Programming. If there is “**” in front of the name, it means the notation is factory default.
- » The third part of the notation is the corresponding Pro CMD string of the Code Programming.





Read the “Code Programming ON” barcode to activate “Code Programming” function. More than one Code Programming barcodes can be read to configure the Engine.

If an option or feature needs additional parameters, such as digits, they can be found at the end of this chapter.

The value of code programming can be sent to the Host. For factory default, “No Send Pro Code Value”, the value of programming codes will not be sent to the Host; by reading “Send Pro Code Value”, the reader will send the value of Programming Code to the Host.

Code Programming ON



Code Programming OFF



Code Programming

In order to avoid misreading, "Code Programming On" barcodes should be read to activate "Code Programming" before reading programming barcodes. After programming, "Code Programming OFF" barcode or any common barcode (not programming barcodes) should be read to quit configuration.

Some working parameters could be programmed. The data type of parameters is Dec or Hex and the numbers are also input through programming barcodes. The Appendix of the Integration Guide includes all needed data barcodes.

Programming barcodes are used to program the engine. For factory default, the reader will not send code value to the Host. But if needed, the engine could be programmed to "Send Pro Code Value". And whether the value is sent or not won't affect the programming function.



Code Programming ON
【Pro CMD: 99900031】



** Code Programming OFF
【Pro CMD: 99900032】



** No Send Pro Code Value
【Pro CMD: 99900033】



Send Pro Code Value
【Pro CMD: 99900034】

1、 Configuration State

Sending certain command to the engine will make it enter or quit the configuration state. Or if in configuration state the engine hasn't received new information for five seconds, the engine will quit the state automatically.

- ※ Sending “\$\$\$\$” and receiving “@@@@” mean entering configuration state successfully.
- ※ Sending “%%%%” and receiving “^^^” mean quitting configuration state successfully.
- ※ Receiving “^^^” in configuration state means that the engine has quitted the state automatically.
- ※ In configuration state, every command begins with “#” and ends with “;”. E.g. “#99900030;”

※ In configuration state, if the command is invalid or executed unsuccessfully, the Host will receive a command which begins with “?” and ends with “;” E.g. “999976543;”

If feedback information may have undisplayable characters, it will be expressed in hexadecimal notation. Two characters represent a character value. E.g.

※ In configuration state, if a command is with parameters, it will be composed following the rules which command system defined. For example, the command string which has 0x0D and 0x0A as ending character and be saved is “#99904112;#99900000;#99900015;#99900000;#99900012;#99900020;”。

Overall Setup



Default



Tools

Factory Default

Code Programming ON



Read “Load All Factory Default” to reset all parameters to factory default.

Code Programming OFF



Applicable conditions:

- » User options programming wrong configuration leads to reading malfunction
- » Forget details of previous programming and start over.
- » Restore to default after unusual settings are not needed.



*Load All Factory Default
【Pro CMD: 99900030】





Mode Select

Code Programming ON



Code Programming OFF



Shut Down

【Pro CMD: 99900100】



Deep Sleep

【Pro CMD: 99900101】



Sleep

【Pro CMD: 99900102】



Test Mode

【Pro CMD: 99900103】



Restart

【Pro CMD: 99900104】



** Hand-held Mode

【Pro CMD: 99900110】



Auto Mode

【Pro CMD: 99900111】



Interval Mode

【Pro CMD: 99900112】



Sensor Mode

【Pro CMD: 99900113】



Continuous Mode

【Pro CMD: 99900114】



Overall Setup



Working Mode Parameters



Tools

For all modes



Time length to read a barcode
(Default 3 seconds.)
【Pro CMD: 99900150】

Code Programming ON



Code Programming OFF



For Interval Mode Only



Interval Length
【Pro CMD: 99900151】

For Sensor Mode Only



High Sensitivity
【Pro CMD: 99900152】



Low Sensitivity
【Pro CMD: 99900154】



Medium Sensitivity
【Pro CMD: 99900153】



User Sensitivity
(Level:0 to F)
【Pro CMD: 99900161】

For Auto Mode Only



Disable Reading Same Barcode
【Pro CMD: 99900155】



Restart Timer After a Valid Reading
【Pro CMD: 99900157】



Enable Reading Same Barcode
【Pro CMD: 99900156】



Do Not Restart Timer After a Valid Reading
【Pro CMD: 99900160】





Security Level

Code Programming ON



Code Programming OFF



Security Level 1
【Pro CMD: 99900120】



Security Level 3
【Pro CMD: 99900122】



Security Level 2
【Pro CMD: 99900121】



Security Level 4
【Pro CMD: 99900123】





Beeper

Code Programming ON



Code Programming OFF



No Beeper Output
【Pro CMD: 99900130】



** High Frequency & Loud Volume
【Pro CMD: 99900131】



High Frequency & Medium Volume
【Pro CMD: 99900132】



High Frequency & Low Volume
【Pro CMD: 99900133】



Medium Frequency & Loud Volume
【Pro CMD: 99900134】



Medium Frequency & Medium Volume
【Pro CMD: 99900135】



Medium Frequency & Low Volume
【Pro CMD: 99900136】



Low Frequency & Loud Volume
【Pro CMD: 99900137】



Low Frequency & Medium Volume
【Pro CMD: 99900140】



Low Frequency & Low Volume
【Pro CMD: 99900141】





Query Command

Introduction

After reading interrelated programming barcodes, the engine will feed information needed back to the Host to achieve the purpose of query.



Code Programming ON



Code Programming OFF



Query all the information of product
【Pro CMD: 99900300】



Query the hardware version
【Pro CMD: 99900301】



Query ID
【Pro CMD: 99900302】



Query Manufacturing Date
【Pro CMD: 99900303】



Query Factory Name
【Pro CMD: 99900304】



Query User ID
【Pro CMD: 99900305】



Query User Date
【Pro CMD: 99900306】



Query User Name
【Pro CMD: 99900307】



Query STM32 MCU ID
【Pro CMD: 99900310】



Communication Setup

Introduction

Under RS232 connection the engine and the Host use the same communication parameters: baud rate, parity check, data bits select and stop bits select.

The engine also supports virtual keyboard (KBW) and the configuration of KBW also be provided.





Under RS232 connection, the engine and the Host should set communication baud rate to the same to keep normal communication.

Baud rate is the bits transmitted per second (8 bits per bytes). The engine and the Host must communicate at the same baud rate.

The reader supports baud rate as the following:

Code Programming ON



Code Programming OFF



** 9600

【Pro CMD: 99902104】



1200

【Pro CMD: 99902101】



2400

【Pro CMD: 99902102】



4800

【Pro CMD: 99902103】



14400

【Pro CMD: 99902105】



19200

【Pro CMD: 99902106】



38400

【Pro CMD: 99902107】



57600

【Pro CMD: 99902110】



115200

【Pro CMD: 99902111】





Check

Code Programming ON



Code Programming OFF



**No Check

【Pro CMD: 99902104】



Even Check

【Pro CMD: 99902101】



Odd Check

【Pro CMD: 99902102】

Stop Digit



** Stop Digit 1

【Pro CMD: 99902131】

Flow Controlling



** No Flow Controlling

【Pro CMD: 99902140】





Keyboard Layout

The keyboard could choose any one of the sixteen layouts which were decided previously.

Code Programming ON



Code Programming OFF



No.0

【Pro CMD: 99902200】



No.1

【Pro CMD: 99902201】



No.2

【Pro CMD: 99902202】



No.3

【Pro CMD: 99902203】



No.4

【Pro CMD: 99902204】



No.5

【Pro CMD: 99902205】



No.6

【Pro CMD: 99902206】



No.7

【Pro CMD: 99902207】



No.8

【Pro CMD: 99902210】



No.9

【Pro CMD: 99902211】



No.10

【Pro CMD: 99902212】



No.11

【Pro CMD: 99902213】



No.12

【Pro CMD: 99902214】



No.13

【Pro CMD: 99902215】



No.14

【Pro CMD: 99902216】



No.15

【Pro CMD: 99902217】



Communication Setup



KBW Programming



Tools

Inter-character Delay



Program Inter-character Delay as 0 ~ 150 ms
【Pro CMD: 99902220】

Code Programming ON



Code Programming OFF



Characters Transformation



Normal
【Pro CMD: 99902230】



Lower
【Pro CMD: 999002232】



Upper
【Pro CMD: 999002231】



Inverse
【Pro CMD: 99902233】

CapsLock



Normal
【Pro CMD: 99902230】



Lower
【Pro CMD: 999002232】



Upper
【Pro CMD: 999002231】



Inverse
【Pro CMD: 99902233】





Data Format

Introduction

1D barcodes could contain digits, letters and symbols, etc. 2D barcodes could contain more data, such as Chinese characters and other multi-byte characters. However, in reality, they do not and should not have all the information we need, such as barcode type, date and time of scan, delimiter, and so on, in order to keep the code short and flexible.

Prefix and Suffix are how to fulfill the needs mentioned above. They can be added, removed, and modified while the original barcode message is still in tact.



Barcode processing sequences:

1. Intercept barcode message
 2. Add Prefix/Suffix
 3. Pack
 4. Terminate with Stop Suffix and transmit
-





Code Programming ON



Code Programming OFF



** CodeID+User Prefix
【Pro CMD: 99904010】



User Prefix+CodeID
【Pro CMD: 99904011】





Disable or Enable User Prefix

User Prefix is added before barcode message. For example, if the user prefix is “AB” and the barcode message is “123” , the Host receives “AB123” .

Code Programming ON



Code Programming OFF



** Disable User Prefix
【Pro CMD: 99904020】



Enable User Prefix
【Pro CMD: 99904021】

Program User Prefix

Enable “Program User Prefix” . Then program user prefix byte(s). To end the prefix, read “Save programming” The user prefix byte is programmed in its hex values. See example below.

Note: The maximum length for user prefix is 10 bytes.



Program User Prefix
【Pro CMD: 99904022】

Example

Program “CODE” as user prefix (The hex of “CODE” are 0x43/0x4F/0x44/0x45):

1. Read “Code Programming ON”
2. Read “Program User Prefix”
3. Read “4,3,4,F,4,4,4,5” in order
4. Read “Save Programming”
5. Read “Code Programming OFF” .
6. Read “Allow User Prefix” to enable above programming. “CODE” will appear to the left of a barcode.





Data Format

AIM Prefix



Tools

AIM (Automatic Identification Manufactures) defines AIM prefix for many standard barcode formats. The engine will add the identifier before the barcodes. And this identifier is the AIM Prefix.

Code Programming ON



Code Programming OFF



****No AIM Prefix**
【Pro CMD: 99904030】



Full Characters Mode
【Pro CMD: 99904031】

AIM Prefix definitions

Symbols	AIM ID	Hex
Code128 / UCC/EAN-128	C	43
UPC-E / UPC-A / EAN-8 / EAN-13	E	45
Interleaved 2 OF 5 / China Post25	I	49
Code39	A	41
Codabar	F	46
Code93	G	47





Besides AIM prefix, Code ID prefix can be used to denote barcode format and can be customized.

The Code ID prefix MUST be one (1) visible English letter, only.

Code Programming ON



Code Programming OFF



** No Code ID Prefix
【Pro CMD: 99904040】



Allow Code ID Prefix
【Pro CMD: 99904041】



Load Code ID Factory Default
【Pro CMD: 99904042】

Symbols	Code ID Default	Hex
Code128 / UCC/EAN-128	j	6A
UPC-E / UPC-A	c	63
EAN-8 / EAN-13	d	64
Interleaved 2 OF 5 / China Post25	e	65
Code39	b	62
Codabar	a	61
Code93	i	69





Disable or Enable User Suffix

User suffix is appended to the right of barcode message. For example, if user suffix is “AB” , and the barcode message is “123” , The Host receives “123AB” .

Code Programming ON



Code Programming OFF



**Disable User Suffix
【Pro CMD: 99904100】



Enable User Suffix
【Pro CMD: 99904101】

Program User Suffix

Read “Program User Suffix” . Then program user suffix byte(s). To end the suffix, read “Save programming” . The user suffix byte is programmed in its hex values. See example below.

Note: The maximum length for user suffix is 10 bytes.



Program User Suffix
【Pro CMD: 99904102】

E xample

Program “CODE” as user suffix (The hex of “CODE” are 0x43, 0x4F, 0x44, and 0x45):

1. Read “Code Programming ON”
2. Read “Program User Suffix”
3. Read “4,3,4,F,4,4,4,5” in order
4. Read “Save Programming”
5. Read “Code Programming OFF”
6. Read “Allow User Suffix” to enable above programming. “CODE” will appear to the right of a barcode.





Disable or Enable Stop Suffix

“Stop Suffix” is the termination for a string of barcode messages. It can not be formatted like other suffix and prefix. It is fixed to the right and the very end of a barcode transmission.

The major difference between "Stop Suffix" and "User Suffix" is that the information and the decoded messages in user suffix could be formatted but couldn't in stop suffix.



****Disable Stop Suffix**
【Pro CMD: 99904110】



Enable Stop Suffix
【Pro CMD: 99904111】

Code Programming ON



Code Programming OFF



Program Stop Suffix

Read “Program Stop Suffix” . Then program stop suffix byte(s). To end the suffix, read “Save programming” . The stop suffix byte is programmed in its hex values. See example below.

Note: The maximum length for stop suffix is 10 bytes.



Program Stop Suffix
【Pro CMD: 99904112】

E
xample

Program “CODE” as stop suffix (The hex of “CODE” are 0x43, 0x4F, 0x44, and 0x45):

1. Read “Code Programming ON”
2. Read “Program Stop Suffix”
3. Read “4,3,4,F,4,4,4,5” in order
4. Read “Save Programming”
5. Read “Code Programming OFF”
6. Read “Allow Stop Suffix” to enable above programming. “CODE” will appear to the right of a barcode.





Symbols

Introduction

Each type of barcode has its unique attribute. With the programming code, the engine will adjust to the changes of these attributes. Disabling reading of the symbols which do not apply will improve reading performance.

Symbols Available

Barcode Type	Factory Default	Barcode Type	Factory Default
Code 128	Allow Reading	Deutsche 12	Forbid Reading
UCC/EAN-128	Allow Reading	COOP 25 (Japanese Matrix 25)	Forbid Reading
AIM128	Forbid Reading	Matrix 25 (Europe Matrix 25)	Forbid Reading
ISBT128	Forbid Reading	Industrial 25	Forbid Reading
EAN-8	Allow Reading	Standard 25	Forbid Reading
EAN-13	Allow Reading	China Post 25	Forbid Reading
ISSN	Forbid Reading	Code 39	Allow Reading
ISBN	Forbid Reading	Codabar	Allow Reading
UPC-E	Allow Reading	Code 93	Allow Reading
UPC-A	Allow Reading	Code11	Allow Reading
Interleaved 2 of 5	Forbid Reading	Plessey	Allow Reading
ITF6	Forbid Reading	MSI-Plessey	Allow Reading
ITF14	Forbid Reading	RSS	Allow Reading
Deutsche 14	Forbid Reading		





Load Factory Default



**** Load Code 128 Factory Default**
【Pro CMD: 99910000】

Code Programming ON



Code Programming OFF



Enable/Disable Code 128



**** Enable Code 128**
【Pro CMD: 99910002】



Disable Code 128
【Pro CMD: 99910001】



When the engine can not read Code 128, please read “Enable Code 128” and try again.

Code 128 Code ID



Code ID Setting
【Pro CMD: 99910005】

Example

Example of setting Code 128 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read Code 128 Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.





Select Message Length

It is used to program the valid reading length of Code 128. The engine will send an error beep, if the decoded data length does not match the valid length.

Code Programming ON



Code Programming OFF



Code 128 Message Length is defined by “Min. Message Length” and “Max. Message Length” .



Min Message Length (default: 1)

【Pro CMD: 99910003】



Max Message Length (default: 48)

【Pro CMD: 99910004】



1D bar code Message Length should not exceed 127 bytes. Max Message Length should not be less than Min Message Length.

Example

To set Min Message Length of Code 128 to 8 bytes and Max Message Length to 12 bytes, read these programming codes

- 1、 “Code Programming ON”
- 2、 “Select Min Message Length”
- 3、 Digit Code “8” , see Digit Code
- 4、 “Save Programming” , see Digit Code
- 5、 “Select Max Message Length”
- 6、 Digit Code “1”
- 7、 Digit Code “2”
- 8、 “Save Programming”
- 9、 “Code Programming OFF”



Check Digit

Code Programming ON



Code Programming OFF



Send Check Digit

【Pro CMD: 99910006】



Do Not Send Check Digit

【Pro CMD: 99910007】



Trans FNC1 to GS

【Pro CMD: 99910010】



Trans FNC1 to ~

【Pro CMD: 99910011】





Load Factory Default



** Load UCC/EAN-128 Factory Default
【Pro CMD: 99910100】

Code Programming ON



Code Programming OFF



Enable/Disable UCC/EAN-128



** Enable UCC/EAN-128
【Pro CMD: 99910102】



Disable UCC/EAN-128
【Pro CMD: 99910101】



When the engine can not read UCC/EAN-128, please read “Enable UCC/EAN-128” and try again.

UCC/EAN-128 Code ID



Code ID Setting
【Pro CMD: 99910105】

Example

Example of setting UCC/EAN-128 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read UCC/EAN-128 Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.





Select Message Length

It is used to program the valid reading length of UCC/EAN-128. The engine will send an error beep, if the decoded data length does not match the valid length.

UCC/EAN-128 Message Length is defined by “Min. Message Length” and “Max. Message Length” .

Code Programming ON



Code Programming OFF



Min Message Length (default: 1)

【Pro CMD: 99910103】



Max Message Length (default: 48)

【Pro CMD: 99910104】



1D bar code Message Length should not exceed 127 bytes. Max Message Length should not be less than Min Message Length.

Example

To set Min Message Length of UCC/EAN-128 to 8 bytes and Max Message Length to 12 bytes, read these programming codes

- 1、 “Code Programming ON”
- 2、 “Select Min Message Length”
- 3、 Digit Code “8” , see Digit Code
- 4、 “Save Programming” , see Digit Code
- 5、 “Select Max Message Length”
- 6、 Digit Code “1”
- 7、 Digit Code “2”
- 8、 “Save Programming”
- 9、 “Code Programming OFF”



Check Digit

Code Programming ON



Code Programming OFF



Send Check Digit

【Pro CMD: 99910106】



Do Not Send Check Digit

【Pro CMD: 99910107】



Trans FNC1 to GS

【Pro CMD: 99910110】



Trans FNC1 to ~

【Pro CMD: 99910111】





Load Factory Default



** Load AIM 128 Factory Default

【Pro CMD: 99910200】

Code Programming ON



Code Programming OFF



Enable/Disable AIM 128



** Enable AIM 128

【Pro CMD: 99910202】



Disable AIM 128

【Pro CMD: 99910201】



When the engine can not read AIM 128, please read “Enable AIM 128” and try again.

AIM 128 Code ID



Code ID Setting

【Pro CMD: 99910205】

Example

Example of setting AIM 128 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read AIM 128 Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.





Select Message Length

It is used to program the valid reading length of AIM 128. The engine will send an error beep, if the decoded data length does not match the valid length.



AIM 128 Message Length is defined by “Min. Message Length” and “Max. Message Length” .



Min Message Length (default: 1)
【Pro CMD: 99910203】



Max Message Length (default: 48)
【Pro CMD: 99910204】



1D bar code Message Length should not exceed 127 bytes. Max Message Length should not be less than Min Message Length.

Example

To set Min Message Length of AIM 128 to 8 bytes and Max Message Length to 12 bytes, read these programming codes

- 1、 “Code Programming ON”
- 2、 “Select Min Message Length”
- 3、 Digit Code “8” , see Digit Code
- 4、 “Save Programming” , see Digit Code
- 5、 “Select Max Message Length”
- 6、 Digit Code “1”
- 7、 Digit Code “2”
- 8、 “Save Programming”
- 9、 “Code Programming OFF”



Load Factory Default



** Load ISBT 128 Factory Default
【Pro CMD: 99910300】

Code Programming ON



Code Programming OFF



Enable/Disable ISBT 128



** Enable ISBT 128
【Pro CMD: 99910302】



Disable ISBT 128
【Pro CMD: 99910301】



When the engine can not read ISBT 128, please read “Enable ISBT 128” and try again.

ISBT 128 Code ID



Code ID Setting
【Pro CMD: 99910303】

Example

Example of setting ISBT 128 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read ISBT 128 Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.





Load Factory Default



** Load EAN-8 Factory Default
【Pro CMD: 99910400】

Code Programming ON



Code Programming OFF



Enable/Disable EAN-8



** Enable EAN-8
【Pro CMD: 9991402】



Disable EAN-8
【Pro CMD: 99910401】



When the engine can not read EAN-8, please read “Enable EAN-8” and try again.

EAN-8 Code ID



Code ID Setting
【Pro CMD: 99910416】

Example

Example of setting EAN-8 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read EAN-8 Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.





2 Digits Addenda Code

2 Digits Addenda Code is the one to the right of an ordinary code.



** Disable 2 Digits Addenda Code
【Pro CMD: 99910405】

Code Programming ON



Code Programming OFF



Only Read With 2 digits Addenda Code
【Pro CMD: 99910407】



Enable 2 Digits Addenda Code
【Pro CMD: 99910406】

5 Digits Addenda Code

5 Digits Addenda Code is the one to the right of an ordinary code.



** Disable 5 Digits Addenda Code
【Pro CMD: 99910410】



Only Read With 5 digits Addenda Code
【Pro CMD: 99910412】



Enable 5 Digits Addenda Code
【Pro CMD: 99910411】



“ Enable 2 Digits Addenda Code “ — read an ordinary code and 2 digits Addenda Code.
“ Disable 2 Digits Addenda Code “ — read an ordinary code only, and ignore 2 digits Addenda Code.
“ Only Read With 2 digits Addenda Code “ — read 2 digits Addenda Code and only read code with 2 digits Addenda Code.



EAN-8 expand to EAN-13

“ Do Not Expand to EAN-13 “ — keep original type and digits, do not expand.

“ Expand to EAN-13 by Adding Leading 0s “ — expand to EAN-13 but keep code type.

“ Expand Message and Convert to EAN-13 “ — expand code digits and convert code type.



Code Programming OFF



** Do Not Expand to EAN-13
【Pro CMD: 99910413】



Expand Message and Convert to EAN-13
【Pro CMD: 99910415】



Expand to EAN-13 by Adding Leading 0s
【Pro CMD: 99910414】

Check Digit

EAN-8 is fixed 8 digits barcode and the last digit is check digit. Check digit is a value calculated from the first seven digits. It is used for checking if the first seven digits are right.



** Transmit Check
【Pro CMD: 99910404】



Do Not Transmit Check
【Pro CMD: 99910403】





Load Factory Default

Code Programming ON



Code Programming OFF



** Load EAN-13 Factory Default

【Pro CMD: 99910500】

Disable/Enable EAN-13



** Enable EAN-13

【Pro CMD: 99910502】



Disable EAN-13

【Pro CMD: 99910501】



When the engine can not read EAN-13, please read “Enable EAN-13” and try again.



Check Digit

EAN-13 is fixed 13 digits barcode and the last digit is check digit. Check digit is a value calculated from the first twelve digits. It is used for checking if the first twelve digits are right.

Code Programming ON



Code Programming OFF



** Transmit Check

【Pro CMD: 99910504】



Do Not Transmit Check

【Pro CMD: 99910503】

EAN-13 Code ID



Code ID Setting

【Pro CMD: 99910513】

E

xample

Example of setting EAN-13 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read EAN-13 Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.





2 Digits Addenda Code

2 Digits Addenda Code is the one to the right of an ordinary code.



**** Disable 2 Digits Addenda Code**

【Pro CMD: 99910505】



Only Read With 2 digits Addenda Code

【Pro CMD: 99910507】



Enable 2 Digits Addenda Code

【Pro CMD: 99910506】

Code Programming ON



Code Programming OFF



5 Digits Addenda Code

5 Digits Addenda Code is the one to the right of an ordinary code.



**** Disable 5 Digits Addenda Code**

【Pro CMD: 99910510】



Only Read With 5 digits Addenda Code

【Pro CMD: 99910512】



Enable 5 Digits Addenda Code

【Pro CMD: 99910511】



“ Enable 2 Digits Addenda Code “ — read an ordinary code and 2 digits Addenda Code.

“ Disable 2 Digits Addenda Code “ — read an ordinary code only, and ignore 2 digits Addenda Code.

“ Only Read With 2 digits Addenda Code “ — read 2 digits Addenda Code and only read code with 2 digits Addenda Code.



Load Factory Default



**** Load ISSN Factory Default**
【Pro CMD: 99910600】

Code Programming ON



Code Programming OFF



Enable/Disable ISSN



**** Enable ISSN**
【Pro CMD: 99910602】



Disable ISSN
【Pro CMD: 99910601】



When the engine can not read ISSN, please read “Enable ISSN” and try again.

ISSN Code ID



Code ID Setting
【Pro CMD: 99910603】

E
xample

- Example of setting ISSN Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
 2. Read ISSN Code ID Setting barcode.
 3. Read Following Barcodes: “7” , and “0”
 4. Read Save barcode
 5. Read Disable Code Programming barcode.



Load Factory Default

Code Programming ON



Code Programming OFF



** Load ISBN Factory Default
【Pro CMD: 99910700】

Enable/Disable ISBN



** Enable ISBN
【Pro CMD: 99910702】



Disable ISBN
【Pro CMD: 99910701】



When the engine can not read ISBN, please read “Enable ISBN” and try again.



ISBN Digits



Use 13 Digits

【Pro CMD: 99910704】

Code Programming ON



Code Programming OFF



** Use 10 Digits

【Pro CMD: 99910703】

ISBN Code ID



Code ID Setting

【Pro CMD: 99910705】

E xample

Example of setting ISBN Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read ISBN Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.





Load Factory Default

Code Programming ON



Code Programming OFF



** Load UPC-E Factory Default

【Pro CMD: 99911000】

Disable/Enable UPC-E



** Enable UPC-E

【Pro CMD: 99911002】



Disable UPC-E

【Pro CMD: 99911001】



When the engine can not read UPC-E, please read “Enable UPC-E” and try again.



Check Digit

Code Programming ON



UPC-E is fixed 8 digits barcode and the last digit is check digit. Check digit is a value calculated from the first seven digits. It is used for checking if the first seven digits are right.



** Transmit Check

【Pro CMD: 99911004】



Do Not Transmit Check

【Pro CMD: 99911003】

UPC-E Code ID



Code ID Setting

【Pro CMD: 99911020】

E xample

Example of setting UPC-E Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read UPC-E Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.



2 Digits Addenda Code

2 Digits Addenda Code is the one to the right of an ordinary code.



** Disable 2 Digits Addenda

【Pro CMD: 99911005】



Only Read With 2 digits Addenda Code

【Pro CMD: 99911007】



Enable 2 Digits Addenda Code

【Pro CMD: 99911006】

Code Programming ON



Code Programming OFF



5 Digits Addenda Code

5 Digits Addenda Code is the one to the right of an ordinary code.



** Disable 5 Digits Addenda Code

【Pro CMD: 99911010】



Only Read With 5 digits Addenda Code

【Pro CMD: 99911012】



Enable 5 Digits Addenda Code

【Pro CMD: 99911011】



“ Enable 2 Digits Addenda Code “ — read an ordinary code and 2 digits Addenda Code.

“Disable 2 Digits Addenda Code “ — read an ordinary code only, and ignore 2 digits Addenda Code.

“ Only Read With 2 digits Addenda Code “ — read 2 digits Addenda Code and only read code with 2 digits Addenda Code.



Transmit Default “0”

The first byte of UPC-E is default to “0” .



**** Do Not Transmit “0”**
【Pro CMD: 99911013】

Code Programming ON



Code Programming OFF



Transmit “0”
【Pro CMD: 99911014】

UPC-E Expand to UPC-A

“ Do Not Expand “ — keep original type and digits, do not expand.

“Expand to UPC-A “ — expand to UPC-A but keep code type.

“ Expand Message and Convert to UPC-A “ — expand code digits and convert code type.



****Do Not Expand**
【Pro CMD: 99911015】



Expand Message and Convert to UPC-A
【Pro CMD: 99911017】



Expand to UPC-A
【Pro CMD: 99911016】



Load Factory Default



** Load UPC-A Factory Default

【Pro CMD: 99911100】

Code Programming ON



Code Programming OFF



Disable/Enable UPC-A



** Enable UPC-A

【Pro CMD: 99911102】



Disable UPC-A

【Pro CMD: 99911101】



When the engine can not read UPC-A, please read “Enable UPC-A” and try again.

UPC-A Code ID



Code ID Setting

【Pro CMD: 99911115】

Example

Example of setting UPC-A Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read UPC-A Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.





Check Digit



UPC-A is fixed 13 digits barcode and the last digit is Check Digit. Check digit is a value calculated from the first twelve digits. It is used for checking if the first twelve digits are right.



**Transmit Check
【Pro CMD: 99911104】



Do Not Transmit Check
【Pro CMD: 99911103】

Transmit Default “0”

The first byte of UPC-A is default to “0” .



** Do Not Transmit “0”
【Pro CMD: 99911113】



Transmit “0”
【Pro CMD: 99911114】



2 Digits Addenda Code

2 Digits Addenda Code is the one to the right of an ordinary code.



**** Disable 2 Digits Addenda Code**

【Pro CMD: 99911105】



Only Read With 2 digits Addenda Code

【Pro CMD: 99911107】



Enable 2 Digits Addenda Code

【Pro CMD: 99911106】

Code Programming ON



Code Programming OFF



5 Digits Addenda Code

5 Digits Addenda Code is the one to the right of an ordinary code.



**** Disable 5 Digits Addenda Code**

【Pro CMD: 99911110】



Only Read With 5 digits Addenda Code

【Pro CMD: 99911112】



Enable 5 Digits Addenda Code

【Pro CMD: 99911111】



“ Enable 2 Digits Addenda Code “ — read an ordinary code and 2 digits Addenda Code.

“Disable 2 Digits Addenda Code “ — read an ordinary code only, and ignore 2 digits Addenda Code.

“ Only Read With 2 digits Addenda Code “ — read 2 digits Addenda Code and only read code with 2 digits Addenda Code.



Load Factory Default



**** Load Interleaved 2 of 5 Factory Default**
【Pro CMD: 99911200】

Code Programming ON



Code Programming OFF



Disable/Enable Interleaved 2 of 5



**** Enable Interleaved 2 of 5**
【Pro CMD: 99911202】



Disable Interleaved 2 of 5
【Pro CMD: 99911201】



 When the engine can not read Interleaved 2 of 5, please read “Enable Interleaved 2 of 5”
 and try again

Interleaved 2 of 5 Code ID



Code ID Setting
【Pro CMD: 99911210】

Example

Example of setting Interleaved 2 of 5 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read Interleaved 2 of 5 Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.





Check Digit

Interleaved 2 of 5 may include Check Digit (not compulsory) following its barcode messages. If included, it must be the last digit. It verifies the barcode message.

» “NO Check, Transmit All” means to read without check and transmit all bytes including barcode message and Check digit.

» “Check, Do Not Transmit Check Digit” means to read and check. If verification is successful, transmit barcode message; if not, engine sends an error beep.

» “Check, Transmit All” means to read and check. If verification is successful, transmit all messages; if not, engine sends an error beep.

Code Programming ON



Code Programming OFF



** “NO Check, Transmit All”
【Pro CMD: 99911203】



Check, Do Not Transmit Check Digit
【Pro CMD: 99911204】



Check, Transmit All
【Pro CMD: 99911205】



When “Check, Do Not Transmit Check digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.
E.g.: Reading a 4-byte (include check Digit) Interleaved 2 of 5 with the Min Message Length being 4 bytes and “Check, Do Not Transmit Check digit” enabled leads to error beep.



Select Message Length

Code Programming ON



It is used to program the valid reading length of Interleaved 2 of 5. The engine will send an error beep, if the decoded data length does not match the valid length.

Code Programming OFF



Interleaved 2 of 5 Message Length is defined by “Min. Message Length” and “Max. Message Length”



Min Message Length (default: 1)

【Pro CMD: 99911206】



Max Message Length (default: 48)

【Pro CMD: 99911207】



1D bar code Message Length should not exceed 127 bytes.
Max Message Length should not be less than Min Message Length.

Example

To set Min Message Length of Interleaved 2 of 5 as 8 bytes, and Max Message length as 12 bytes, read these programming codes:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8” , see Digit Code Appendix (Pxxx)
4. “Save Programming” , see Digit Code Appendix (Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”



ITF-6 is a fixed length 6 bytes Interleaved 2 of 5 barcode with check digit.
When enabled, ITF-6 precedes 6-byte Interleaved 2 of 5 barcode.



**** Load ITF-6 Factory Default**
【Pro CMD: 99911300】



****Disable ITF-6 User Selection**
【Pro CMD: 99911301】



Enable ITF-6, Do Not Transmit Check Digit
【Pro CMD: 99911302】



Enable ITF-6, Transmit Check Digit
【Pro CMD: 99911303】



For instance, when ITF-6 is enabled and Interleaved 2 of 5 is disabled, the ITF-6 and 6 bytes Interleaved 2 of 5 with check digit can be read, but other Interleaved 2 of 5 can not.

ITF-6 Code ID



Code ID Setting
【Pro CMD: 99911304】

Example

- Example of setting ITF-6 Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
 2. Read ITF-6 Code ID Setting barcode.
 3. Read Following Barcodes: “7” , and “0”
 4. Read Save barcode
 5. Read Disable Code Programming barcode.



ITF-14 is a fixed length of 14 bytes Interleaved 2 of 5 barcode with Check digit. By factory default, it is disabled.

Code Programming ON



When enabled, ITF-14 precedes 14-byte Interleaved 2 of 5 barcode.

Code Programming OFF



** Load ITF-14 Factory Default
【Pro CMD: 99911400】



Enable ITF-14, Do Not Transmit Check Digit
【Pro CMD: 99911402】



**Disable ITF-14
【Pro CMD: 99911401】



Enable ITF-14, Transmit Check Digit
【Pro CMD: 99911403】



For instance, when ITF-14 is enabled and Interleaved 2 of 5 is disabled, the ITF-14 and 14 bytes Interleaved 2 of 5 with check digit can be read, but other Interleaved 2 of 5 can not.

ITF-14 Code ID



Code ID Setting
【Pro CMD: 99911404】

E

Example

Example of setting ITF-14 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read ITF-14 Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.



Load Factory Default



**** Load Deutshe14 Factory Default**
【Pro CMD: 99911500】

Code Programming ON



Code Programming OFF



Disable/Enable Deutshe14



**** Enable Deutshe14, Do Not Transmit Check Digit**
【Pro CMD: 99911502】



Disable Deutshe14
【Pro CMD: 99911501】



**** Enable Deutshe14, Transmit Check Digit**
【Pro CMD: 99911503】



When the engine can not read Deutshe14, please read “Enable Deutshe14” and try again

Deutshe14 Code ID



Code ID Setting
【Pro CMD: 99911504】

Example

Example of setting Deutshe14 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read Deutshe14 Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.



Load Factory Default



**** Load Deutshe12 Factory Default**
【Pro CMD: 99911600】

Code Programming ON



Code Programming OFF



Disable/Enable Deutshe12



**** Enable Deutshe12, Do Not Transmit Check Digit**
【Pro CMD: 99911602】



Disable Deutshe12
【Pro CMD: 99911601】



**** Enable Deutshe12, Transmit Check Digit**
【Pro CMD: 99911603】



When the engine can not read Deutshe12, please read “Enable Deutshe12” and try again

Deutshe12 Code ID



Code ID Setting
【Pro CMD: 99911604】

E
Example

Example of setting Deutshe12 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read Deutshe12 Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.



Load Factory Default



** Load COOP25 Factory Default

【Pro CMD: 99911700】

Code Programming ON



Code Programming OFF



Enable/ Disable COOP25



**Enable COOP25

【Pro CMD: 99911702】



Disable COOP25

【Pro CMD: 99911701】



When the engine can not read COOP25, please read “Enable COOP25” and try again.

COOP25 (Japanese Matrix 25) Code ID



Code ID Setting

【Pro CMD: 99911710】

Example

Example of setting COOP25 (Japanese Matrix 25) Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read COOP25 (Japanese Matrix 25) Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.





Check Digit



COOP25 may include Check Digit (not compulsory) following its barcode messages. If included, it must be the last digit. It verifies the barcode message.



» “NO Check, Transmit All” means to read without check and transmit all bytes including barcode message and Check Digit.

» “Check, Do Not Transmit Check Digit” means to read and check. If verification is successful, transmits barcode message; if not, engine sends an error beep.

» “Check, Transmit All” means to read and check. If verification is successful, transmits all messages; if not, engine sends an error beep.



** NO Check, Transmit All

【Pro CMD: 99911703】



Check, Transmit All

【Pro CMD: 99911704】



Check, Do Not Transmit Check Digit

【Pro CMD: 99911705】



When “Check, Do Not Transmit Check Digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.

E.g.: Reading a 4-byte (include Check Digit) COOP25 with the Min Message Length being 4 bytes and “Check, Do Not Transmit Check Digit” enabled leads to error beep.



Select Message Length

It is used to program the valid reading length of COOP25. The engine will send an error beep, if the decoded data length does not match the valid length.

COOP25 Message Length is defined by “Min. Message Length” and “Max. Message Length”.

Code Programming ON



Code Programming OFF



Min Message Length (default: 1)
【Pro CMD: 99911706】



Max Message Length (default: 48)
【Pro CMD: 99911707】



1D bar code Message Length should not exceed 127 bytes.
Max Message Length should not be less than Min Message Length.

Example

To set Min Message Length of COOP25 to 8 bytes and the Max Message Length to 12 bytes. Read these programming code:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8”, see Digit Code (Appendix Pxxx)
4. “Save Programming”, see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”





Load Factory Default



**** Load Matrix 25 Factory Default**
【Pro CMD: 99912000】

Code Programming ON



Code Programming OFF



Enable/ Disable Matrix 25



****Enable Matrix 25**
【Pro CMD: 99912002】



Disable Matrix 25
【Pro CMD: 99912001】



When the engine can not read Matrix 25, please read “Enable Matrix 25” and try again.

Matrix 25 Code ID



Code ID Setting
【Pro CMD: 99912010】

E xample

Example of setting Matrix 25 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read Matrix 25 Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.



Check Digit



Matrix 25 may include Check Digit (not compulsory) following its barcode messages. If included, it must be the last digit. It verifies the barcode message.



» “NO Check, Transmit All” means to read without check and transmit all bytes including barcode message and Check Digit.

» “Check, Do Not Transmit Check Digit” means to read and check. If verification is successful, transmits barcode message; if not, engine sends an error beep.

» “Check, Transmit All” means to read and check. If verification is successful, transmits all messages; if not, engine sends an error beep.



** NO Check, Transmit All

【Pro CMD: 99912003】



Check, Transmit All

【Pro CMD: 99912004】



Check, Do Not Transmit Check Digit

【Pro CMD: 99912005】



When “Check, Do Not Transmit Check Digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.

E.g.: Reading a 4-byte (include Check Digit) Matrix 25 with the Min Message Length being 4 bytes and “Check, Do Not Transmit Check Digit” enabled leads to error beep.



Select Message Length

It is used to program the valid reading length of Matrix 25. The engine will send an error beep, if the decoded data length does not match the valid length.

Matrix 25 Message Length is defined by “Min. Message Length” and “Max. Message Length” .

Code Programming ON



Code Programming OFF



Min Message Length (default: 1)
【Pro CMD: 99912006】



Max Message Length (default: 48)
【Pro CMD: 99912007】



ID bar code Message Length should not exceed 127 bytes.
Max Message Length should not be less than Min Message Length.

Example

To set Min Message Length of Matrix 25 to 8 bytes and the Max Message Length to 12 bytes. Read these programming code:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8” , see Digit Code (Appendix Pxxx)
4. “Save Programming” , see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”





Load Factory Default



** Load Industrial 25 Factory Default

【Pro CMD: 99912100】

Code Programming ON



Code Programming OFF



Enable/ Disable Industrial 25



**Enable Industrial 25
【Pro CMD: 99912102】



Disable Industrial 25
【Pro CMD: 99912101】



When the engine can not read Industrial 25, please read “Enable Industrial 25” and try again.

Industrial 25 Code ID



Code ID Setting
【Pro CMD: 99912110】

Example

Example of setting Industrial 25 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read Industrial 25 Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.





Check Digit



Industrial 25 may include Check Digit (not compulsory) following its barcode messages. If included, it must be the last digit. It verifies the barcode message.

Code Programming OFF



» “NO Check, Transmit All” means to read without check and transmit all bytes including barcode message and Check Digit.

» “Check, Do Not Transmit Check Digit” means to read and check. If verification is successful, transmits barcode message; if not, engine sends an error beep.

» “Check, Transmit All” means to read and check. If verification is successful, transmits all messages; if not, engine sends an error beep.



** NO Check, Transmit All

【Pro CMD: 99912103】



Check, Transmit All

【Pro CMD: 99912104】



Check, Do Not Transmit Check Digit

【Pro CMD: 99912105】



When “Check, Do Not Transmit Check Digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.

E.g.: Reading a 4-byte (include Check Digit) Industrial 25 with the Min Message Length being 4 bytes and “Check, Do Not Transmit Check Digit” enabled leads to error beep.



Select Message Length

It is used to program the valid reading length of Industrial 25. The engine will send an error beep, if the decoded data length does not match the valid length.

Industrial 25 Message Length is defined by “Min. Message Length” and “Max. Message Length” .

Code Programming ON



Code Programming OFF



Min Message Length (default: 1)
【Pro CMD: 99912106】



Max Message Length (default: 48)
【Pro CMD: 99912107】



ID bar code Message Length should not exceed 127 bytes.
Max Message Length should not be less than Min Message Length.

Example

To set Min Message Length of Industrial 25 to 8 bytes and the Max Message Length to 12 bytes. Read these programming code:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8” , see Digit Code (Appendix Pxxx)
4. “Save Programming” , see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”





Load Factory Default



** Load Standard 25 Factory Default

【Pro CMD: 99912200】

Code Programming ON



Code Programming OFF



Enable/ Disable Standard 25



**Enable Standard 25

【Pro CMD: 99912202】



Disable Standard 25

【Pro CMD: 99912201】



When the engine can not read Standard 25, please read “Enable Standard 25” and try again.

Standard 25 Code ID



Code ID Setting

【Pro CMD: 99912210】

E xample

Example of setting Standard 25 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read Standard 25 Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.





Check Digit



Standard 25 may include Check Digit (not compulsory) following its barcode messages. If included, it must be the last digit. It verifies the barcode message.



» “NO Check, Transmit All” means to read without check and transmit all bytes including barcode message and Check Digit.

» “Check, Do Not Transmit Check Digit” means to read and check. If verification is successful, transmits barcode message; if not, engine sends an error beep.

» “Check, Transmit All” means to read and check. If verification is successful, transmits all messages; if not, engine sends an error beep.



** NO Check, Transmit All

【Pro CMD: 99912203】



Check, Transmit All

【Pro CMD: 99912204】



Check, Do Not Transmit Check Digit

【Pro CMD: 99912205】



When “Check, Do Not Transmit Check Digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.

E.g.: Reading a 4-byte (include Check Digit) Standard 25 with the Min Message Length being 4 bytes and “Check, Do Not Transmit Check Digit” enabled leads to error beep.



Select Message Length

It is used to program the valid reading length of Standard 25. The engine will send an error beep, if the decoded data length does not match the valid length.

Standard 25 Message Length is defined by “Min. Message Length” and “Max. Message Length” .

Code Programming ON



Code Programming OFF



Min Message Length (default: 1)
【Pro CMD: 99912206】



Max Message Length (default: 48)
【Pro CMD: 99912207】



1D bar code Message Length should not exceed 127 bytes.
Max Message Length should not be less than Min Message Length.

Example

To set Min Message Length of Standard 25 to 8 bytes and the Max Message Length to 12 bytes. Read these programming code:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8” , see Digit Code (Appendix Pxxx)
4. “Save Programming” , see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”





Load Factory Default



** Load Code 39 Factory Default
【Pro CMD: 99912400】

Code Programming ON



Code Programming OFF



Enable/Disable Code 39



** Enable Code 39
【Pro CMD: 99912402】



Disable Code 39
【Pro CMD: 99912401】



When the engine can not read Code 39, please read “Enable Code 39” and try again

Code 39 Code ID



Code ID Setting
【Pro CMD: 99912414】

E xample

Example of setting Code 39 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read Code 39 Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.





Check Digit

Code 39 may include Check Digit (not compulsory) following its barcode message. It verifies the barcode message.

» "NO Check, Transmit All" means to read without check and transmit all bytes including barcode message and Check Digit.

» "Check, Do Not Transmit Check Digit" means to read and check. If verification is successful, transmits barcode message; if not, engine sends an error beep.

» "Check, Transmit All" means to read and check. If verification is successful, transmits all messages; if not, engine sends an error beep.

Code Programming ON



Code Programming OFF



** NO Check, Transmit All
【Pro CMD: 99912403】



Check, Do not transmit Check Digit
【Pro CMD: 99912404】



Check, Transmit All
【Pro CMD: 99912405】



When "Check, Do not Transmit Check digit" is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.

E.g.: Reading a 4-byte (include check byte) Code 39 with the Min Message Length being 4 bytes and "Check, Do not transmit Check Digit" enabled leads to error beep.



Transmit Start & Stop Character

Code 39 has one "*" before and another after digits as Start & Stop Character.
Transmission of "*" can be selected.

Code Programming ON



Code Programming OFF



Transmit Both "

【Pro CMD: 99912407】



Transmit Neither "**

【Pro CMD: 99912406】

Decode ASCII

Code 39 can include full ASCII characters. For factory default, the engine only decodes part of them.
Read "Enable Full ASCII decode" to decode full ASCII characters.



**Partial ASCII Decode

【Pro CMD: 99912410】



Full ASCII Decode

【Pro CMD: 99912411】





Select Message Length

Code 39 Message Length is defined by “Min. Message Length” and “Max. Message Length”. It is used to program the valid reading length of Code 39. The engine will send an error beep, if the decoded data length does not match the valid length.

Code Programming ON



Code Programming OFF



Min Message Length (default: 1)
【Pro CMD: 99912412】



Max Message Length (default: 48)
【Pro CMD: 99912413】



1D bar code Message Length should not exceed 127 bytes.
Max Message Length should not be less than Min Message Length.

Example

To set Min Message Length of Code 39 to 8 bytes, and Max Message Length to 12 bytes, read these programming codes:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8”, see Digit Code (Appendix Pxxx)
4. “Save Programming”, see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”



Load Factory Default



** Load Codabar Factory Default
【Pro CMD: 99912500】

Code Programming ON



Code Programming OFF



Enable/Disable Codabar



** Enable Codabar
【Pro CMD: 99912502】



Disable Codabar
【Pro CMD: 99912501】



When the engine can not read Codabar, please read “Enable Codabar” and try again.

Codabar Code ID



Code ID Setting
【Pro CMD: 99912516】

Example

Example of setting Codabar Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read Codabar Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.



Check Digit

Codabar may include Check Digit (not compulsory) following its barcode message. It verifies the barcode message.

» "NO Check, Transmit All" means to read without check and transmit all bytes including barcode message and Check Digit.

» "Check, Do Not Transmit Check Digit" means to read and check. If verification is successful, transmits barcode message; if not, engine sends an error beep.

» "Check, Transmit All" means to read and check. If verification is successful, transmits all messages; if not, engine sends an error beep.

Code Programming ON



Code Programming OFF



** NO Check, Transmit All
【Pro CMD: 99912503】



Check, Do not transmit Check Digit
【Pro CMD: 99912505】



Check, Transmit All
【Pro CMD: 99912504】



When "Check, Do not Transmit Check digit" is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.

E.g.: Reading a 4-byte (include check byte) Codabar with the Min Message Length being 4 bytes and "Check, Do not transmit Check Digit" enabled leads to error beep.



Transmit Start & Stop Character

Code Programming ON



Code Programming OFF



Do Not Transmit Both Start & Stop Character
【Pro CMD: 99912506】



**Transmit Both Start & Stop Character
【Pro CMD: 99912507】



** Use ABCD/ABCD As Start & Stop Character
【Pro CMD: 99912510】



Use ABCD/TN*E As Start & Stop Character
【Pro CMD: 99912511】



Use abcd/abcd As Start & Stop Character
【Pro CMD: 99912512】



Use abcd/tn*e As Start & Stop Character
【Pro CMD: 99912513】





Select Message Length

Codabar Message Length is defined by “Min. Message Length” and “Max. Message Length”. It is used to program the valid reading length of Codabar. The engine will send an error beep, if the decoded data length does not match the valid length.

Code Programming ON



Code Programming OFF



Min Message Length (default: 1)
【Pro CMD: 99912514】



Max Message Length (default: 48)
【Pro CMD: 99912515】



1D bar code Message Length should not exceed 127 bytes.
Max Message Length should not be less than Min Message Length.

Example

To set Min Message Length of Codabar to 8 bytes, and Max Message Length to 12 bytes, read these programming codes:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8”, see Digit Code (Appendix Pxxx)
4. “Save Programming”, see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”



Load Factory Default



** Load Code 93 Factory Default
【Pro CMD: 99912600】

Code Programming ON



Code Programming OFF



Enable /Disable Code 93



**Enable Code 93
【Pro CMD: 99912602】



Disable Code 93
【Pro CMD: 99912601】



When the engine can not read Code 93, please read “Enable Code 93” and try again.

Code 93 Code ID



Code ID Setting
【Pro CMD: 99912610】



Example of setting Code 93 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read Code 93 Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.



Check Digit

Code 93 may include Check Digit (not compulsory) following its barcode message. It verifies the barcode message.

» "NO Check, Transmit All" means to read without check and transmit all bytes including barcode message and Check Digit.

» "Check, Do Not Transmit Check Digit" means to read and check. If verification is successful, transmits barcode message; if not, engine sends an error beep.

» "Check, Transmit All" means to read and check. If verification is successful, transmits all messages; if not, engine sends an error beep.

Code Programming ON



Code Programming OFF



** NO Check, Transmit All
【Pro CMD: 99912603】



Check, Do not transmit Check Digit
【Pro CMD: 99912604】



Check, Transmit All
【Pro CMD: 99912605】



When "Check, Do not Transmit Check digit" is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.

E.g.: Reading a 4-byte (include check byte) Code 93 with the Min Message Length being 4 bytes and "Check, Do not transmit Check Digit" enabled leads to error beep.



Select Message Length

Code Programming ON



It is used to program the valid reading length of Code 93. The engine will send an error beep, if the decoded data length does not match the valid length.

Code 93 Message Length is defined by “Min. Message Length” and “Max. Message Length .”

Code Programming OFF



Min Message Length (default: 1)

【Pro CMD: 99912606】



Max Message Length (default: 48)

【Pro CMD: 99912607】



1D bar code Message Length should not exceed 127 bytes.
Max Message Length should not be less than Min Message Length.

Example

To set Min Message Length of Code 93 to 8 bytes and Max Message Length to 12 bytes, read these programming codes:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8” , see Digit Code (Appendix Pxxx)
4. “Save Programming” , see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”



Load Factory Default



**** Load Code 11 Factory Default**

【Pro CMD: 99912700】

Code Programming ON



Code Programming OFF



Enable/ Disable Code 11



****Enable Code 11**

【Pro CMD: 99912702】



Disable Code 11

【Pro CMD: 99912701】



When the engine can not read Code 11, please read “Enable Code 11” and try again.

Code 11 Code ID



Code ID Setting

【Pro CMD: 99912715】

Example

Example of setting Code 11 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read Code 11 Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.



Check Digit

Code 11 may include Check Digit (not compulsory) following its barcode messages. If included, it must be the last digit. It verifies the barcode message.

» “NO Check, Transmit All” means to read without check and transmit all bytes including barcode message and Check Digit.



** No Check

【Pro CMD: 99912703】



Single Check Digit, MOD11

【Pro CMD: 99912704】



Double Check Digits, MOD11/MOD11

【Pro CMD: 99912705】



Double Check Digits, MOD11/MOD9

【Pro CMD: 99912706】



Single Check Digit MOD11 (Len <= 10)

Double Check Digits MOD11/
MOD11 (Len > 10)

【Pro CMD: 99912707】



Single Check Digit MOD11 (Len <= 10)

Double Check Digits MOD11/
MOD9 (Len > 10)

【Pro CMD: 99912710】



Do not transmit Check Digit

【Pro CMD: 99912711】



Transmit Check Digit

【Pro CMD: 99912712】



When “Check, Do Not Transmit Check Digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.

E.g.: Reading a 4-byte (include Check Digit) Code 11 with the Min Message Length being 4 bytes and “Check, Do Not Transmit Check Digit” enabled leads to error beep.



Select Message Length

It is used to program the valid reading length of Code 11. The engine will send an error beep, if the decoded data length does not match the valid length.

Code 11 Message Length is defined by “Min. Message Length” and “Max. Message Length” .

Code Programming ON



Code Programming OFF



Min Message Length (default: 1)
【Pro CMD: 99912713】



Max Message Length (default: 48)
【Pro CMD: 99912714】



1D bar code Message Length should not exceed 127 bytes.
Max Message Length should not be less than Min Message Length.

Example

To set Min Message Length of Code 11 to 8 bytes and the Max Message Length to 12 bytes. Read these programming code:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8” , see Digit Code (Appendix Pxxx)
4. “Save Programming” , see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”





Load Factory Default



**** Load Plessey Factory Default**
【Pro CMD: 99913000】

Code Programming ON



Code Programming OFF



Enable/ Disable Plessey



****Enable Plessey**
【Pro CMD: 99913002】



Disable Plessey
【Pro CMD: 99913001】



When the engine can not read Plessey, please read “Enable Plessey” and try again.

Plessey Code ID



Code ID Setting
【Pro CMD: 99913010】

E
Example

Example of setting Plessey Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read Plessey Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.



Check Digit



Plessey may include Check Digit (not compulsory) following its barcode messages. If included, it must be the last digit. It verifies the barcode message.



» “NO Check, Transmit All” means to read without check and transmit all bytes including barcode message and Check Digit.

» “Check, Do Not Transmit Check Digit” means to read and check. If verification is successful, transmits barcode message; if not, engine sends an error beep.

» “Check, Transmit All” means to read and check. If verification is successful, transmits all messages; if not, engine sends an error beep.



**** NO Check, Transmit All**
【Pro CMD: 99913003】



Check, Do not transmit Check Digit
【Pro CMD: 99913005】



Check, Transmit All
【Pro CMD: 99913004】



When “Check, Do Not Transmit Check Digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.

E.g.: Reading a 4-byte (include Check Digit) Plessey with the Min Message Length being 4 bytes and “Check, Do Not Transmit Check Digit” enabled leads to error beep.



Select Message Length

It is used to program the valid reading length of Plessey. The engine will send an error beep, if the decoded data length does not match the valid length.

Plessey Message Length is defined by “Min. Message Length” and “Max. Message Length” .

Code Programming ON



Code Programming OFF



Min Message Length (default: 1)
【Pro CMD: 99913006】



Max Message Length (default: 48)
【Pro CMD: 99913007】



1D bar code Message Length should not exceed 127 bytes.
Max Message Length should not be less than Min Message Length.

Example

To set Min Message Length of Plessey to 8 bytes and the Max Message Length to 12 bytes.
Read these programming code:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8” , see Digit Code (Appendix Pxxx)
4. “Save Programming” , see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”





Load Factory Default



** Load MSI-Plessey Factory Default

【Pro CMD: 99913100】

Code Programming ON



Code Programming OFF



Enable/ Disable MSI-Plessey



**Enable MSI-Plessey
【Pro CMD: 99913102】



Disable MSI-Plessey
【Pro CMD: 99913101】



When the engine can not read MSI-Plessey, please read “Enable MSI-Plessey” and try again.

MSI-Plessey Code ID



Code ID Setting
【Pro CMD: 99913113】

E xample

Example of setting MSI-Plessey Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read MSI-Plessey Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.



Check Digit

MSI-Plessey may include Check Digit (not compulsory) following its barcode messages. If included, it must be the last digit. It verifies the barcode message.

» “NO Check, Transmit All” means to read without check and transmit all bytes including barcode message and Check Digit.



Code Programming OFF



** No Check

【Pro CMD: 99913103】



Single Check Digit, MOD10

【Pro CMD: 99913104】



Double Check Digits, MOD10/MOD10

【Pro CMD: 99913105】



Double Check Digits, MOD10/MOD11

【Pro CMD: 99913106】



Do not transmit Check Digit

【Pro CMD: 99913107】



Transmit Check Digit

【Pro CMD: 99913110】



When “Check, Do Not Transmit Check Digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.

E.g.: Reading a 4-byte (include Check Digit) MSI-Plessey with the Min Message Length being 4 bytes and “Check, Do Not Transmit Check Digit” enabled leads to error beep.



Select Message Length

MSI-Plessey Message Length is defined by “Min. Message Length” and “Max. Message Length”. It is used to program the valid reading length of MSI-Plessey. The engine will send an error beep, if the decoded data length does not match the valid length.

Code Programming ON



Code Programming OFF



Min Message Length (default: 1)
【Pro CMD: 99913111】



Max Message Length (default: 48)
【Pro CMD: 99913112】



ID bar code Message Length should not exceed 127 bytes.
Max Message Length should not be less than Min Message Length.

Example

To set Min Message Length of MSI-Plessey to 8 bytes and the Max Message Length to 12 bytes. Read these programming code:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8”, see Digit Code (Appendix Pxxx)
4. “Save Programming”, see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”





Load Factory Default



**** Load RSS Factory Default**

【Pro CMD: 99913200】

Code Programming ON



Code Programming OFF



Enable/ Disable RSS



****Enable RSS**

【Pro CMD: 99913202】



Disable RSS

【Pro CMD: 99913201】



When the engine can not read RSS, please read “Enable RSS” and try again.

RSS Code ID



Code ID Setting

【Pro CMD: 99913203】

Example

Example of setting RSS Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read RSS Code ID Setting barcode.
3. Read Following Barcodes: “7” , and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.





Appendix

Digit Code

It is must to be read save after read digit code.



Code Programming ON



Code Programming OFF



0

【Pro CMD: 99900000】



4

【Pro CMD: 99900004】



1

【Pro CMD: 99900001】



5

【Pro CMD: 99900005】



2

【Pro CMD: 99900002】



6

【Pro CMD: 99900006】



3

【Pro CMD: 99900003】



7

【Pro CMD: 99900007】



Code Programming ON



Code Programming OFF



8

【Pro CMD: 99900010】



C

【Pro CMD: 99900014】



9

【Pro CMD: 99900011】



D

【Pro CMD: 99900015】



A

【Pro CMD: 99900012】



E

【Pro CMD: 99900016】



B

【Pro CMD: 99900013】



F

【Pro CMD: 99900017】





In order to save the received data “Save” has to be read after data transition completed. If error occurs when reading data, the wrong data can be deleted and the setting up can be done again..

Eg, after a program code is received then ‘1 2 3’ in order is received, if then read “Abort One Data of Current Setting” the “3” will be deleted; if read “Abort One String of Current Setting” the ‘123’ will be deleted; if read “Abort Current Setting” both the program code and ‘123’ will be deleted, the device will be on status of “initiating program code” .

Code Programming ON



Code Programming OFF



Save

【Pro CMD: 99900020】



Abort One Data of Current Setting

【Pro CMD: 99900021】



Abort Current Setting

【Pro CMD: 99900023】



Abort All String of Current Setting

【Pro CMD: 99900022】