

Control Register

19 June 2025 11:46

- UE is essential to enable only rs 232 or rs485 protocols. So do not enable for the uart protocol.
- CR1 :
 - set OVER8 to 1, for opting OVER8 sampling
 - UE bit, enable UE bit
 - M bit set 0, for 8-bit data
 - Set TE and RE bits for Tx and Rx.
- CR2 :
 - set 00 for the STOP bit
- CR3 :
 - No changes all default values.