

```

Q 1.
fck = float(input("Enter the value of characteristics compressive strength:"))
fy= float(input("Enter the grade of steel:"))
Es = float(input("Enter the value of Modulus of Elasticity of steel:"))
b= float(input("Enter the value of Width: "))
d= float(input("Enter the value of effective depth:"))
d1 = float(input("Enter the value of bar diameter (d1):"))
d2 = float(input("Enter the value of bar diameter (d2):"))
n=int(input("Enter the number of bars"))
Ast1= (n*0.7854*d1*d1)
Ast2= (n*0.7854*d2*d2)
print("The value of area of steel (Ast1):", Ast1)
print("The value of area of steel (Ast2):", Ast2)
# Total area of steel
Ast = Ast1 + Ast2
print("The value of area of steel (Ast):", Ast)
# Neutral Axis Factor
ku = 0.0035/(0.0055 + (fy/(1.15*Es)))
print("The value of Neutral axis factor (ku):", ku)
# Moment of Resistance factor
Ru= 0.36*fck*ku*(1-(0.42*ku))
print("The value of Moment of Resistance factor (Ru):", Ru)
# Maximum Neutral Axis:
xumax = ku*d
print("The value of maximum neutral axis (xumax):", xumax)
xu = (0.87 *fy*Ast)/(0.36*fck*b)
print("The value of Actual Neutral Axis (xu):", xu)
if xumax>xu:
    print("UNDER REINFORCED")
else:
    print("OVER REINFORCED")
# By Comparing
X = float(input("Enter the value of Neutral Axis:"))
# Moment of Resistance
Mu = 0.36*fck*X*b*(d-(0.42*X))
print("The value of Moment of Resistance is N/mm^2:", Mu)

```

```

Enter the value of characteristics compressive strength:20
Enter the grade of steel:415
Enter the value of Modulus of Elasticity of steel:200000
Enter the value of Width: 230
Enter the value of effective depth:400
Enter the value of bar diameter (d1):20
Enter the value of bar diameter (d2):16
Enter the number of bars:2
The value of area of steel (Ast1): 628.32
The value of area of steel (Ast2): 402.1248
The value of area of steel (Ast): 1030.4448
The value of Neutral axis factor (ku): 0.4791666666666667
The value of Moment of Resistance factor (Ru): 2.7556874999999996
The value of maximum neutral axis (xumax): 191.66666666666669
The value of Actual Neutral Axis (xu): 224.66310086956523
OVER REINFORCED
Enter the value of Neutral Axis:191.666667
The value of Moment of Resistance is N/mm^2: 101409300.13192798

```

```

Q 2.
# Design of Slab
# Given Data
# Effective span is already given in question
span= float(input("Enter the value of effective span in meters:"))
b= float(input("Enter the value of width of slab in mm:"))
bs= float(input("Enter the value of Support Width in meters:"))

```

```

fck = float(input(" Enter the value of Characteristics Compressive Strength:"))
fy = float(input("Enter the value of grade of steel:"))
Es = float (input("Enter the value of Modulus of Elasticity is:"))
LL = float(input("Enter the value of Live Load:"))
FF = float(input("Enter the value of Floor Finish:"))
Density = float(input("Enter the value of Density of RCC:"))
# Design Constants
# Neutral Axis Factor
ku = 0.0035/ ((0.0055)+ (fy/(1.15*Es)))
print("The value of Neutral Axis Factor (ku) is:", ku)
# Moment of Resistance Factor
Ru = 0.36*fck*ku*(1-(0.42*ku))
print("The value of Moment Resistance factor (Ru) is:", Ru)
# Assuming pt 0.5 from fig.4 from IS 456:2007 page no.38
fs = float(input("Enter the value of Steel Stress of Service:"))
# From Graph find out the Modification Factor
MF = float(input("Enter the value of Modification Factor:"))
# From Clause 23.2.1 Select span/d Ratio
S= float(input("Enter the value of span/d ratio:"))
# Correction Factors
k1 = float(input("Enter the value of Correction factor if span > 10m (k1):"))
k2= float(input(" Enter the value of Tension r/f correction factor (k2):"))
k3= float(input("Enter the value of Compression r/f correction factor (k3):"))
k4= float (input("Enter the value of correction factor in case of flanged section (k4):"))
# Effective depth
d1= (span*1000)/(S*MF*k1*k2*k3*k4)
print ("The value of effective depth as per deflection criteria is:", d1)
# Define Effective depth and overall depth Assuming value of cover
d = float(input("Enter the value of Effective depth in mm (d):"))
D= float(input("Enter the value of Overall depth in mm (D):"))
# Load Calculations
# Self Weight of slab
DL = D*Density/1000
print("The Dead load is:", DL)
# Total Load is
Factor = float(input("Enter the value of partial Safety Factor is: "))
TL = DL + LL + FF
print("The value of total load is:", TL)
Wu = Factor*TL
print("Wu=", Wu)
# Bending Moment Calculations (Mu)
Mu= Wu*span*span/8
print("The Value of Bending Moment (Mu) is:", Mu)
# Check for effective depth
d2 = ((Mu*1000000)/(Ru*b))**0.5
print("The value of Effective depth as per Moment criteria:", d2)
if d2>d:
    print("Revise the Depth:")
else:
    print("SAFE")
d = float(input("Enter the value of Effective depth in mm (d):"))
print("Minimum Steel Calculations")
Astmin = 0.12*b*D/100
print("The value of Minimum steel is:", Astmin)
print("Main Steel calculations'")
Ast = ((0.5*fck*b*d)/(fy))*(1-((1-((4.6*Mu*1000000)/(fck*b*d*d))**0.5))
print("Ast:", Ast)
print("Check for Ast")

```

```

if Ast<Astmin:
    print("Take Ast=Astmin")
else:
    print("Ast>Astmin, Hence SAFE")
dia1 = float(input("Enter the value of bar diameter for main steel:"))
dia2 = float(input(" Enter the value of bar diameter for Distribution steel:"))
# Area of bar
a01 = 0.7854*dia1*dia1
print("The Value of Area of main steel bar (a01):", a01)
a02= 0.7854* dia2*dia2
print("The Value of Area of main steel bar (a02):", a02)
# Sapcing Calculations
Spacing1 = a01*b/Ast
print("The sapcing for main steel bars is;", Spacing1)
Spacing2 = a02*b/Astmin
print("The sapcing for distribution steel bars is;", Spacing2)
print("Check 1 for main steel")
if Spacing1>300:
    print("UNSAFE")
else:
    print("SAFE")
print("'Check 2 for main steel")
if Spacing1> 3*d:
    print("UNSAFE")
else:
    print("SAFE")
print("Check 1 fon Distribution steel")
if Spacing1>300:
    print("UNSAFE")
else:
    print("SAFE")
print("Check 2 for Distribution steel")
if Spacing1>5*d:
    print("UNSAFE")
else:
    print("'SAFE")
print("'Approximated values of Sapcing:")
S1 = float(input("Enter the value of spacing of main bars:"))
S2 = float(input("Enter the value of spacing of distribution bars:"))
Astprovided = a01*b/S1
print ("The provided steel area for main bars at section in mm^2 is:", Astprovided)
Astprodist = a02*b/S2
print ("The provided steel area for distribution bars at section in mm^2 is: ", Astprodist)
# Check for Shear
Vu = (Wu*span/2)-(Wu*((bs/2)-(d/1000)))
print ("The value of SF at a Section is:", Vu)
SStress = (Vu*1000)/(b*d)
print ("The value of shear stress is:", SStress)
# From table 20 IS 456:2007 page 73
SStressmax = float(input("Enter the value of maximum Shear stress:"))
if SStress>SStressmax:
    print("Crushing will happen")
else:
    print("SAFE")
# Percentage Steel
pt =(100* Ast)/ (b *d) *120
print("Enter the value of percentage steel is:", pt)
# From table 19 IS 456:2007 page 73

```

```

SS= float(input("Enter the value of Shear Stress is:"))
k= float(input("Enter the value of depth factor:"))
Shear = k*SS
print("The value of shear at section is:", Shear)
if SStress>Shear:
    print("Shear Reinforcement Required")
else:
    print("Shear Reinforcement not Required, SAFE")
# Check for Deflection
ActDEF = span*1000/d
print("The value od span/d is:", ActDEF)
# Actual Deflection
MaxDEF = S*MF*k1*k2*k3*k4
print("The permissible deflection is:", MaxDEF)
if MaxDEF>S/d:
    print("SAFE")
else:
    print("UNSAFE")
# Check for Anchorage Length
M1 = 0.87*fy*Ast* (d - (fy*Ast)/(fck*b))
print("The value of Moment (M1)''", M1)
lo = 8*dia1
La = 1.3*(M1/Vu)+10
print("The value of Anchorage length is:", La)
# Development Length
bonds = float(input("Enter the value of Bond Stress:"))
Ld = 0.87 *fy*dia1/4* bonds *1.6
print("The value of Development length is:", Ld)
if La>Ld:
    print("'SAFE")
else:
    print("increase anchorage")

```

```

Enter the value of effective span in meters:3
Enter the value of width of slab in mm:1000
Entert the value of Support Width in meters:0.23
Enter the value of Characteristics Compressive Strength:20
Enter the value of grade of steel:415
Enter the value of Modulus of Elasticity is:200000
Enter the value of Live Load:4
Enter the value of Floor Finish:1.8
Enter the value of Density of RCC:25
The value of Neutral Axis Factor (ku) is: 0.4791666666666667
The value of Moment Resistance factor (Ru) is: 2.7556874999999996
Ent er the value of Steel Stress of Service:240
Enter the value of Modification Factor:1.2
Enter the value of span/d ratio:20
Enter the value of Correction factor if sapn> 10m (k1):1
Enter the value of Tension r/f correction factor (k2):1
Enter the value of Compression r/f correction factor (k3):1
Enter the value of correction factor in case of flanged section (k4):1
The value of effective depth as per deflection criteria is: 125.0
Enter the value of Effective depth in mm (d):130
Enter the value of Overall depth in mm (D):150
The Dead load is: 3.75
Enter the value of partial Safety Factor is: 1.5
The value of total load is: 9.55
Wu= 14.325000000000001
The Value of Bending Moment (Mu) is: 16.115625
The value of Effective depth as per Mornent criteria: 76.473082008588
SAFE
Enter the value of Effective depth in mm (d):130
Minimum Steel Calculations
The value of Minimum steel is: 180.0
Main Steel calculations'
Ast= 364.7577413804497
Check for Ast
Ast>Astmin, Hence SAFE
Enter the value of bar diameter for main steel:10
Enter the value of bar diameter for Distribution steel:8

```

The Value of Area of main steel bar (ao1): 78.54
The Value of Area of main steel bar (ao2): 50.2656
The sapcing for main steel bars is; 215.32099552640113
The sapcing for distribution steel bars is; 279.25333333333333
Check 1 for main steel
SAFE
'Check 2 for main steel
SAFE
Check 1 fon Distribution steel
SAFE
Check 2 for Distribution steel
'SAFE
'Approximated values of Sapcing:
Enter the value of spacing of main bars:210
Enter the value of spacing of distribution bars:270
The provided steel area for main bars at section in mm² is: 374.0
The provided steel area for distribution bars at section in mm² is: 186.1688888888889
The value of SF at a Section is: 21.702375
The vaue of shear stress is: 0.16694134615384615
Enter the value of maximum Shear stress:2.8
SAFE

SOHAM JOSHI