

Arduino UNO R3

- D3 to SIM900A (DB9-3 (RXD))
- D2 to SIM900A (DB9-2 (TXD))
- 5V to LCD 16x2 (VDD), SIM900A (VCC)
- GND to LCD 16x2 (VSS) ,LCD 16x2 (RW), SIM900A (GND), 9V Battery (-)
- D7 to 4X4 Membrane Matrix Keypad (R1)
- D6 to 4X4 Membrane Matrix Keypad (R2)
- D5 to 4X4 Membrane Matrix Keypad (R3)
- D4 to 4X4 Membrane Matrix Keypad (R4)
- D11 to 4X4 Membrane Matrix Keypad (C1)
- D10 to 4X4 Membrane Matrix Keypad (C2)
- D9 to 4X4 Membrane Matrix Keypad (C3)
- D8 to 4X4 Membrane Matrix Keypad (C4)
- A0 to LCD 16x2 (RS)
- A1 to LCD 16x2 (E)
- A2 to LCD 16x2 (D4)
- A3 to LCD 16x2 (D5)
- A4 to LCD 16x2 (D6)
- A5 to LCD 16x2 (D7)
- Vin to 9V Battery (+)

4*4 Membrane Matrix Keypad

- R1 to Arduino UNO (D7), C1 to Arduino UNO (D11)
- R2 to Arduino UNO (D6), C2 to Arduino UNO (D10)
- R3 to Arduino UNO (D5), C3 to Arduino UNO (D9)
- R4 to Arduino UNO (D4), C4 to Arduino UNO (D8)

LCD 16*2

- VDD to Arduino UNO (5V)
- VSS to Arduino UNO (GND)
- RW to Arduino UNO (GND)
- RS to Arduino UNO (A0)
- E to Arduino UNO (A1)
- D4 to Arduino UNO (A2)
- D5 to Arduino UNO (A3)
- D6 to Arduino UNO (A4)
- D7 to Arduino UNO (A5)

SIM900A

- DB9-3 (RXD) to Arduino UNO (D3)
- DB9-2 (TXD) to Arduino UNO (D2)
- VCC to Arduino UNO (5V)
- GND to Arduino UNO (GND)
- 5VT to Loudspeaker (pin1)
- 5VR to Loudspeaker (pin2)
- 3VT to Condenser Microphone (pin1)
- 3VR to Condenser Microphone (pin2)

9V Battery

- + to Arduino UNO (Vin)
- - to Arduino UNO (GND)