

Extern Control (PLC, fieldbus, network)

XTS TRANSPORT LAYER

GVL_XTS.XtsTransportCtrl

GVL_XTS.XtsTransportState

GVL_XTS.StationCtrl[]

GVL_XTS.StationState[]

GVL_XTS.MoverCtrl[]

GVL_XTS.MoverState[]

GVL_XTS.XtsTransport

GVL_XTS.Station[]

GVL_XTS.Mover[]

