


XTS TRANSPORT LAYER – Mover Class

BECKHOFF




1. Design




▪ GVL_XTS.Mover (fb_MoverCtrl)

- fb_Mover
 - Encapsulates Motion Control and Collision Avoidance function blocks
 - Message handling
 - Base class of fb_MoverCtrl
- fb_MoverCtrl
 - Cyclic execution wrapper
 - OnChange check of commands
 - State feedback
- I_XtsTransport_Mover
 - Interface for use in fb_CaGroup, fb_Station, fb_TransportUnit




▪ fb_Mover:

- **Cycle()** method must be called by extending class
- **Check()** must be used in extending class (pointer checks)
- Method flow charts, see doc folder
 - Execute behaviour:
 - initialize call with 'Execute:=FALSE'
- Methods feedback: E_PROGRESS



- **fb_MoverCtrl():**
 - Requires cyclic call of instance
 - See calls in MAIN() as example
 - OnChange check of Ctrl.Cmd
 - References to Ctrl/State structs
 - References to Mover motion parameter structs
 - State.State feedback:
 - Command enum equivalent + E_PROGRESS




- **fb_MoverCtrl():**
 - Cyclic execution of movement commands
 - OnChange check of Ctrl.Cmd
 - References to Ctrl/State structs
 - References to Mover motion parameter structs

```


21 FUNCTION_BLOCK fb_MoverCtrl EXTENDS fb_Mover
22 VAR
23     // Ctrl and State for executing commands
24     _stCtrl      : REFERENCE TO ARRAY[1..MAX_MOVER] OF ST_MOVER_CTRL;
25     _stState     : REFERENCE TO ARRAY[1..MAX_MOVER] OF ST_MOVER_STATE;
26
27     // data structures to use with commands
28     _stMoveData  : REFERENCE TO ARRAY[1..MAX_MOVER] OF ST_MOVE_DATA;
29     _stGearData  : REFERENCE TO ARRAY[1..MAX_MOVER] OF ST_GEAR_DATA;
30
31     _eCmd,
32     _eCmdOld     : E_MOVER_CTRL;
33
34     _eState      : E_MOVER_STATE;
35
36     _eResult     : E_PROGRESS;
37 END_VAR
38
39 1 IF NOT Check() THEN RETURN; END_IF
40 2
41 3 _stMsg.eDevice      := e_Device.Mover + _nMoverId;
42 4
43 5 // copy to local for debug
44 6 _eCmd              := _stCtrl[_nMoverId].Cmd;
45 7
46 8 // cyclic check for command change
47 9 // get state for cmd
48 10 IF (_eCmd <> _eCmdOld)
49 11 THEN
50 12     // get matching sdtate for Ctrl.Cmd
51 13     _eState        := Cmd(_eCmd);
52 14     _eCmdOld       := _eCmd;
53 15 END_IF

```

- **fb_MoverCtrl():**
 - Control structure
 - ST_MOVER_CTRL
 - State structure
 - ST_MOVER_STATE
 - Ctrl/State structs are used to address mover
 - Parameter structures are to be used according to the job you want to give to the mover
 - ST_MOVE_DATA
 - ST_GEAR_DATA
 - Mover information:
 - ST_MOVER_INFO



- **fb_MoverCtrl():**
 - **ST_MOVER_CTRL / ST_MOVER_STATE**
 - Command
 - State + Progress
 - See doc folder for flow chart



- **fb_MoverCtrl():**
 - **ST_MOVE_DATA**
 - Parameter struct for motion commands

```
XTS_TRANSPORT  ▸ ST_MOVE_DATA  ▸ × TC_XTS_BASE
1 {attribute 'pack_mode' := '2'}
2 TYPE ST_MOVE_DATA :
3 STRUCT
4 // HAUD 2024 03 14
5 // some init data added for example
6 rPos          : LREAL := 2275.0;
7 rVelo         : LREAL := 500.0;
8 rAcc          : LREAL := 5000.0;
9 rJerk         : LREAL := 500000.0;
10 rGap         : LREAL := 100.0;
11 rOverride    : LREAL := 100.0;
12 rDelta       : LREAL := 0.05;
13 rDistance    : LREAL := 25.0;
14 END_STRUCT
15 END_TYPE
16
```


- **fb_MoverCtrl():**
 - **ST_GEAR_DATA**
 - Parameter struct for motion commands
 - E_MOVER_CTRL.MOVER_GEAR_IN
 - E_MOVER_CTRL.MOVER_GEAR_OUT
 - E_MOVER_CTRL.MOVER_GEAR_IN_POS_CA

```
XTS_TRANSPORT  ▸ ST_GEAR_DATA  ▸ X E_MOVER_CTRL
1 {attribute 'pack_mode' := '2'}
2 TYPE ST_GEAR_DATA :
3 STRUCT
4     rDeltaToMasterPos      : LREAL;
5     rModuloSyncPosSlave    : LREAL;
6     rMasterStartDistance   : LREAL;
7     rGearNumerator         : LREAL;
8     iGearDenominator       : USINT
9 END_STRUCT
10 END_TYPE
11
```

- **fb_MoverCtrl():**
 - **ST_GEAR_DATA**
 - Reference to MasterAxis
 - local var '_Master' must be valid reference
 - Base class contains property to link **AXIS_REF** of master axis to **fb_Mover**


```
XTS_TRANSPORT  ▸  fb_Mover  ✕  fb_Mover.Master  ST_GEAR_DATA  E_MOVER_CTRL  ST_MOVE_DATA
20  //-----
21  FUNCTION_BLOCK fb_Mover IMPLEMENTS I_XtsTransport_Mover
22  VAR
23      _nMoverId      : UINT;
24
25      _sState        : STRING;
26
27      _Master,
28      _Mover          : REFERENCE TO AXIS_REF;
29      _rLastPosition  : REFERENCE TO LREAL;
30      _rLastGap       : REFERENCE TO LREAL;
31
32      _RailLength     : LREAL;
33      _nSyncStrategy  : Tc3_Mc3Definitions.MC_SYNC_STRATEGY := Tc3_Mc3Definitions.MC
34
35      // mover compact axis information
36      _stInfo          : REFERENCE TO ST_MOVER_INFO; // ActPos, Enable, ...
37
38      _bError          : BOOL; // used in Cycle()
```

- **fb_MoverCtrl():**
 - **ST_GEAR_DATA**
 - Reference to MasterAxis
 - local var ‘_Master’ must be valid reference
 - Base class contains property to link AXIS_REF of master axis to Mover
 - Property you have to set before / on use of gearing motion function






▪ I_Transport_Mover:

- Interface for use in other classes
 - Fb_TransportUnit
 - Fb_CaGroup
 - Fb_Station
- Interface is implemented by fb_Mover



- **I_Transport_Mover:**
 - Used in Property by other classes



XTS_TRANSPORT_LAYER project

MIT License

Copyright (c) 2025 HAUD

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.