

# XTS TRANSPORT LAYER

- ST\_STATION\_PARAMETER: placement of 12 parallel synced working XtsStations
- equally spaced
  - ST\_STATION\_PARAMETER.rReleaseDistance takes care of movers being entered into the target stations LinkedList in correct order!
  - Stations have individual PosWait values, so movers that will enter are already in motion after the process released the prior set of movers.
- PosWait, PosStop[1] = 0, Release Distance > 0

Direction  forward

Ex06

