
DroneKit Documentation

Release 2.4.0

Kevin Hester

May 06, 2019

Contents

1	Introducing DroneKit-Python	3
1.1	About DroneKit	3
1.2	Release Notes	4
1.3	Migrating to DKPY 2.0	9
1.4	Open Source Licence	14
2	Quick Start	19
2.1	Installation	19
2.2	Basic “Hello Drone”	19
2.3	Next Steps	21
3	Developing with DroneKit	23
3.1	Installing DroneKit	23
3.2	Companion Computers	24
3.3	Setting up a Simulated Vehicle (SITL)	24
3.4	Best Practices	28
3.5	Coding Standards	31
4	Guide	33
4.1	Connecting to a Vehicle	33
4.2	Vehicle State and Settings	34
4.3	Taking Off	40
4.4	Guiding and Controlling Copter	43
4.5	Missions (AUTO Mode)	50
4.6	Debugging	56
4.7	MAVLink Messages	57
5	Examples	59
5.1	Running the Examples	59
5.2	Example: Vehicle State	60
5.3	Example: Simple Go To (Copter)	69
5.4	Example: Guided Mode Movement and Commands (Copter)	74
5.5	Example: Basic Mission	93
5.6	Example: Mission Import/Export	100
5.7	Example: Create Attribute in App	106
5.8	Example: Follow Me	114
5.9	Example: Drone Delivery	119

5.10	Example: Flight Replay	128
5.11	Example: Channels and Channel Overrides	136
6	Contributing	141
6.1	How you can Contribute	141
6.2	Contributing to the API	141
6.3	Contributing to the Documentation	144
6.4	Building DroneKit-Python on Windows	146
6.5	Building DroneKit-Python on Linux	147
7	DroneKit-Python API Reference	149
	Python Module Index	177

DroneKit-Python 2.x helps you create powerful apps for UAVs. These apps run on a UAV's *Companion Computer*, and augment the autopilot by performing tasks that are both computationally intensive and require a low-latency link (e.g. computer vision).

This documentation provides everything you need to get started with DroneKit-Python, including an *overview* of the API, quick start, guide material, a number of demos and examples, and *API Reference*.

Tip: *DroneKit-Python version 1.5* has now been superseded (see these links for legacy [documentation](#) and [examples](#)). If you're migrating from *DroneKit-Python version 1.x*, check out our comprehensive *Migration Guide*.

Contents:

Introducing DroneKit-Python

This section provides an overview of DroneKit-Python’s functionality, licensing, and supported companion computers. After reading, you will understand what the kit offers and the opportunities it provides. You will also know where to go if you have further questions for suggestions for improvement.

1.1 About DroneKit

DroneKit-Python allows developers to create apps that run on an onboard *companion computer* and communicate with the *ArduPilot* flight controller using a low-latency link. Onboard apps can significantly enhance the autopilot, adding greater intelligence to vehicle behaviour, and performing tasks that are computationally intensive or time-sensitive (for example, computer vision, path planning, or 3D modelling). DroneKit-Python can also be used for ground station apps, communicating with vehicles over a higher latency RF-link.

The API communicates with vehicles over MAVLink. It provides programmatic access to a connected vehicle’s telemetry, state and parameter information, and enables both mission management and direct control over vehicle movement and operations.

1.1.1 Open source community

DroneKit-Python is an open source and community-driven project.

You can find all the source code on [Github here](#) and check out our permissive *Apache v2 Licence*. If you want to join the community, then see our *contributing section* for lots of ideas on how you can help.

1.1.2 Compatibility

DroneKit-Python is compatible with vehicles that communicate using the *MAVLink protocol* (including most vehicles made by *3DR* and other members of the *DroneCode foundation*). It runs on Linux, Mac OS X, or Windows.

Note: DroneKit-Python is validated against, and hence *most compatible* with, the [ArduPilot UAV Platform](#). Vehicles running other autopilots may be less compatible due to differences in adherence/interpretation of the MAVLink specification. Please report any autopilot-specific issues [on Github here](#).

1.1.3 API features

The API provides classes and methods to:

- Connect to a vehicle (or multiple vehicles) from a script
- Get and set vehicle state/telemetry and parameter information.
- Receive asynchronous notification of state changes.
- Guide a UAV to specified position (GUIDED mode).
- Send arbitrary custom messages to control UAV movement and other hardware (GUIDED mode).
- Create and manage waypoint missions (AUTO mode).
- Override RC channel settings.

A complete API reference is available [here](#).

1.1.4 Technical support

This documentation is a great place to get started with developing DroneKit Python APIs.

If you run into problems, the best place to ask questions is the [DroneKit-Python Forum](#). If your problem turns out to be a bug, then it should be [posted on Github](#).

1.2 Release Notes

This page contains the release notes for DroneKit-Python `minor` and `major` releases.

Note: DroneKit-Python marks releases using the `major.minor.patch` release numbering convention, where `patch` is used to denote only bug fixes, `minor` is used for releases with new features, and `major` indicates the release contains significant API changes.

1.2.1 Latest release

1.2.2 Changelog

Version 2.9.1 (2017-04-21)

Improvements

- home locatin notifications
- notify ci status to gitter

- basic python 3 support
- isolated logger function so implementers can override
- rename windows installer

Cleanup

- removed legacy cloud integrations

Bug Fixes

- fix missing `**` operator for pymavlink compatibility

Version 2.9.0 (2016-08-29)

Bug Fixes

- MAVConnection stops threads on exit and close
- PX4 Pro flight modes are now properly supported
- go to test now uses correct `global_relative_frame` alt

Improvements

- Updated pymavlink dependency to v2 from v1 hoping we don't fall behind again.

Version 2.8.0 (2016-07-15)

Bug Fixes

- Makes sure we are listening to `HOME_LOCATION` message, before we would only set home location if received by waypoints.

Version 2.7.0 (2016-06-21)

Improvements

- Adds `udpin-multi` support

Version 2.6.0 (2016-06-17)

Bug Fixes

- Fixes patched `mavutil` `sendfn`

Version 2.5.0 (2016-05-04)

Improvements

- Catch and display message and attribute errors, then continue
- Improved takeoff example docs
- Deploy docs on successful merge into master (from CircleCI)
- Drone delivery example, explain port to connect
- MicroCGS example now uses SITL
- Make running examples possible on Vagrant

Bug Fixes

- Mav type for rover was incorrect
- `_is_mode_available` can now handle unrecognized mode codes
- Fix broken links on companion computer page
- Fix infinite loop on channel test

Version 2.4.0 (2016-02-29)

Bug Fixes

- Use monotonic clock for all of the internal timeouts and time measurements
- Docs fixes

Version 2.3.0 (2016-02-26)

New Features

- PX4 compatibility improvements

Updated Features

- Documentation fixes
- PIP repository improvements
- Mode-setting API improvements
- ardupilot-solo compatibility fixes

Version 2.2.0 (2016-02-19)

Bug Fixes

- Splits outbound messages into its own thread.
- Remove of capabilities request on HEARTBEAT listener
- Check if mode_mapping has items before iteration

Version 2.1.0 (2016-02-16)

New Features

- Gimbal control attribute
- Autopilot version attribute
- Autopilot capabilities attribute
- Best Practice guide documentation.
- Performance test example (restructured and docs added)

Updated Features:

Many documentation fixes:

- Restructured documentation with Develop (Concepts) and Guide (HowTo) sections
- Docs separated out “Connection Strings” section.
- Improved test and contribution sections.
- Updated examples and documentation to use DroneKit-Sitl for simulation (“zero setup examples”)
- Debugging docs updated with additional libraries.
- Flight Replay example fetches data from TLOG rather than droneshare
- Drone Delivery example now uses start location for home address.
- Disabled web tests (not currently supported/used)
- Updated copyright range to include changes in 2016

Bug Fixes

- Numerous minor docs fixes.
- Harmonise nosetest options across each of the integration platforms
- Fix incorrect property marker for airspeed attribute

Version 2.0.2 (2015-11-30)

Bug Fixes:

- Updates `requests` dependency to work $\geq 2.5.0$

Version 2.0.0 (2015-11-23)

New Features:

- Renamed library and package from DroneAPI to DroneKit on pip
- DroneKit Python is now a standalone library and no longer requires use of MAVProxy
- Connect multiple vehicles in one script by creating separate vehicle instances
- Removed NumPy, ProtoBuf as dependencies
- Add MAVLink message listeners using `add_message_listener` methods
- Added `on_attribute` and `on_message` function decorator shorthands
- Added `mount_status`, `system_status`, `ekf_ok`, `is_armable`, `heading`
- Made `settable` `groundspeed`, `airspeed`
- Moved `dronekit.lib` entries to root package `dronekit`
- Added `parameters.set` and `parameters.get` for fine-tuned parameter access
- `parameters` now observable and iterable ([#442](#))
- Added `last_heartbeat` attribute, updated every event loop with time since last heartbeat ([#451](#))
- Await attributes through `wait_ready` method and `connect` method parameter
- Adds subclassable `Vehicle` class, used by `vehicle_class` parameter in `connect`

Updated Features:

- `local_connect` renamed to `connect()`, accepting a connection path, link configuration, and timeout settings
- Removed `.set_mavrx_callback`. Use `vehicle.on_message('*', obj)` methods
- Renamed `add_attribute_observer` methods to `add_attribute_listener`, etc. ([#420](#))
- Renamed `wait_init` and `wait_valid` to `wait_ready`
- Split `home_location` is a separate attribute from `commands` `waypoint` array
- Moved RC channels into `.channels` object ([#427](#))
- Split location information into `local_frame`, `global_frame`, and `global_relative_frame` (and removed `is_relative`) ([#445](#))
- Renamed `flush` to `commands.upload`, as it only impacts waypoints ([#276](#))
- `commands.goto` and `commands.takeoff` renamed to `simple_goto` and `simple_takeoff`

Bug Fixes:

- `armed` and `mode` attributes updated constantly (#60, #446)
- Parameter setting times out (#12)
- `battery` access can throw exception (#298)
- `Vehicle.location` reports incorrect `is_relative` value for Copter (#130)
- Excess arming message when already armed

1.2.3 All releases

For information about all past releases, please see [this link on Github](#).

1.2.4 Working with releases

The following PyPI commands are useful for working with different version of DroneKit Python:

```
pip install dronekit      # Install the latest version
pip install dronekit --upgrade  # Update to the latest version
pip show dronekit        # Find out what release you have installed
pip install dronekit==2.0.0rc1  # Get a specific old release (in this case 2.0.0rc1)
```

See [Release History on the package ranking page](#) for a list of all releases available on PyPI.

1.3 Migrating to DKPY 2.0

DroneKit-Python 2.0 has undergone a significant *architectural* evolution when compared to version 1.x (the library changed from a MAVProxy extension to a standalone Python module). The API itself remains similar, with the most important difference being that you now need to specify the vehicle target address inside the script.

The sections below outline the main migration areas.

Note: *DroneKit-Python version 1.5* has now been superseded (see these links for legacy [documentation](#) and [examples](#)).

1.3.1 Installation

DKPY 2.0 is now installed from *pip* on all platforms - see [Installing DroneKit](#) for more information.

Installation is generally simpler than on DK 1.x because there are far fewer dependencies (both MAVProxy and numpy are no longer needed).

Note:

- The DroneKit-Python Windows installer cannot be used for DKPY2.x (and is no longer needed).
 - One implication of the reduced dependencies is that it should now be easier to use other Python distributions (like ActivePython - although this has not been verified!)
-

1.3.2 Launching scripts

DroneKit-Python 2.0 apps are run from an ordinary Python command prompt. For example:

```
some_python_script.py      # or `python some_python_script.py`
```

Note: This contrasts with DKPY 1.x scripts, which were run from within MAVProxy using the command:

```
api start some_python_script.py
```

1.3.3 Code changes

This section outlines the changes you will need to make to your DroneKit-Python scripts.

Connecting to a vehicle

You must specify the target vehicle address in your script (in DKPY 1.x this was done when you launched MAVProxy).

The code fragment below shows how you import the `connect()` method and use it to return a connected `Vehicle` object. The address string passed to `connect()` takes the same values as were passed to *MAVProxy* when setting up a connection in DKPY 1.x (in this case, a SITL instance running on the same computer).

```
from dronekit import connect

# Connect to the Vehicle (in this case a UDP endpoint)
vehicle = connect('127.0.0.1:14550', wait_ready=True)
```

Note: The `wait_ready=True` parameter ensures that `connect()` won't return until `Vehicle.parameters` and most other default attributes have been populated with values from the vehicle. Check out `Vehicle.wait_ready()` for more information (this method is used by the `connect()` implementation).

`connect()` also has arguments for setting the baud rate, returning your own *custom vehicle classes* and setting the length of the connection timeout.

After connecting, the returned `vehicle` can be used in exactly the same way as in DKPY 1.x.

Note: The above code replaces DKPY 1.x code to get the Vehicle (similar to the example below):

```
# Get an instance of the API endpoint
api = local_connect()
# Get the connected vehicle (currently only one vehicle can be returned).
vehicle = api.get_vehicles()[0]
```

Connection status checks

DroneKit no longer runs in *MAVProxy* so scripts don't need to monitor and act on external thread shutdown commands.

Remove code that checks the `api.exit` status (note that the `api.exit` call below is commented out).

```
while not vehicle.armed # and not api.exit:
    print "Waiting for arming..."
    time.sleep(1)
```

Note: In fact you should delete all references to `APIConnection` class and its methods (`get_vehicles()`, `exit()` and `stop()`).

Script completion checks

Examples that might possibly have outstanding messages should call `Vehicle.close()` before exiting to ensure that all messages have flushed before the script completes:

```
# About to exit script
vehicle.close()
```

Command line arguments

Remove any code that uses the `local_arguments` array to get script-local command line arguments (via `MAVProxy`).

From DKPY 2.0 command line arguments are passed to `sys.argv` as with any other script. The examples use the `argparse` module for argument parsing, but you can use whatever method you like.

Note: In DKPY 1.x the script's `sys.argv` values were the values passed to `MAVProxy` when it was started. To access arguments passed to the script from `MAVProxy` you used the `local_arguments` array. For example if you started a script as shown below:

```
api start my_script.py 101
```

Then you would read the integer in your code using

```
my_argument = int(local_arguments[0])
```

Current script directory

DroneKit-Python v1.x passed a global property `load_path` to any executed file containing the directory in which the script was running. This is no longer needed in version 2 and has been removed.

Instead, use normal Python methods for getting file system information:

```
import os.path
full_directory_path_of_current_script = os.path.dirname(os.path.abspath(__file__))
```

Vehicle.location

DroneKit-Python v1.x had a `Vehicle.location` attribute which provided latitude and longitude information in the global frame, and altitude either relative to sea-level or the home location (depending on the value of its `is_relative` member).

DKPY2.0 uses and attribute with the same name to provide location in global, global-relative and local (NED) frames:

```
print "Global Location: %s" % vehicle.location.global_frame
print "Global Location (relative altitude): %s" % vehicle.location.global_relative_
↪frame
print "Local Location: %s" % vehicle.location.local_frame
```

For more information see: *Vehicle.location*, *Vehicle.location.global_frame*, *Vehicle.location.global_relative_frame*, *Vehicle.location.local_frame*, and *Vehicle State and Settings*.

Takeoff and movement commands

DroneKit-Python v1.x provided guided mode takeoff and movement methods `Vehicle.commands.takeoff()` and `Vehicle.commands.goto()`.

DKPY2.0 instead provides *Vehicle.simple_takeoff* and *Vehicle.simple_goto*. These are the same as the old methods except that *simple_goto* allows you to optionally set the default target groundspeed and airspeed.

Vehicle.airspeed and *Vehicle.groundspeed* are now settable values. Call these to set the default target speed used when moving with *Vehicle.simple_goto* (or other position-based movement commands).

Home location

DroneKit-Python 1.x code retrieved the home location from the first element in *Vehicle.commands*. This code must be replaced with the DroneKit-Python 2.x *Vehicle.home_location* attribute.

Tip: Even though the home location is no longer returned as the first waypoint in *Vehicle.commands*, you will still need to download the commands in order to populate the value of *Vehicle.home_location*.

Missions and Waypoints

The API for working with missions has been improved and made significantly more robust.

One of the major changes is that the *Vehicle.commands* list no longer includes the *home location* waypoint in the 0th index. Another change is that we now wait for command download to complete using *Vehicle.commands.wait_ready()*.

All the known bugs have been fixed. It is now much easier to download, clear, and add items to the mission because there is no need to work around race conditions and other issues with the API.

For more information see *Missions (AUTO Mode)*.

Observing attribute changes

The DroneKit-Python 1.x observer function `vehicle.add_attribute_observer` has been replaced by *Vehicle.add_attribute_listener()* or *Vehicle.on_attribute()* in DKYP2.x, and `Vehicle.remove_attribute_observer` has been replaced by *remove_attribute_listener()*.

The main difference is that the callback function now takes three arguments (the vehicle object, attribute name, attribute value) rather than just the attribute name. This allows you to more easily write callbacks that support attribute-specific and vehicle-specific handling and means that you can get the new value from the callback attribute rather than by re-querying the vehicle.

Note: The difference between `Vehicle.add_attribute_listener()` and `Vehicle.on_attribute()` is that attribute listeners added using `Vehicle.on_attribute()` cannot be removed (while `on_attribute()` has a more elegant syntax).

A few attributes have been modified so that they only notify when the value changes: `Vehicle.system_status`, `Vehicle.armed`, and `Vehicle.mode`. Users no longer need to add caching code for these attributes in their listeners. Attributes that provide “streams” of information (i.e. sensor output) remain unchanged.

Note: If you’re *creating your own attributes* this caching is trivially provided using the `cache=True` argument to `Vehicle.notify_attribute_listeners()`.

See *Observing attribute changes* for more information.

Parameter changes

In DKPY2 you can now *observe* parameters in order to be notified of changes, and also *iterate* `Vehicle.parameters` to get a list of off the supported values in the connected vehicle.

In addition, the code to download parameters and keep information in sync with the vehicle is now a lot more robust.

Intercepting MAVLink Messages

DroneKit-Python 1.x used `Vehicle.set_mavlink_callback()` and `Vehicle.unset_mavlink_callback` to set/unset a callback function that was invoked for every single mavlink message.

In DKPY2 this has been replaced by the `Vehicle.on_message()` decorator, which allows you to specify a callback function that will be invoked for a single message (or all messages, by specifying the message name as the wildcard string ‘*’).

Tip: `Vehicle.on_message()` is used in core DroneKit code for message capture and to create `Vehicle` attributes.

The API also adds `Vehicle.add_message_listener()` and `Vehicle.remove_message_listener()`. These can be used instead of `Vehicle.on_message()` when you need to be able to *remove* an added listener. Typically you won’t need to!

See *MAVLink Messages* for more information.

New attributes

In addition to the *home_location*, a few more attributes have been added, including: `Vehicle.system_status`, `Vehicle.heading`, `Vehicle.mount_status`, `Vehicle.ekf_ok`, `Vehicle.is_armable`, `Vehicle.last_heartbeat`.

Channel Overrides

Warning: Channel overrides (a.k.a “RC overrides”) are highly discommended (they are primarily implemented for simulating user input and when implementing certain types of joystick control).

DKPY v2 replaces the `vehicle.channel_readback` attribute with `Vehicle.channels` (and the `Channels` class) and the `vehicle.channel_override` attribute with `Vehicle.channels.overrides` (and the `ChannelsOverrides` class).

Documentation and example code for how to use the new API are provided in *Example: Channels and Channel Overrides*.

1.3.4 Debugging

DroneKit-Python 1.x scripts were run in the context of a MAVProxy. This made them difficult to debug because you had to instrument your code in order to launch the debugger, and debug messages were interleaved with MAVProxy output.

Debugging on DroneKit-Python 2.x is much easier. Apps are now just standalone scripts, and can be debugged using standard Python methods (including the debugger/IDE of your choice).

1.4 Open Source Licence

DroneKit-Python is licensed under the *Apache License Version 2.0, January 2004* (<http://www.apache.org/licenses/>). This is present in the `LICENSE` file in the source tree, and reproduced below:

Apache License

Version 2.0, January 2004
<http://www.apache.org/licenses/>

TERMS AND CONDITIONS FOR USE, REPRODUCTION, AND DISTRIBUTION

1. Definitions.

"License" shall mean the terms and conditions for use, reproduction, and distribution as defined by Sections 1 through 9 of this document.

"Licensor" shall mean the copyright owner or entity authorized by the copyright owner that is granting the License.

"Legal Entity" shall mean the union of the acting entity and all other entities that control, are controlled by, or are under common control with that entity. For the purposes of this definition, "control" means (i) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (ii) ownership of fifty percent (50%) or more of the outstanding shares, or (iii) beneficial ownership of such entity.

"You" (or "Your") shall mean an individual or Legal Entity exercising permissions granted by this License.

"Source" form shall mean the preferred form for making modifications,

(continues on next page)

(continued from previous page)

including but not limited to software source code, documentation source, and configuration files.

"Object" form shall mean any form resulting from mechanical transformation or translation of a Source form, including but not limited to compiled object code, generated documentation, and conversions to other media types.

"Work" shall mean the work of authorship, whether in Source or Object form, made available under the License, as indicated by a copyright notice that is included in or attached to the work (an example is provided in the Appendix below).

"Derivative Works" shall mean any work, whether in Source or Object form, that is based on (or derived from) the Work and for which the editorial revisions, annotations, elaborations, or other modifications represent, as a whole, an original work of authorship. For the purposes of this License, Derivative Works shall not include works that remain separable from, or merely link (or bind by name) to the interfaces of, the Work and Derivative Works thereof.

"Contribution" shall mean any work of authorship, including the original version of the Work and any modifications or additions to that Work or Derivative Works thereof, that is intentionally submitted to Licensor for inclusion in the Work by the copyright owner or by an individual or Legal Entity authorized to submit on behalf of the copyright owner. For the purposes of this definition, "submitted" means any form of electronic, verbal, or written communication sent to the Licensor or its representatives, including but not limited to communication on electronic mailing lists, source code control systems, and issue tracking systems that are managed by, or on behalf of, the Licensor for the purpose of discussing and improving the Work, but excluding communication that is conspicuously marked or otherwise designated in writing by the copyright owner as "Not a Contribution."

"Contributor" shall mean Licensor and any individual or Legal Entity on behalf of whom a Contribution has been received by Licensor and subsequently incorporated within the Work.

2. Grant of Copyright License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable copyright license to reproduce, prepare Derivative Works of, publicly display, publicly perform, sublicense, and distribute the Work and such Derivative Works in Source or Object form.
3. Grant of Patent License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable (except as stated in this section) patent license to make, have made, use, offer to sell, sell, import, and otherwise transfer the Work, where such license applies only to those patent claims licensable by such Contributor that are necessarily infringed by their Contribution(s) alone or by combination of their Contribution(s) with the Work to which such Contribution(s) was submitted. If You institute patent litigation against any entity (including a cross-claim or counterclaim in a lawsuit) alleging that the Work

(continues on next page)

(continued from previous page)

or a Contribution incorporated within the Work constitutes direct or contributory patent infringement, then any patent licenses granted to You under this License for that Work shall terminate as of the date such litigation is filed.

4. Redistribution. You may reproduce and distribute copies of the Work or Derivative Works thereof in any medium, with or without modifications, and in Source or Object form, provided that You meet the following conditions:

- (a) You must give any other recipients of the Work or Derivative Works a copy of this License; and
- (b) You must cause any modified files to carry prominent notices stating that You changed the files; and
- (c) You must retain, in the Source form of any Derivative Works that You distribute, all copyright, patent, trademark, and attribution notices from the Source form of the Work, excluding those notices that do not pertain to any part of the Derivative Works; and
- (d) If the Work includes a "NOTICE" text file as part of its distribution, then any Derivative Works that You distribute must include a readable copy of the attribution notices contained within such NOTICE file, excluding those notices that do not pertain to any part of the Derivative Works, in at least one of the following places: within a NOTICE text file distributed as part of the Derivative Works; within the Source form or documentation, if provided along with the Derivative Works; or, within a display generated by the Derivative Works, if and wherever such third-party notices normally appear. The contents of the NOTICE file are for informational purposes only and do not modify the License. You may add Your own attribution notices within Derivative Works that You distribute, alongside or as an addendum to the NOTICE text from the Work, provided that such additional attribution notices cannot be construed as modifying the License.

You may add Your own copyright statement to Your modifications and may provide additional or different license terms and conditions for use, reproduction, or distribution of Your modifications, or for any such Derivative Works as a whole, provided Your use, reproduction, and distribution of the Work otherwise complies with the conditions stated in this License.

5. Submission of Contributions. Unless You explicitly state otherwise, any Contribution intentionally submitted for inclusion in the Work by You to the Licensor shall be under the terms and conditions of this License, without any additional terms or conditions. Notwithstanding the above, nothing herein shall supersede or modify the terms of any separate license agreement you may have executed with Licensor regarding such Contributions.
6. Trademarks. This License does not grant permission to use the trade names, trademarks, service marks, or product names of the Licensor, except as required for reasonable and customary use in describing the

(continues on next page)

(continued from previous page)

origin of the Work and reproducing the content of the NOTICE file.

7. Disclaimer of Warranty. Unless required by applicable law or agreed to in writing, Licensor provides the Work (and each Contributor provides its Contributions) on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied, including, without limitation, any warranties or conditions of TITLE, NON-INFRINGEMENT, MERCHANTABILITY, or FITNESS FOR A PARTICULAR PURPOSE. You are solely responsible for determining the appropriateness of using or redistributing the Work and assume any risks associated with Your exercise of permissions under this License.
8. Limitation of Liability. In no event and under no legal theory, whether in tort (including negligence), contract, or otherwise, unless required by applicable law (such as deliberate and grossly negligent acts) or agreed to in writing, shall any Contributor be liable to You for damages, including any direct, indirect, special, incidental, or consequential damages of any character arising as a result of this License or out of the use or inability to use the Work (including but not limited to damages for loss of goodwill, work stoppage, computer failure or malfunction, or any and all other commercial damages or losses), even if such Contributor has been advised of the possibility of such damages.
9. Accepting Warranty or Additional Liability. While redistributing the Work or Derivative Works thereof, You may choose to offer, and charge a fee for, acceptance of support, warranty, indemnity, or other liability obligations and/or rights consistent with this License. However, in accepting such obligations, You may act only on Your own behalf and on Your sole responsibility, not on behalf of any other Contributor, and only if You agree to indemnify, defend, and hold each Contributor harmless for any liability incurred by, or claims asserted against, such Contributor by reason of your accepting any such warranty or additional liability.

END OF TERMS AND CONDITIONS

APPENDIX: How to apply the Apache License to your work.

To apply the Apache License to your work, attach the following boilerplate notice, with the fields enclosed by brackets "{}" replaced with your own identifying information. (Don't include the brackets!) The text should be enclosed in the appropriate comment syntax for the file format. We also recommend that a file or class name and description of purpose be included on the same "printed page" as the copyright notice for easier identification within third-party archives.

Copyright {yyyy} {name of copyright owner}

Licensed under the Apache License, Version 2.0 (the "License");
you may not use this file except in compliance with the License.
You may obtain a copy of the License at

<http://www.apache.org/licenses/LICENSE-2.0>

Unless required by applicable law or agreed to in writing, software

(continues on next page)

(continued from previous page)

distributed under the License is distributed on an "AS IS" BASIS,
WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied.
See the License for the specific language governing permissions and
limitations under the License.

This topic shows how to quickly install a DroneKit-Python *development environment* and run a simple example to get vehicle attributes from a *simulated* Copter.

2.1 Installation

DroneKit-Python and the *dronekit-sitl simulator* are installed from **pip** on all platforms.

On Linux you will first need to install **pip** and **python-dev**:

```
sudo apt-get install python-pip python-dev
```

pip is then used to install *dronekit* and *dronekit-sitl*. Mac and Linux may require you to prefix these commands with `sudo`:

```
pip install dronekit
pip install dronekit-sitl
```

See *Installing DroneKit* and *dronekit-sitl* for more detailed installation instructions.

2.2 Basic “Hello Drone”

The script below first launches the simulator. It then imports and calls the `connect()` method, specifying the simulator’s connection string (`tcp:127.0.0.1:5760`). The method returns a *Vehicle* object that we then use to query the attributes.

```
print "Start simulator (SITL)"
import dronekit_sitl
sitl = dronekit_sitl.start_default()
connection_string = sitl.connection_string()
```

(continues on next page)

(continued from previous page)

```
# Import DroneKit-Python
from dronekit import connect, VehicleMode

# Connect to the Vehicle.
print("Connecting to vehicle on: %s" % (connection_string,))
vehicle = connect(connection_string, wait_ready=True)

# Get some vehicle attributes (state)
print "Get some vehicle attribute values:"
print " GPS: %s" % vehicle.gps_0
print " Battery: %s" % vehicle.battery
print " Last Heartbeat: %s" % vehicle.last_heartbeat
print " Is Armable?: %s" % vehicle.is_armable
print " System status: %s" % vehicle.system_status.state
print " Mode: %s" % vehicle.mode.name      # settable

# Close vehicle object before exiting script
vehicle.close()

# Shut down simulator
sitl.stop()
print("Completed")
```

Copy the text above into a new text file (**hello.py**) and run it in the same way as you would any other standalone Python script.

```
python hello.py
```

You should see the following output from the simulated vehicle:

```
Start simulator (SITL)
Downloading SITL from http://dronekit-assets.s3.amazonaws.com/sitl/copter/sitl-win-
↪copter-3.3.tar.gz
Extracted.
Connecting to vehicle on: 'tcp:127.0.0.1:5760'
>>> APM:Copter V3.3 (d6053245)
>>> Frame: QUAD
>>> Calibrating barometer
>>> Initialising APM...
>>> barometer calibration complete
>>> GROUND START
Get some vehicle attribute values:
  GPS: GPSInfo:fix=3,num_sat=10
  Battery: Battery:voltage=12.587,current=0.0,level=100
  Last Heartbeat: 0.713999986649
  Is Armable?: False
  System status: STANDBY
  Mode: STABILIZE
Completed
```

That's it- you've run your first DroneKit-Python script.

2.3 Next Steps

- Learn more about *Developing with DroneKit*. This covers development best practices and coding standards, and has more information about installation, working with a simulator and setting up a companion computer.
- Read through our step by step *Guide* to learn how to connect to your vehicle, takeoff, fly, and much more.
- Check out our *Examples*.

Developing with DroneKit

DroneKit-Python is primarily intended for use on Linux-based *Companion Computers* that travel on a vehicle and communicate with the autopilot via a serial port. It can also be used on ground-based computers running Linux, Windows or Mac OSX (communicating using WiFi or a telemetry radio).

During development you'll generally run it on a development computer, communicating with a *simulated vehicle* running on the same machine (via a UDP connection).

This section contains topics explaining how to develop with DroneKit-Python, covering subjects like installation, setting up the target vehicle or simulator, best practices and coding standards.

3.1 Installing DroneKit

DroneKit-Python can be installed on a Linux, Mac OSX, or Windows computer that has *Python 2.7* and can install Python packages from the Internet.

It is installed from **pip** on all platforms:

```
pip install dronekit
```

Installation notes:

- Mac and Linux require you prefix the command with `sudo`.

```
sudo pip install dronekit
```

- On Linux you may need to first install **pip** and **python-dev**:

```
sudo apt-get install python-pip python-dev
```

Alternatively, the *easy_install* tool provides another way to install pip:

```
sudo easy_install pip
```

- *Companion Computers* are likely to run on stripped down versions of Linux. Ensure you use a variant that supports Python 2.7 and can install Python packages from the Internet.
- Windows does not come with Python by default, but there are [many distributions available](#). We have tested against:
 - [WinPython 2.7 64bit](#) (see [these instructions for installation and registration](#)). This is the most tested version.
 - [ActiveState ActivePython 2.7](#).
- Python 3 is not supported.

3.2 Companion Computers

A companion computer is a device that travels on-board the vehicle and controls/communicates with the autopilot over a low-latency link. Apps running on a companion computer can perform computationally intensive or time-sensitive tasks, and add much greater intelligence than is provided by the autopilot alone.

DroneKit can be used with onboard computers running variants of Linux that support both Python and the installation of Python packages from the Internet. The following computing platforms are known to work with DroneKit, and are supported by the ArduPilot developer community.

3.2.1 RaspberryPi

- [Communicating with Raspberry Pi via MAVLink](#)
- [Making a Mavlink WiFi bridge using the Raspberry Pi](#)

3.2.2 Intel Edison

- [Edison for drones](#)

3.2.3 BeagleBoneBlack

- [BeaglePilot](#)

3.2.4 Odroid

- [Communicating with ODroid via MAVLink](#)
- [ODroid Wifi Access Point for sharing files via Samba](#)

3.3 Setting up a Simulated Vehicle (SITL)

The [SITL \(Software In The Loop\)](#) simulator allows you to create and test DroneKit-Python apps without a real vehicle (and from the comfort of your own developer desktop!).

SITL can run natively on Linux (x86 architecture only), Mac and Windows, or within a virtual machine. It can be installed on the same computer as DroneKit, or on another computer on the same network.

The sections below explain how to install and run SITL, and how to connect to DroneKit-Python and Ground Stations at the same time.

3.3.1 DroneKit-SITL

DroneKit-SITL is the simplest, fastest and easiest way to run SITL on Windows, Linux (x86 architecture only), or Mac OS X. It is installed from Python's *pip* tool on all platforms, and works by downloading and running pre-built vehicle binaries that are appropriate for the host operating system.

This section provides an overview of how to install and use DroneKit-SITL. For more information, see the [project on Github](#).

Note: DroneKit-SITL is still relatively experimental and there are only a few pre-built vehicles (some of which are quite old and/or unstable).

The binaries are built and tested on Windows 10, Ubuntu Linux, and Mac OS X “El Capitan”. Binaries are only available for x86 architectures. ARM builds (e.g. for RPi) are not supported.

Please report any issues on [Github here](#).

Installation

The tool is installed (or updated) on all platforms using the command:

```
pip install dronekit-sitl -UI
```

Running SITL

To run the latest version of Copter for which we have binaries (downloading the binaries if needed), you can simply call:

```
dronekit-sitl copter
```

SITL will then start and wait for TCP connections on 127.0.0.1:5760.

You can specify a particular vehicle and version, and also parameters like the home location, the vehicle model type (e.g. “quad”), etc. For example:

```
dronekit-sitl plane-3.3.0 --home=-35.363261,149.165230,584,353
```

There are a number of other useful arguments:

```
dronekit-sitl -h           #List all parameters to dronekit-sitl.
dronekit-sitl copter -h   #List additional parameters for the specified vehicle (in_
↳this case "copter").
dronekit-sitl --list       #List all available vehicles.
dronekit-sitl --reset      #Delete all downloaded vehicle binaries.
dronekit-sitl ./path [args...] #Start SITL instance at target file location.
```

Note: You can also use *dronekit-sitl* to start a SITL executable that you have built locally from source. To do this, put the file path of the target executable in the *SITL_BINARY* environment variable, or as the first argument when calling the tool.

Connecting to DroneKit-SITL

DroneKit-SITL waits for TCP connections on `127.0.0.1:5760`. DroneKit-Python scripts running on the same computer can connect to the simulation using the connection string as shown:

```
vehicle = connect('tcp:127.0.0.1:5760', wait_ready=True)
```

After something connects to port 5760, SITL will then wait for additional connections on port 5763 (and subsequently 5766, 5769 etc.)

Note: While you can connect to these additional ports, some users have reported problems when viewing the running examples with *Mission Planner*. If you need to connect a ground station and DroneKit at the same time we recommend you use *MAVProxy* (see [Connecting an additional Ground Station](#)).

DroneKit-SITL Python API

DroneKit-SITL exposes a [Python API](#), which you can use to start and control simulation from within your scripts. This is particularly useful for test code and [examples](#).

3.3.2 Building SITL from source

You can natively build SITL from source on Linux, Windows and Mac OS X, or from within a Vagrant Linux virtual environment.

Building from source is useful if you want to need to test the latest changes (or any use a version for which DroneKit-SITL does not have pre-built binaries). It can also be useful if you have problems getting DroneKit-SITL to work.

SITL built from source has a few differences from DroneKit-SITL:

- MAVProxy is included and started by default. You can use MAVProxy terminal to control the autopilot.
- You connect to SITL via UDP on `127.0.0.1:14550`. You can use MAVProxy's `output add` command to add additional ports if needed.
- You may need to disable arming checks and load autotest parameters to run examples.
- It is easier to [add a virtual rangefinder](#) and [add a virtual gimbal](#) for testing.

The following topics from the ArduPilot wiki explain how to set up Native SITL builds:

- [Setting up SITL on Linux](#)
- [Setting up SITL on Windows](#)
- [Setting up SITL using Vagrant](#)

3.3.3 Connecting an additional Ground Station

You can connect a ground station to an unused port to which messages are being forwarded.

The most reliable way to add new ports is to use *MAVProxy*:

- If you're using SITL built from source you will already have *MAVProxy* running. You can add new ports in the MAVProxy console using `output add`:

```
output add 127.0.0.1:14552
```

- If you're using Dronekit-SITL you can:
 - Install [MAVProxy](#) for your system.
 - In a second terminal spawn an instance of *MAVProxy* to forward messages from TCP 127.0.0.1:5760 to other UDP ports like 127.0.0.1:14550 and 127.0.0.1:14551:

```
mavproxy.py --master tcp:127.0.0.1:5760 --sitl 127.0.0.1:5501 --out 127.0.0.1:14550 --out 127.0.0.1:14551
```

Once you have available ports you can connect to a ground station using one UDP address, and DroneKit-Python using the other.

For example, first connect the script:

```
vehicle = connect('127.0.0.1:14550', wait_ready=True)
```

Then connect Mission Planner to the second UDP port:

- [Download and install Mission Planner](#)
- Ensure the selection list at the top right of the Mission Planner screen says *UDP* and then select the **Connect** button next to it. When prompted, enter the port number (in this case 14552).




Fig. 1: Mission Planner: Listen Port Dialog

After connecting, vehicle parameters will be loaded into *Mission Planner* and the vehicle is displayed on the map.

Tip: If you're using the [DroneKit-SITL Python API](#) then you will instead have to connect to SITLs TCP port (as there is no way to set up MAVProxy in this case). So if DroneKit is connecting to TCP port 5760, you would connect your GCS to 5763.

Note that a few examples may not behave perfectly using this approach. If you need to observe them in a GCS you should run SITL externally and use MAVProxy to connect to it.

3.4 Best Practices

This guide provides a broad overview of how to use the API, its main programming idioms and best practices. More detail information is linked from each section.

3.4.1 General considerations

DroneKit-Python communicates with vehicle autopilots using the MAVLink protocol, which defines how commands, telemetry and vehicle settings/parameters are sent between vehicles, companion computers, ground stations and other systems on a MAVLink network.

Some general considerations from using this protocol are:

- Messages and message acknowledgments are not guaranteed to arrive (the protocol is not “lossless”).
- Commands may be silently ignored by the Autopilot if it is not in a state where it can safely act on them.
- Command acknowledgment and completion messages are not sent in most cases (and if sent, may not arrive).
- Commands may be interrupted before completion.
- Autopilots may choose to interpret the protocol in slightly different ways.
- Commands can arrive at the autopilot from multiple sources.

Developers should code defensively. Where possible:

- Check that a vehicle is in a state to obey a command (for example, poll on `Vehicle.is_armable` before trying to arm the vehicle).
- Don’t assume that a command has succeeded until the changed behaviour is observed. In particular we recommend a launch sequence where you check that the mode and arming have succeeded before attempting to take off.
- Monitor for state changes and react accordingly. For example, if the user changes the mode from `GUIDED` your script should stop sending commands.
- Verify that your script can run inside the normal latency limits for message passing from the vehicle and tune any monitoring appropriately.

3.4.2 Connecting

In most cases you’ll use the normal way to *connect to a vehicle*, setting `wait_ready=True` to ensure that the vehicle is already populated with attributes when the `connect()` returns:

```
from dronekit import connect

# Connect to the Vehicle (in this case a UDP endpoint)
vehicle = connect('REPLACE_connection_string_for_your_vehicle', wait_ready=True)
```

The `connect()` call will sometimes fail with an exception. Additional information about an exception can be obtained by running the connect within a `try-catch` block as shown:

```
import dronekit
import socket
import exceptions
```

(continues on next page)

(continued from previous page)

```

try:
    dronekit.connect('REPLACE_connection_string_for_your_vehicle', heartbeat_
↳ timeout=15)

# Bad TCP connection
except socket.error:
    print 'No server exists!'

# Bad TTY connection
except exceptions OSError as e:
    print 'No serial exists!'

# API Error
except dronekit.APIException:
    print 'Timeout!'

# Other error
except:
    print 'Some other error!'

```

Tip: The default `heartbeat_timeout` on connection is 30 seconds. Usually a connection will succeed quite quickly, so you may wish to reduce this in the `connect()` method as shown in the code snippet above.

If a connection succeeds from a ground station, but not from DroneKit-Python it may be that your baud rate is incorrect for your hardware. This rate can also be set in the `connect()` method.

3.4.3 Launch sequence

Generally you should use the standard launch sequence described in *Taking Off*:

- Poll on `Vehicle.is_armable` until the vehicle is ready to arm.
- Set the `Vehicle.mode` to GUIDED
- Set `Vehicle.armed` to True and poll on the same attribute until the vehicle is armed.
- Call `Vehicle.simple_takeoff` with a target altitude.
- Poll on the altitude and allow the code to continue only when it is reached.

The approach ensures that commands are only sent to the vehicle when it is able to act on them (e.g. we know `Vehicle.is_armable` is True before trying to arm, we know `Vehicle.armed` is True before we take off). It also makes debugging takeoff problems a lot easier.

3.4.4 Movement commands

DroneKit-Python provides `Vehicle.simple_goto` for moving to a specific position (at a defined speed). It is also possible to control movement by sending commands to specify the vehicle's *velocity components*.

Note: As with `Vehicle.simple_takeoff`, movement commands are asynchronous, and will be interrupted if another command arrives before the vehicle reaches its target. Calling code should block and wait (or check that the operation is complete) before proceeding to the next command.

For more information see: *Guiding and Controlling Copter*.

3.4.5 Vehicle information

Vehicle state information is exposed through vehicle *attributes* which can be read and observed (and in some cases written) and vehicle settings which can be read, written, iterated and observed using *parameters* (a special attribute). All the attributes are documented in *Vehicle State and Settings*.

Attributes are populated by MAVLink messages from the vehicle. Information read from an attribute may not precisely reflect the actual value on the vehicle. Commands sent to the vehicle may not arrive, or may be ignored by the autopilot.

If low-latency is critical, we recommend you verify that the update rate is achievable and perhaps modify script behaviour if `Vehicle.last_heartbeat` falls outside a useful range.

When setting attributes, poll their values to confirm that they have changed. This applies, in particular, to `Vehicle.armed` and `Vehicle.mode`.

3.4.6 Missions and waypoints

DroneKit-Python can also *create and modify autonomous missions*.

While it is possible to construct DroneKit-Python apps by dynamically constructing missions “on the fly”, we recommend you use guided mode for Copter apps. This generally results in a better experience.

Tip: If a mission command is not available in guided mode, it can be useful to switch to a mission and call it, then change back to normal guided mode operation.

3.4.7 Monitor and react to state changes

Almost all attributes can be observed - see *Observing attribute changes* for more information.

Exactly what state information you observe, and how you react to it, depends on your particular script:

- Most standalone apps should monitor the `Vehicle.mode` and stop sending commands if the mode changes unexpectedly (this usually indicates that the user has taken control of the vehicle).
- Apps might monitor `Vehicle.last_heartbeat` and could attempt to reconnect if the value gets too high.
- Apps could monitor `Vehicle.system_status` for CRITICAL or EMERGENCY in order to implement specific emergency handling.

3.4.8 Sleep the script when not needed

Sleeping your script can reduce the CPU overhead.

For example, at low speeds you might only need to check whether you’ve reached a target every few seconds. Using `time.sleep(2)` between checks will be more efficient than checking more often.

3.4.9 Exiting a script

Scripts should call `Vehicle.close()` before exiting to ensure that all messages have flushed before the script completes:

```
# About to exit script
vehicle.close()
```

3.4.10 Subclass Vehicle

If you need to use functionality that is specific to particular hardware, we recommend you subclass `Vehicle` and pass this new class into `connect()`.

Example: Create Attribute in App shows how you can do this.

3.4.11 Debugging

DroneKit-Python apps are ordinary standalone Python scripts, and can be *debugged using standard Python methods* (including the debugger/IDE of your choice).

3.4.12 Launching scripts

Scripts are run from an ordinary Python command prompt. For example:

```
python some_python_script.py [arguments]
```

Command line arguments are passed into the script as `sys.argv` variables (the normal) and you can use these directly or via an argument parser (e.g. `argparse`).

3.4.13 Current script directory

You can use normal Python methods for getting file system information:

```
import os.path
full_directory_path_of_current_script = os.path.dirname(os.path.abspath(__file__))
```

3.5 Coding Standards

DroneKit-Python does not impose (or recommend) a particular set of coding standards for third party code.

Internally we run the `YAPF formatter` on major releases and we expect contributors to copy the patterns used in similar code within the existing code base.

The guide contains how-to documentation for using the DroneKit-Python API. Additional guide material can be found in the *Examples*.

4.1 Connecting to a Vehicle

The connection to the vehicle (or multiple vehicles) is set up within the DroneKit script. Scripts import and call the `connect()` method. After connecting this returns a *Vehicle* object from which you can get/set parameters and attributes, and control vehicle movement.

The most common way to call `connect()` is shown below:

```
from dronekit import connect

# Connect to the Vehicle (in this case a UDP endpoint)
vehicle = connect('127.0.0.1:14550', wait_ready=True)
```

The first parameter specifies the target address (in this case the loopback address for UDP port 14550). See *Connection string options* for the strings to use for other common vehicles.

The second parameter (`wait_ready`) is used to determine whether `connect()` returns immediately on connection or if it waits until *some* vehicle parameters and attributes are populated. In most cases you should use `wait_ready=True` to wait on the default set of parameters.

Connecting over a serial device will look something like this:

```
from dronekit import connect

# Connect to the Vehicle (in this case a UDP endpoint)
vehicle = connect('/dev/ttyAMA0', wait_ready=True, baud=57600)
```

Tip: If the baud rate is not set correctly, `connect` may fail with a timeout error. It is best to set the baud rate

explicitly.

`connect()` also has arguments for setting the baud rate, the length of the connection timeout, and/or to use a *custom vehicle class*.

There is more documentation on all of the parameters in the [API Reference](#).

4.1.1 Connection string options

The table below shows *connection strings* you can use for some of the more common connection types:

Connection type	Connection string
Linux computer connected to the vehicle via USB	/dev/ttyUSB0
Linux computer connected to the vehicle via Serial port (RaspberryPi example)	/dev/ttyAMA0 (also set baud=57600)
SITL connected to the vehicle via UDP	127.0.0.1:14550
SITL connected to the vehicle via TCP	tcp:127.0.0.1:5760
OSX computer connected to the vehicle via USB	dev/cu.usbmodem1
Windows computer connected to the vehicle via USB (in this case on COM14)	com14
Windows computer connected to the vehicle using a 3DR Telemetry Radio on COM14	com14 (also set baud=57600)

Tip: The strings above are the same as are used when connecting the MAVProxy GCS. For other options see the [MAVProxy documentation](#).

Note: The default baud rate may not be appropriate for all connection types (this may be the cause if you can connect via a GCS but not DroneKit).

4.1.2 Connecting to multiple vehicles

You can control multiple vehicles from within a single script by calling `connect()` for each vehicle with the appropriate *connection strings*.

The returned *Vehicle* objects are independent of each other and can be separately used to control their respective vehicle.

4.2 Vehicle State and Settings

The *Vehicle* class exposes *most* state information (position, speed, etc.) through python *attributes*, while vehicle *parameters* (settings) are accessed through named elements of *Vehicle.parameters*.

This topic explains how to get, set and observe vehicle state and parameter information (including getting the *Home location*).

Tip: You can test most of the code in this topic by running the *Vehicle State* example.

4.2.1 Attributes

Vehicle state information is exposed through vehicle *attributes*. DroneKit-Python currently supports the following “standard” attributes: `Vehicle.version`, `Vehicle.location.capabilities`, `Vehicle.location.global_frame`, `Vehicle.location.global_relative_frame`, `Vehicle.location.local_frame`, `Vehicle.attitude`, `Vehicle.velocity`, `Vehicle.gps_0`, `Vehicle.gimbal`, `Vehicle.battery`, `Vehicle.rangefinder`, `Vehicle.ekf_ok`, `Vehicle.last_heartbeat`, `Vehicle.home_location`, `Vehicle.system_status`, `Vehicle.heading`, `Vehicle.is_armable`, `Vehicle.airspeed`, `Vehicle.groundspeed`, `Vehicle.armed`, `Vehicle.mode`.

Attributes are initially created with `None` values for their members. In most cases the members are populated (and repopulated) as new MAVLink messages of the associated types are received from the vehicle.

All of the attributes can be *read*, but only the *Vehicle.home_location*, *Vehicle.gimbal* *Vehicle.airspeed*, *Vehicle.groundspeed*, *Vehicle.mode* and *Vehicle.armed* status can be *set*.

Almost all of the attributes can be *observed*.

The behaviour of `Vehicle.home_location` is different from the other attributes, and is *discussed in its own section below*.

Getting attributes

The code fragment below shows how to read and print almost all the attributes (values are regularly updated from MAVLink messages sent by the vehicle).

```
# vehicle is an instance of the Vehicle class
print "Autopilot Firmware version: %s" % vehicle.version
print "Autopilot capabilities (supports ftp): %s" % vehicle.capabilities.ftp
print "Global Location: %s" % vehicle.location.global_frame
print "Global Location (relative altitude): %s" % vehicle.location.global_relative_
↳ frame
print "Local Location: %s" % vehicle.location.local_frame #NED
print "Attitude: %s" % vehicle.attitude
print "Velocity: %s" % vehicle.velocity
print "GPS: %s" % vehicle.gps_0
print "Groundspeed: %s" % vehicle.groundspeed
print "Airspeed: %s" % vehicle.airspeed
print "Gimbal status: %s" % vehicle.gimbal
print "Battery: %s" % vehicle.battery
print "EKF OK?: %s" % vehicle.ekf_ok
print "Last Heartbeat: %s" % vehicle.last_heartbeat
print "Rangefinder: %s" % vehicle.rangefinder
print "Rangefinder distance: %s" % vehicle.rangefinder.distance
print "Rangefinder voltage: %s" % vehicle.rangefinder.voltage
print "Heading: %s" % vehicle.heading
print "Is Armable?: %s" % vehicle.is_armable
print "System status: %s" % vehicle.system_status.state
print "Mode: %s" % vehicle.mode.name # settable
print "Armed: %s" % vehicle.armed # settable
```

Note: A value of `None` for an attribute member indicates that the value has not yet been populated from the vehicle. For example, before GPS lock `Vehicle.gps_0` will return a `GPSInfo` with `None` values for `eph`, `satellites_visible` etc. Attributes will also return `None` if the associated hardware is not present on the connected device.

Tip: If you’re using a *simulated vehicle* you can add support for optional hardware including rangefinders and optical flow sensors.

Setting attributes

The *Vehicle.mode*, *Vehicle.armed*, *Vehicle.airspeed* and *Vehicle.groundspeed*, attributes can all be “directly” written (*Vehicle.home_location* can also be directly written, but has special considerations that are *discussed below*).

These attributes are set by assigning a value:

```
#disarm the vehicle
vehicle.armed = False

#set the default groundspeed to be used in movement commands
vehicle.groundspeed = 3.2
```

Commands to change a value are **not guaranteed to succeed** (or even to be received) and code should be written with this in mind. For example, the code snippet below polls the attribute values to confirm they have changed before proceeding.

```
vehicle.mode = VehicleMode("GUIDED")
vehicle.armed = True
while not vehicle.mode.name=='GUIDED' and not vehicle.armed and not api.exit:
    print " Getting ready to take off ..."
    time.sleep(1)
```

Note: While the autopilot does send information about the success (or failure) of the request, this is *not currently handled by DroneKit*.

Vehicle.gimbal can’t be written directly, but the gimbal can be controlled using the *Vehicle.gimbal.rotate()* and *Vehicle.gimbal.target_location()* methods. The first method lets you set the precise orientation of the gimbal while the second makes the gimbal track a specific “region of interest”.

```
#Point the gimbal straight down
vehicle.gimbal.rotate(-90, 0, 0)
time.sleep(10)

#Set the camera to track the current home position.
vehicle.gimbal.target_location(vehicle.home_location)
time.sleep(10)
```

Observing attribute changes

You can observe any of the vehicle attributes and monitor for changes without the need for polling.

Listeners (“observer callback functions”) are invoked differently based on the *type of observed attribute*. Attributes that represent sensor values or other “streams of information” are updated whenever a message is received from the vehicle. Attributes which reflect vehicle “state” are only updated when their values change (for example *Vehicle.system_status*, *Vehicle.armed*, and *Vehicle.mode*).

Callbacks are added using `Vehicle.add_attribute_listener()` or the `Vehicle.on_attribute()` decorator method. The main difference between these methods is that only attribute callbacks added with `Vehicle.add_attribute_listener()` can be removed (see `remove_attribute_listener()`).

The observer callback function is invoked with the following arguments:

- `self` - the associated `Vehicle`. This may be compared to a global vehicle handle to implement vehicle-specific callback handling (if needed).
- `attr_name` - the attribute name. This can be used to infer which attribute has triggered if the same callback is used for watching several attributes.
- `value` - the attribute value (so you don't need to re-query the vehicle object).

The code snippet below shows how to add (and remove) a callback function to observe changes in `Vehicle.location.global_frame` using `Vehicle.add_attribute_listener()`. The two second `sleep()` is required because otherwise the observer might be removed before the the callback is first run.

```
#Callback to print the location in global frames. 'value' is the updated value
def location_callback(self, attr_name, value):
    print "Location (Global): ", value

# Add a callback `location_callback` for the `global_frame` attribute.
vehicle.add_attribute_listener('location.global_frame', location_callback)

# Wait 2s so callback can be notified before the observer is removed
time.sleep(2)

# Remove observer - specifying the attribute and previously registered callback_
↪function
vehicle.remove_message_listener('location.global_frame', location_callback)
```

Note: The example above adds a listener on `Vehicle` to for attribute name `'location.global_frame'`. You can alternatively add (and remove) a listener `Vehicle.location` for the attribute name `'global_frame'`. Both alternatives are shown below:

```
vehicle.add_attribute_listener('location.global_frame', location_callback)
vehicle.location.add_attribute_listener('global_frame', location_callback)
```

The example below shows how you can declare an attribute callback using the `Vehicle.on_attribute()` decorator function.

```
last_rangefinder_distance=0

@vehicle.on_attribute('rangefinder')
def rangefinder_callback(self,attr_name):
    #attr_name not used here.
    global last_rangefinder_distance
    if last_rangefinder_distance == round(self.rangefinder.distance, 1):
        return
    last_rangefinder_distance = round(self.rangefinder.distance, 1)
    print " Rangefinder (metres): %s" % last_rangefinder_distance
```

Note: The fragment above stores the result of the previous callback and only prints the output when there is a significant change in `Vehicle.rangefinder`. You might want to perform caching like this to ignore updates that

are not significant to your code.

The examples above show how you can monitor a single attribute. You can pass the special name ('*') to specify a callback that will be called for any/all attribute changes:

```
# Demonstrate getting callback on any attribute change
def wildcard_callback(self, attr_name, value):
    print " CALLBACK: (%s): %s" % (attr_name,value)

print "\nAdd attribute callback detecting any attribute change"
vehicle.add_attribute_listener('*', wildcard_callback)

print " Wait 1s so callback invoked before observer removed"
time.sleep(1)

print " Remove Vehicle attribute observer"
# Remove observer added with `add_attribute_listener()`
vehicle.remove_attribute_listener('*', wildcard_callback)
```

Home location

The *Home location* is set when a vehicle first gets a good location fix from the GPS. The location is used as the target when the vehicle does a “return to launch”. In Copter missions (and often Plane) missions, the altitude of waypoints is set relative to this position.

Vehicle.home_location has the following behaviour:

- In order to *get* the current value (in a *LocationGlobal* object) you must first download *Vehicle.commands*, as shown:

```
cmds = vehicle.commands
cmds.download()
cmds.wait_ready()
print " Home Location: %s" % vehicle.home_location
```

The returned value is *None* before you download the commands or if the *home_location* has not yet been set by the autopilot. For this reason our example code checks that the value exists (in a loop) before writing it.

```
# Get Vehicle Home location - will be `None` until first set by autopilot
while not vehicle.home_location:
    cmds = vehicle.commands
    cmds.download()
    cmds.wait_ready()
    if not vehicle.home_location:
        print " Waiting for home location ..."

# We have a home location.
print "\n Home location: %s" % vehicle.home_location
```

- The attribute can be *set* to a *LocationGlobal* object (the code fragment below sets it to the current location):

```
vehicle.home_location=vehicle.location.global_frame
```

There are some caveats:

- You must be able to read a non-None value before you can write it (the autopilot has to set the value initially before it can be written or read).
 - The new location must be within 50 km of the EKF origin or setting the value will silently fail.
 - The value is cached in the `home_location`. If the variable can potentially change on the vehicle you will need to re-download the `Vehicle.commands` in order to confirm the value.
- The attribute is not observable.

Note: `Vehicle.home_location` behaves this way because ArduPilot implements/stores the home location as a waypoint rather than sending them as messages. While DroneKit-Python hides this fact from you when working with commands, to access the value you still need to download the commands.

We hope to improve this attribute in later versions of ArduPilot, where there may be specific commands to get the home location from the vehicle.

4.2.2 Parameters

Vehicle parameters provide the information used to configure the autopilot for the vehicle-specific hardware/capabilities. The available parameters for each platform are documented in the ArduPilot wiki here: [Copter Parameters](#), [Plane Parameters](#), [Rover Parameters](#) (the lists are automatically generated from the latest ArduPilot source code, and may contain or omit parameters in your vehicle).

DroneKit downloads all parameters when you first connect to the UAV (forcing parameter reads to wait until the download completes), and subsequently keeps the values updated by monitoring vehicle messages for changes to individual parameters. This process ensures that it is always safe to read supported parameters, and that their values will match the information on the vehicle.

Parameters can be read, set, observed and iterated using the `Vehicle.parameters` attribute (a `Parameters` object).

Getting parameters

The parameters are read using the parameter name as a key (case-insensitive). Reads will always succeed unless you attempt to access an unsupported parameter (which will result in a `KeyError` exception).

The code snippet below shows how to get the Minimum Throttle (THR_MIN) setting. On Copter and Rover (not Plane), this is the minimum PWM setting for the throttle at which the motors will keep spinning.

```
# Print the value of the THR_MIN parameter.
print "Param: %s" % vehicle.parameters['THR_MIN']
```

Setting parameters

Vehicle parameters are set as shown in the code fragment below, using the parameter name as a “key”:

```
# Change the parameter value (Copter, Rover)
vehicle.parameters['THR_MIN']=100
```

Listing all parameters

`Vehicle.parameters` can be iterated to list all parameters and their values:

```
print "\nPrint all parameters (iterate `vehicle.parameters`):"
for key, value in vehicle.parameters.iteritems():
    print " Key:%s Value:%s" % (key,value)
```

Observing parameter changes

You can observe any of the vehicle parameters and monitor for changes without the need for polling. The parameters are cached, so that callback functions are only invoked when parameter values change.

Tip: Observing parameters is virtually identical to *observing attributes*.

The code snippet below shows how to add a callback function to observe changes in the “THR_MIN” parameter using a decorator. Note that the parameter name is case-insensitive, and that callbacks added using a decorator cannot be removed.

```
@vehicle.parameters.on_attribute('THR_MIN')
def decorated_thr_min_callback(self, attr_name, value):
    print " PARAMETER CALLBACK: %s changed to: %s" % (attr_name, value)
```

The observer callback function is invoked with the following arguments:

- `self` - the associated Parameters.
- `attr_name` - the parameter name (useful if the same callback is used for watching several parameters).
- `msg` - the parameter value (so you don’t need to re-query the `Vehicle.parameters` object).

The code snippet below demonstrates how you can add and remove a listener (in this case for “any parameter”) using the `Parameters.add_attribute_listener()` and `Parameters.remove_attribute_listener()`.

```
#Callback function for "any" parameter
def any_parameter_callback(self, attr_name, value):
    print " ANY PARAMETER CALLBACK: %s changed to: %s" % (attr_name, value)

#Add observer for the vehicle's any/all parameters parameter (note wildcard string ``
↪ '*'``)
vehicle.parameters.add_attribute_listener('*', any_parameter_callback)
```

4.2.3 Known issues

Known issues and improvement suggestions can viewed on [Github here](#).

4.3 Taking Off

This article explains how to get your *Copter* to take off.

At high level, the steps are: check that the vehicle is *able* to arm, set the mode to GUIDED, command the vehicle to arm, takeoff and block until we reach the desired altitude.

Tip: Copter is usually started in GUIDED mode.

- For Copter 3.2.1 and earlier you cannot take off in AUTO mode (if you need to run a mission you take off in GUIDED mode and then switch to AUTO mode once you're in the air).
- Starting from Copter 3.3 you can takeoff in AUTO mode (provided the mission has a `MAV_CMD_NAV_TAKEOFF` command) but the mission will not start until you explicitly send the `MAV_CMD_MISSION_START` message.

By contrast, Plane apps take off using the `MAV_CMD_NAV_TAKEOFF` command in a mission. Plane should first arm and then change to AUTO mode to start the mission.

The code below shows a function to arm a Copter, take off, and fly to a specified altitude. This is taken from *Example: Simple Go To (Copter)*.

```
# Connect to the Vehicle (in this case a simulator running the same computer)
vehicle = connect('tcp:127.0.0.1:5760', wait_ready=True)

def arm_and_takeoff(aTargetAltitude):
    """
    Arms vehicle and fly to aTargetAltitude.
    """

    print "Basic pre-arm checks"
    # Don't try to arm until autopilot is ready
    while not vehicle.is_armable:
        print " Waiting for vehicle to initialise..."
        time.sleep(1)

    print "Arming motors"
    # Copter should arm in GUIDED mode
    vehicle.mode = VehicleMode("GUIDED")
    vehicle.armed = True

    # Confirm vehicle armed before attempting to take off
    while not vehicle.armed:
        print " Waiting for arming..."
        time.sleep(1)

    print "Taking off!"
    vehicle.simple_takeoff(aTargetAltitude) # Take off to target altitude

    # Wait until the vehicle reaches a safe height before processing the goto_
    ↪ (otherwise the command
    # after Vehicle.simple_takeoff will execute immediately).
    while True:
        print " Altitude: ", vehicle.location.global_relative_frame.alt
        #Break and return from function just below target altitude.
        if vehicle.location.global_relative_frame.alt>=aTargetAltitude*0.95:
            print "Reached target altitude"
            break
        time.sleep(1)

arm_and_takeoff(20)
```

The function first performs some pre-arm checks.

Note: Arming turns on the vehicle's motors in preparation for flight. The flight controller will not arm until the vehicle has passed a series of pre-arm checks to ensure that it is safe to fly.

These checks are encapsulated by the `Vehicle.is_armable` attribute, which is `true` when the vehicle has booted, EKF is ready, and the vehicle has GPS lock.

```
print "Basic pre-arm checks"
# Don't let the user try to arm until autopilot is ready
while not vehicle.is_armable:
    print " Waiting for vehicle to initialise..."
    time.sleep(1)
```

Note: If you need more status information you can perform the following sorts of checks:

```
if v.mode.name == "INITIALISING":
    print "Waiting for vehicle to initialise"
    time.sleep(1)
while vehicle.gps_0.fix_type < 2:
    print "Waiting for GPS...:", vehicle.gps_0.fix_type
    time.sleep(1)
```

You should always do a final check on `Vehicle.is_armable`!

Once the vehicle is ready we set the mode to GUIDED and arm it. We then wait until arming is confirmed before sending the `takeoff` command.

```
print "Arming motors"
# Copter should arm in GUIDED mode
vehicle.mode = VehicleMode("GUIDED")
vehicle.armed = True

while not vehicle.armed:
    print " Waiting for arming..."
    time.sleep(1)

print "Taking off!"
vehicle.simple_takeoff(aTargetAltitude) # Take off to target altitude
```

The `takeoff` command is asynchronous and can be interrupted if another command arrives before it reaches the target altitude. This could have potentially serious consequences if the vehicle is commanded to move horizontally before it reaches a safe height. In addition, there is no message sent back from the vehicle to inform the client code that the target altitude has been reached.

To address these issues, the function waits until the vehicle reaches a specified height before returning. If you're not concerned about reaching a particular height, a simpler implementation might just "wait" for a few seconds.

```
while True:
    print " Altitude: ", vehicle.location.global_relative_frame.alt
    #Break and return from function just below target altitude.
    if vehicle.location.global_relative_frame.alt >= aTargetAltitude*0.95:
        print "Reached target altitude"
        break
    time.sleep(1)
```

When the function returns the app can continue in GUIDED mode or switch to AUTO mode to start a mission.

4.4 Guiding and Controlling Copter

GUIDED mode is the recommended mode for flying Copter autonomously without a predefined mission. It allows a Ground Control Station (GCS) or *Companion Computer* to control the vehicle “on the fly” and react to new events or situations as they occur.

This topic explains how you can *control vehicle movement*, and also how to send *MAVLink commands* to control vehicle orientation, region of interest, servos and other hardware. We also *list a few functions* that are useful for converting location and bearings from a global into a local frame of reference.

Most of the code can be observed running in *Example: Guided Mode Movement and Commands (Copter)*.

Note: This topic is Copter specific. Plane apps typically use AUTO mode and dynamically modify missions as needed (Plane supports GUIDED mode but it is less full featured than on Copter).

4.4.1 Controlling vehicle movement

Copter movement can be controlled either by explicitly setting a *target position*, or by specifying the vehicle’s *velocity components* to guide it in a preferred direction.

Note: Changing to a new movement method is treated as a “mode change”. If you’ve set a yaw or region-of-interest value then this will be set to the default (vehicle faces the direction of travel).

Position control

Controlling the vehicle by explicitly setting the target position is useful when the final position is known/fixed.

The recommended method for position control is `Vehicle.simple_goto()`. This takes a `LocationGlobal` or `LocationGlobalRelative` argument.

The method is used as shown below:

```
# Set mode to guided - this is optional as the goto method will change the mode if_
↪needed.
vehicle.mode = VehicleMode("GUIDED")

# Set the target location in global-relative frame
a_location = LocationGlobalRelative(-34.364114, 149.166022, 30)
vehicle.simple_goto(a_location)
```

`Vehicle.simple_goto()` can be interrupted by a later command, and does not provide any functionality to indicate when the vehicle has reached its destination. Developers can use either a time delay or *measure proximity to the target* to give the vehicle an opportunity to reach its destination. The *Example: Guided Mode Movement and Commands (Copter)* shows both approaches.

You can optionally set the target movement speed using the function’s `airspeed` or `groundspeed` parameters (this is equivalent to setting `Vehicle.airspeed` or `Vehicle.groundspeed`). The speed setting will then be used for all positional movement commands until it is set to another value.

```
# Set airspeed using attribute
vehicle.airspeed = 5 #m/s
```

(continues on next page)

(continued from previous page)

```
# Set groundspeed using attribute
vehicle.groundspeed = 7.5 #m/s

# Set groundspeed using `simple_goto()` parameter
vehicle.simple_goto(a_location, groundspeed=10)
```

Note: `Vehicle.simple_goto()` will use the last speed value set. If both speed values are set at the same time the resulting behaviour will be vehicle dependent.

Tip: You can also set the position by sending the MAVLink commands `SET_POSITION_TARGET_GLOBAL_INT` or `SET_POSITION_TARGET_LOCAL_NED`, specifying a `type_mask` bitmask that enables the position parameters. The main difference between these commands is that the former allows you to specify the location relative to the “global” frames (like `Vehicle.simple_goto()`), while the later lets you specify the location in NED coordinates relative to the home location or the vehicle itself. For more information on these options see the example code: `goto_position_target_global_int()` and `goto_position_target_local_ned()`.

Velocity control

Controlling vehicle movement using velocity is much smoother than using position when there are likely to be many updates (for example when tracking moving objects).

The function `send_ned_velocity()` below generates a `SET_POSITION_TARGET_LOCAL_NED` MAVLink message which is used to directly specify the speed components of the vehicle in the `MAV_FRAME_LOCAL_NED` frame (relative to home location). The message is re-sent every second for the specified duration.

Note: From Copter 3.3 the vehicle will stop moving if a new message is not received in approximately 3 seconds. Prior to Copter 3.3 the message only needs to be sent once, and the velocity remains active until the next movement command is received. The example code works for both cases!

```
def send_ned_velocity(velocity_x, velocity_y, velocity_z, duration):
    """
    Move vehicle in direction based on specified velocity vectors.
    """
    msg = vehicle.message_factory.set_position_target_local_ned_encode(
        0,          # time_boot_ms (not used)
        0, 0,       # target system, target component
        mavutil.mavlink.MAV_FRAME_LOCAL_NED, # frame
        0b000011111000111, # type_mask (only speeds enabled)
        0, 0, 0,    # x, y, z positions (not used)
        velocity_x, velocity_y, velocity_z, # x, y, z velocity in m/s
        0, 0, 0,    # x, y, z acceleration (not supported yet, ignored in GCS_Mavlink)
        0, 0)       # yaw, yaw_rate (not supported yet, ignored in GCS_Mavlink)

    # send command to vehicle on 1 Hz cycle
    for x in range(0,duration):
        vehicle.send_mavlink(msg)
        time.sleep(1)
```


The `type_mask` parameter is a bitmask that indicates which of the other parameters in the message are used/ignored by the vehicle (0 means that the dimension is enabled, 1 means ignored). In the example the value `0b0000111111000111` is used to enable the velocity components.

In the `MAV_FRAME_LOCAL_NED` the speed components `velocity_x` and `velocity_y` are parallel to the North and East directions (not to the front and side of the vehicle). The `velocity_z` component is perpendicular to the plane of `velocity_x` and `velocity_y`, with a positive value **towards the ground**, following the right-hand convention. For more information about the `MAV_FRAME_LOCAL_NED` frame of reference, see this [wikipedia article](#) on [NED](#).

Tip: From Copter 3.3 you can [specify other frames](#), for example `MAV_FRAME_BODY_OFFSET_NED` makes the velocity components relative to the current vehicle heading. In Copter 3.2.1 (and earlier) the frame setting is ignored (`MAV_FRAME_LOCAL_NED` is always used).

The code fragment below shows how to call this method:

```
# Set up velocity mappings
# velocity_x > 0 => fly North
# velocity_x < 0 => fly South
# velocity_y > 0 => fly East
# velocity_y < 0 => fly West
# velocity_z < 0 => ascend
# velocity_z > 0 => descend
SOUTH=-2
UP=-0.5    #NOTE: up is negative!

#Fly south and up.
send_ned_velocity(SOUTH,0,UP,DURATION)
```

When moving the vehicle you can send separate commands to control the yaw (and other behaviour).

Tip: You can also control the velocity using the `SET_POSITION_TARGET_GLOBAL_INT` MAVLink command, as described in [send_global_velocity\(\)](#).

Acceleration and force control

ArduPilot does not currently support controlling the vehicle by specifying acceleration/force components.

Note: The `SET_POSITION_TARGET_GLOBAL_INT` and `SET_POSITION_TARGET_LOCAL_NED` MAVLink commands allow you to specify the acceleration, force and yaw. However, commands setting these parameters are ignored by the vehicle.

4.4.2 Guided mode commands

This section explains how to send MAVLink commands, what commands can be sent, and lists a number of real examples you can use in your own code.

Sending messages/commands

MAVLink commands are sent by first using `message_factory()` to encode the message and then calling `send_mavlink()` to send them.

Note: Vehicles support a subset of the messages defined in the MAVLink standard. For more information about the supported sets see wiki topics: [Copter Commands in Guided Mode](#) and [Plane Commands in Guided Mode](#).

`message_factory()` uses a factory method for the encoding. The name of this method will always be the lower case version of the message/command name with `_encode` appended. For example, to encode a [SET_POSITION_TARGET_LOCAL_NED](#) message we call `message_factory.set_position_target_local_ned_encode()` with values for all the message fields as arguments:

```
msg = vehicle.message_factory.set_position_target_local_ned_encode(
    0,          # time_boot_ms (not used)
    0, 0,       # target_system, target_component
    mavutil.mavlink.MAV_FRAME_BODY_NED, # frame
    0b0000111111000111, # type_mask (only speeds enabled)
    0, 0, 0,    # x, y, z positions
    velocity_x, velocity_y, velocity_z, # x, y, z velocity in m/s
    0, 0, 0,    # x, y, z acceleration (not supported yet, ignored in GCS_Mavlink)
    0, 0)       # yaw, yaw_rate (not supported yet, ignored in GCS_Mavlink)
# send command to vehicle
vehicle.send_mavlink(msg)
```

If a message includes `target_system` id you can set it to zero (DroneKit will automatically update the value with the correct ID for the connected vehicle). Similarly CRC fields and sequence numbers (if defined in the message type) can be set to zero as they are automatically updated by DroneKit. The `target_component` is not updated by DroneKit, but should be set to 0 (broadcast) unless the message is really intended for a specific component.

In Copter, the [COMMAND_LONG](#) message can be used send/package a number of different supported [MAV_CMD](#) commands. The factory function is again the lower case message name with suffix `_encode` (`message_factory.command_long_encode`). The message parameters include the actual command to be sent (in the code fragment below [MAV_CMD_CONDITION_YAW](#)) and its fields.

```
msg = vehicle.message_factory.command_long_encode(
    0, 0,       # target_system, target_component
    mavutil.mavlink.MAV_CMD_CONDITION_YAW, #command
    0,          #confirmation
    heading,    # param 1, yaw in degrees
    0,          # param 2, yaw speed deg/s
    1,          # param 3, direction -1 ccw, 1 cw
    is_relative, # param 4, relative offset 1, absolute angle 0
    0, 0, 0)    # param 5 ~ 7 not used
# send command to vehicle
vehicle.send_mavlink(msg)
```

Supported commands

[Copter Commands in Guided Mode](#) lists all the commands that *can* be sent to Copter in GUIDED mode (in fact most of the commands can be sent in any mode!)

DroneKit-Python provides a friendly Python API that abstracts many of the commands. Where possible you should use the API rather than send messages directly> For example, use:

- `Vehicle.simple_takeoff()` instead of the `MAV_CMD_NAV_TAKEOFF` command.
- `Vehicle.simple_goto()`, `Vehicle.airspeed`, or `Vehicle.groundspeed` rather than `MAV_CMD_DO_CHANGE_SPEED`.

Some of the `MAV_CMD` commands that you might want to send include: `MAV_CMD_CONDITION_YAW`, `MAV_CMD_DO_SET_ROI`, `MAV_CMD_DO_SET_SERVO`, `MAV_CMD_DO_REPEAT_SERVO`, `MAV_CMD_DO_SET_RELAY`, `MAV_CMD_DO_REPEAT_RELAY`, `MAV_CMD_DO_FENCE_ENABLE`, `MAV_CMD_DO_PARACHUTE`, `MAV_CMD_DO_GRIPPER`, `MAV_CMD_MISSION_START`. These would be sent in a `COMMAND_LONG` message *as discussed above*.

Setting the Yaw

The vehicle “yaw” is the direction that the vehicle is facing in the horizontal plane. On Copter this yaw need not be the direction of travel (though it is by default).

You can set the yaw direction using the `MAV_CMD_CONDITION_YAW` command, encoded in a `COMMAND_LONG` message as shown below.

```
def condition_yaw(heading, relative=False):
    if relative:
        is_relative=1 #yaw relative to direction of travel
    else:
        is_relative=0 #yaw is an absolute angle
    # create the CONDITION_YAW command using command_long_encode()
    msg = vehicle.message_factory.command_long_encode(
        0, 0, # target system, target component
        mavutil.mavlink.MAV_CMD_CONDITION_YAW, #command
        0, #confirmation
        heading, # param 1, yaw in degrees
        0, # param 2, yaw speed deg/s
        1, # param 3, direction -1 ccw, 1 cw
        is_relative, # param 4, relative offset 1, absolute angle 0
        0, 0, 0) # param 5 ~ 7 not used
    # send command to vehicle
    vehicle.send_mavlink(msg)
```

The command allows you to specify that whether the heading is an absolute angle in degrees (0 degrees is North) or a value that is relative to the previously set heading.

Note:

- The yaw will return to the default (facing direction of travel) after you set the mode or change the command used for controlling movement.
- *At time of writing* there is no *safe* way to return to the default yaw “face direction of travel” behaviour.
- After taking off, yaw commands are ignored until the first “movement” command has been received. If you need to yaw immediately following takeoff then send a command to “move” to your current position.
- *Setting the ROI* may work to get yaw to track a particular point (depending on the gimbal setup).

Setting the ROI

Send the `MAV_CMD_DO_SET_ROI` command to point camera gimbal at a specified region of interest (`LocationGlobal`). The vehicle may also turn to face the ROI.

```
def set_roi(location):  
    # create the MAV_CMD_DO_SET_ROI command  
    msg = vehicle.message_factory.command_long_encode(  
        0, 0,      # target system, target component  
        mavutil.mavlink.MAV_CMD_DO_SET_ROI, #command  
        0, #confirmation  
        0, 0, 0, 0, #params 1-4  
        location.lat,  
        location.lon,  
        location.alt  
    )  
    # send command to vehicle  
    vehicle.send_mavlink(msg)
```

New in version Copter: 3.2.1. You can explicitly reset the ROI by sending the `MAV_CMD_DO_SET_ROI` command with zero in all parameters. The front of the vehicle will then follow the direction of travel.

The ROI (and yaw) is also reset when the mode, or the command used to control movement, is changed.

Command acknowledgements and response values

ArduPilot typically sends a command acknowledgement indicating whether a command was received, and whether it was accepted or rejected. At time of writing there is no way to intercept this acknowledgement in the API (#168).

Some MAVLink messages request information from the autopilot, and expect the result to be returned in another message. Provided the message is handled by the AutoPilot in GUIDED mode you can send the request and process the response by creating a *message listener*.

4.4.3 Frame conversion functions

The functions in this section help convert between different frames-of-reference. In particular they make it easier to navigate in terms of “metres from the current position” when using commands that take absolute positions in decimal degrees.

The methods are approximations only, and may be less accurate over longer distances, and when close to the Earth’s poles.

```
def get_location_metres(original_location, dNorth, dEast):  
    """  
    Returns a LocationGlobal object containing the latitude/longitude `dNorth` and  
    ↪ `dEast` metres from the  
    specified `original_location`. The returned LocationGlobal has the same `alt`  
    ↪ value  
    as `original_location`.  
  
    The function is useful when you want to move the vehicle around specifying  
    ↪ locations relative to  
    the current vehicle position.  
  
    The algorithm is relatively accurate over small distances (10m within 1km) except  
    ↪ close to the poles.  
  
    For more information see:  
    http://gis.stackexchange.com/questions/2951/algorithm-for-offsetting-a-latitude-  
    ↪ longitude-by-some-amount-of-meters
```

(continues on next page)

(continued from previous page)

```

"""
earth_radius=6378137.0 #Radius of "spherical" earth
#Coordinate offsets in radians
dLat = dNorth/earth_radius
dLon = dEast/(earth_radius*math.cos(math.pi*original_location.lat/180))

#New position in decimal degrees
newlat = original_location.lat + (dLat * 180/math.pi)
newlon = original_location.lon + (dLon * 180/math.pi)
if type(original_location) is LocationGlobal:
    targetlocation=LocationGlobal(newlat, newlon,original_location.alt)
elif type(original_location) is LocationGlobalRelative:
    targetlocation=LocationGlobalRelative(newlat, newlon,original_location.alt)
else:
    raise Exception("Invalid Location object passed")

return targetlocation;

```

```

def get_distance_metres(aLocation1, aLocation2):
    """
    Returns the ground distance in metres between two `LocationGlobal` or
    ↪ `LocationGlobalRelative` objects.

    This method is an approximation, and will not be accurate over large distances
    ↪ and close to the
    earth's poles. It comes from the ArduPilot test code:
    https://github.com/diydrones/ardupilot/blob/master/Tools/autotest/common.py
    """
    dlat = aLocation2.lat - aLocation1.lat
    dlong = aLocation2.lon - aLocation1.lon
    return math.sqrt((dlat*dlat) + (dlong*dlong)) * 1.113195e5

```

```

def get_bearing(aLocation1, aLocation2):
    """
    Returns the bearing between the two LocationGlobal objects passed as parameters.

    This method is an approximation, and may not be accurate over large distances and
    ↪ close to the
    earth's poles. It comes from the ArduPilot test code:
    https://github.com/diydrones/ardupilot/blob/master/Tools/autotest/common.py
    """
    off_x = aLocation2.lon - aLocation1.lon
    off_y = aLocation2.lat - aLocation1.lat
    bearing = 90.00 + math.atan2(-off_y, off_x) * 57.2957795
    if bearing < 0:
        bearing += 360.00
    return bearing;

```

Tip: The `common.py` file in the ArduPilot test code may have other functions that you will find useful.

4.4.4 Other information

- NED Frame

- [MISSION_ITEM](#)
- [GUIDED Mode for Copter \(wiki\)](#).
- [GUIDED mode for Plane \(wiki\)](#).
- [Copter Commands in Guided Mode \(wiki\)](#).
- [MAVLink mission command messages \(wiki\)](#).
- [GCS_Mavlink.cpp \(Copter\)](#)

4.5 Missions (AUTO Mode)

AUTO mode is used run pre-defined waypoint missions on Copter, Plane and Rover.

DroneKit-Python provides basic methods to download and clear the current mission commands from the vehicle, to add and upload new mission commands, to count the number of waypoints, and to read and set the currently executed mission command. You can build upon these basic primitives to create high-level mission planning functionality.

This section shows how to use the basic methods and provides a few useful helper functions. Most of the code can be observed running in [Example: Basic Mission](#) and [Example: Mission Import/Export](#).

Note: We recommend that you *use GUIDED mode* instead of AUTO mode where possible, because it offers finer and more responsive control over movement, and can emulate most mission planning activities.

AUTO mode can be helpful if a command you need is not supported in GUIDED mode on a particular vehicle type.

4.5.1 Mission Command Overview

The mission commands (e.g. `MAV_CMD_NAV_TAKEOFF`, `MAV_CMD_NAV_WAYPOINT`) supported for each vehicle type are listed here: [Copter](#), [Plane](#), [Rover](#).

There are three types of commands:

- *NAVigation commands* (`MAV_CMD_NAV_*`) are used to control vehicle movement, including takeoff, moving to and around waypoints, changing altitude, and landing.
- *DO commands* (`MAV_CMD_DO_*`) are for auxiliary functions that do not affect the vehicle's position (for example, setting the camera trigger distance, or setting a servo value).
- *CONDITION commands* (`MAV_CMD_NAV_*`) are used to delay *DO commands* until some condition is met. For example `MAV_CMD_CONDITION_DISTANCE` will prevent DO commands executing until the vehicle reaches the specified distance from the waypoint.

During a mission at most one *NAV* command and one *DO* or *CONDITION* command can be running **at the same time**. *CONDITION* and *DO* commands are associated with the last *NAV* command that was sent: if the UAV reaches the waypoint before these commands are executed, the next *NAV* command is loaded and they will be skipped.

The [MAVLink Mission Command Messages \(MAV_CMD\)](#) wiki topic provides a more detailed overview of commands.

Note:

- If the autopilot receives a command that it cannot handle, then the command will be (silently) dropped.

- You cannot yet determine dynamically what commands are supported. We hope to deliver this functionality in the forthcoming [capability API](#).
-

4.5.2 Download current mission

The mission commands for a vehicle are accessed using the `Vehicle.commands` attribute. The attribute is of type `CommandSequence`, a class that provides ‘array style’ indexed access to the waypoints which make up the mission.

Waypoints are not downloaded from vehicle until `download()` is called. The download is asynchronous; use `wait_ready()` to block your thread until the download is complete:

```
# Connect to the Vehicle (in this case a simulated vehicle at 127.0.0.1:14550)
vehicle = connect('127.0.0.1:14550', wait_ready=True)

# Download the vehicle waypoints (commands). Wait until download is complete.
cmds = vehicle.commands
cmds.download()
cmds.wait_ready()
```

Note: In DroneKit-Python 2 `Vehicle.commands` contains just the editable waypoints (in version 1.x, the commands included the non-editable home location as the first item).

4.5.3 Clearing current mission

To clear a mission you call `clear()` and then `Vehicle.commands.upload()` (to upload the changes to the vehicle):

```
# Connect to the Vehicle (in this case a simulated vehicle at 127.0.0.1:14550)
vehicle = connect('127.0.0.1:14550', wait_ready=True)

# Get commands object from Vehicle.
cmds = vehicle.commands

# Call clear() on Vehicle.commands and upload the command to the vehicle.
cmds.clear()
cmds.upload()
```

Note: If a mission that is underway is cleared, the mission will continue to the next waypoint. If you don’t add a new command before the waypoint is reached then the vehicle mode will change to RTL (return to launch) mode.

4.5.4 Creating/adding mission commands

After *downloading* or *clearing* a mission new commands can be added and uploaded to the vehicle. Commands are added to the mission using `add()` and are sent to the vehicle (either individually or in batches) using `upload()`.

Each command is packaged in a `Command` object (see that class for the order/meaning of the parameters). The supported commands for each vehicle are [linked above](#).

```
# Connect to the Vehicle (in this case a simulated vehicle at 127.0.0.1:14550)
vehicle = connect('127.0.0.1:14550', wait_ready=True)

# Get the set of commands from the vehicle
cmds = vehicle.commands
cmds.download()
cmds.wait_ready()

# Create and add commands
cmd1=Command( 0, 0, 0, mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT, mavutil.mavlink.
↳MAV_CMD_NAV_TAKEOFF, 0, 0, 0, 0, 0, 0, 0, 0, 10)
cmd2=Command( 0, 0, 0, mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT, mavutil.mavlink.
↳MAV_CMD_NAV_WAYPOINT, 0, 0, 0, 0, 0, 0, 10, 10, 10)
cmds.add(cmd1)
cmds.add(cmd2)
cmds.upload() # Send commands
```

4.5.5 Modifying missions

While you can *add new commands* after *downloading a mission* it is not possible to directly modify and upload existing commands in `Vehicle.commands` (you can modify the commands but changes do not propagate to the vehicle).

Instead you copy all the commands into another container (e.g. a list), modify them as needed, then clear `Vehicle.commands` and upload the list as a new mission:

```
# Connect to the Vehicle (in this case a simulated vehicle at 127.0.0.1:14550)
vehicle = connect('127.0.0.1:14550', wait_ready=True)

# Get the set of commands from the vehicle
cmds = vehicle.commands
cmds.download()
cmds.wait_ready()

# Save the vehicle commands to a list
missionlist=[]
for cmd in cmds:
    missionlist.append(cmd)

# Modify the mission as needed. For example, here we change the
# first waypoint into a MAV_CMD_NAV_TAKEOFF command.
missionlist[0].command=mavutil.mavlink.MAV_CMD_NAV_TAKEOFF

# Clear the current mission (command is sent when we call upload())
cmds.clear()

#Write the modified mission and flush to the vehicle
for cmd in missionlist:
    cmds.add(cmd)
cmds.upload()
```

The changes are not guaranteed to be complete until `upload()` is called on the parent `Vehicle.commands` object.

4.5.6 Running and monitoring missions

To start a mission, change the mode to AUTO:


```
# Connect to the Vehicle (in this case a simulated vehicle at 127.0.0.1:14550)
vehicle = connect('127.0.0.1:14550', wait_ready=True)

# Set the vehicle into auto mode
vehicle.mode = VehicleMode("AUTO")
```

Note: If the vehicle is in the air, then changing the mode to AUTO is all that is required to start the mission.

Copter 3.3 release and later: If the vehicle is on the ground (only), you will additionally need to send the `MAV_CMD_MISSION_START` command.

You can stop/pause the current mission by switching out of AUTO mode (e.g. into GUIDED mode). If you switch back to AUTO mode the mission will either restart at the beginning or resume at the current waypoint - the behaviour depends on the value of the `MIS_RESTART` parameter (available on all vehicle types).

You can monitor the progress of the mission by polling the `Vehicle.commands.next` attribute to get the current command number. You can also change the current command by setting the attribute to the desired command number.

```
vehicle.commands.next=2
print "Current Waypoint: %s" % vehicle.commands.next
vehicle.commands.next=4
print "Current Waypoint: %s" % vehicle.commands.next
```

There is no need to `upload()` changes to send an update to the `next` attribute to the vehicle (and as with other attributes, if you fetch a value, it is updated from the vehicle).

4.5.7 Handling the end of a mission

At the end of the mission the vehicle will enter LOITER mode (hover in place for Copter, circle for Plane, stop for Rover). You can add new commands to the mission, but you will need to toggle from/back to AUTO mode to start it running again.

Currently there is no notification in DroneKit when a mission completes. If you need to detect mission end (in order to perform some other operation) then you can either:

- Add a dummy mission command and poll `Vehicle.commands.next` for the transition to the final command, or
- Compare the current position to the target position in the final waypoint.

4.5.8 Useful Mission functions

This example code contains a number of functions that might be useful for managing and monitoring missions:

Load a mission from a file

`upload_mission()` uploads a mission from a file.

The implementation calls `readmission()` (below) to import the mission from a file into a list. The method then clears the existing mission and uploads the new version.

Adding mission commands is discussed [here in the guide](#).

```
def upload_mission(aFileName):
    """
    Upload a mission from a file.
    """
    #Read mission from file
    missionlist = readmission(aFileName)

    print "\nUpload mission from a file: %s" % import_mission_filename
    #Clear existing mission from vehicle
    print ' Clear mission'
    cmds = vehicle.commands
    cmds.clear()
    #Add new mission to vehicle
    for command in missionlist:
        cmds.add(command)
    print ' Upload mission'
    vehicle.commands.upload()
```

`readmission()` reads a mission from the specified file and returns a list of *Command* objects.

Each line is split up. The first line is used to test whether the file has the correct (stated) format. For subsequent lines the values are stored in a *Command* object (the values are first cast to the correct float and int types for their associated parameters). The commands are added to a list which is returned by the function.

```
def readmission(aFileName):
    """
    Load a mission from a file into a list.

    This function is used by upload_mission().
    """
    print "Reading mission from file: %s\n" % aFileName
    cmds = vehicle.commands
    missionlist=[]
    with open(aFileName) as f:
        for i, line in enumerate(f):
            if i==0:
                if not line.startswith('QGC WPL 110'):
                    raise Exception('File is not supported WP version')
            else:
                linearray=line.split('\t')
                ln_index=int(linearray[0])
                ln_currentwp=int(linearray[1])
                ln_frame=int(linearray[2])
                ln_command=int(linearray[3])
                ln_param1=float(linearray[4])
                ln_param2=float(linearray[5])
                ln_param3=float(linearray[6])
                ln_param4=float(linearray[7])
                ln_param5=float(linearray[8])
                ln_param6=float(linearray[9])
                ln_param7=float(linearray[10])
                ln_autocontinue=int(linearray[11].strip())
                cmd = Command( 0, 0, 0, ln_frame, ln_command, ln_currentwp, ln_
→autocontinue, ln_param1, ln_param2, ln_param3, ln_param4, ln_param5, ln_param6, ln_
→param7)
                missionlist.append(cmd)
    return missionlist
```

Save a mission to a file

`save_mission()` saves the current mission to a file (in the [Waypoint file format](http://qgroundcontrol.org/mavlink/waypoint_protocol#waypoint_file_format)). It uses `download_mission()` (below) to get the mission, and then writes the list line-by-line to the file.

```
def save_mission(aFileName):
    """
    Save a mission in the Waypoint file format (http://qgroundcontrol.org/mavlink/
    ↪waypoint\_protocol#waypoint\_file\_format).
    """
    missionlist = download_mission()
    output='QGC WPL 110\n'
    for cmd in missionlist:
        cmdline="%s\t%s\t%s\t%s\t%s\t%s\t%s\t%s\t%s\t%s\t%s\t%s\n" % (cmd.seq,cmd.
    ↪current,cmd.frame,cmd.command,cmd.param1,cmd.param2,cmd.param3,cmd.param4,cmd.x,cmd.
    ↪y,cmd.z,cmd.autocontinue)
        output+=cmdline
    with open(aFileName, 'w') as file_:
        file_.write(output)
```

`download_mission()` downloads the `Vehicle.commands` from the vehicle and adds them to a list. Downloading mission is discussed *in the guide*.

```
def download_mission():
    """
    Downloads the current mission and returns it in a list.
    It is used in save_mission() to get the file information to save.
    """
    missionlist=[]
    cmds = vehicle.commands
    cmds.download()
    cmds.wait_ready()
    for cmd in cmds:
        missionlist.append(cmd)
    return missionlist
```

Get distance to waypoint

`distance_to_current_waypoint()` returns the distance (in metres) to the next waypoint:

```
def distance_to_current_waypoint():
    """
    Gets distance in metres to the current waypoint.
    It returns None for the first waypoint (Home location).
    """
    nextwaypoint=vehicle.commands.next
    if nextwaypoint ==0:
        return None
    missionitem=vehicle.commands[nextwaypoint-1] #commands are zero indexed
    lat=missionitem.x
    lon=missionitem.y
    alt=missionitem.z
    targetWaypointLocation=LocationGlobalRelative(lat,lon,alt)
    distancetopoint = get_distance_metres(vehicle.location.global_frame,
    ↪targetWaypointLocation)
    return distancetopoint
```

The function determines the current target waypoint number with `Vehicle.commands.next` and uses it to index the commands to get the latitude, longitude and altitude of the target waypoint. The `get_distance_metres()` function (see [Frame conversion functions](#)) is then used to calculate and return the (horizontal) distance from the current vehicle location.

Tip: This implementation is very basic. It assumes that the next command number is for a valid NAV command (it might not be) and that the lat/lon/alt values are non-zero. It is however a useful indicator for test code.

4.5.9 Useful Links

- [MAVLink mission command messages](#) (all vehicle types - wiki).

4.6 Debugging

DroneKit-Python apps can be debugged in the same way as any other standalone Python scripts. The sections below outline a few methods.

4.6.1 pdb - The Python Debugger

The [Python Debugger](#) - `pdb` can be used to debug *DroneKit-Python* apps.

The command below can be used to run a script in debug mode:

```
python -m pdb my_dronekit_script.py
```

You can also instrument your code to invoke the debugger at a certain point. To do this add `set_trace()` at the point where you want to break execution:

```
# Connect to the Vehicle on udp at 127.0.0.1:14550
vehicle = connect('127.0.0.1:14550', wait_ready=True)

import pdb; pdb.set_trace()
print "Global Location: %s" % vehicle.location.global_frame
```

The available [debugger commands](#) are listed here.

4.6.2 pudb - A full-screen, console-based Python debugger

If you prefer a IDE like debug you can use [pudb](#) - A full-screen, console-based Python debugger.

```
pip install pudb
```

To start debugging, simply insert:

```
from pudb import set_trace; set_trace()
```

Insert either of these snippets into the piece of code you want to debug, or run the entire script with:

```
pudb my-script.py
```

4.6.3 Print/log statements

The simplest and most common method of debugging is to manually add debug/print statements to the source.

```
# Connect to the Vehicle on udp at 127.0.0.1:14550
vehicle = connect('127.0.0.1:14550', wait_ready=True)

# print out debug information
print "Global Location: %s" % vehicle.location.global_frame
```

In addition to printing DroneKit variables, Python provides numerous inbuilt and add-on modules/methods for inspecting code (e.g. `dir()`, `traceback`, etc.)

4.6.4 Other IDEs/debuggers

There is no reason you should not be able to straightforwardly use other popular Python IDEs including IDLE and Eclipse.

4.7 MAVLink Messages

Some useful MAVLink messages sent by the autopilot are not (yet) directly available to DroneKit-Python scripts through the *observable attributes* in *Vehicle*.

This topic shows how you can intercept specific MAVLink messages by defining a listener callback function using the *Vehicle.on_message()* decorator.

Tip: *Example: Create Attribute in App* shows how you can extend this approach to create a new *Vehicle* attribute in your client code.

4.7.1 Creating a message listener

The *Vehicle.on_message()* decorator can be used to set a particular function as the callback handler for a particular message type. You can create listeners for as many messages as you like, or even multiple listeners for the same message.

For example, the code snippet below shows how to set a listener for the `RANGEFINDER` message:

```
#Create a message listener using the decorator.
@vehicle.on_message('RANGEFINDER')
def listener(self, name, message):
    print message
```

Tip: Every single listener can have the same name/prototpye as above (“listener”) because Python does not notice the decorated functions are in the same scope.

Unfortunately this also means that you can’t unregister a callback created using this method.

The messages are *classes* from the *pymavlink* library. The output of the code above looks something like:

```
RANGEFINDER {distance : 0.0899999961257, voltage : 0.00900000054389}
...
```

You can access the message fields directly. For example, to access the `RANGEFINDER` message your listener function might look like this:

```
#Create a message listener using the decorator.
@vehicle.on_message('RANGEFINDER')
def listener(self, name, message):
    print 'distance: %s' % message.distance
    print 'voltage: %s' % message.voltage
```

4.7.2 Watching all messages

You can register a callback for *all messages* by setting the message name as the wildcard string (`'*'`):

```
#Create a message listener for all messages.
@vehicle.on_message('*')
def listener(self, name, message):
    print 'message: %s' % message
```

4.7.3 Removing an observer

Callbacks registered using the `Vehicle.on_message()` decorator *cannot be removed*. This is generally not a problem, because in most cases you're interested in messages for the lifetime of a session.

If you do need to be able to remove messages you can instead add the callback using `Vehicle.add_message_listener`, and then remove it by calling `Vehicle.remove_message_listener`.

Examples

This section contains the documentation for a number of useful DroneKit-Python examples. These demonstrate common use-cases, and show (among other things) how to use the API to query vehicle state and parameters, and how to control a vehicle during missions and outside missions using custom commands.

5.1 Running the Examples

General instructions for running the [example source code](#) are given below. More explicit instructions are provided within the documentation for each example (and within the examples themselves by passing the `-h` (help) command line argument).

Tip: The examples all launch the [dronekit-sitl](#) simulator and connect to it by default. The `--connect` argument is used to instead specify the [connection string](#) for a target vehicle or an externally managed SITL instance.

To run the examples:

1. [Install DroneKit-Python](#) if you have not already done so! Install [dronekit-sitl](#) if you want to test against simulated vehicles.
2. Get the DroneKit-Python example source code onto your local machine. The easiest way to do this is to clone the **dronekit-python** repository from Github.

On the command prompt enter:

```
git clone http://github.com/dronekit/dronekit-python.git
```

3. Navigate to the example you wish to run (or specify the full path in the next step). The examples are all stored in subdirectories of **dronekit-python/examples/**.

For example, to run the [vehicle_state](#) example, you would navigate as shown:

```
cd dronekit-python/examples/vehicle_state/
```

4. Start the example as shown:

- To connect to a simulator started/managed by the script:

```
python vehicle_state.py
```

- To connect to a specific vehicle, pass its *connection string* via the `connect` argument. For example, to run the example on Solo you would use the following command:

```
python vehicle_state.py --connect udpin:0.0.0.0:14550
```

Warning: Propellers should be removed before testing examples indoors (on real vehicles).

5.2 Example: Vehicle State

This example shows how to get/set vehicle attribute and parameter information, how to observe vehicle attribute changes, and how to get the home position.

The guide topic *Vehicle State and Settings* provides a more detailed explanation of how the API should be used.

5.2.1 Running the example

The example can be run as described in *Running the Examples* (which in turn assumes that the vehicle and DroneKit have been set up as described in *Installing DroneKit*).

In summary, after cloning the repository:

1. Navigate to the example folder as shown:

```
cd dronekit-python/examples/vehicle_state/
```

2. You can run the example against a simulator (DroneKit-SITL) by specifying the Python script without any arguments. The example will download SITL binaries (if needed), start the simulator, and then connect to it:

```
python vehicle_state.py
```

On the command prompt you should see (something like):

```
Connecting to vehicle on: tcp:127.0.0.1:5760
>>> APM:Copter V3.3 (d6053245)
>>> Frame: QUAD
>>> Calibrating barometer
>>> Initialising APM...
>>> barometer calibration complete
>>> GROUND START

Get all vehicle attribute values:
Autopilot Firmware version: APM:Copter-3.3.0-alpha64
Major version number: 3
Minor version number: 3
Patch version number: 0
Release type: rc
Release version: 0
```

(continues on next page)

(continued from previous page)

```

    Stable release?: True
Autopilot capabilities
    Supports MISSION_FLOAT message type: True
    Supports PARAM_FLOAT message type: True
    Supports MISSION_INT message type: False
    Supports COMMAND_INT message type: False
    Supports PARAM_UNION message type: False
    Supports ftp for file transfers: False
    Supports commanding attitude offboard: False
    Supports commanding position and velocity targets in local NED frame: True
    Supports set position + velocity targets in global scaled integers: True
    Supports terrain protocol / data handling: True
    Supports direct actuator control: False
    Supports the flight termination command: True
    Supports mission_float message type: True
    Supports onboard compass calibration: False
Global Location: LocationGlobal:lat=-35.363261,lon=149.1652299,alt=None
Global Location (relative altitude): LocationGlobalRelative:lat=-35.363261,
↪lon=149.1652299,alt=0.0
Local Location: LocationLocal:north=None,east=None,down=None
Attitude: Attitude:pitch=0.00294387154281,yaw=-0.11805768311,roll=0.
↪00139428151306
Velocity: [-0.03, 0.02, 0.0]
GPS: GPSInfo:fix=3,num_sat=10
Gimbal status: Gimbal: pitch=None, roll=None, yaw=None
Battery: Battery:voltage=12.587,current=0.0,level=100
EKF OK?: False
Last Heartbeat: 0.769999980927
Rangefinder: Rangefinder: distance=None, voltage=None
Rangefinder distance: None
Rangefinder voltage: None
Heading: 353
Is Armable?: False
System status: STANDBY
Groundspeed: 0.0
Airspeed: 0.0
Mode: STABILIZE
Armed: False
Waiting for home location ...
...
Waiting for home location ...
Waiting for home location ...

Home location: LocationGlobal:lat=-35.3632621765,lon=149.165237427,alt=583.
↪989990234

Set new home location
New Home Location (from attribute - altitude should be 222): LocationGlobal:lat=-
↪35.363261,lon=149.1652299,alt=222
New Home Location (from vehicle - altitude should be 222): LocationGlobal:lat=-
↪35.3632621765,lon=149.165237427,alt=222.0

Set Vehicle.mode=GUIDED (currently: STABILIZE)
Waiting for mode change ...

Set Vehicle.armed=True (currently: False)
Waiting for arming...
```

(continues on next page)

(continued from previous page)

```

Waiting for arming...
Waiting for arming...
>>> ARMING MOTORS
>>> GROUND START
Waiting for arming...
Waiting for arming...
>>> Initialising APM...
Vehicle is armed: True

Add `attitude` attribute callback/observer on `vehicle`
Wait 2s so callback invoked before observer removed
CALLBACK: Attitude changed to Attitude:pitch=-0.000483880605316,yaw=-0.
↪0960851684213,roll=-0.00799709651619
CALLBACK: Attitude changed to Attitude:pitch=0.000153727291035,yaw=-0.
↪0962921902537,roll=-0.00707155792043
...
CALLBACK: Attitude changed to Attitude:pitch=0.00485319690779,yaw=-0.
↪100129388273,roll=0.00181497994345
Remove Vehicle.attitude observer

Add `mode` attribute callback/observer using decorator
Set mode=STABILIZE (currently: GUIDED) and wait for callback
Wait 2s so callback invoked before moving to next example
CALLBACK: Mode changed to VehicleMode:STABILIZE

Attempt to remove observer added with `on_attribute` decorator (should fail)
Exception: Cannot remove observer added using decorator

Add attribute callback detecting ANY attribute change
Wait 1s so callback invoked before observer removed
CALLBACK: (attitude): Attitude:pitch=0.00716688157991,yaw=-0.0950401723385,
↪roll=0.00759896961972
CALLBACK: (heading): 354
CALLBACK: (location): <dronekit.Locations object at 0x000000000767F2B0>
CALLBACK: (airspeed): 0.0
CALLBACK: (groundspeed): 0.0
CALLBACK: (ekf_ok): True
CALLBACK: (battery): Battery:voltage=12.538,current=3.48,level=99
CALLBACK: (gps_0): GPSInfo:fix=3,num_sat=10
CALLBACK: (location): <dronekit.Locations object at 0x000000000767F2B0>
CALLBACK: (velocity): [-0.14, 0.1, 0.0]
CALLBACK: (local_position): LocationLocal:north=-0.136136248708,east=-0.
↪0430941730738,down=-0.00938374921679
CALLBACK: (channels): {'1': 1500, '3': 1000, '2': 1500, '5': 1800, '4': 1500, '7'
↪': 1000, '6': 1000, '8': 1800}
...
CALLBACK: (ekf_ok): True
Remove Vehicle attribute observer

Read and write parameters
Read vehicle param 'THR_MIN': 130.0
Write vehicle param 'THR_MIN' : 10
Read new value of param 'THR_MIN': 10.0

Print all parameters (iterate `vehicle.parameters`):
Key:RC7_REV Value:1.0
Key:GPS_INJECT_TO Value:127.0

```

(continues on next page)

(continued from previous page)

```

Key:FLTMODE1 Value:7.0
...
Key:SR2_POSITION Value:0.0
Key:SIM_FLOW_DELAY Value:0.0
Key:BATT_CURR_PIN Value:12.0

Create parameter observer using decorator
Write vehicle param 'THR_MIN' : 20 (and wait for callback)
PARAMETER CALLBACK: THR_MIN changed to: 20.0

Create (removable) observer for any parameter using wildcard string
Change THR_MID and THR_MIN parameters (and wait for callback)
ANY PARAMETER CALLBACK: THR_MID changed to: 400.0
PARAMETER CALLBACK: THR_MIN changed to: 30.0
ANY PARAMETER CALLBACK: THR_MIN changed to: 30.0

Reset vehicle attributes/parameters and exit
>>> DISARMING MOTORS
PARAMETER CALLBACK: THR_MIN changed to: 130.0
ANY PARAMETER CALLBACK: THR_MIN changed to: 130.0
ANY PARAMETER CALLBACK: THR_MID changed to: 500.0

Close vehicle object
Completed

```

3. You can run the example against a specific connection (simulated or otherwise) by passing the *connection string* for your vehicle in the `--connect` parameter.

For example, to connect to SITL running on UDP port 14550 on your local computer:

```
python vehicle_state.py --connect 127.0.0.1:14550
```

Note: DroneKit-SITL does not automatically add a virtual gimbal and rangefinder, so these attributes will always report None.

5.2.2 How does it work?

The guide topic *Vehicle State and Settings* provides an explanation of how this code works.

5.2.3 Known issues

This example has no known issues.

5.2.4 Source code

The full source code at documentation build-time is listed below ([current version on github](#)):

```
#!/usr/bin/env python
# -*- coding: utf-8 -*-

"""
```

(continues on next page)

(continued from previous page)

```

© Copyright 2015-2016, 3D Robotics.
vehicle_state.py:

Demonstrates how to get and set vehicle state and parameter information,
and how to observe vehicle attribute (state) changes.

Full documentation is provided at http://python.dronekit.io/examples/vehicle\_state.html
"""
from __future__ import print_function
from dronekit import connect, VehicleMode
import time

#Set up option parsing to get connection string
import argparse
parser = argparse.ArgumentParser(description='Print out vehicle state information.
↳html
↳Connects to SITL on local PC by default.')
parser.add_argument('--connect',
                    help="vehicle connection target string. If not specified, SITL
↳automatically started and used.")
args = parser.parse_args()

connection_string = args.connect
sitl = None

#Start SITL if no connection string specified
if not connection_string:
    import dronekit_sitl
    sitl = dronekit_sitl.start_default()
    connection_string = sitl.connection_string()

# Connect to the Vehicle.
# Set `wait_ready=True` to ensure default attributes are populated before
↳`connect()` returns.
print("\nConnecting to vehicle on: %s" % connection_string)
vehicle = connect(connection_string, wait_ready=True)

vehicle.wait_ready('autopilot_version')

# Get all vehicle attributes (state)
print("\nGet all vehicle attribute values:")
print(" Autopilot Firmware version: %s" % vehicle.version)
print("   Major version number: %s" % vehicle.version.major)
print("   Minor version number: %s" % vehicle.version.minor)
print("   Patch version number: %s" % vehicle.version.patch)
print("   Release type: %s" % vehicle.version.release_type())
print("   Release version: %s" % vehicle.version.release_version())
print("   Stable release?: %s" % vehicle.version.is_stable())
print(" Autopilot capabilities")
print("   Supports MISSION_FLOAT message type: %s" % vehicle.capabilities.mission_
↳float)
print("   Supports PARAM_FLOAT message type: %s" % vehicle.capabilities.param_float)
print("   Supports MISSION_INT message type: %s" % vehicle.capabilities.mission_int)
print("   Supports COMMAND_INT message type: %s" % vehicle.capabilities.command_int)
print("   Supports PARAM_UNION message type: %s" % vehicle.capabilities.param_union)

```

(continues on next page)

(continued from previous page)

```

print(" Supports ftp for file transfers: %s" % vehicle.capabilities.ftp)
print(" Supports commanding attitude offboard: %s" % vehicle.capabilities.set_
↳attitude_target)
print(" Supports commanding position and velocity targets in local NED frame: %s" %
↳vehicle.capabilities.set_attitude_target_local_ned)
print(" Supports set position + velocity targets in global scaled integers: %s" %
↳vehicle.capabilities.set_altitude_target_global_int)
print(" Supports terrain protocol / data handling: %s" % vehicle.capabilities.
↳terrain)
print(" Supports direct actuator control: %s" % vehicle.capabilities.set_actuator_
↳target)
print(" Supports the flight termination command: %s" % vehicle.capabilities.flight_
↳termination)
print(" Supports mission_float message type: %s" % vehicle.capabilities.mission_
↳float)
print(" Supports onboard compass calibration: %s" % vehicle.capabilities.compass_
↳calibration)
print(" Global Location: %s" % vehicle.location.global_frame)
print(" Global Location (relative altitude): %s" % vehicle.location.global_relative_
↳frame)
print(" Local Location: %s" % vehicle.location.local_frame)
print(" Attitude: %s" % vehicle.attitude)
print(" Velocity: %s" % vehicle.velocity)
print(" GPS: %s" % vehicle.gps_0)
print(" Gimbal status: %s" % vehicle.gimbal)
print(" Battery: %s" % vehicle.battery)
print(" EKF OK?: %s" % vehicle.ekf_ok)
print(" Last Heartbeat: %s" % vehicle.last_heartbeat)
print(" Rangefinder: %s" % vehicle.rangefinder)
print(" Rangefinder distance: %s" % vehicle.rangefinder.distance)
print(" Rangefinder voltage: %s" % vehicle.rangefinder.voltage)
print(" Heading: %s" % vehicle.heading)
print(" Is Armable?: %s" % vehicle.is_armable)
print(" System status: %s" % vehicle.system_status.state)
print(" Groundspeed: %s" % vehicle.groundspeed) # settable
print(" Airspeed: %s" % vehicle.airspeed) # settable
print(" Mode: %s" % vehicle.mode.name) # settable
print(" Armed: %s" % vehicle.armed) # settable

# Get Vehicle Home location - will be `None` until first set by autopilot
while not vehicle.home_location:
    cmds = vehicle.commands
    cmds.download()
    cmds.wait_ready()
    if not vehicle.home_location:
        print(" Waiting for home location ...")
# We have a home location, so print it!
print("\n Home location: %s" % vehicle.home_location)

# Set vehicle home_location, mode, and armed attributes (the only settable attributes)

print("\nSet new home location")
# Home location must be within 50km of EKF home location (or setting will fail_
↳silently)

```

(continues on next page)

(continued from previous page)

```

# In this case, just set value to current location with an easily recognisable_
↪altitude (222)
my_location_alt = vehicle.location.global_frame
my_location_alt.alt = 222.0
vehicle.home_location = my_location_alt
print(" New Home Location (from attribute - altitude should be 222): %s" % vehicle.
↪home_location)

#Confirm current value on vehicle by re-downloading commands
cmds = vehicle.commands
cmds.download()
cmds.wait_ready()
print(" New Home Location (from vehicle - altitude should be 222): %s" % vehicle.home_
↪location)

print("\nSet Vehicle.mode = GUIDED (currently: %s)" % vehicle.mode.name)
vehicle.mode = VehicleMode("GUIDED")
while not vehicle.mode.name=='GUIDED': #Wait until mode has changed
    print(" Waiting for mode change ...")
    time.sleep(1)

# Check that vehicle is armable
while not vehicle.is_armable:
    print(" Waiting for vehicle to initialise...")
    time.sleep(1)
    # If required, you can provide additional information about initialisation
    # using `vehicle.gps_0.fix_type` and `vehicle.mode.name`.

#print "\nSet Vehicle.armed=True (currently: %s)" % vehicle.armed
#vehicle.armed = True
#while not vehicle.armed:
#    print " Waiting for arming..."
#    time.sleep(1)
#print " Vehicle is armed: %s" % vehicle.armed

# Add and remove and attribute callbacks

#Define callback for `vehicle.attitude` observer
last_attitude_cache = None
def attitude_callback(self, attr_name, value):
    # `attr_name` - the observed attribute (used if callback is used for multiple_
↪attributes)
    # `self` - the associated vehicle object (used if a callback is different for_
↪multiple vehicles)
    # `value` is the updated attribute value.
    global last_attitude_cache
    # Only publish when value changes
    if value!=last_attitude_cache:
        print(" CALLBACK: Attitude changed to", value)
        last_attitude_cache=value

print("\nAdd `attitude` attribute callback/observer on `vehicle`")
vehicle.add_attribute_listener('attitude', attitude_callback)

```

(continues on next page)

(continued from previous page)

```

print(" Wait 2s so callback invoked before observer removed")
time.sleep(2)

print(" Remove Vehicle.attitude observer")
# Remove observer added with `add_attribute_listener()` specifying the attribute and
↳callback function
vehicle.remove_attribute_listener('attitude', attitude_callback)

# Add mode attribute callback using decorator (callbacks added this way cannot be
↳removed).
print("\nAdd `mode` attribute callback/observer using decorator")
@vehicle.on_attribute('mode')
def decorated_mode_callback(self, attr_name, value):
    # `attr_name` is the observed attribute (used if callback is used for multiple
    ↳attributes)
    # `attr_name` - the observed attribute (used if callback is used for multiple
    ↳attributes)
    # `value` is the updated attribute value.
    print(" CALLBACK: Mode changed to", value)

print(" Set mode=STABILIZE (currently: %s) and wait for callback" % vehicle.mode.name)
vehicle.mode = VehicleMode("STABILIZE")

print(" Wait 2s so callback invoked before moving to next example")
time.sleep(2)

print("\n Attempt to remove observer added with `on_attribute` decorator (should fail)
↳")
try:
    vehicle.remove_attribute_listener('mode', decorated_mode_callback)
except:
    print(" Exception: Cannot remove observer added using decorator")

# Demonstrate getting callback on any attribute change
def wildcard_callback(self, attr_name, value):
    print(" CALLBACK: (%s): %s" % (attr_name,value))

print("\nAdd attribute callback detecting ANY attribute change")
vehicle.add_attribute_listener('*', wildcard_callback)

print(" Wait 1s so callback invoked before observer removed")
time.sleep(1)

print(" Remove Vehicle attribute observer")
# Remove observer added with `add_attribute_listener()`
vehicle.remove_attribute_listener('*', wildcard_callback)

# Get/Set Vehicle Parameters
print("\nRead and write parameters")

```

(continues on next page)

(continued from previous page)

```

print(" Read vehicle param 'THR_MIN': %s" % vehicle.parameters['THR_MIN'])

print(" Write vehicle param 'THR_MIN' : 10")
vehicle.parameters['THR_MIN']=10
print(" Read new value of param 'THR_MIN': %s" % vehicle.parameters['THR_MIN'])

print("\nPrint all parameters (iterate `vehicle.parameters`):")
for key, value in vehicle.parameters.iteritems():
    print(" Key:%s Value:%s" % (key,value))

print("\nCreate parameter observer using decorator")
# Parameter string is case-insensitive
# Value is cached (listeners are only updated on change)
# Observer added using decorator can't be removed.

@vehicle.parameters.on_attribute('THR_MIN')
def decorated_thr_min_callback(self, attr_name, value):
    print(" PARAMETER CALLBACK: %s changed to: %s" % (attr_name, value))

print("Write vehicle param 'THR_MIN' : 20 (and wait for callback)")
vehicle.parameters['THR_MIN']=20
for x in range(1,5):
    #Callbacks may not be updated for a few seconds
    if vehicle.parameters['THR_MIN']==20:
        break
    time.sleep(1)

#Callback function for "any" parameter
print("\nCreate (removable) observer for any parameter using wildcard string")
def any_parameter_callback(self, attr_name, value):
    print(" ANY PARAMETER CALLBACK: %s changed to: %s" % (attr_name, value))

#Add observer for the vehicle's any/all parameters parameter (defined using wildcard_
↪string ``*``)
vehicle.parameters.add_attribute_listener('*', any_parameter_callback)
print(" Change THR_MID and THR_MIN parameters (and wait for callback)")
vehicle.parameters['THR_MID']=400
vehicle.parameters['THR_MIN']=30

## Reset variables to sensible values.
print("\nReset vehicle attributes/parameters and exit")
vehicle.mode = VehicleMode("STABILIZE")
#vehicle.armed = False
vehicle.parameters['THR_MIN']=130
vehicle.parameters['THR_MID']=500

#Close vehicle object before exiting script
print("\nClose vehicle object")
vehicle.close()

# Shut down simulator if it was started.

```

(continues on next page)

(continued from previous page)

```
if sitl is not None:
    sitl.stop()

print("Completed")
```

5.3 Example: Simple Go To (Copter)

This example demonstrates how to arm and launch a Copter in GUIDED mode, travel towards a number of target points, and then return to the home location. It uses `Vehicle.simple_takeoff()`, `Vehicle.simple_goto()` and `Vehicle.mode`.

The target locations are centered around the home location when the Simulated Vehicle is booted; you can edit the latitude and longitude to use more appropriate positions for your own vehicle.

Note: This example will only run on *Copter*:

- *Plane* does not support takeoff in GUIDED mode.
- *Rover* will ignore the `takeoff` command and will then stick at the altitude check.




Fig. 1: Simple Goto Example: Flight path

5.3.1 Running the example

The example can be run as described in *Running the Examples* (which in turn assumes that the vehicle and DroneKit have been set up as described in *Installing DroneKit*).

In summary, after cloning the repository:

1. Navigate to the example folder as shown:

```
cd dronekit-python/examples/simple_goto/
```

2. You can run the example against a simulator (DroneKit-SITL) by specifying the Python script without any arguments. The example will download SITL binaries if needed, start the simulator, and then connect to it:

```
python simple_goto.py
```

On the command prompt you should see (something like):

```
Starting copter simulator (SITL)
SITL already Downloaded.
Connecting to vehicle on: tcp:127.0.0.1:5760
>>> APM:Copter V3.3 (d6053245)
>>> Frame: QUAD
>>> Calibrating barometer
>>> Initialising APM...
>>> barometer calibration complete
>>> GROUND START
Basic pre-arm checks
Waiting for vehicle to initialise...
...
Waiting for vehicle to initialise...
Arming motors
Waiting for arming...
...
Waiting for arming...
>>> ARMING MOTORS
>>> GROUND START
Waiting for arming...
>>> Initialising APM...
Taking off!
Altitude: 0.0
...
Altitude: 7.4
Altitude: 9.0
Altitude: 9.65
Reached target altitude
Set default/target airspeed to 3
Going towards first point for 30 seconds ...
Going towards second point for 30 seconds (groundspeed set to 10 m/s) ...
Returning to Launch
Close vehicle object
```

Tip: It is more interesting to watch the example run on a map than the console. The topic [Connecting an additional Ground Station](#) explains how to set up *Mission Planner* to view a vehicle running on the simulator (SITL).

3. You can run the example against a specific connection (simulated or otherwise) by passing the *connection string* for your vehicle in the `--connect` parameter.

For example, to connect to SITL running on UDP port 14550 on your local computer:

```
python simple_goto.py --connect 127.0.0.1:14550
```

5.3.2 How does it work?

The code has three distinct sections: arming and takeoff, flight to two locations, and return-to-home.

Takeoff

To launch *Copter* you need to first check that the vehicle `Vehicle.is_armable`. Then set the mode to GUIDED, arm the vehicle, and call `Vehicle.simple_takeoff()`. The takeoff code in this example is explained in the guide topic *Taking Off*.

Flying to a point - simple_goto

The vehicle is already in GUIDED mode, so to send it to a certain point we just need to call `Vehicle.simple_goto()` with the target `dronekit.LocationGlobalRelative`:

```
# set the default travel speed
vehicle.airspeed=3

point1 = LocationGlobalRelative(-35.361354, 149.165218, 20)
vehicle.simple_goto(point1)

# sleep so we can see the change in map
time.sleep(30)
```

Tip: Without some sort of “wait” the next command would be executed immediately. In this example we just sleep for 30 seconds before executing the next command.

When moving towards the first point we set the airspeed using the `Vehicle.airspeed` attribute. For the second point the example specifies the target groundspeed when calling `Vehicle.simple_goto()`

```
vehicle.simple_goto(point2, groundspeed=10)
```

Tip: The script doesn’t report anything during the sleep periods, but you can observe the vehicle’s movement on a ground station map.

RTL - Return to launch

To return to the home position and land, we set the mode to RTL. The vehicle travels at the previously set default speed:

```
vehicle.mode = VehicleMode("RTL")
```

5.3.3 Source code

The full source code at documentation build-time is listed below ([current version on Github](#)):

```
#!/usr/bin/env python
# -*- coding: utf-8 -*-

"""
© Copyright 2015-2016, 3D Robotics.
simple_goto.py: GUIDED mode "simple goto" example (Copter Only)

Demonstrates how to arm and takeoff in Copter and how to navigate to points using
↳Vehicle.simple_goto.

Full documentation is provided at http://python.dronekit.io/examples/simple\_goto.html
"""

from __future__ import print_function
import time
from dronekit import connect, VehicleMode, LocationGlobalRelative

# Set up option parsing to get connection string
import argparse
parser = argparse.ArgumentParser(description='Commands vehicle using vehicle.simple_
↳goto.')
parser.add_argument('--connect',
                    help="Vehicle connection target string. If not specified, SITL_
↳automatically started and used.")
args = parser.parse_args()

connection_string = args.connect
sitl = None

# Start SITL if no connection string specified
if not connection_string:
    import dronekit_sitl
    sitl = dronekit_sitl.start_default()
    connection_string = sitl.connection_string()

# Connect to the Vehicle
print('Connecting to vehicle on: %s' % connection_string)
vehicle = connect(connection_string, wait_ready=True)

def arm_and_takeoff(aTargetAltitude):
    """
    Arms vehicle and fly to aTargetAltitude.
    """

    print("Basic pre-arm checks")
    # Don't try to arm until autopilot is ready
    while not vehicle.is_armable:
        print(" Waiting for vehicle to initialise...")
        time.sleep(1)

    print("Arming motors")
    # Copter should arm in GUIDED mode
    vehicle.mode = VehicleMode("GUIDED")
```

(continues on next page)

(continued from previous page)

```

vehicle.armed = True

# Confirm vehicle armed before attempting to take off
while not vehicle.armed:
    print(" Waiting for arming...")
    time.sleep(1)

print("Taking off!")
vehicle.simple_takeoff(aTargetAltitude) # Take off to target altitude

# Wait until the vehicle reaches a safe height before processing the goto
# (otherwise the command after Vehicle.simple_takeoff will execute
# immediately).
while True:
    print(" Altitude: ", vehicle.location.global_relative_frame.alt)
    # Break and return from function just below target altitude.
    if vehicle.location.global_relative_frame.alt >= aTargetAltitude * 0.95:
        print("Reached target altitude")
        break
    time.sleep(1)

arm_and_takeoff(10)

print("Set default/target airspeed to 3")
vehicle.airspeed = 3

print("Going towards first point for 30 seconds ...")
point1 = LocationGlobalRelative(-35.361354, 149.165218, 20)
vehicle.simple_goto(point1)

# sleep so we can see the change in map
time.sleep(30)

print("Going towards second point for 30 seconds (groundspeed set to 10 m/s) ...")
point2 = LocationGlobalRelative(-35.363244, 149.168801, 20)
vehicle.simple_goto(point2, groundspeed=10)

# sleep so we can see the change in map
time.sleep(30)

print("Returning to Launch")
vehicle.mode = VehicleMode("RTL")

# Close vehicle object before exiting script
print("Close vehicle object")
vehicle.close()

# Shut down simulator if it was started.
if sitl:
    sitl.stop()

```

5.4 Example: Guided Mode Movement and Commands (Copter)

This example shows how to control Copter movement and send immediate commands in *GUIDED mode*. It demonstrates three methods for explicitly specifying a target position and two commands for controlling movement by setting the vehicle's velocity vectors. It also shows how to send commands to control the yaw (direction that the front of the vehicle is pointing), region of interest, speed and home location, along with some useful functions for converting between frames of reference.

The example is *documented in the source code*. More detailed information about using GUIDED mode can be found in the guide: *Guiding and Controlling Copter*.




Fig. 2: Setting destination using position and changing speed and ROI




Fig. 3: Setting destination using velocity and changing yaw and home location

5.4.1 Running the example

The example can be run as described in *Running the Examples* (which in turn assumes that the vehicle and DroneKit have been set up as described in *Installing DroneKit*).

In summary, after cloning the repository:

1. Navigate to the example folder as shown:

```
cd dronekit-python/examples/guided_set_speed_yaw/
```

2. You can run the example against a simulator (DroneKit-SITL) by specifying the Python script without any arguments. The example will download SITL binaries if needed, start the simulator, and then connect to it:

```
python guided_set_speed_yaw.py
```

On the command prompt you should see (something like):

```
Starting copter simulator (SITL)
SITL already Downloaded.
Connecting to vehicle on: tcp:127.0.0.1:5760
>>> APM:Copter V3.3 (d6053245)
>>> Frame: QUAD
>>> Calibrating barometer
>>> Initialising APM...
>>> barometer calibration complete
>>> GROUND START
Basic pre-arm checks
Waiting for vehicle to initialise...
...
Waiting for vehicle to initialise...
Arming motors
Waiting for arming...
...
Waiting for arming...
>>> ARMING MOTORS
>>> GROUND START
Waiting for arming...
>>> Link timeout, no heartbeat in last 5 seconds
>>> ...link restored.
>>> Initialising APM...
Taking off!
Altitude: 0.0
Altitude: 0.28
...
Altitude: 4.76
Reached target altitude
TRIANGLE path using standard Vehicle.simple_goto()
Set groundspeed to 5m/s.
Position North 80 West 50
Distance to target: 100.792763565
Distance to target: 99.912599325
...
Distance to target: 1.21731863826
Distance to target: 0.846001925791
Reached target
Position North 0 East 100
Distance to target: 122.623210813
...
Distance to target: 4.75876224557
Distance to target: 0.244650555031
Reached target
Position North -80 West 50
```

(continues on next page)

(continued from previous page)

```

Distance to target: 100.792430814
Distance to target: 100.592652053
...
Distance to target: 2.48849019535
Distance to target: 0.73822537077
Reached target
TRIANGLE path using standard SET_POSITION_TARGET_GLOBAL_INT message and with
↳varying speed.
Position South 100 West 130
Set groundspeed to 5m/s.
Distance to target: 188.180927131
Distance to target: 186.578341133
...
Distance to target: 9.87090024758
Distance to target: 1.4668164732
Reached target
Set groundspeed to 15m/s (max).
Position South 0 East 200
Distance to target: 318.826732298
Distance to target: 320.787965033
...
Distance to target: 11.5626483964
Distance to target: 0.335164775811
Reached target
Set airspeed to 10m/s (max).
Position North 100 West 130
Distance to target: 188.182420209
Distance to target: 189.860730713
...
Distance to target: 10.4263414971
Distance to target: 1.29857175712
Reached target
SQUARE path using SET_POSITION_TARGET_LOCAL_NED and position parameters
North 50m, East 0m, 10m altitude for 20 seconds
Point ROI at current location (home position)
North 50m, East 50m, 10m altitude
Point ROI at current location
North 0m, East 50m, 10m altitude
North 0m, East 0m, 10m altitude
SQUARE path using SET_POSITION_TARGET_LOCAL_NED and velocity parameters
Yaw 180 absolute (South)
Velocity South & up
Yaw 270 absolute (West)
Velocity West & down
Yaw 0 absolute (North)
Velocity North
Yaw 90 absolute (East)
Velocity East
DIAMOND path using SET_POSITION_TARGET_GLOBAL_INT and velocity parameters
Yaw 225 absolute
Velocity South, West and Up
Yaw 90 relative (to previous yaw heading)
Velocity North, West and Down
Set new home location to current location
Get new home location
Home Location: LocationGlobal:lat=-35.363243103,lon=149.164337158,alt=593.
↳890014648

```

(continues on next page)

(continued from previous page)

```

Yaw 90 relative (to previous yaw heading)
Velocity North and East
Yaw 90 relative (to previous yaw heading)
Velocity South and East
Setting LAND mode...
Close vehicle object
Completed

```

Tip: It is more interesting to watch the example run on a map than the console. The topic [Connecting an additional Ground Station](#) explains how to set up *Mission Planner* to view a vehicle running on the simulator (SITL).

3. You can run the example against a specific connection (simulated or otherwise) by passing the *connection string* for your vehicle in the `--connect` parameter.

For example, to connect to SITL running on UDP port 14550 on your local computer:

```
python guided_set_speed_yaw.py --connect 127.0.0.1:14550
```

5.4.2 How does it work?

The example is [documented in source code](#). Additional information on the methods is provided either below or [in the guide](#).

The functions for controlling vehicle movement are:

- `Vehicle.simple_goto()` is the standard DroneKit position controller method. It is called from `goto` to fly a triangular path.
- `goto_position_target_global_int()` is a position controller that uses the `SET_POSITION_TARGET_GLOBAL_INT` command.
- `goto_position_target_local_ned()` is a position controller that uses `SET_POSITION_TARGET_LOCAL_NED` command (taking values in NED frame, relative to the home position). This is used to fly a square path. The script is put to sleep for a certain time in order to allow the vehicle to reach the specified position.
- `send_ned_velocity()` is a velocity controller. It uses `SET_POSITION_TARGET_LOCAL_NED` to fly a square path using velocity vectors to define the speed in each direction.
- `send_global_velocity()` is a velocity controller. It uses `SET_POSITION_TARGET_GLOBAL_INT` to fly a diamond-shaped path. The behaviour is essentially the same as for `send_ned_velocity()` because the velocity components in both commands are in the NED frame.
- `goto` is a convenience function for specifying a target location in metres from the current location and reporting the result.

The functions sending immediate commands are:

- `condition_yaw()`
- `set_roi(location)`

The example uses a number functions to convert global locations co-ordinates (decimal degrees) into local coordinates relative to the vehicle (in metres). These are [described in the guide](#).

goto() - convenience function

This is a convenience function for setting position targets in metres North and East of the current location. It reports the distance to the target every two seconds and completes when the target is reached.

This takes a function argument of either `Vehicle.simple_goto()` or `goto_position_target_global_int()`

```
def goto(dNorth, dEast, gotoFunction=vehicle.simple_goto):
    currentLocation=vehicle.location.global_relative_frame
    targetLocation=get_location_metres(currentLocation, dNorth, dEast)
    targetDistance=get_distance_metres(currentLocation, targetLocation)
    gotoFunction(targetLocation)

    while vehicle.mode.name=="GUIDED": #Stop action if we are no longer in guided_
↳mode.
        remainingDistance=get_distance_metres(vehicle.location.global_frame,
↳targetLocation)
        print "Distance to target: ", remainingDistance
        if remainingDistance<=targetDistance*0.01: #Just below target, in case of_
↳undershoot.
            print "Reached target"
            break;
        time.sleep(2)
```

send_ned_velocity()

The function `send_ned_velocity()` generates a `SET_POSITION_TARGET_LOCAL_NED` MAVLink message which is used to directly specify the speed components of the vehicle.

The message is resent at 1Hz for a set duration.

This is documented in [the guide here](#).

send_global_velocity()

The function `send_global_velocity()` generates a `SET_POSITION_TARGET_GLOBAL_INT` MAVLink message which is used to directly specify the speed components of the vehicle in the NED frame.

The function behaviour is otherwise exactly the same as when using `SET_POSITION_TARGET_LOCAL_NED`.

```
def send_global_velocity(velocity_x, velocity_y, velocity_z, duration):
    """
    Move vehicle in direction based on specified velocity vectors.
    """
    msg = vehicle.message_factory.set_position_target_global_int_encode(
        0,          # time_boot_ms (not used)
        0, 0,      # target system, target component
        mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT_INT, # frame
        0b0000111111000111, # type_mask (only speeds enabled)
        0, # lat_int - X Position in WGS84 frame in 1e7 * meters
        0, # lon_int - Y Position in WGS84 frame in 1e7 * meters
        0, # alt - Altitude in meters in AMSL altitude(not WGS84 if absolute or_
↳relative)
        # altitude above terrain if GLOBAL_TERRAIN_ALT_INT
        velocity_x, # X velocity in NED frame in m/s
        velocity_y, # Y velocity in NED frame in m/s
```

(continues on next page)

(continued from previous page)

```

        velocity_z, # Z velocity in NED frame in m/s
        0, 0, 0, # afx, afy, afz acceleration (not supported yet, ignored in GCS_
↪Mavlink)
        0, 0)    # yaw, yaw_rate (not supported yet, ignored in GCS_Mavlink)

# send command to vehicle on 1 Hz cycle
for x in range(0,duration):
    vehicle.send_mavlink(msg)
    time.sleep(1)

```

Note: The message is re-sent every second for the specified duration. From Copter 3.3 the vehicle will stop moving if a new message is not received in approximately 3 seconds. Prior to Copter 3.3 the message only needs to be sent once, and the velocity remains active until the next movement message is received. The above code works for both cases!

goto_position_target_global_int()

The function `goto_position_target_global_int()` generates a `SET_POSITION_TARGET_GLOBAL_INT` MAVLink message which is used to directly specify the target location of the vehicle. When used with `MAV_FRAME_GLOBAL_RELATIVE_ALT_INT` as shown below, this method is effectively the same as `Vehicle.simple_goto`.

```

def goto_position_target_global_int(aLocation):
    """
    Send SET_POSITION_TARGET_GLOBAL_INT command to request the vehicle fly to a_
↪specified location.
    """
    msg = vehicle.message_factory.set_position_target_global_int_encode(
        0,          # time_boot_ms (not used)
        0, 0,      # target system, target component
        mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT_INT, # frame
        0b0000111111111000, # type_mask (only speeds enabled)
        aLocation.lat*1e7, # lat_int - X Position in WGS84 frame in 1e7 * meters
        aLocation.lon*1e7, # lon_int - Y Position in WGS84 frame in 1e7 * meters
        aLocation.alt, # alt - Altitude in meters in AMSL altitude, not WGS84 if_
↪absolute or relative, above terrain if GLOBAL_TERRAIN_ALT_INT
        0, # X velocity in NED frame in m/s
        0, # Y velocity in NED frame in m/s
        0, # Z velocity in NED frame in m/s
        0, 0, 0, # afx, afy, afz acceleration (not supported yet, ignored in GCS_
↪Mavlink)
        0, 0)    # yaw, yaw_rate (not supported yet, ignored in GCS_Mavlink)

    # send command to vehicle
    vehicle.send_mavlink(msg)

```

In the example code this function is called from the `goto()` convenience function.

goto_position_target_local_ned()

The function `goto_position_target_local_ned()` generates a `SET_POSITION_TARGET_LOCAL_NED` MAVLink message which is used to directly specify the target location in the North, East, Down frame. The

`type_mask` enables the position parameters (the last three bits of the mask are zero).

Warning: In the NED frame positive altitudes are entered as negative “Down” values. So if down is “10”, this will be 10 metres below the home altitude.

Note: The [MAVLink protocol documentation](#) lists a number of possible frames of reference. Up until Copter 3.2.1 the actual frame used is always relative to the home location (as indicated by `MAV_FRAME_LOCAL_NED`). Starting from Copter 3.3 you can specify other frames, for example to move the vehicle relative to its current position.

```
def goto_position_target_local_ned(north, east, down):
    """
    Send SET_POSITION_TARGET_LOCAL_NED command to request the vehicle fly to a
    ↪specified
    location in the North, East, Down frame.
    """
    msg = vehicle.message_factory.set_position_target_local_ned_encode(
        0,          # time_boot_ms (not used)
        0, 0,       # target system, target component
        mavutil.mavlink.MAV_FRAME_LOCAL_NED, # frame
        0b000011111111000, # type_mask (only positions enabled)
        north, east, down,
        0, 0, 0,    # x, y, z velocity in m/s (not used)
        0, 0, 0,    # x, y, z acceleration (not supported yet, ignored in GCS_Mavlink)
        0, 0)      # yaw, yaw_rate (not supported yet, ignored in GCS_Mavlink)
    # send command to vehicle
    vehicle.send_mavlink(msg)
```

At time of writing, acceleration and yaw bits are ignored.

5.4.3 Testbed settings

This example has been tested on Windows against SITL running both natively and in a virtual machine (as described in *Installing DroneKit*).

- DroneKit version: 2.0.2
- ArduPilot version: 3.3

5.4.4 Source code

The full source code at documentation build-time is listed below ([current version on Github](#)):

```
#!/usr/bin/env python
# -*- coding: utf-8 -*-

"""
© Copyright 2015-2016, 3D Robotics.
guided_set_speed_yaw.py: (Copter Only)

This example shows how to move/direct Copter and send commands in GUIDED mode using
↪DroneKit Python.
```

(continues on next page)

(continued from previous page)

```

Example documentation: http://python.dronekit.io/examples/guided-set-speed-yaw-demo.html
"""
from __future__ import print_function

from dronekit import connect, VehicleMode, LocationGlobal, LocationGlobalRelative
from pymavlink import mavutil # Needed for command message definitions
import time
import math

#Set up option parsing to get connection string
import argparse
parser = argparse.ArgumentParser(description='Control Copter and send commands in_
↳GUIDED mode ')
parser.add_argument('--connect',
                    help="Vehicle connection target string. If not specified, SITL_
↳automatically started and used.")
args = parser.parse_args()

connection_string = args.connect
sitl = None

#Start SITL if no connection string specified
if not connection_string:
    import dronekit_sitl
    sitl = dronekit_sitl.start_default()
    connection_string = sitl.connection_string()

# Connect to the Vehicle
print('Connecting to vehicle on: %s' % connection_string)
vehicle = connect(connection_string, wait_ready=True)

def arm_and_takeoff(aTargetAltitude):
    """
    Arms vehicle and fly to aTargetAltitude.
    """

    print("Basic pre-arm checks")
    # Don't let the user try to arm until autopilot is ready
    while not vehicle.is_armable:
        print(" Waiting for vehicle to initialise...")
        time.sleep(1)

    print("Arming motors")
    # Copter should arm in GUIDED mode
    vehicle.mode = VehicleMode("GUIDED")
    vehicle.armed = True

    while not vehicle.armed:
        print(" Waiting for arming...")
        time.sleep(1)

```

(continues on next page)

(continued from previous page)

```

print("Taking off!")
vehicle.simple_takeoff(aTargetAltitude) # Take off to target altitude

# Wait until the vehicle reaches a safe height before processing the goto
→ (otherwise the command
# after Vehicle.simple_takeoff will execute immediately).
while True:
    print(" Altitude: ", vehicle.location.global_relative_frame.alt)
    if vehicle.location.global_relative_frame.alt>=aTargetAltitude*0.95: #Trigger
→ just below target alt.
        print("Reached target altitude")
        break
    time.sleep(1)

#Arm and take of to altitude of 5 meters
arm_and_takeoff(5)

"""
Convenience functions for sending immediate/guided mode commands to control the
→ Copter.

The set of commands demonstrated here include:
* MAV_CMD_CONDITION_YAW - set direction of the front of the Copter (latitude,
→ longitude)
* MAV_CMD_DO_SET_ROI - set direction where the camera gimbal is aimed (latitude,
→ longitude, altitude)
* MAV_CMD_DO_CHANGE_SPEED - set target speed in metres/second.

The full set of available commands are listed here:
http://dev.ardupilot.com/wiki/copter-commands-in-guided-mode/
"""

def condition_yaw(heading, relative=False):
    """
    Send MAV_CMD_CONDITION_YAW message to point vehicle at a specified heading (in
    → degrees).

    This method sets an absolute heading by default, but you can set the `relative`
    → parameter
    to `True` to set yaw relative to the current yaw heading.

    By default the yaw of the vehicle will follow the direction of travel. After
    → setting
    the yaw using this function there is no way to return to the default yaw "follow
    → direction
    of travel" behaviour (https://github.com/diydrones/ardupilot/issues/2427)

    For more information see:
    http://copter.ardupilot.com/wiki/common-mavlink-mission-command-messages-mav\_cmd/
    → #mav_cmd_condition_yaw
    """
    if relative:
        is_relative = 1 #yaw relative to direction of travel

```

(continues on next page)

(continued from previous page)

```

else:
    is_relative = 0 #yaw is an absolute angle
    # create the CONDITION_YAW command using command_long_encode()
    msg = vehicle.message_factory.command_long_encode(
        0, 0,      # target system, target component
        mavutil.mavlink.MAV_CMD_CONDITION_YAW, #command
        0, #confirmation
        heading,   # param 1, yaw in degrees
        0,         # param 2, yaw speed deg/s
        1,         # param 3, direction -1 ccw, 1 cw
        is_relative, # param 4, relative offset 1, absolute angle 0
        0, 0, 0)   # param 5 ~ 7 not used
    # send command to vehicle
    vehicle.send_mavlink(msg)

def set_roi(location):
    """
    Send MAV_CMD_DO_SET_ROI message to point camera gimbal at a
    specified region of interest (LocationGlobal).
    The vehicle may also turn to face the ROI.

    For more information see:
    http://copter.ardupilot.com/common-mavlink-mission-command-messages-mav_cmd/#mav_
    ↪cmd_do_set_roi
    """
    # create the MAV_CMD_DO_SET_ROI command
    msg = vehicle.message_factory.command_long_encode(
        0, 0,      # target system, target component
        mavutil.mavlink.MAV_CMD_DO_SET_ROI, #command
        0, #confirmation
        0, 0, 0, 0, #params 1-4
        location.lat,
        location.lon,
        location.alt
    )
    # send command to vehicle
    vehicle.send_mavlink(msg)

"""
Functions to make it easy to convert between the different frames-of-reference. In_
↪particular these
make it easy to navigate in terms of "metres from the current position" when using_
↪commands that take
absolute positions in decimal degrees.

The methods are approximations only, and may be less accurate over longer distances,_
↪and when close
to the Earth's poles.

Specifically, it provides:
* get_location_metres - Get LocationGlobal (decimal degrees) at distance (m) North &_
↪East of a given LocationGlobal.
* get_distance_metres - Get the distance between two LocationGlobal objects in metres
* get_bearing - Get the bearing in degrees to a LocationGlobal

```

(continues on next page)

(continued from previous page)

```

"""
def get_location_metres(original_location, dNorth, dEast):
    """
    Returns a LocationGlobal object containing the latitude/longitude `dNorth` and
    ↪ `dEast` metres from the
        specified `original_location`. The returned LocationGlobal has the same `alt`
    ↪ value
        as `original_location`.

    The function is useful when you want to move the vehicle around specifying
    ↪ locations relative to
        the current vehicle position.

    The algorithm is relatively accurate over small distances (10m within 1km) except
    ↪ close to the poles.

    For more information see:
    http://gis.stackexchange.com/questions/2951/algorithm-for-offsetting-a-latitude-
    ↪ longitude-by-some-amount-of-meters
    """
    earth_radius = 6378137.0 #Radius of "spherical" earth
    #Coordinate offsets in radians
    dLat = dNorth/earth_radius
    dLon = dEast/(earth_radius*math.cos(math.pi*original_location.lat/180))

    #New position in decimal degrees
    newlat = original_location.lat + (dLat * 180/math.pi)
    newlon = original_location.lon + (dLon * 180/math.pi)
    if type(original_location) is LocationGlobal:
        targetlocation=LocationGlobal(newlat, newlon,original_location.alt)
    elif type(original_location) is LocationGlobalRelative:
        targetlocation=LocationGlobalRelative(newlat, newlon,original_location.alt)
    else:
        raise Exception("Invalid Location object passed")

    return targetlocation;

def get_distance_metres(aLocation1, aLocation2):
    """
    Returns the ground distance in metres between two LocationGlobal objects.

    This method is an approximation, and will not be accurate over large distances
    ↪ and close to the
        earth's poles. It comes from the ArduPilot test code:
    https://github.com/diydrones/ardupilot/blob/master/Tools/autotest/common.py
    """
    dlat = aLocation2.lat - aLocation1.lat
    dlong = aLocation2.lon - aLocation1.lon
    return math.sqrt((dlat*dlat) + (dlong*dlong)) * 1.113195e5

def get_bearing(aLocation1, aLocation2):
    """
    Returns the bearing between the two LocationGlobal objects passed as parameters.

```

(continues on next page)

(continued from previous page)

```

    This method is an approximation, and may not be accurate over large distances and
    ↪close to the
    earth's poles. It comes from the ArduPilot test code:
    https://github.com/diydrones/ardupilot/blob/master/Tools/autotest/common.py
    """
    off_x = aLocation2.lon - aLocation1.lon
    off_y = aLocation2.lat - aLocation1.lat
    bearing = 90.00 + math.atan2(-off_y, off_x) * 57.2957795
    if bearing < 0:
        bearing += 360.00
    return bearing;

"""
Functions to move the vehicle to a specified position (as opposed to controlling
↪movement by setting velocity components).

The methods include:
* goto_position_target_global_int - Sets position using SET_POSITION_TARGET_GLOBAL_
    ↪INT command in
        MAV_FRAME_GLOBAL_RELATIVE_ALT_INT frame
* goto_position_target_local_ned - Sets position using SET_POSITION_TARGET_LOCAL_NED_
    ↪command in
        MAV_FRAME_BODY_NED frame
* goto - A convenience function that can use Vehicle.simple_goto (default) or
        goto_position_target_global_int to travel to a specific position in metres
        North and East from the current location.
        This method reports distance to the destination.
"""

def goto_position_target_global_int(aLocation):
    """
    Send SET_POSITION_TARGET_GLOBAL_INT command to request the vehicle fly to a
    ↪specified LocationGlobal.

    For more information see: https://pixhawk.ethz.ch/mavlink/#SET_POSITION_TARGET_
    ↪GLOBAL_INT

    See the above link for information on the type_mask (0=enable, 1=ignore).
    At time of writing, acceleration and yaw bits are ignored.
    """
    msg = vehicle.message_factory.set_position_target_global_int_encode(
        0,          # time_boot_ms (not used)
        0, 0,       # target system, target component
        mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT_INT, # frame
        0b00001111111111000, # type_mask (only speeds enabled)
        aLocation.lat*1e7, # lat_int - X Position in WGS84 frame in 1e7 * meters
        aLocation.lon*1e7, # lon_int - Y Position in WGS84 frame in 1e7 * meters
        aLocation.alt, # alt - Altitude in meters in AMSL altitude, not WGS84 if
    ↪absolute or relative, above terrain if GLOBAL_TERRAIN_ALT_INT
        0, # X velocity in NED frame in m/s
        0, # Y velocity in NED frame in m/s
        0, # Z velocity in NED frame in m/s
        0, 0, 0, # afx, afy, afz acceleration (not supported yet, ignored in GCS_
    ↪Mavlink)
        0, 0)      # yaw, yaw_rate (not supported yet, ignored in GCS_Mavlink)

```

(continues on next page)

(continued from previous page)

```

# send command to vehicle
vehicle.send_mavlink(msg)

def goto_position_target_local_ned(north, east, down):
    """
    Send SET_POSITION_TARGET_LOCAL_NED command to request the vehicle fly to a
    ↪specified
    location in the North, East, Down frame.

    It is important to remember that in this frame, positive altitudes are entered as
    ↪negative
    "Down" values. So if down is "10", this will be 10 metres below the home altitude.

    Starting from AC3.3 the method respects the frame setting. Prior to that the
    ↪frame was
    ignored. For more information see:
    http://dev.ardupilot.com/wiki/copter-commands-in-guided-mode/#set_position_target_
    ↪local_ned

    See the above link for information on the type_mask (0=enable, 1=ignore).
    At time of writing, acceleration and yaw bits are ignored.

    """
    msg = vehicle.message_factory.set_position_target_local_ned_encode(
        0,          # time_boot_ms (not used)
        0, 0,       # target system, target component
        mavutil.mavlink.MAV_FRAME_LOCAL_NED, # frame
        0b0000111111111000, # type_mask (only positions enabled)
        north, east, down, # x, y, z positions (or North, East, Down in the MAV_FRAME_
    ↪BODY_NED frame
        0, 0, 0, # x, y, z velocity in m/s (not used)
        0, 0, 0, # x, y, z acceleration (not supported yet, ignored in GCS_Mavlink)
        0, 0)    # yaw, yaw_rate (not supported yet, ignored in GCS_Mavlink)
    # send command to vehicle
    vehicle.send_mavlink(msg)

def goto(dNorth, dEast, gotoFunction=vehicle.simple_goto):
    """
    Moves the vehicle to a position dNorth metres North and dEast metres East of the
    ↪current position.

    The method takes a function pointer argument with a single `dronekit.lib.
    ↪LocationGlobal` parameter for
    the target position. This allows it to be called with different position-setting
    ↪commands.
    By default it uses the standard method: dronekit.lib.Vehicle.simple_goto().

    The method reports the distance to target every two seconds.
    """

    currentLocation = vehicle.location.global_relative_frame
    targetLocation = get_location_metres(currentLocation, dNorth, dEast)
    targetDistance = get_distance_metres(currentLocation, targetLocation)

```

(continues on next page)

(continued from previous page)

```

gotoFunction(targetLocation)

#print "DEBUG: targetLocation: %s" % targetLocation
#print "DEBUG: targetLocation: %s" % targetDistance

while vehicle.mode.name=="GUIDED": #Stop action if we are no longer in guided_
↳mode.
    #print "DEBUG: mode: %s" % vehicle.mode.name
    remainingDistance=get_distance_metres(vehicle.location.global_relative_frame,
↳targetLocation)
    print("Distance to target: ", remainingDistance)
    if remainingDistance<=targetDistance*0.01: #Just below target, in case of_
↳undershoot.
        print("Reached target")
        break;
    time.sleep(2)

"""
Functions that move the vehicle by specifying the velocity components in each_
↳direction.
The two functions use different MAVLink commands. The main difference is
that depending on the frame used, the NED velocity can be relative to the vehicle
orientation.

The methods include:
* send_ned_velocity - Sets velocity components using SET_POSITION_TARGET_LOCAL_NED_
↳command
* send_global_velocity - Sets velocity components using SET_POSITION_TARGET_GLOBAL_
↳INT command
"""

def send_ned_velocity(velocity_x, velocity_y, velocity_z, duration):
    """
    Move vehicle in direction based on specified velocity vectors and
    for the specified duration.

    This uses the SET_POSITION_TARGET_LOCAL_NED command with a type mask enabling_
↳only
    velocity components
    (http://dev.ardupilot.com/wiki/copter-commands-in-guided-mode/#set\_position\_
↳target\_local\_ned).

    Note that from AC3.3 the message should be re-sent every second (after about 3_
↳seconds
    with no message the velocity will drop back to zero). In AC3.2.1 and earlier the_
↳specified
    velocity persists until it is canceled. The code below should work on either_
↳version
    (sending the message multiple times does not cause problems).

    See the above link for information on the type_mask (0=enable, 1=ignore).
    At time of writing, acceleration and yaw bits are ignored.
    """
    msg = vehicle.message_factory.set_position_target_local_ned_encode(
        0,          # time_boot_ms (not used)

```

(continues on next page)

(continued from previous page)

```

    0, 0,      # target system, target component
    mavutil.mavlink.MAV_FRAME_LOCAL_NED, # frame
    0b0000111111000111, # type_mask (only speeds enabled)
    0, 0, 0, # x, y, z positions (not used)
    velocity_x, velocity_y, velocity_z, # x, y, z velocity in m/s
    0, 0, 0, # x, y, z acceleration (not supported yet, ignored in GCS_Mavlink)
    0, 0)    # yaw, yaw_rate (not supported yet, ignored in GCS_Mavlink)

# send command to vehicle on 1 Hz cycle
for x in range(0,duration):
    vehicle.send_mavlink(msg)
    time.sleep(1)

def send_global_velocity(velocity_x, velocity_y, velocity_z, duration):
    """
    Move vehicle in direction based on specified velocity vectors.

    This uses the SET_POSITION_TARGET_GLOBAL_INT command with type mask enabling only
    velocity components
    (http://dev.ardupilot.com/wiki/copter-commands-in-guided-mode/#set\_position\_
    ↪target\_global\_int).

    Note that from AC3.3 the message should be re-sent every second (after about 3_
    ↪seconds
    with no message the velocity will drop back to zero). In AC3.2.1 and earlier the_
    ↪specified
    velocity persists until it is canceled. The code below should work on either_
    ↪version
    (sending the message multiple times does not cause problems).

    See the above link for information on the type_mask (0=enable, 1=ignore).
    At time of writing, acceleration and yaw bits are ignored.
    """
    msg = vehicle.message_factory.set_position_target_global_int_encode(
        0,      # time_boot_ms (not used)
        0, 0,   # target system, target component
        mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT_INT, # frame
        0b0000111111000111, # type_mask (only speeds enabled)
        0, # lat_int - X Position in WGS84 frame in 1e7 * meters
        0, # lon_int - Y Position in WGS84 frame in 1e7 * meters
        0, # alt - Altitude in meters in AMSL altitude(not WGS84 if absolute or_
    ↪relative)
        # altitude above terrain if GLOBAL_TERRAIN_ALT_INT
        velocity_x, # X velocity in NED frame in m/s
        velocity_y, # Y velocity in NED frame in m/s
        velocity_z, # Z velocity in NED frame in m/s
        0, 0, 0, # afx, afy, afz acceleration (not supported yet, ignored in GCS_
    ↪Mavlink)
        0, 0)    # yaw, yaw_rate (not supported yet, ignored in GCS_Mavlink)

# send command to vehicle on 1 Hz cycle
for x in range(0,duration):
    vehicle.send_mavlink(msg)
    time.sleep(1)

```

(continues on next page)

(continued from previous page)

```

"""
Fly a triangular path using the standard Vehicle.simple_goto() method.

The method is called indirectly via a custom "goto" that allows the target position
↳to be
specified as a distance in metres (North/East) from the current position, and which
↳reports
the distance-to-target.
"""
print("TRIANGLE path using standard Vehicle.simple_goto()")

print("Set groundspeed to 5m/s.")
vehicle.groundspeed=5

print("Position North 80 West 50")
goto(80, -50)

print("Position North 0 East 100")
goto(0, 100)

print("Position North -80 West 50")
goto(-80, -50)


"""
Fly a triangular path using the SET_POSITION_TARGET_GLOBAL_INT command and specifying
a target position (rather than controlling movement using velocity vectors). The
↳command is
called from goto_position_target_global_int() (via `goto`).

The goto_position_target_global_int method is called indirectly from a custom "goto"
↳that allows
the target position to be specified as a distance in metres (North/East) from the
↳current position,
and which reports the distance-to-target.

The code also sets the speed (MAV_CMD_DO_CHANGE_SPEED). In AC3.2.1 Copter will
↳accelerate to this speed
near the centre of its journey and then decelerate as it reaches the target.
In AC3.3 the speed changes immediately.
"""
print("TRIANGLE path using standard SET_POSITION_TARGET_GLOBAL_INT message and with
↳varying speed.")
print("Position South 100 West 130")

print("Set groundspeed to 5m/s.")
vehicle.groundspeed = 5
goto(-100, -130, goto_position_target_global_int)

print("Set groundspeed to 15m/s (max).")
vehicle.groundspeed = 15
print("Position South 0 East 200")
goto(0, 260, goto_position_target_global_int)

```

(continues on next page)

(continued from previous page)

```

print("Set airspeed to 10m/s (max).")
vehicle.airspeed = 10

print("Position North 100 West 130")
goto(100, -130, goto_position_target_global_int)

"""
Fly the vehicle in a 50m square path, using the SET_POSITION_TARGET_LOCAL_NED command
and specifying a target position (rather than controlling movement using velocity_
↳vectors).
The command is called from goto_position_target_local_ned() (via `goto`).

The position is specified in terms of the NED (North East Down) relative to the Home_
↳location.

WARNING: The "D" in NED means "Down". Using a positive D value will drive the vehicle_
↳into the ground!

The code sleeps for a time (DURATION) to give the vehicle time to reach each position_
↳(rather than
sending commands based on proximity).

The code also sets the region of interest (MAV_CMD_DO_SET_ROI) via the `set_roi()``_
↳method. This points the
camera gimbal at the the selected location (in this case it aligns the whole vehicle_
↳to point at the ROI).
"""

print("SQUARE path using SET_POSITION_TARGET_LOCAL_NED and position parameters")
DURATION = 20 #Set duration for each segment.

print("North 50m, East 0m, 10m altitude for %s seconds" % DURATION)
goto_position_target_local_ned(50,0,-10)
print("Point ROI at current location (home position)")
# NOTE that this has to be called after the goto command as first "move" command of a_
↳particular type
# "resets" ROI/YAW commands
set_roi(vehicle.location.global_relative_frame)
time.sleep(DURATION)

print("North 50m, East 50m, 10m altitude")
goto_position_target_local_ned(50,50,-10)
time.sleep(DURATION)

print("Point ROI at current location")
set_roi(vehicle.location.global_relative_frame)

print("North 0m, East 50m, 10m altitude")
goto_position_target_local_ned(0,50,-10)
time.sleep(DURATION)

print("North 0m, East 0m, 10m altitude")
goto_position_target_local_ned(0,0,-10)
time.sleep(DURATION)

```

(continues on next page)

(continued from previous page)

```

"""
Fly the vehicle in a SQUARE path using velocity vectors (the underlying code calls
↳the
SET_POSITION_TARGET_LOCAL_NED command with the velocity parameters enabled).

The thread sleeps for a time (DURATION) which defines the distance that will be
↳travelled.

The code also sets the yaw (MAV_CMD_CONDITION_YAW) using the `set_yaw()` method in
↳each segment
so that the front of the vehicle points in the direction of travel
"""

#Set up velocity vector to map to each direction.
# vx > 0 => fly North
# vx < 0 => fly South
NORTH = 2
SOUTH = -2

# Note for vy:
# vy > 0 => fly East
# vy < 0 => fly West
EAST = 2
WEST = -2

# Note for vz:
# vz < 0 => ascend
# vz > 0 => descend
UP = -0.5
DOWN = 0.5

# Square path using velocity
print("SQUARE path using SET_POSITION_TARGET_LOCAL_NED and velocity parameters")

print("Yaw 180 absolute (South)")
condition_yaw(180)

print("Velocity South & up")
send_ned_velocity(SOUTH, 0, UP, DURATION)
send_ned_velocity(0, 0, 0, 1)

print("Yaw 270 absolute (West)")
condition_yaw(270)

print("Velocity West & down")
send_ned_velocity(0, WEST, DOWN, DURATION)
send_ned_velocity(0, 0, 0, 1)

print("Yaw 0 absolute (North)")
condition_yaw(0)

```

(continues on next page)

(continued from previous page)

```

print("Velocity North")
send_ned_velocity(NORTH,0,0,DURATION)
send_ned_velocity(0,0,0,1)

print("Yaw 90 absolute (East)")
condition_yaw(90)

print("Velocity East")
send_ned_velocity(0,EAST,0,DURATION)
send_ned_velocity(0,0,0,1)

"""
Fly the vehicle in a DIAMOND path using velocity vectors (the underlying code calls
↳the
SET_POSITION_TARGET_GLOBAL_INT command with the velocity parameters enabled).

The thread sleeps for a time (DURATION) which defines the distance that will be
↳travelled.

The code sets the yaw (MAV_CMD_CONDITION_YAW) using the `set_yaw()` method using
↳relative headings
so that the front of the vehicle points in the direction of travel.

At the end of the second segment the code sets a new home location to the current
↳point.
"""

print("DIAMOND path using SET_POSITION_TARGET_GLOBAL_INT and velocity parameters")
# vx, vy are parallel to North and East (independent of the vehicle orientation)

print("Yaw 225 absolute")
condition_yaw(225)

print("Velocity South, West and Up")
send_global_velocity(SOUTH,WEST,UP,DURATION)
send_global_velocity(0,0,0,1)

print("Yaw 90 relative (to previous yaw heading)")
condition_yaw(90,relative=True)

print("Velocity North, West and Down")
send_global_velocity(NORTH,WEST,DOWN,DURATION)
send_global_velocity(0,0,0,1)

print("Set new home location to current location")
vehicle.home_location=vehicle.location.global_frame
print("Get new home location")
#This reloads the home location in DroneKit and GCSS
cmds = vehicle.commands
cmds.download()
cmds.wait_ready()
print(" Home Location: %s" % vehicle.home_location)

```

(continues on next page)

(continued from previous page)

```

print("Yaw 90 relative (to previous yaw heading)")
condition_yaw(90,relative=True)

print("Velocity North and East")
send_global_velocity(NORTH,EAST,0,DURATION)
send_global_velocity(0,0,0,1)

print("Yaw 90 relative (to previous yaw heading)")
condition_yaw(90,relative=True)

print("Velocity South and East")
send_global_velocity(SOUTH,EAST,0,DURATION)
send_global_velocity(0,0,0,1)

"""
The example is completing. LAND at current location.
"""

print("Setting LAND mode...")
vehicle.mode = VehicleMode("LAND")

#Close vehicle object before exiting script
print("Close vehicle object")
vehicle.close()

# Shut down simulator if it was started.
if sitl is not None:
    sitl.stop()

print("Completed")

```

5.5 Example: Basic Mission

This example demonstrates the basic mission operations provided by DroneKit-Python, including: downloading missions from the vehicle, clearing missions, creating mission commands and uploading them to the vehicle, monitoring the current active command, and changing the active command.

The guide topic *Missions (AUTO Mode)* provides more detailed explanation of how the API should be used.

5.5.1 Running the example

The example can be run as described in *Running the Examples* (which in turn assumes that the vehicle and DroneKit have been set up as described in *Installing DroneKit*).

In summary, after cloning the repository:

1. Navigate to the example folder as shown:

```
cd dronekit-python/examples/mission_basic/
```




Fig. 4: Basic Mission Example: Flight path

2. You can run the example against a simulator (DroneKit-SITL) by specifying the Python script without any arguments. The example will download SITL binaries (if needed), start the simulator, and then connect to it:

```
python mission_basic.py
```

On the command prompt you should see (something like):

```
Starting copter simulator (SITL)
SITL already Downloaded.
Connecting to vehicle on: tcp:127.0.0.1:5760
>>> APM:Copter V3.3 (d6053245)
>>> Frame: QUAD
>>> Calibrating barometer
>>> Initialising APM...
>>> barometer calibration complete
>>> GROUND START
>>> Mission Planner 1.3.35
Create a new mission (for current location)
  Clear any existing commands
  Define/add new commands.
  Upload new commands to vehicle
Basic pre-arm checks
  Waiting for vehicle to initialise...
>>> flight plan received
  Waiting for vehicle to initialise...
  ...
  Waiting for vehicle to initialise...
Arming motors
  Waiting for arming...
  ...
  Waiting for arming...
>>> ARMING MOTORS
>>> GROUND START
  Waiting for arming...
```

(continues on next page)

(continued from previous page)

```
>>> Initialising APM...
Taking off!
Altitude: 0.0
Altitude: 0.11
...
Altitude: 8.9
Altitude: 9.52
Reached target altitude
Starting mission
Distance to waypoint (0): None
Distance to waypoint (1): 78.8000191616
Distance to waypoint (1): 78.3723704927
...
Distance to waypoint (1): 20.7131390269
Distance to waypoint (1): 15.4196151863
>>> Reached Command #1
Distance to waypoint (2): 115.043560356
Distance to waypoint (2): 117.463458185
...
Distance to waypoint (2): 25.7122243168
Distance to waypoint (2): 16.8624794106
>>> Reached Command #2
Distance to waypoint (3): 100.45231832
Skipping to Waypoint 5 when reach waypoint 3
Distance to waypoint (5): 154.645144788
Exit 'standard' mission when start heading to final waypoint (5)
Return to launch
Close vehicle object
```

Tip: It is more interesting to watch the example run on a map than the console. The topic [Connecting an additional Ground Station](#) explains how to set up *Mission Planner* to view a vehicle running on the simulator (SITL).

3. You can run the example against a specific connection (simulated or otherwise) by passing the *connection string* for your vehicle in the `--connect` parameter.

For example, to connect to SITL running on UDP port 14550 on your local computer:

```
python mission_basic.py --connect 127.0.0.1:14550
```

5.5.2 How does it work?

The *source code* is relatively self-documenting, and most of its main operations are explained in the guide topic *Missions (AUTO Mode)*.

In overview, the example calls `adds_square_mission(vehicle.location.global_frame, 50)` to first clear the current mission and then define a new mission with a takeoff command and four waypoints arranged in a square around the central position (two waypoints are added in the last position - we use *next* to determine when we've reached the final point). The clear command and new mission items are then uploaded to the vehicle.

After taking off (in guided mode using the `takeoff()` function) the example starts the mission by setting the mode to AUTO:

```
print "Starting mission"
# Set mode to AUTO to start mission
vehicle.mode = VehicleMode("AUTO")
```

The progress of the mission is monitored in a loop. The convenience function `distance_to_current_waypoint()` gets the distance to the next waypoint and `Vehicle.commands.next` gets the value of the next command.

We also show how to jump to a specified command using `Vehicle.commands.next` (note how we skip the third command below):

```
while True:
    nextwaypoint=vehicle.commands.next
    print 'Distance to waypoint (%s): %s' % (nextwaypoint, distance_to_current_
↪waypoint())

    if nextwaypoint==3: #Skip to next waypoint
        print 'Skipping to Waypoint 5 when reach waypoint 3'
        vehicle.commands.next=5
        vehicle.commands.upload()
    if nextwaypoint==5: #Dummy waypoint - as soon as we reach waypoint 4 this is true,
↪and we exit.
        print "Exit 'standard' mission when start heading to final waypoint (5)"
        break;
    time.sleep(1)
```

When the vehicle starts the 5th command (a dummy waypoint) the loop breaks and the mode is set to RTL (return to launch).

5.5.3 Known issues

This example has no known issues.

5.5.4 Source code

The full source code at documentation build-time is listed below (current version on Github):

```
#!/usr/bin/env python
# -*- coding: utf-8 -*-

"""
© Copyright 2015-2016, 3D Robotics.
mission_basic.py: Example demonstrating basic mission operations including creating,
↪clearing and monitoring missions.

Full documentation is provided at http://python.dronekit.io/examples/mission_basic.
↪html
"""
from __future__ import print_function

from dronekit import connect, VehicleMode, LocationGlobalRelative, LocationGlobal,
↪Command
import time
import math
from pymavlink import mavutil
```

(continues on next page)

(continued from previous page)

```

#Set up option parsing to get connection string
import argparse
parser = argparse.ArgumentParser(description='Demonstrates basic mission operations.')
parser.add_argument('--connect',
                    help="vehicle connection target string. If not specified, SITL_
↳ automatically started and used.")
args = parser.parse_args()

connection_string = args.connect
sitl = None

#Start SITL if no connection string specified
if not connection_string:
    import dronekit_sitl
    sitl = dronekit_sitl.start_default()
    connection_string = sitl.connection_string()

# Connect to the Vehicle
print('Connecting to vehicle on: %s' % connection_string)
vehicle = connect(connection_string, wait_ready=True)

def get_location_metres(original_location, dNorth, dEast):
    """
    Returns a LocationGlobal object containing the latitude/longitude `dNorth` and_
    ↳ `dEast` metres from the
    specified `original_location`. The returned Location has the same `alt` value
    as `original_location`.

    The function is useful when you want to move the vehicle around specifying_
    ↳ locations relative to
    the current vehicle position.
    The algorithm is relatively accurate over small distances (10m within 1km) except_
    ↳ close to the poles.
    For more information see:
    http://gis.stackexchange.com/questions/2951/algorithm-for-offsetting-a-latitude-
    ↳ longitude-by-some-amount-of-meters
    """
    earth_radius=6378137.0 #Radius of "spherical" earth
    #Coordinate offsets in radians
    dLat = dNorth/earth_radius
    dLon = dEast/(earth_radius*math.cos(math.pi*original_location.lat/180))

    #New position in decimal degrees
    newlat = original_location.lat + (dLat * 180/math.pi)
    newlon = original_location.lon + (dLon * 180/math.pi)
    return LocationGlobal(newlat, newlon,original_location.alt)

def get_distance_metres(aLocation1, aLocation2):
    """
    Returns the ground distance in metres between two LocationGlobal objects.

    This method is an approximation, and will not be accurate over large distances_
    ↳ and close to the

```

(continues on next page)

(continued from previous page)

```

earth's poles. It comes from the ArduPilot test code:
https://github.com/diydrones/ardupilot/blob/master/Tools/autotest/common.py
"""
dlat = aLocation2.lat - aLocation1.lat
dlong = aLocation2.lon - aLocation1.lon
return math.sqrt((dlat*dlat) + (dlong*dlong)) * 1.113195e5

def distance_to_current_waypoint():
    """
    Gets distance in metres to the current waypoint.
    It returns None for the first waypoint (Home location).
    """
    nextwaypoint = vehicle.commands.next
    if nextwaypoint==0:
        return None
    missionitem=vehicle.commands[nextwaypoint-1] #commands are zero indexed
    lat = missionitem.x
    lon = missionitem.y
    alt = missionitem.z
    targetWaypointLocation = LocationGlobalRelative(lat,lon,alt)
    distancetopoint = get_distance_metres(vehicle.location.global_frame,
    ↪targetWaypointLocation)
    return distancetopoint

def download_mission():
    """
    Download the current mission from the vehicle.
    """
    cmds = vehicle.commands
    cmds.download()
    cmds.wait_ready() # wait until download is complete.

def adds_square_mission(aLocation, aSize):
    """
    Adds a takeoff command and four waypoint commands to the current mission.
    The waypoints are positioned to form a square of side length 2*aSize around the
    ↪specified LocationGlobal (aLocation).

    The function assumes vehicle.commands matches the vehicle mission state
    (you must have called download at least once in the session and after clearing
    ↪the mission)
    """

    cmds = vehicle.commands

    print(" Clear any existing commands")
    cmds.clear()

    print(" Define/add new commands.")
    # Add new commands. The meaning/order of the parameters is documented in the
    ↪Command class.

```

(continues on next page)

(continued from previous page)

```

#Add MAV_CMD_NAV_TAKEOFF command. This is ignored if the vehicle is already in_
↳the air.
cmds.add(Command( 0, 0, 0, mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT, mavutil.
↳mavlink.MAV_CMD_NAV_TAKEOFF, 0, 0, 0, 0, 0, 0, 0, 0, 10))

#Define the four MAV_CMD_NAV_WAYPOINT locations and add the commands
point1 = get_location_metres(aLocation, aSize, -aSize)
point2 = get_location_metres(aLocation, aSize, aSize)
point3 = get_location_metres(aLocation, -aSize, aSize)
point4 = get_location_metres(aLocation, -aSize, -aSize)
cmds.add(Command( 0, 0, 0, mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT, mavutil.
↳mavlink.MAV_CMD_NAV_WAYPOINT, 0, 0, 0, 0, 0, 0, point1.lat, point1.lon, 11))
cmds.add(Command( 0, 0, 0, mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT, mavutil.
↳mavlink.MAV_CMD_NAV_WAYPOINT, 0, 0, 0, 0, 0, 0, point2.lat, point2.lon, 12))
cmds.add(Command( 0, 0, 0, mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT, mavutil.
↳mavlink.MAV_CMD_NAV_WAYPOINT, 0, 0, 0, 0, 0, 0, point3.lat, point3.lon, 13))
cmds.add(Command( 0, 0, 0, mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT, mavutil.
↳mavlink.MAV_CMD_NAV_WAYPOINT, 0, 0, 0, 0, 0, 0, point4.lat, point4.lon, 14))
#add dummy waypoint "5" at point 4 (lets us know when have reached destination)
cmds.add(Command( 0, 0, 0, mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT, mavutil.
↳mavlink.MAV_CMD_NAV_WAYPOINT, 0, 0, 0, 0, 0, 0, point4.lat, point4.lon, 14))

print(" Upload new commands to vehicle")
cmds.upload()

def arm_and_takeoff(aTargetAltitude):
    """
    Arms vehicle and fly to aTargetAltitude.
    """

    print("Basic pre-arm checks")
    # Don't let the user try to arm until autopilot is ready
    while not vehicle.is_armable:
        print(" Waiting for vehicle to initialise...")
        time.sleep(1)

    print("Arming motors")
    # Copter should arm in GUIDED mode
    vehicle.mode = VehicleMode("GUIDED")
    vehicle.armed = True

    while not vehicle.armed:
        print(" Waiting for arming...")
        time.sleep(1)

    print("Taking off!")
    vehicle.simple_takeoff(aTargetAltitude) # Take off to target altitude

    # Wait until the vehicle reaches a safe height before processing the goto_
    ↳(otherwise the command
    # after Vehicle.simple_takeoff will execute immediately).
    while True:
        print(" Altitude: ", vehicle.location.global_relative_frame.alt)
        if vehicle.location.global_relative_frame.alt>=aTargetAltitude*0.95: #Trigger_
        ↳just below target alt.

```

(continues on next page)

(continued from previous page)

```

        print("Reached target altitude")
        break
    time.sleep(1)

print('Create a new mission (for current location)')
adds_square_mission(vehicle.location.global_frame,50)

# From Copter 3.3 you will be able to take off using a mission item. Plane must take_
↪off using a mission item (currently).
arm_and_takeoff(10)

print("Starting mission")
# Reset mission set to first (0) waypoint
vehicle.commands.next=0

# Set mode to AUTO to start mission
vehicle.mode = VehicleMode("AUTO")

# Monitor mission.
# Demonstrates getting and setting the command number
# Uses distance_to_current_waypoint(), a convenience function for finding the
# distance to the next waypoint.

while True:
    nextwaypoint=vehicle.commands.next
    print('Distance to waypoint (%s): %s' % (nextwaypoint, distance_to_current_
    ↪waypoint()))

    if nextwaypoint==3: #Skip to next waypoint
        print('Skipping to Waypoint 5 when reach waypoint 3')
        vehicle.commands.next = 5
    if nextwaypoint==5: #Dummy waypoint - as soon as we reach waypoint 4 this is true_
    ↪and we exit.
        print("Exit 'standard' mission when start heading to final waypoint (5)")
        break;
    time.sleep(1)

print('Return to launch')
vehicle.mode = VehicleMode("RTL")

#Close vehicle object before exiting script
print("Close vehicle object")
vehicle.close()

# Shut down simulator if it was started.
if sitl is not None:
    sitl.stop()

```

5.6 Example: Mission Import/Export

This example shows how to import and export files in the Waypoint file format.

The commands are first imported from a file into a list and then uploaded to the vehicle. Then the current mission is downloaded from the vehicle and put into a list, which is then saved into (another file). Finally, we print out both the original and new files for comparison

The example does not show how missions can be modified, but once the mission is in a list, changing the order and content of commands is straightforward.

The guide topic *Missions (AUTO Mode)* provides information about missions and AUTO mode.

5.6.1 Running the example

The example can be run as described in *Running the Examples* (which in turn assumes that the vehicle and DroneKit have been set up as described in *Installing DroneKit*).

In summary, after cloning the repository:

1. Navigate to the example folder as shown:

```
cd dronekit-python/examples/mission_import_export/
```

2. You can run the example against a simulator (DroneKit-SITL) by specifying the Python script without any arguments. The example will download SITL binaries (if needed), start the simulator, and then connect to it:

```
python mission_import_export.py
```

On the command prompt you should see (something like):

```
Starting copter simulator (SITL)
SITL already Downloaded.
Connecting to vehicle on: tcp:127.0.0.1:5760
>>> APM:Copter V3.3 (d6053245)
>>> Frame: QUAD
>>> Calibrating barometer
>>> Initialising APM...
>>> barometer calibration complete
>>> GROUND START
Waiting for vehicle to initialise...
Waiting for vehicle to initialise...
Waiting for vehicle to initialise...
Waiting for vehicle to initialise...
Waiting for vehicle to initialise...
Reading mission from file: mpmission.txt
Upload mission from a file: mpmission.txt
Clear mission
Upload mission
Save mission from Vehicle to file: exportedmission.txt
Download mission from vehicle
>>> flight plan received
Write mission to file
Close vehicle object
Show original and uploaded/downloaded files:

Mission file: mpmission.txt
QGC WPL 110
0 1 0 16 0 0 0 0 -35.363262 149.165237 584.000000 1
1 0 0 22 0.000000 0.000000 0.000000 0.000000 -35.361988 149.
↪163753 00.000000 1
2 0 0 16 0.000000 0.000000 0.000000 0.000000 -35.361992 149.
↪163593 00.000000 1
```

(continues on next page)

(continued from previous page)

```

3 0 0 16 0.000000 0.000000 0.000000 0.000000 -35.363812 149.
↪163609 00.000000 1
4 0 0 16 0.000000 0.000000 0.000000 0.000000 -35.363768 149.
↪166055 00.000000 1
5 0 0 16 0.000000 0.000000 0.000000 0.000000 -35.361835 149.
↪166012 00.000000 1
6 0 0 16 0.000000 0.000000 0.000000 0.000000 -35.362150 149.
↪165046 00.000000 1

Mission file: exportedmission.txt
QGC WPL 110
0 1 0 16 0 0 0 0 -35.3632621765 149.165237427 ↪
↪583.989990234 1
1 0 0 22 0.0 0.0 0.0 0.0 -35.3619880676 149.163757324 ↪
↪100.0 1
2 0 0 16 0.0 0.0 0.0 0.0 -35.3619918823 149.163589478 ↪
↪100.0 1
3 0 0 16 0.0 0.0 0.0 0.0 -35.3638114929 149.163604736 ↪
↪100.0 1
4 0 0 16 0.0 0.0 0.0 0.0 -35.3637695312 149.166061401 ↪
↪100.0 1
5 0 0 16 0.0 0.0 0.0 0.0 -35.3618354797 149.166015625 ↪
↪100.0 1
6 0 0 16 0.0 0.0 0.0 0.0 -35.3621482849 149.165039062 ↪
↪100.0 1

```

Note: The position values uploaded and then downloaded above do not match exactly. This rounding error can be ignored because the difference is much smaller than the precision provided by GPS.

The error occurs because all the params are encoded as 32-bit floats rather than 64-bit doubles (Python's native datatype).

3. You can run the example against a specific connection (simulated or otherwise) by passing the *connection string* for your vehicle in the `--connect` parameter.

For example, to connect to SITL running on UDP port 14550 on your local computer:

```
python mission_import_export.py --connect 127.0.0.1:14550
```

5.6.2 How does it work?

The *source code* is largely self-documenting.

More information about the functions can be found in the guide at *Load a mission from a file* and *Save a mission to a file*.

5.6.3 Known issues

There are no known issues with this example.

5.6.4 Source code

The full source code at documentation build-time is listed below (current version on [github](#)):

```
#!/usr/bin/env python
# -*- coding: utf-8 -*-

"""
© Copyright 2015-2016, 3D Robotics.
mission_import_export.py:

This example demonstrates how to import and export files in the Waypoint file format
(http://qgroundcontrol.org/mavlink/waypoint\_protocol#waypoint\_file\_format). The
↳ commands are imported
into a list, and can be modified before saving and/or uploading.

Documentation is provided at http://python.dronekit.io/examples/mission\_import\_export.html.
↳ html
"""
from __future__ import print_function

from dronekit import connect, Command
import time

#Set up option parsing to get connection string
import argparse
parser = argparse.ArgumentParser(description='Demonstrates mission import/export from
↳ a file.')
parser.add_argument('--connect',
                    help="Vehicle connection target string. If not specified, SITL
↳ automatically started and used.")
args = parser.parse_args()

connection_string = args.connect
sitl = None

#Start SITL if no connection string specified
if not connection_string:
    import dronekit_sitl
    sitl = dronekit_sitl.start_default()
    connection_string = sitl.connection_string()

# Connect to the Vehicle
print('Connecting to vehicle on: %s' % connection_string)
vehicle = connect(connection_string, wait_ready=True)

# Check that vehicle is armable.
# This ensures home_location is set (needed when saving WP file)

while not vehicle.is_armable:
    print(" Waiting for vehicle to initialise...")
    time.sleep(1)
```

(continues on next page)

(continued from previous page)

```

def readmission(aFileName):
    """
    Load a mission from a file into a list. The mission definition is in the Waypoint_
    ↪file
    format (http://qgroundcontrol.org/mavlink/waypoint\_protocol#waypoint\_file\_format).

    This function is used by upload_mission().
    """
    print("\nReading mission from file: %s" % aFileName)
    cmds = vehicle.commands
    missionlist=[]
    with open(aFileName) as f:
        for i, line in enumerate(f):
            if i==0:
                if not line.startswith('QGC WPL 110'):
                    raise Exception('File is not supported WP version')
            else:
                linearray=line.split('\t')
                ln_index=int(linearray[0])
                ln_currentwp=int(linearray[1])
                ln_frame=int(linearray[2])
                ln_command=int(linearray[3])
                ln_param1=float(linearray[4])
                ln_param2=float(linearray[5])
                ln_param3=float(linearray[6])
                ln_param4=float(linearray[7])
                ln_param5=float(linearray[8])
                ln_param6=float(linearray[9])
                ln_param7=float(linearray[10])
                ln_autocontinue=int(linearray[11].strip())
                cmd = Command( 0, 0, 0, ln_frame, ln_command, ln_currentwp, ln_
                ↪autocontinue, ln_param1, ln_param2, ln_param3, ln_param4, ln_param5, ln_param6, ln_
                ↪param7)
                missionlist.append(cmd)
    return missionlist

def upload_mission(aFileName):
    """
    Upload a mission from a file.
    """
    #Read mission from file
    missionlist = readmission(aFileName)

    print("\nUpload mission from a file: %s" % aFileName)
    #Clear existing mission from vehicle
    print(' Clear mission')
    cmds = vehicle.commands
    cmds.clear()
    #Add new mission to vehicle
    for command in missionlist:
        cmds.add(command)
    print(' Upload mission')
    vehicle.commands.upload()

def download_mission():

```

(continues on next page)

(continued from previous page)

```

"""
Downloads the current mission and returns it in a list.
It is used in save_mission() to get the file information to save.
"""

print(" Download mission from vehicle")
missionlist=[]
cmds = vehicle.commands
cmds.download()
cmds.wait_ready()
for cmd in cmds:
    missionlist.append(cmd)
return missionlist

def save_mission(aFileName):
    """
    Save a mission in the Waypoint file format
    (http://qgroundcontrol.org/mavlink/waypoint_protocol#waypoint_file_format).
    """
    print("\nSave mission from Vehicle to file: %s" % aFileName)
    #Download mission from vehicle
    missionlist = download_mission()
    #Add file-format information
    output='QGC WPL 110\n'
    #Add home location as 0th waypoint
    home = vehicle.home_location
    output+="%s\t%s\t%s\t%s\t%s\t%s\t%s\t%s\t%s\t%s\t%s\t%s\n" % (0,1,0,16,0,0,0,0,
↪home.lat,home.lon,home.alt,1)
    #Add commands
    for cmd in missionlist:
        commandline="%s\t%s\t%s\t%s\t%s\t%s\t%s\t%s\t%s\t%s\t%s\t%s\n" % (cmd.seq,cmd.
↪current,cmd.frame,cmd.command,cmd.param1,cmd.param2,cmd.param3,cmd.param4,cmd.x,cmd.
↪y,cmd.z,cmd.autocontinue)
        output+=commandline
    with open(aFileName, 'w') as file_:
        print(" Write mission to file")
        file_.write(output)

def printfile(aFileName):
    """
    Print a mission file to demonstrate "round trip"
    """
    print("\nMission file: %s" % aFileName)
    with open(aFileName) as f:
        for line in f:
            print(' %s' % line.strip())

import_mission_filename = 'mpmission.txt'
export_mission_filename = 'exportedmission.txt'

#Upload mission from file
upload_mission(import_mission_filename)

#Download mission we just uploaded and save to a file
save_mission(export_mission_filename)

```

(continues on next page)

(continued from previous page)

```
#Close vehicle object before exiting script
print("Close vehicle object")
vehicle.close()

# Shut down simulator if it was started.
if sitl is not None:
    sitl.stop()

print("\nShow original and uploaded/downloaded files:")
#Print original file (for demo purposes only)
printfile(import_mission_filename)
#Print exported file (for demo purposes only)
printfile(export_mission_filename)
```

5.7 Example: Create Attribute in App

This example shows how you can subclass *Vehicle* in order to support new attributes for MAVLink messages within your DroneKit-Python script. The new class is defined in a separate file (making re-use easy) and is very similar to the code used to implement the in-built attributes. The new attributes are used *in the same way* as the built-in *Vehicle* attributes.

The new class uses the *Vehicle.on_message()* decorator to set a function that is called to process a specific message, copy its values into an attribute, and notify observers. An observer is then set on the new attribute using *Vehicle.add_attribute_listener()*.

Additional information is provided in the guide topic *MAVLink Messages*.

Tip: This approach is useful when you urgently need to access messages that are not yet supported as *Vehicle* attributes.

Please *contribute your code to the API* so that it is available to (and can be tested by) the whole DroneKit-Python community.

5.7.1 Running the example

The example can be run as described in *Running the Examples* (which in turn assumes that the vehicle and DroneKit have been set up as described in *Installing DroneKit*).

In summary, after cloning the repository:

1. Navigate to the example folder as shown:

```
cd dronekit-python\examples\create_attribute\
```

2. You can run the example against a simulator (DroneKit-SITL) by specifying the Python script without any arguments. The example will download SITL binaries (if needed), start the simulator, and then connect to it:

```
python create_attribute.py
```

On the command prompt you should see (something like):

```

Starting copter simulator (SITL)
SITL already Downloaded.
Connecting to vehicle on: tcp:127.0.0.1:5760
>>> APM:Copter V3.3 (d6053245)
>>> Frame: QUAD
>>> Calibrating barometer
>>> Initialising APM...
>>> barometer calibration complete
>>> GROUND START
Display RAW_IMU messages for 5 seconds and then exit.
RAW_IMU: time_boot_us=15340000, xacc=0, yacc=0, zacc=-1000, xgyro=0, ygyro=1, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=15580000, xacc=0, yacc=0, zacc=-1000, xgyro=0, ygyro=0, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=15820000, xacc=0, yacc=0, zacc=-999, xgyro=0, ygyro=1, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=16060000, xacc=0, yacc=1, zacc=-999, xgyro=0, ygyro=0, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=16300000, xacc=0, yacc=0, zacc=-999, xgyro=0, ygyro=0, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=16540000, xacc=0, yacc=0, zacc=-1000, xgyro=0, ygyro=1, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=16780000, xacc=0, yacc=0, zacc=-999, xgyro=0, ygyro=0, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=17020000, xacc=1, yacc=0, zacc=-999, xgyro=0, ygyro=0, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=17260000, xacc=0, yacc=0, zacc=-999, xgyro=0, ygyro=0, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=17500000, xacc=0, yacc=0, zacc=-1000, xgyro=1, ygyro=0, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=17740000, xacc=0, yacc=0, zacc=-999, xgyro=0, ygyro=0, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=17980000, xacc=0, yacc=0, zacc=-999, xgyro=0, ygyro=0, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=18220000, xacc=0, yacc=0, zacc=-1000, xgyro=0, ygyro=0, zgyro=1,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=18460000, xacc=0, yacc=0, zacc=-1000, xgyro=0, ygyro=0, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=18700000, xacc=0, yacc=0, zacc=-999, xgyro=0, ygyro=0, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=18940000, xacc=1, yacc=0, zacc=-1000, xgyro=0, ygyro=1, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=19180000, xacc=1, yacc=0, zacc=-1000, xgyro=0, ygyro=0, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=19420000, xacc=0, yacc=0, zacc=-999, xgyro=0, ygyro=0, zgyro=0,
↪ xmag=161, ymag=19, zmag=-365
RAW_IMU: time_boot_us=19660000, xacc=0, yacc=0, zacc=-1000, xgyro=0, ygyro=0, zgyro=0,
↪ xmag=154, ymag=52, zmag=-365
RAW_IMU: time_boot_us=19900000, xacc=0, yacc=0, zacc=-999, xgyro=0, ygyro=0, zgyro=0,
↪ xmag=154, ymag=52, zmag=-365
RAW_IMU: time_boot_us=20140000, xacc=0, yacc=0, zacc=-1000, xgyro=0, ygyro=0, zgyro=0,
↪ xmag=154, ymag=52, zmag=-365
Close vehicle object

```

3. You can run the example against a specific connection (simulated or otherwise) by passing the *connection string* for your vehicle in the `--connect` parameter.

For example, to connect to SITL running on UDP port 14550 on your local computer:

```
python create_attribute.py --connect 127.0.0.1:14550
```

5.7.2 How does it work?

Subclassing Vehicle

The example file **my_vehicle.py** defines a class for the new attribute (RawIMU) and a new vehicle subclass (MyVehicle).

Note: The example uses the same documentation markup used by the native code, which can be generated into a document set using Sphinx/autodoc.

RawIMU has members for each of the values in the message (in this case [RAW_IMU](#)). It provides an initialiser that sets all the values to None and a string representation for printing the object.

```
class RawIMU(object):
    """
    The RAW IMU readings for the usual 9DOF sensor setup.
    This contains the true raw values without any scaling to allow data capture and
    ↪ system debugging.

    The message definition is here: http://mavlink.org/messages/common#RAW\_IMU

    :param time_boot_us: Timestamp (microseconds since system boot). #Note, not
    ↪ milliseconds as per spec
    :param xacc: X acceleration (mg)
    :param yacc: Y acceleration (mg)
    :param zacc: Z acceleration (mg)
    :param xgyro: Angular speed around X axis (millirad /sec)
    :param ygyro: Angular speed around Y axis (millirad /sec)
    :param zgyro: Angular speed around Z axis (millirad /sec)
    :param xmag: X Magnetic field (milli tesla)
    :param ymag: Y Magnetic field (milli tesla)
    :param zmag: Z Magnetic field (milli tesla)
    """

    def __init__(self, time_boot_us=None, xacc=None, yacc=None, zacc=None, xgyro=None,
    ↪ ygyro=None, zgyro=None, xmag=None, ymag=None, zmag=None):
        """
        RawIMU object constructor.
        """
        self.time_boot_us = time_boot_us
        self.xacc = xacc
        self.yacc = yacc
        self.zacc = zacc
        self.xgyro = xgyro
        self.ygyro = ygyro
        self.zgyro = zgyro
        self.xmag = xmag
        self.ymag = ymag
        self.zmag = zmag

    def __str__(self):
        """
```

(continues on next page)

(continued from previous page)

```

String representation of the RawIMU object
"""
    return "RAW_IMU: time_boot_us={}, xacc={}, yacc={}, zacc={}, xgyro={}, ygyro={},
↪ zgyro={}, xmag={}, ymag={}, zmag={}".format(self.time_boot_us, self.xacc, self.yacc,
↪ self.zacc, self.xgyro, self.ygyro, self.zgyro, self.xmag, self.ymag, self.zmag)

```

MyVehicle is a superclass of Vehicle (and hence inherits all its attributes). This first creates a private instance of RawIMU.

We create a listener using the `Vehicle.on_message()` decorator. The listener is called for messages that contain the string “RAW_IMU”, with arguments for the vehicle, message name, and the message. It copies the message information into the attribute and then notifies all observers.

```

class MyVehicle(Vehicle):
    def __init__(self, *args):
        super(MyVehicle, self).__init__(*args)

        # Create an Vehicle.raw_imu object with initial values set to None.
        self._raw_imu = RawIMU()

        # Create a message listener using the decorator.
        @self.on_message('RAW_IMU')
        def listener(self, name, message):
            """
            The listener is called for messages that contain the string specified in ↪
            ↪ the decorator,
            passing the vehicle, message name, and the message.

            The listener writes the message to the (newly attached) ``vehicle.raw_
            ↪ imu`` object
            and notifies observers.
            """
            self._raw_imu.time_boot_us=message.time_usec
            self._raw_imu.xacc=message.xacc
            self._raw_imu.yacc=message.yacc
            self._raw_imu.zacc=message.zacc
            self._raw_imu.xgyro=message.xgyro
            self._raw_imu.ygyro=message.ygyro
            self._raw_imu.zgyro=message.zgyro
            self._raw_imu.xmag=message.xmag
            self._raw_imu.ymag=message.ymag
            self._raw_imu.zmag=message.zmag

            # Notify all observers of new message (with new value)
            # Note that argument `cache=False` by default so listeners
            # are updaed with every new message
            self.notify_attribute_listeners('raw_imu', self._raw_imu)

    @property
    def raw_imu(self):
        return self._raw_imu

```

Note: The notifier function (`Vehicle.notify_attribute_listeners()`) should be called every time there is an update from the vehicle.

You can set a third parameter (`cache=True`) so that it only invokes the listeners when the value *changes*. This is

normally used for attributes like the vehicle mode, where the information is updated regularly from the vehicle, but client code is only interested when the attribute changes.

You should not set `cache=True` for attributes that represent sensor information or other “live” information, including the RAW_IMU attribute demonstrated here. Clients can then implement their own caching strategy if needed.

At the end of the class we create the public property `raw_imu` which client code may read and observe.

Note: The decorator pattern means that you can have multiple listeners for a particular message or for different messages and they can all have the same function name/prototype (in this case `listener(self, name, message)`).

Using the Vehicle subclass

The `create_attribute.py` file first imports the `MyVehicle` class.

```
from dronekit import connect, Vehicle
from my_vehicle import MyVehicle #Our custom vehicle class
import time
```

We then call `connect()`, specifying this new class in the `vehicle_class` argument.

```
# Connect to our custom vehicle_class `MyVehicle` at address `args.connect`
vehicle = connect(args.connect, wait_ready=True, vehicle_class=MyVehicle)
```

`connect()` returns a `MyVehicle` class which can be used in *exactly the same way* as `Vehicle` but with an additional attribute `raw_imu`. You can query the attribute to get any of its members, and even add an observer as shown:

```
# Add observer for the custom attribute

def raw_imu_callback(self, attr_name, value):
    # attr_name == 'raw_imu'
    # value == vehicle.raw_imu
    print value

vehicle.add_attribute_listener('raw_imu', raw_imu_callback)
```

5.7.3 Known issues

This code has no known issues.

5.7.4 Source code

The full source code at documentation build-time is listed below (current version on [github](#)):

```
#!/usr/bin/env python
# -*- coding: utf-8 -*-

"""
© Copyright 2015-2016, 3D Robotics.
```

(continues on next page)

(continued from previous page)

```

create_attribute.py:

Demonstrates how to create attributes from MAVLink messages within your DroneKit-
↳Python script
and use them in the same way as the built-in Vehicle attributes.

The code adds a new attribute to the Vehicle class, populating it with information_
↳from RAW_IMU messages
intercepted using the message_listener decorator.

Full documentation is provided at http://python.dronekit.io/examples/create\_attribute.html
↳html
"""
from __future__ import print_function

from dronekit import connect, Vehicle
from my_vehicle import MyVehicle #Our custom vehicle class
import time

#Set up option parsing to get connection string
import argparse
parser = argparse.ArgumentParser(description='Demonstrates how to create attributes_
↳from MAVLink messages. ')
parser.add_argument('--connect',
                    help="Vehicle connection target string. If not specified, SITL_
↳automatically started and used.")
args = parser.parse_args()

connection_string = args.connect
sitl = None

#Start SITL if no connection string specified
if not connection_string:
    import dronekit_sitl
    sitl = dronekit_sitl.start_default()
    connection_string = sitl.connection_string()

# Connect to the Vehicle
print('Connecting to vehicle on: %s' % connection_string)
vehicle = connect(connection_string, wait_ready=True, vehicle_class=MyVehicle)

# Add observer for the custom attribute

def raw_imu_callback(self, attr_name, value):
    # attr_name == 'raw_imu'
    # value == vehicle.raw_imu
    print(value)

vehicle.add_attribute_listener('raw_imu', raw_imu_callback)

print('Display RAW_IMU messages for 5 seconds and then exit.')
time.sleep(5)

```

(continues on next page)

(continued from previous page)

```

#The message listener can be unset using ``vehicle.remove_message_listener``

#Close vehicle object before exiting script
print("Close vehicle object")
vehicle.close()

# Shut down simulator if it was started.
if sitl is not None:
    sitl.stop()

```

```

#!/usr/bin/env python
# -*- coding: utf-8 -*-

"""
© Copyright 2015-2016, 3D Robotics.

my_vehicle.py:

Custom Vehicle subclass to add IMU data.
"""

from dronekit import Vehicle

class RawIMU(object):
    """
    The RAW IMU readings for the usual 9DOF sensor setup.
    This contains the true raw values without any scaling to allow data capture and
    ↪ system debugging.

    The message definition is here: https://mavlink.io/en/messages/common.html#RAW\_IMU

    :param time_boot_us: Timestamp (microseconds since system boot). #Note, not
    ↪ milliseconds as per spec
    :param xacc: X acceleration (mg)
    :param yacc: Y acceleration (mg)
    :param zacc: Z acceleration (mg)
    :param xgyro: Angular speed around X axis (millirad /sec)
    :param ygyro: Angular speed around Y axis (millirad /sec)
    :param zgyro: Angular speed around Z axis (millirad /sec)
    :param xmag: X Magnetic field (milli tesla)
    :param ymag: Y Magnetic field (milli tesla)
    :param zmag: Z Magnetic field (milli tesla)
    """
    def __init__(self, time_boot_us=None, xacc=None, yacc=None, zacc=None, xgyro=None,
    ↪ ygyro=None, zgyro=None, xmag=None, ymag=None, zmag=None):
        """
        RawIMU object constructor.
        """
        self.time_boot_us = time_boot_us
        self.xacc = xacc
        self.yacc = yacc
        self.zacc = zacc
        self.xgyro = zgyro
        self.ygyro = ygyro
        self.zgyro = zgyro

```

(continues on next page)

(continued from previous page)

```

        self.xmag = xmag
        self.ymag = ymag
        self.zmag = zmag

    def __str__(self):
        """
        String representation used to print the RawIMU object.
        """
        return "RAW_IMU: time_boot_us={},xacc={},yacc={},zacc={},xgyro={},ygyro={},\
↪zgyro={},xmag={},ymag={},zmag={}".format(self.time_boot_us, self.xacc, self.yacc,
↪self.zacc, self.xgyro, self.ygyro, self.zgyro, self.xmag, self.ymag, self.zmag)

class MyVehicle(Vehicle):
    def __init__(self, *args):
        super(MyVehicle, self).__init__(*args)

        # Create an Vehicle.raw_imu object with initial values set to None.
        self._raw_imu = RawIMU()

        # Create a message listener using the decorator.
        @self.on_message('RAW_IMU')
        def listener(self, name, message):
            """
            The listener is called for messages that contain the string specified in ↪
↪the decorator,
            passing the vehicle, message name, and the message.

            The listener writes the message to the (newly attached) ``vehicle.raw_
↪imu`` object
            and notifies observers.
            """
            self._raw_imu.time_boot_us=message.time_usec
            self._raw_imu.xacc=message.xacc
            self._raw_imu.yacc=message.yacc
            self._raw_imu.zacc=message.zacc
            self._raw_imu.xgyro=message.xgyro
            self._raw_imu.ygyro=message.ygyro
            self._raw_imu.zgyro=message.zgyro
            self._raw_imu.xmag=message.xmag
            self._raw_imu.ymag=message.ymag
            self._raw_imu.zmag=message.zmag

            # Notify all observers of new message (with new value)
            # Note that argument `cache=False` by default so listeners
            # are updated with every new message
            self.notify_attribute_listeners('raw_imu', self._raw_imu)

    @property
    def raw_imu(self):
        return self._raw_imu

```

5.8 Example: Follow Me

The *Follow Me* example moves a vehicle to track your position, using location information from a USB GPS attached to your (Linux) laptop.

The source code is a good *starting point* for your own applications. It can be extended to use other python language features and libraries (OpenCV, classes, lots of packages etc. . .)

Note: This example can only run on a Linux computer, because it depends on the Linux-only *gpsd* service.

Warning: Run this example with caution - be ready to exit follow-me mode by switching the flight mode switch on your RC radio.

5.8.1 Running the example

DroneKit (for Linux) and the vehicle should be set up as described in *Installing DroneKit*.

Once you've done that:

1. Install the *gpsd* service (as shown for Ubuntu Linux below):

```
sudo apt-get install gpsd gpsd-clients
```

You can then plug in a USB GPS and run the “xgps” client to confirm that it is working.

Note: If you do not have a USB GPS you can use simulated data by running *dronekit-python/examples/follow_me/run-fake-gps.sh* (in a separate terminal from where you're running DroneKit-Python). This approach simulates a single location, and so is really only useful for verifying that the script is working correctly.

2. Get the DroneKit-Python example source code onto your local machine. The easiest way to do this is to clone the **dronekit-python** repository from Github. On the command prompt enter:

```
git clone http://github.com/dronekit/dronekit-python.git
```

3. Navigate to the example folder as shown:

```
cd dronekit-python/examples/follow_me/
```

4. You can run the example against a simulator (DroneKit-SITL) by specifying the Python script without any arguments. The example will download SITL binaries (if needed), start the simulator, and then connect to it:

```
python follow_me.py
```

On the command prompt you should see (something like):

```
Starting copter simulator (SITL)
SITL already Downloaded.
Connecting to vehicle on: tcp:127.0.0.1:5760
>>> APM:Copter V3.4-dev (e0810c2e)
>>> Frame: QUAD
```

(continues on next page)

(continued from previous page)

```

Link timeout, no heartbeat in last 5 seconds
Basic pre-arm checks
Waiting for GPS...: None
...
Waiting for GPS...: None
Taking off!
  Altitude:  0.019999999553
...
  Altitude:  4.76000022888
Reached target altitude
Going to: Location:lat=50.616468333,lon=7.131903333,alt=30,is_relative=True
...
Going to: Location:lat=50.616468333,lon=7.131903333,alt=30,is_relative=True
Going to: Location:lat=50.616468333,lon=7.131903333,alt=30,is_relative=True
User has changed flight modes - aborting follow-me
Close vehicle object
Completed

```

Note: The terminal output above was created using simulated GPS data (which is why the same target location is returned every time).

To stop follow-me you can change the vehicle mode or do Ctrl+C (on a real flight you can just change the mode switch on your RC transmitter).

5. You can run the example against a specific connection (simulated or otherwise) by passing the *connection string* for your vehicle in the `--connect` parameter.

For example, to connect to SITL running on UDP port 14550 on your local computer:

```
python follow_me.py --connect 127.0.0.1:14550
```

5.8.2 How does it work?

Most of the example should be fairly familiar as it uses the same code as other examples for connecting to the vehicle, *taking off*, and closing the vehicle object.

The example-specific code is shown below. All this does is attempt to get a gps socket and read the location in a two second loop. If it is successful it reports the value and uses `Vehicle.simple_goto` to move to the new position. The loop exits when the mode is changed.

```

import gps
import socket

...

try:
    # Use the python gps package to access the laptop GPS
    gpsd = gps.gps(mode=gps.WATCH_ENABLE)

    #Arm and take off to an altitude of 5 meters
    arm_and_takeoff(5)

    while True:

```

(continues on next page)

(continued from previous page)

```

    if vehicle.mode.name != "GUIDED":
        print "User has changed flight modes - aborting follow-me"
        break

    # Read the GPS state from the laptop
    gpsd.next()

    # Once we have a valid location (see gpsd documentation) we can start moving_
    ↳our vehicle around
    if (gpsd.valid & gps.LATLON_SET) != 0:
        altitude = 30 # in meters
        dest = LocationGlobalRelative(gpsd.fix.latitude, gpsd.fix.longitude,
    ↳altitude)
        print "Going to: %s" % dest

        # A better implementation would only send new waypoints if the position_
    ↳had changed significantly
        vehicle.simple_goto(dest)

        # Send a new target every two seconds
        # For a complete implementation of follow me you'd want adjust this delay
        time.sleep(2)

except socket.error:
    print "Error: gpsd service does not seem to be running, plug in USB GPS or run_
    ↳run-fake-gps.sh"
    sys.exit(1)

```

5.8.3 Source code

The full source code at documentation build-time is listed below (current version on github):

```

#!/usr/bin/env python
# -*- coding: utf-8 -*-

"""
© Copyright 2015-2016, 3D Robotics.
followme - Tracks GPS position of your computer (Linux only).

This example uses the python gps package to read positions from a GPS attached to_
↳your
laptop and sends a new vehicle.simple_goto command every two seconds to move the
vehicle to the current point.

When you want to stop follow-me, either change vehicle modes or type Ctrl+C to exit_
↳the script.

Example documentation: http://python.dronekit.io/examples/follow\_me.html
"""
from __future__ import print_function

from dronekit import connect, VehicleMode, LocationGlobalRelative
import gps
import socket
import time

```

(continues on next page)

(continued from previous page)

```

import sys

#Set up option parsing to get connection string
import argparse
parser = argparse.ArgumentParser(description='Tracks GPS position of your computer_
↳(Linux only).')
parser.add_argument('--connect',
                    help="vehicle connection target string. If not specified, SITL_
↳automatically started and used.")
args = parser.parse_args()

connection_string = args.connect
sitl = None

#Start SITL if no connection string specified
if not connection_string:
    import dronekit_sitl
    sitl = dronekit_sitl.start_default()
    connection_string = sitl.connection_string()

# Connect to the Vehicle
print('Connecting to vehicle on: %s' % connection_string)
vehicle = connect(connection_string, wait_ready=True, timeout=300)

def arm_and_takeoff(aTargetAltitude):
    """
    Arms vehicle and fly to aTargetAltitude.
    """

    print("Basic pre-arm checks")
    # Don't let the user try to arm until autopilot is ready
    while not vehicle.is_armable:
        print(" Waiting for vehicle to initialise...")
        time.sleep(1)

    print("Arming motors")
    # Copter should arm in GUIDED mode
    vehicle.mode = VehicleMode("GUIDED")
    vehicle.armed = True

    while not vehicle.armed:
        print(" Waiting for arming...")
        time.sleep(1)

    print("Taking off!")
    vehicle.simple_takeoff(aTargetAltitude) # Take off to target altitude

    # Wait until the vehicle reaches a safe height before processing the goto_
↳(otherwise the command
    # after Vehicle.simple_takeoff will execute immediately).
    while True:
        print(" Altitude: ", vehicle.location.global_relative_frame.alt)
        if vehicle.location.global_relative_frame.alt>=aTargetAltitude*0.95: #Trigger_
↳just below target alt.

```

(continues on next page)

(continued from previous page)

```

        print("Reached target altitude")
        break
    time.sleep(1)

try:
    # Use the python gps package to access the laptop GPS
    gpsd = gps.gps(mode=gps.WATCH_ENABLE)

    #Arm and take off to altitude of 5 meters
    arm_and_takeoff(5)

    while True:

        if vehicle.mode.name != "GUIDED":
            print("User has changed flight modes - aborting follow-me")
            break

        # Read the GPS state from the laptop
        next(gpsd)

        # Once we have a valid location (see gpsd documentation) we can start moving_
        ↳our vehicle around
        if (gpsd.valid & gps.LATLON_SET) != 0:
            altitude = 30 # in meters
            dest = LocationGlobalRelative(gpsd.fix.latitude, gpsd.fix.longitude,
        ↳altitude)
            print("Going to: %s" % dest)

            # A better implementation would only send new waypoints if the position_
        ↳had changed significantly
            vehicle.simple_goto(dest)

            # Send a new target every two seconds
            # For a complete implementation of follow me you'd want adjust this delay
            time.sleep(2)

except socket.error:
    print("Error: gpsd service does not seem to be running, plug in USB GPS or run_
    ↳run-fake-gps.sh")
    sys.exit(1)

#Close vehicle object before exiting script
print("Close vehicle object")
vehicle.close()

# Shut down simulator if it was started.
if sitl is not None:
    sitl.stop()

print("Completed")

```

5.9 Example: Drone Delivery

This example shows how to create a [CherryPy](#) based web application that displays a mapbox map to let you view the current vehicle position and send the vehicle commands to fly to a particular latitude and longitude.

New functionality demonstrated by this example includes:

- Using attribute observers to be notified of vehicle state changes.
- Starting *CherryPy* from a DroneKit application.

5.9.1 Running the example

The example can be run much as described in [Running the Examples](#) (which in turn assumes that the vehicle and DroneKit have been set up as described in [Installing DroneKit](#)). The main exception is that you need to install the CherryPy dependencies and view the behaviour in a web browser.

In summary, after cloning the repository:

1. Navigate to the example folder as shown:

```
cd dronekit-python\examples\drone_delivery\
```

2. Install *CherryPy* and any other dependencies from **requirements.pip** in that directory:

```
pip install -r requirements.pip
```

3. You can run the example against the simulator by specifying the Python script without any arguments. The example will download and start DroneKit-SITL, and then connect to it:

```
python drone_delivery.py
```

On the command prompt you should see (something like):

```
>python drone_delivery.py

D:\Github\dronekit-python\examples\drone_delivery>drone_delivery.py
Starting copter simulator (SITL)
SITL already Downloaded.
local path: D:\Github\dronekit-python\examples\drone_delivery
Connecting to vehicle on: tcp:127.0.0.1:5760
>>> APM:Copter V3.3 (d6053245)
>>> Frame: QUAD
>>> Calibrating barometer
>>> Initialising APM...
>>> barometer calibration complete
>>> GROUND START
Launching Drone...
[DEBUG]: Connected to vehicle.
[DEBUG]: DroneDelivery Start
[DEBUG]: Waiting for location...
[DEBUG]: Waiting for ability to arm...
[DEBUG]: Running initial boot sequence
[DEBUG]: Changing to mode: GUIDED
[DEBUG]: ... polled mode: GUIDED
[DEBUG]: Waiting for arming...
>>> ARMING MOTORS
```

(continues on next page)

(continued from previous page)

```
>>> GROUND START
>>> Initialising APM...
[DEBUG]: Taking off
http://localhost:8080/
Waiting for cherypy engine...
```

4. You can run the example against a specific connection (simulated or otherwise) by passing the *connection string* for your vehicle in the `--connect` parameter. For example, to connect to Solo:

```
python drone_delivery.py --connect udpin:0.0.0.0:14550
```


5. After a short while you should be able to reach your new webserver at <http://localhost:8080>. Navigate to the **Command** screen, select a target on the map, then select **Go**. The command prompt will show something like the message below.


```
[DEBUG]: Goto: [u'-35.4', u'149.2'], 29.98
```


The web server will switch you to the **Track** screen. You can view the vehicle progress by pressing the **Update** button.

5.9.2 Screenshots

The webserver (<http://localhost:8080>) will look like the following:







5.9.3 How it works

Using attribute observers

All attributes in DroneKit can have observers - this is the primary mechanism you should use to be notified of changes in vehicle state. For instance, `drone_delivery.py` calls:

```
self.vehicle.add_attribute_listener('location', self.location_callback)
```

```
...
```

(continues on next page)

(continued from previous page)

```
def location_callback(self, vehicle, name, location):
    if location.global_relative_frame.alt is not None:
        self.altitude = location.global_relative_frame.alt

    self.current_location = location.global_relative_frame
```

This results in DroneKit calling our `location_callback` method any time the location attribute gets changed.

Tip: It is also possible (and often more elegant) to add listeners using a decorator - see [Vehicle.on_attribute](#).

Starting CherryPy from a DroneKit application

We start running a web server by calling `cherrypy.engine.start()`.

CherryPy is a very small and simple webserver. It is probably best to refer to their eight line [tutorial](#) for more information.

5.9.4 Known issues

This example has the following issues:

- #537: Dronekit delivery tracking needs to zoom and also ideally auto update
- #538: Dronekit delivery example does not exit

5.9.5 Source code

The full source code at documentation build-time is listed below (current version on [github](#)):

```
#!/usr/bin/env python
# -*- coding: utf-8 -*-

"""
© Copyright 2015-2016, 3D Robotics.
drone_delivery.py:

A CherryPy based web application that displays a mapbox map to let you view the
↪current vehicle position and send the vehicle commands to fly to a particular
↪latitude and longitude.

Full documentation is provided at http://python.dronekit.io/examples/drone_delivery.
↪html
"""

from __future__ import print_function
import os
import simplejson
import time

from dronekit import connect, VehicleMode, LocationGlobal, LocationGlobalRelative
import cherrypy
from jinja2 import Environment, FileSystemLoader
```

(continues on next page)

(continued from previous page)

```

# Set up option parsing to get connection string
import argparse
parser = argparse.ArgumentParser(description='Creates a CherryPy based web_
↳application that displays a mapbox map to let you view the current vehicle position_
↳and send the vehicle commands to fly to a particular latitude and longitude. Will_
↳start and connect to SITL if no connection string specified.')
parser.add_argument('--connect',
                    help="vehicle connection target string. If not specified, SITL is_
↳automatically started and used.")
args = parser.parse_args()

connection_string = args.connect

# Start SITL if no connection string specified
if not connection_string:
    import dronekit_sitl
    sitl = dronekit_sitl.start_default()
    connection_string = sitl.connection_string()

local_path = os.path.dirname(os.path.abspath(__file__))
print("local path: %s" % local_path)

cherrypy_conf = {
    '/': {
        'tools.sessions.on': True,
        'tools.staticdir.root': local_path
    },
    '/static': {
        'tools.staticdir.on': True,
        'tools.staticdir.dir': './html/assets'
    }
}

class Drone(object):
    def __init__(self, server_enabled=True):
        self.gps_lock = False
        self.altitude = 30.0

        # Connect to the Vehicle
        self._log('Connected to vehicle.')
        self.vehicle = vehicle
        self.commands = self.vehicle.commands
        self.current_coords = []
        self.webserver_enabled = server_enabled
        self._log("DroneDelivery Start")

        # Register observers
        self.vehicle.add_attribute_listener('location', self.location_callback)

    def launch(self):
        self._log("Waiting for location...")
        while self.vehicle.location.global_frame.lat == 0:
            time.sleep(0.1)
        self.home_coords = [self.vehicle.location.global_frame.lat,

```

(continues on next page)

(continued from previous page)

```

        self.vehicle.location.global_frame.lon]

    self._log("Waiting for ability to arm...")
    while not self.vehicle.is_armable:
        time.sleep(.1)

    self._log('Running initial boot sequence')
    self.change_mode('GUIDED')
    self.arm()
    self.takeoff()

    if self.webserver_enabled is True:
        self._run_server()

def takeoff(self):
    self._log("Taking off")
    self.vehicle.simple_takeoff(30.0)

def arm(self, value=True):
    if value:
        self._log('Waiting for arming...')
        self.vehicle.armed = True
        while not self.vehicle.armed:
            time.sleep(.1)
    else:
        self._log("Disarming!")
        self.vehicle.armed = False

def _run_server(self):
    # Start web server if enabled
    cherrypy.tree.mount(DroneDelivery(self), '/', config=cherrypy_conf)

    cherrypy.config.update({'server.socket_port': 8080,
                           'server.socket_host': '0.0.0.0',
                           'log.screen': None})

    print("""Server is bound on all addresses, port 8080
You may connect to it using your web broser using a URL looking like this:
http://localhost:8080/
""")

    cherrypy.engine.start()

def change_mode(self, mode):
    self._log("Changing to mode: {0}".format(mode))

    self.vehicle.mode = VehicleMode(mode)
    while self.vehicle.mode.name != mode:
        self._log('... polled mode: {0}'.format(mode))
        time.sleep(1)

def goto(self, location, relative=None):
    self._log("Goto: {0}, {1}".format(location, self.altitude))

    if relative:
        self.vehicle.simple_goto(
            LocationGlobalRelative(
                float(location[0]), float(location[1]),

```

(continues on next page)

(continued from previous page)

```

        float(self.altitude)
    )
    )
    else:
        self.vehicle.simple_goto(
            LocationGlobal(
                float(location[0]), float(location[1]),
                float(self.altitude)
            )
        )
    self.vehicle.flush()

def get_location(self):
    return [self.current_location.lat, self.current_location.lon]

def location_callback(self, vehicle, name, location):
    if location.global_relative_frame.alt is not None:
        self.altitude = location.global_relative_frame.alt

    self.current_location = location.global_relative_frame

def _log(self, message):
    print("[DEBUG]: {0}".format(message))

class Templates:
    def __init__(self, home_coords):
        self.home_coords = home_coords
        self.options = self.get_options()
        self.environment = Environment(loader=FileSystemLoader(local_path + '/html'))

    def get_options(self):
        return {'width': 670,
                'height': 470,
                'zoom': 13,
                'format': 'png',
                'access_token': 'pk.
→eyJlIjoia2V2aW4zZHIiLCJhIjoiy2lrOGoxN2s2MDJzYnR6a3drbTYwdGxmMiJ9.
→bv5u7QgmcJd6dZfLDGoykw',
                'mapid': 'kevin3dr.n56ffjoo',
                'home_coords': self.home_coords,
                'menu': [{'name': 'Home', 'location': '/'},
                        {'name': 'Track', 'location': '/track'},
                        {'name': 'Command', 'location': '/command'}],
                'current_url': '/',
                'json': ''
                }

    def index(self):
        self.options = self.get_options()
        self.options['current_url'] = '/'
        return self.get_template('index')

    def track(self, current_coords):
        self.options = self.get_options()
        self.options['current_url'] = '/track'
        self.options['current_coords'] = current_coords

```

(continues on next page)

(continued from previous page)

```

        self.options['json'] = simplejson.dumps(self.options)
        return self.get_template('track')

    def command(self, current_coords):
        self.options = self.get_options()
        self.options['current_url'] = '/command'
        self.options['current_coords'] = current_coords
        return self.get_template('command')

    def get_template(self, file_name):
        template = self.environment.get_template(file_name + '.html')
        return template.render(options=self.options)

class DroneDelivery(object):
    def __init__(self, drone):
        self.drone = drone
        self.templates = Templates(self.drone.home_coords)

    @cherry.py.expose
    def index(self):
        return self.templates.index()

    @cherry.py.expose
    def command(self):
        return self.templates.command(self.drone.get_location())

    @cherry.py.expose
    @cherry.py.tools.json_out()
    def vehicle(self):
        return dict(position=self.drone.get_location())

    @cherry.py.expose
    def track(self, lat=None, lon=None):
        # Process POST request from Command
        # Sending MAVLink packet with goto instructions
        if lat is not None and lon is not None:
            self.drone.goto([lat, lon], True)

        return self.templates.track(self.drone.get_location())

# Connect to the Vehicle
print('Connecting to vehicle on: %s' % connection_string)
vehicle = connect(connection_string, wait_ready=True)

print('Launching Drone...')
Drone().launch()

print('Waiting for cherry.py engine...')
cherry.py.engine.block()

if not args.connect:
    # Shut down simulator if it was started.
    sitl.stop()

```

5.10 Example: Flight Replay

This example creates and runs a waypoint mission using position information from a TLOG file.

The log used in this example contains around 2700 points. This is too many points to upload to the autopilot (and to usefully display). Instead we only add points that are more than 3 metres away from the previously kept point, and only store 99 points in total. After 60 seconds the mission is ended by setting the mode to RTL (return to launch).




Fig. 5: 99 point mission generated from log

Note: The method used to reduce the number of points is fairly effective, but we could do better by grouping some of the waypoints, and mapping others using spline waypoints. This might be a [fun research project](#)!

5.10.1 Running the example

The example can be run as described in *Running the Examples* (which in turn assumes that the vehicle and DroneKit have been set up as described in *Installing DroneKit*).

In summary, after cloning the repository:

1. Navigate to the example folder as shown:

```
cd dronekit-python/examples/flight_replay/
```

2. You can run the example against a simulator (DroneKit-SITL) by specifying the Python script without any arguments. The example will download SITL binaries if needed, start the simulator, and then connect to it:

```
python flight_replay.py
```

On the command prompt you should see (something like):

```

Generating waypoints from tlog...
Generated 100 waypoints from tlog
Starting copter simulator (SITL)
SITL already Downloaded.
Connecting to vehicle on: tcp:127.0.0.1:5760
>>> APM:Copter V3.3 (d6053245)
>>> Frame: QUAD
>>> Calibrating barometer
>>> Initialising APM...
>>> barometer calibration complete
>>> GROUND START
Uploading 100 waypoints to vehicle...
Arm and Takeoff
Waiting for vehicle to initialise...
>>> flight plan received
Waiting for arming...
Waiting for arming...
Waiting for arming...
Waiting for arming...
>>> ARMING MOTORS
>>> GROUND START
Waiting for arming...
>>> Initialising APM...
Waiting for arming...
>>> ARMING MOTORS
Taking off!
Altitude: 0.000000 < 28.500000
Altitude: 0.010000 < 28.500000
...
Altitude: 26.350000 < 28.500000
Altitude: 28.320000 < 28.500000
Reached target altitude of ~30.000000
Starting mission
Distance to waypoint (1): 3.02389745499
>>> Reached Command #1
Distance to waypoint (2): 5.57718471895
Distance to waypoint (2): 4.1504263025
>>> Reached Command #2
Distance to waypoint (3): 0.872847106279
Distance to waypoint (3): 1.88967925144
Distance to waypoint (3): 2.16157704522
>>> Reached Command #3
Distance to waypoint (4): 4.91867197924
...
...
Distance to waypoint (35): 4.37309981133
>>> Reached Command #35
Distance to waypoint (36): 5.61829417257
>>> Reached Command #36
Return to launch
Close vehicle object
Completed...

```

Tip: It is more interesting to watch the example run on a map than the console. The topic [Connecting an additional Ground Station](#) explains how to set up *Mission Planner* to view a vehicle running on the simulator

(SITL).

3. You can run the example against a specific connection (simulated or otherwise) by passing the *connection string* for your vehicle in the `--connect` parameter.

For example, to connect to SITL running on UDP port 14550 on your local computer:

```
python simple_goto.py --connect 127.0.0.1:14550
```

5.10.2 How it works

Getting the points

The example parses the **flight.tlog** file for position information. First we read all the points. We then keep the first 99 points that are at least 3 metres separated from the preceding kept point.

For safety reasons, the altitude for the waypoints is set to 30 meters (irrespective of the recorded height).

```
def position_messages_from_tlog(filename):  
    """  
    Given telemetry log, get a series of wpts approximating the previous flight  
    """  
    # Pull out just the global position msgs  
    messages = []  
    mlog = mavutil.mavlink_connection(filename)  
    while True:  
        try:  
            m = mlog.recv_match(type=['GLOBAL_POSITION_INT'])  
            if m is None:  
                break  
        except Exception:  
            break  
        # ignore we get where there is no fix:  
        if m.lat == 0:  
            continue  
        messages.append(m)  
  
    # Shrink the number of points for readability and to stay within autopilot memory  
    ↪limits.  
    # For coding simplicity we:  
    #   - only keep points that are with 3 metres of the previous kept point.  
    #   - only keep the first 100 points that meet the above criteria.  
    num_points = len(messages)  
    keep_point_distance=3 #metres  
    kept_messages = []  
    kept_messages.append(messages[0]) #Keep the first message  
    pt1num=0  
    pt2num=1  
    while True:  
        #Keep the last point. Only record 99 points.  
        if pt2num==num_points-1 or len(kept_messages)==99:  
            kept_messages.append(messages[pt2num])  
            break  
        pt1 = LocationGlobalRelative(messages[pt1num].lat/1.0e7, messages[pt1num].lon/  
    ↪1.0e7, 0)  
        pt2 = LocationGlobalRelative(messages[pt2num].lat/1.0e7, messages[pt2num].lon/  
    ↪1.0e7, 0)
```

(continues on next page)

(continued from previous page)

```

        distance_between_points = get_distance_metres(pt1,pt2)
        if distance_between_points > keep_point_distance:
            kept_messages.append(messages[pt2num])
            pt1num=pt2num
            pt2num=pt2num+1

    return kept_messages

```

Setting the new waypoints

The following code shows how the vehicle writes the received messages as commands (this part of the code is very similar to that shown in *Example: Basic Mission*):

```

print "Generating %s waypoints from replay..." % len(messages)
cmds = vehicle.commands
cmds.clear()
for i in xrange(0, len(messages)):
    pt = messages[i]
    lat = pt['lat']
    lon = pt['lon']
    # To prevent accidents we don't trust the altitude in the original flight, instead
    # we just put in a conservative cruising altitude.
    altitude = 30.0 # pt['alt']
    cmd = Command( 0,
                   0,
                   0,
                   mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT,
                   mavutil.mavlink.MAV_CMD_NAV_WAYPOINT,
                   0, 0, 0, 0, 0, 0,
                   lat, lon, altitude)
    cmds.add(cmd)
#Upload clear message and command messages to vehicle.
cmds.upload()

```

5.10.3 Known issues

There are no known issues with this example.

5.10.4 Source code

The full source code at documentation build-time is listed below (current version on [github](#)):

```

#!/usr/bin/env python
# -*- coding: utf-8 -*-

"""
© Copyright 2015-2016, 3D Robotics.
flight_replay.py:

This example requests a past flight from Droneshare, and then 'replays'
the flight by sending waypoints to a vehicle.

```

(continues on next page)

(continued from previous page)

```

Full documentation is provided at http://python.dronekit.io/examples/flight\_replay.html
"""
from __future__ import print_function

from dronekit import connect, Command, VehicleMode, LocationGlobalRelative
from pymavlink import mavutil
import json, urllib, math
import time

#Set up option parsing to get connection string
import argparse
parser = argparse.ArgumentParser(description='Load a telemetry log and use position_
↳data to create mission waypoints for a vehicle. Connects to SITL on local PC by_
↳default.')
parser.add_argument('--connect', help="vehicle connection target.")
parser.add_argument('--tlog', default='flight.tlog',
                    help="Telemetry log containing path to replay")
args = parser.parse_args()

def get_distance_metres(aLocation1, aLocation2):
    """
    Returns the ground distance in metres between two LocationGlobal objects.

    This method is an approximation, and will not be accurate over large distances_
↳and close to the
    earth's poles. It comes from the ArduPilot test code:
    https://github.com/diydrones/ardupilot/blob/master/Tools/autotest/common.py
    """
    dlat = aLocation2.lat - aLocation1.lat
    dlong = aLocation2.lon - aLocation1.lon
    return math.sqrt((dlat*dlat) + (dlong*dlong)) * 1.113195e5

def distance_to_current_waypoint():
    """
    Gets distance in metres to the current waypoint.
    It returns None for the first waypoint (Home location).
    """
    nextwaypoint = vehicle.commands.next
    if nextwaypoint==0:
        return None
    missionitem=vehicle.commands[nextwaypoint-1] #commands are zero indexed
    lat = missionitem.x
    lon = missionitem.y
    alt = missionitem.z
    targetWaypointLocation = LocationGlobalRelative(lat,lon,alt)
    distancetopoint = get_distance_metres(vehicle.location.global_frame,
↳targetWaypointLocation)
    return distancetopoint

def position_messages_from_tlog(filename):
    """
    Given telemetry log, get a series of wpts approximating the previous flight
    """

```

(continues on next page)

(continued from previous page)

```

# Pull out just the global position msgs
messages = []
mlog = mavutil.mavlink_connection(filename)
while True:
    try:
        m = mlog.recv_match(type=['GLOBAL_POSITION_INT'])
        if m is None:
            break
    except Exception:
        break
    # ignore we get where there is no fix:
    if m.lat == 0:
        continue
    messages.append(m)

# Shrink the number of points for readability and to stay within autopilot memory_
↳limits.
# For coding simplicity we:
# - only keep points that are with 3 metres of the previous kept point.
# - only keep the first 100 points that meet the above criteria.
num_points = len(messages)
keep_point_distance=3 #metres
kept_messages = []
kept_messages.append(messages[0]) #Keep the first message
pt1num=0
pt2num=1
while True:
    #Keep the last point. Only record 99 points.
    if pt2num==num_points-1 or len(kept_messages)==99:
        kept_messages.append(messages[pt2num])
        break
    pt1 = LocationGlobalRelative(messages[pt1num].lat/1.0e7,messages[pt1num].lon/
↳1.0e7,0)
    pt2 = LocationGlobalRelative(messages[pt2num].lat/1.0e7,messages[pt2num].lon/
↳1.0e7,0)
    distance_between_points = get_distance_metres(pt1,pt2)
    if distance_between_points > keep_point_distance:
        kept_messages.append(messages[pt2num])
        pt1num=pt2num
        pt2num=pt2num+1

return kept_messages

def arm_and_takeoff(aTargetAltitude):
    """
    Arms vehicle and fly to aTargetAltitude.
    """

    # Don't try to arm until autopilot is ready
    while not vehicle.is_armable:
        print(" Waiting for vehicle to initialise...")
        time.sleep(1)

    # Set mode to GUIDED for arming and takeoff:
    while (vehicle.mode.name != "GUIDED"):
        vehicle.mode = VehicleMode("GUIDED")

```

(continues on next page)

(continued from previous page)

```

        time.sleep(0.1)

        # Confirm vehicle armed before attempting to take off
        while not vehicle.armed:
            vehicle.armed = True
            print(" Waiting for arming...")
            time.sleep(1)

        print(" Taking off!")
        vehicle.simple_takeoff(aTargetAltitude) # Take off to target altitude

        # Wait until the vehicle reaches a safe height
        # before allowing next command to process.
        while True:
            requiredAlt = aTargetAltitude*0.95
            #Break and return from function just below target altitude.
            if vehicle.location.global_relative_frame.alt>=requiredAlt:
                print(" Reached target altitude of ~%f" % (aTargetAltitude))
                break
            print(" Altitude: %f < %f" % (vehicle.location.global_relative_frame.alt,
                                          requiredAlt))

            time.sleep(1)

    print("Generating waypoints from tlog...")
    messages = position_messages_from_tlog(args.tlog)
    print(" Generated %d waypoints from tlog" % len(messages))
    if len(messages) == 0:
        print("No position messages found in log")
        exit(0)

    #Start SITL if no connection string specified
    if args.connect:
        connection_string = args.connect
        sitl = None
    else:
        start_lat = messages[0].lat/1.0e7
        start_lon = messages[0].lon/1.0e7

        import dronekit_sitl
        sitl = dronekit_sitl.start_default(lat=start_lat,lon=start_lon)
        connection_string = sitl.connection_string()

    # Connect to the Vehicle
    print('Connecting to vehicle on: %s' % connection_string)
    vehicle = connect(connection_string, wait_ready=True)

    # Now download the vehicle waypoints
    cmds = vehicle.commands
    cmds.wait_ready()

    cmds = vehicle.commands
    cmds.clear()
    for pt in messages:
        #print "Point: %d %d" % (pt.lat, pt.lon,)

```

(continues on next page)

(continued from previous page)

```

lat = pt.lat
lon = pt.lon
# To prevent accidents we don't trust the altitude in the original flight, instead
# we just put in a conservative cruising altitude.
altitude = 30.0
cmd = Command( 0,
               0,
               0,
               mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT,
               mavutil.mavlink.MAV_CMD_NAV_WAYPOINT,
               0, 0, 0, 0, 0, 0,
               lat/1.0e7, lon/1.0e7, altitude)

cmds.add(cmd)

#Upload clear message and command messages to vehicle.
print("Uploading %d waypoints to vehicle..." % len(messages))
cmds.upload()

print("Arm and Takeoff")
arm_and_takeoff(30)

print("Starting mission")

# Reset mission set to first (0) waypoint
vehicle.commands.next=0

# Set mode to AUTO to start mission:
while (vehicle.mode.name != "AUTO"):
    vehicle.mode = VehicleMode("AUTO")
    time.sleep(0.1)

# Monitor mission for 60 seconds then RTL and quit:
time_start = time.time()
while time.time() - time_start < 60:
    nextwaypoint=vehicle.commands.next
    print('Distance to waypoint (%s): %s' % (nextwaypoint, distance_to_current_
↪waypoint()))

    if nextwaypoint==len(messages):
        print("Exit 'standard' mission when start heading to final waypoint")
        break;
    time.sleep(1)

print('Return to launch')
while (vehicle.mode.name != "RTL"):
    vehicle.mode = VehicleMode("RTL")
    time.sleep(0.1)

#Close vehicle object before exiting script
print("Close vehicle object")
vehicle.close()

# Shut down simulator if it was started.
if sitl is not None:
    sitl.stop()

```

(continues on next page)

(continued from previous page)

```
print("Completed...")
```

5.11 Example: Channels and Channel Overrides

This example shows how to get channel information and to get/set channel-override information.

Warning: Channel overrides (a.k.a. “RC overrides”) are highly dis-commended (they are primarily intended for simulating user input and when implementing certain types of joystick control).

Instead use the appropriate MAVLink commands like DO_SET_SERVO/DO_SET_RELAY, or more generally set the desired position or direction/speed.

If you have no choice but to use a channel-override please explain why in a [Github issue](#) and we will attempt to find a better alternative.

5.11.1 Running the example

The example can be run as described in *Running the Examples* (which in turn assumes that the vehicle and DroneKit have been set up as described in *Installing DroneKit*).

In summary, after cloning the repository:

1. Navigate to the example folder as shown:

```
cd dronekit-python/examples/channel_overrides/
```

2. You can run the example against a simulator (DroneKit-SITL) by specifying the Python script without any arguments. The example will download SITL binaries (if needed), start the simulator, and then connect to it:

```
python channel_overrides.py
```

On the command prompt you should see (something like):

```
Starting copter simulator (SITL)
SITL already Downloaded.
Connecting to vehicle on: tcp:127.0.0.1:5760
>>> APM:Copter V3.3 (d6053245)
>>> Frame: QUAD
>>> Calibrating barometer
>>> Initialising APM...
>>> barometer calibration complete
>>> GROUND START
Channel values from RC Tx: {'1': 1500, '3': 1000, '2': 1500, '5': 1800, '4': 1500,
↪ '7': 1000, '6': 1000, '8': 1800}
Read channels individually:
Ch1: 1500
Ch2: 1500
Ch3: 1000
Ch4: 1500
Ch5: 1800
Ch6: 1000
Ch7: 1000
```

(continues on next page)

(continued from previous page)

```

Ch8: 1800
Number of channels: 8
Channel overrides: {}
Set Ch2 override to 200 (indexing syntax)
Channel overrides: {'2': 200}
Ch2 override: 200
Set Ch3 override to 300 (dictionary syntax)
Channel overrides: {'3': 300}
Set Ch1-Ch8 overrides to 110-810 respectively
Channel overrides: {'1': 110, '3': 310, '2': 210, '5': 510, '4': 4100, '7': 710,
↪ '6': 610, '8': 810}
Cancel Ch2 override (indexing syntax)
Channel overrides: {'1': 110, '3': 310, '5': 510, '4': 4100, '7': 710, '6': 610,
↪ '8': 810}
Clear Ch3 override (del syntax)
Channel overrides: {'1': 110, '5': 510, '4': 4100, '7': 710, '6': 610, '8': 810}
Clear Ch5, Ch6 override and set channel 3 to 500 (dictionary syntax)
Channel overrides: {'3': 500}
Clear all overrides
Channel overrides: {}
Close vehicle object
Completed

```

3. You can run the example against a specific connection (simulated or otherwise) by passing the *connection string* for your vehicle in the `--connect` parameter.

For example, to connect to SITL running on UDP port 14550 on your local computer:

```
python channel_overrides.py --connect 127.0.0.1:14550
```

5.11.2 How does it work?

The RC transmitter channels are connected to the autopilot and control the vehicle.

The values of the first four channels map to the main flight controls: 1=Roll, 2=Pitch, 3=Throttle, 4=Yaw (the mapping is defined in `RCMAP_` parameters in [Plane](#), [Copter](#), [Rover](#)).

The remaining channel values are configurable, and their purpose can be determined using the `RCn_FUNCTION` parameters. In general a value of 0 set for a specific `RCn_FUNCTION` indicates that the channel can be *mission controlled* (i.e. it will not directly be controlled by normal autopilot code).

You can read the values of the channels using the `Vehicle.channels` attribute. The values are regularly updated, from the UAV, based on the RC inputs from the transmitter. These can be read either as a set or individually:

```

# Get all channel values from RC transmitter
print "Channel values from RC Tx:", vehicle.channels

# Access channels individually
print "Read channels individually:"
print " Ch1: %s" % vehicle.channels['1']
print " Ch2: %s" % vehicle.channels['2']

```

You can override the values sent to the vehicle by the autopilot using `Vehicle.channels.overrides`. The overrides can be written individually using an indexing syntax or as a set using a dictionary syntax.

```
# Set Ch2 override to 200 using indexing syntax
vehicle.channels.overrides['2'] = 200
# Set Ch3, Ch4 override to 300,400 using dictionary syntax
vehicle.channels.overrides = {'3':300, '4':400}
```

To clear all overrides, set the attribute to an empty dictionary. To clear an individual override you can set its value to None (or call `del` on it):

```
# Clear override by setting channels to None
# Clear using index syntax
vehicle.channels.overrides['2'] = None

# Clear using 'del' syntax
del vehicle.channels.overrides['3']

# Clear using dictionary syntax (and set override at same time!)
vehicle.channels.overrides = {'5':None, '6':None, '3':500}

# Clear all overrides by setting an empty dictionary
vehicle.channels.overrides = {}
```

Read the channel overrides either as a dictionary or by index.

```
# Get all channel overrides
print " Channel overrides: %s" % vehicle.channels.overrides
# Print just one channel override
print " Ch2 override: %s" % vehicle.channels.overrides['2']
```

Note: You'll get a `KeyError` exception if you read a channel override that has not been set.

5.11.3 Source code

The full source code at documentation build-time is listed below (current version on [github](#)):

```
#!/usr/bin/env python
# -*- coding: utf-8 -*-

"""
© Copyright 2015-2016, 3D Robotics.

channel_overrides.py:

Demonstrates how set and clear channel-override information.

# NOTE:
Channel overrides (a.k.a "RC overrides") are highly discommended (they are primarily
↳ implemented
for simulating user input and when implementing certain types of joystick control).

They are provided for development purposes. Please raise an issue explaining why you
↳ need them
and we will try to find a better alternative: https://github.com/dronekit/dronekit-
↳ python/issues
```

(continues on next page)

(continued from previous page)

```

Full documentation is provided at http://python.dronekit.io/examples/channel\_
↳overrides.html
"""
from __future__ import print_function
from dronekit import connect

#Set up option parsing to get connection string
import argparse
parser = argparse.ArgumentParser(description='Example showing how to set and clear_
↳vehicle channel-override information.')
parser.add_argument('--connect',
                    help="vehicle connection target string. If not specified, SITL_
↳automatically started and used.")
args = parser.parse_args()

connection_string = args.connect
sitl = None

#Start SITL if no connection string specified
if not connection_string:
    import dronekit_sitl
    sitl = dronekit_sitl.start_default()
    connection_string = sitl.connection_string()

# Connect to the Vehicle
print('Connecting to vehicle on: %s' % connection_string)
vehicle = connect(connection_string, wait_ready=True)

# Get all original channel values (before override)
print("Channel values from RC Tx:", vehicle.channels)

# Access channels individually
print("Read channels individually:")
print(" Ch1: %s" % vehicle.channels['1'])
print(" Ch2: %s" % vehicle.channels['2'])
print(" Ch3: %s" % vehicle.channels['3'])
print(" Ch4: %s" % vehicle.channels['4'])
print(" Ch5: %s" % vehicle.channels['5'])
print(" Ch6: %s" % vehicle.channels['6'])
print(" Ch7: %s" % vehicle.channels['7'])
print(" Ch8: %s" % vehicle.channels['8'])
print("Number of channels: %s" % len(vehicle.channels))

# Override channels
print("\nChannel overrides: %s" % vehicle.channels.overrides)

print("Set Ch2 override to 200 (indexing syntax)")
vehicle.channels.overrides['2'] = 200
print(" Channel overrides: %s" % vehicle.channels.overrides)
print(" Ch2 override: %s" % vehicle.channels.overrides['2'])

print("Set Ch3 override to 300 (dictionary syntax)")
vehicle.channels.overrides = {'3':300}

```

(continues on next page)

(continued from previous page)

```
print(" Channel overrides: %s" % vehicle.channels.overrides)

print("Set Ch1-Ch8 overrides to 110-810 respectively")
vehicle.channels.overrides = {'1': 110, '2': 210, '3': 310, '4':4100, '5':510, '6':610, '7
↪':710, '8':810}
print(" Channel overrides: %s" % vehicle.channels.overrides)

# Clear override by setting channels to None
print("\nCancel Ch2 override (indexing syntax)")
vehicle.channels.overrides['2'] = None
print(" Channel overrides: %s" % vehicle.channels.overrides)

print("Clear Ch3 override (del syntax)")
del vehicle.channels.overrides['3']
print(" Channel overrides: %s" % vehicle.channels.overrides)

print("Clear Ch5, Ch6 override and set channel 3 to 500 (dictionary syntax)")
vehicle.channels.overrides = {'5':None, '6':None, '3':500}
print(" Channel overrides: %s" % vehicle.channels.overrides)

print("Clear all overrides")
vehicle.channels.overrides = {}
print(" Channel overrides: %s" % vehicle.channels.overrides)

#Close vehicle object before exiting script
print("\nClose vehicle object")
vehicle.close()

# Shut down simulator if it was started.
if sitl is not None:
    sitl.stop()

print("Completed")
```


DroneKit is an open-source project. We welcome any contribution that will improve the API and make it easier to use. The articles below explain some of the *opportunities* for working on the project, how to *contribute to the API* or the *documentation*, and how to set up a *development environment on Linux or Windows*.

6.1 How you can Contribute

One of the best ways you can contribute is to simply *use the API* and share your *bug reports and enhancement suggestions on Github*. These can cover anything: from APIs that don't work properly through to needed features or documentation.

If you want to take a more active role, then a good place to start is with the project's *open issues* on Github. In particular, *documentation issues* can be resolved without a deep knowledge of the code, and will help you learn more about the project.

If there is a feature that you want to add, then please do so! Before you start we highly recommend that you first create an issue in Github so it can be tracked and discussed!

6.2 Contributing to the API

This article provides a high level overview of how to contribute changes to the DroneKit-Python source code.

Tip: We highly recommend that changes and ideas are *discussed with the project team* before starting work!

6.2.1 Submitting changes

Contributors should fork the main *dronekit/dronekit-python/* repository and contribute changes back to the project master branch using pull requests

- Changes should be *tested locally* before submission.
- Changes to the public API should be *documented* (we will provide subediting support!)
- Pull requests should be as small and focussed as possible to make them easier to review.
- Pull requests should be rebased against the main project before submission to make integration easier.

6.2.2 Test code

There are three test suites in DroneKit-Python:

- **Unit tests** (`tests/unit`) — verify all code paths of the API.
- **Integration tests** (`tests/sitl`) — verify real-world code, examples, and documentation as they would perform in a real environment.

Test code should be used to verify new and changed functionality. New tests should:

1. Verify all code paths that code can take.
2. Be concise and straightforward.
3. Be documented.

Setting up local testing

Follow the links below to set up a development environment on your Linux or Windows computer.

- [Building DroneKit-Python on Linux](#)
- [Building DroneKit-Python on Windows](#)

The tests require additional pip modules, including `nose`, a Python library and tool for writing and running test scripts. These can be installed separately using either of the commands below:

```
# Install just the additional requirements for tests
pip install requests nose mock

# (or) Install all requirements for dronekit, tests, and building documentation
pip install -r requirements.txt
```

For several tests, you may be required to set an **environment variable**. In your command line, you can set the name of a variable to equal a value using the following invocation, depending on your OS:

```
export NAME=VALUE      # works on OS X and Linux
set NAME=VALUE         # works on Windows cmd.exe
$env:NAME = "VALUE"    # works on Windows Powershell
```

Unit tests

All new features should be created with accompanying unit tests.

DroneKit-Python unit tests are based on the `nose` test framework, and use `mock` to simulate objects and APIs and ensure correct results.

To run the tests and display a summary of the results (on any OS), navigate to the **dronekit-python** folder and enter the following command on a terminal/prompt:

```
nosetests dronekit.test.unit
```

Writing a new unit test

Create any file named `test_XXX.py` in the `tests/unit` folder to add it as a test. Feel free to copy from existing tests to get started. When *nosetests* is run, it will add your new test to its summary.

Tests names should be named based on their associated Github issue (for example, `test_12.py` for [issue #12](#)) or describe the functionality covered (for example, `test_waypoints.py` for a unit test for the waypoints API).

Use assertions to test your code is consistent. You can use the built-in Python `assert` macro as well as `assert_equals` and `assert_not_equals` from the `notestools` module:

Note: Avoiding printing any data from your test!

```
from nose.tools import assert_equals, assert_not_equals

def test_this(the_number_two):
    assert the_number_two > 0, '2 should be greater than zero!'
    assert_equals(the_number_two, 2, '2 should equal two!')
    assert_not_equals(the_number_two, 1, '2 should equal one!')
```

Please add documentation to each test function describing what behavior it verifies.

Integration tests

Integrated tests use a custom test runner that is similar to *nosetests*. On any OS, enter the following command on a terminal/prompt to run all the integrated tests (and display summary results):

```
cd dronekit-python
nosetests dronekit.test.sitl
```

You can choose to run a specific tests. The example below shows how to run **dronekit-pythondronekittestsitltest_12.py**.

```
nosetests dronekit.test.sitl.test_12
```

Configuring the test environment

Integrated tests use the SITL environment to run DroneKit tests against a simulated Copter. Because these tests emulate Copter in real-time, you can set several environment variables to tweak the environment that code is run in:

1. `TEST_SPEEDUP` - Speedup factor to SITL. Default is `TEST_SPEEDUP=1`. You can increase this factor to speed up how long your tests take to run.
2. `TEST_RATE` - Sets framerate. Default is `TEST_RATE=200` for copter, 50 for rover, 50 for plane.
3. `TEST_RETRY` - Retry failed tests. Default is `TEST_RETRY=1`. This is useful if your testing environment generates inconsistent success rates because of timing.

Writing a new integration test

Integration tests should be written or improved whenever:

1. New functionality has been added to encapsulate or abstract older methods of interacting with the API.
2. Example code or documentation has been added.
3. A feature could not be tested by unit tests alone (e.g. timing issues, mode changing, etc.)

You can write a new integrated test by adding (or copying) a file with the naming scheme `test_XXX.py` to the `tests/sitl` directory.

Tests names should be named based on their associated Github issue (for example, `test_12.py` for [issue #12](#)) or describe the functionality covered (for example, `test_waypoints.py` for an integration test for the waypoints API).

Tests should minimally use the imports shown below and decorate test functions with `@with_sitl` (this sets up the test and passes in a connection string for SITL).

```
from dronekit import connect
from dronekit.test import with_sitl
from nose.tools import assert_equals, assert_not_equals

@with_sitl
def test_something(connpath):
    vehicle = connect(connpath)

    # Test using assert, assert_equals and assert_not_equals
    ...

    vehicle.close()
```

Use assertions to test your code is consistent. You can use the built-in Python `assert` macro as well as `assert_equals` and `assert_not_equals` from the `testlib` module:

Note: Avoiding printing any data from your test!

```
from testlib import assert_equals

def test_this(the_number_two):
    assert the_number_two > 0, '2 should be greater than zero!'
    assert_equals(the_number_two, 2, '2 should equal two!')
```

Please add documentation to each test function describing what behavior it verifies.

6.3 Contributing to the Documentation

One of the best ways that you can help is by improving this documentation. Here we explain the documentation system, how to build the documents locally, and how to submit your changes.

6.3.1 Documentation system overview

The documentation source files are [stored in Github](#). The content is written in plain-text files (file-extension `.rst`) using [reStructuredText](#) markup, and is compiled into HTML using the [Sphinx Documentation Generator](#).

6.3.2 Submitting changes

The process and requirements for submitting changes to the documentation are **the same** as when *contributing to the source code*.

As when submitting source code you should fork the main project Github repository and contribute changes back to the project using pull requests. The changes should be tested locally (by *building the docs*) before being submitted.

See *Contributing to the API* for more information.

6.3.3 Building the docs

We've made it very easy to get started by providing a **Vagrant** based setup for **Sphinx**. Using **Vagrant** you can work with source files on your host machine using a familiar **git** client and text editor, and then invoke **Sphinx** in the **Vagrant** VM to compile the source to HTML.

The instructions below explain how to get the documentation source, and build it using our Vagrant VM:

- Install the Vagrant pre-conditions:
 - Download and install VirtualBox.
 - Download and install Vagrant for your platform (Windows, OS-X and Linux are supported).
- Fork the official dronekit-python repo
- Clone your fork of the Github repository anywhere on the host PC:

```
git clone https://github.com/YOUR-REPOSITORY/dronekit-python.git
```

- Navigate to the root of *dronekit-python* and start the Vagrant VM:

```
cd /your-path-to-clone/dronekit-python/
vagrant up
```

Note: This may take a long time to complete the first time it is run — Vagrant needs to download the virtual machine and then set up Sphinx.

- When the VM is running, you can build the source by entering the following command in the prompt:

```
vagrant ssh -c "cd /vagrant/docs && make html"
```

The files will be built by **Sphinx**, and will appear on the host system in `<clone-path>/dronekit-python/docs/_build/html/`. To preview, simply open them in a Web browser.

Note: The `vagrant ssh -c "cd /vagrant/docs && make html"` command starts (and closes) an SSH session with the VM. If you plan on building the source a number of times it is much faster to keep the session open:

```
vagrant ssh      # Open an SSH session with the Vagrant VM
cd /vagrant/docs # Navigate to the docs root (contains Sphinx configuration_
↳files)
make html        # Build the HTML
...              # Repeat "make html" as many time as needed
make html
exit             # Close the SSH session.
```

- When you are finished you can suspend the VM. Next time you need to build more HTML simply restart it (this is a fast operation):

```
vagrant suspend    #Suspend the VM
vagrant resume     #Restart the VM
vagrant ssh -c "cd /vagrant/docs && make html"    #Build files when needed.
```

6.3.4 Style guide

Tip: This guide is evolving. The most important guidance we can give is to *copy the existing style of reference, guide and example material!*

1. Use US English for spelling.
2. Use emphasis sparingly (italic, bold, underline).
3. Use [Sphinx semantic markup](#) to mark up *types* of text (key-presses, file names etc.)
4. Use double backticks (``) around `inline code` items.

6.4 Building DroneKit-Python on Windows

This article shows how to set up an environment for *developing* DroneKit-Python on Windows.

6.4.1 Install DroneKit using WinPython command line

First set up a command line DroneKit-Python installation. We recommend *WinPython* or *ActivePython*, as discussed in [Installing DroneKit](#).

6.4.2 Fetch and build DroneKit source

1. Fork the [dronekit-python](#) project on Github.
2. Open the *WinPython Command Prompt*. Run the following commands to clone and build DroneKit (in the directory of your choice):

```
git clone https://github.com/<your_fork_of_dronekit>/dronekit-python.git
cd dronekit-python
python setup.py build
python setup.py install
```

6.4.3 Updating DroneKit

Navigate to your local git fork, pull the latest version, and rebuild/install:

```
cd <path-to-your-dronekit-fork>/dronekit-python
git pull
python setup.py build
python setup.py install
```

6.5 Building DroneKit-Python on Linux

The setup for *developing* DroneKit-Python on Linux is almost the same as for *using* DroneKit-Python. We therefore recommend that you start by following the instructions in [Installing DroneKit](#).

When you've got DroneKit and a vehicle (simulated or real) communicating, you can then build and install your own fork of DroneKit, as discussed below.

6.5.1 Fetch and build DroneKit source

1. Fork the [dronekit-python](#) project on Github.
2. Run the following commands to clone and build DroneKit (in the directory of your choice):

```
git clone https://github.com/<your_fork_of_dronekit>/dronekit-python.git
cd ./dronekit-python
sudo python setup.py build
sudo python setup.py install
```

6.5.2 Updating DroneKit

Navigate to your local git fork, pull the latest version, and rebuild/install:

```
cd ./<path-to-your-dronekit-fork>/dronekit-python
git pull
sudo python setup.py build
sudo python setup.py install
```

DroneKit-Python API Reference

This is the API Reference for the DroneKit-Python API.

The main API is the *Vehicle* class. The code snippet below shows how to use *connect()* to obtain an instance of a connected vehicle:

```
from dronekit import connect

# Connect to the Vehicle using "connection string" (in this case an address on a
↪network)
vehicle = connect('127.0.0.1:14550', wait_ready=True)
```

Vehicle provides access to vehicle *state* through python attributes (e.g. *Vehicle.mode*) and to settings/parameters through the *Vehicle.parameters* attribute. Asynchronous notification on vehicle attribute changes is available by registering listeners/observers.

Vehicle movement is primarily controlled using the *Vehicle.armed* attribute and *Vehicle.simple_takeoff()* and *Vehicle.simple_goto* in GUIDED mode.

Velocity-based movement and control over other vehicle features can be achieved using custom MAVLink messages (*Vehicle.send_mavlink()*, *Vehicle.message_factory()*).

It is also possible to work with vehicle “missions” using the *Vehicle.commands* attribute, and run them in AUTO mode.

All the logging is handled through the builtin Python *logging* module.

A number of other useful classes and methods are listed below.

exception *dronekit.APIException*

Base class for DroneKit related exceptions.

Parameters *message* (*String*) – Message string describing the exception

with_traceback()

Exception.with_traceback(tb) – set self.__traceback__ to tb and return self.

class `dronekit.Attitude` (*pitch, yaw, roll*)

Attitude information.

An object of this type is returned by `Vehicle.attitude`.




Fig. 1: Diagram showing Pitch, Roll, Yaw (Creative Commons)

Parameters

- **pitch** – Pitch in radians
- **yaw** – Yaw in radians
- **roll** – Roll in radians

class `dronekit.Battery` (*voltage, current, level*)

System battery information.

An object of this type is returned by `Vehicle.battery`.

Parameters

- **voltage** – Battery voltage in millivolts.
- **current** – Battery current, in 10 * milliamperes. None if the autopilot does not support current measurement.
- **level** – Remaining battery energy. None if the autopilot cannot estimate the remaining battery.

class `dronekit.Capabilities` (*capabilities*)

Autopilot capabilities (supported message types and functionality).

An object of this type is returned by `Vehicle.capabilities`.

See the enum `MAV_PROTOCOL_CAPABILITY`.

New in version 2.0.3.

mission_float

Autopilot supports MISSION float message type (Boolean).

param_float

Autopilot supports the PARAM float message type (Boolean).

mission_int

Autopilot supports MISSION_INT scaled integer message type (Boolean).

command_int

Autopilot supports COMMAND_INT scaled integer message type (Boolean).

param_union

Autopilot supports the PARAM_UNION message type (Boolean).

ftp

Autopilot supports ftp for file transfers (Boolean).

set_attitude_target

Autopilot supports commanding attitude offboard (Boolean).

set_attitude_target_local_ned

Autopilot supports commanding position and velocity targets in local NED frame (Boolean).

set_altitude_target_global_int

Autopilot supports commanding position and velocity targets in global scaled integers (Boolean).

terrain

Autopilot supports terrain protocol / data handling (Boolean).

set_actuator_target

Autopilot supports direct actuator control (Boolean).

flight_termination

Autopilot supports the flight termination command (Boolean).

compass_calibration

Autopilot supports onboard compass calibration (Boolean).

class `dronekit.Channels` (*vehicle*, *count*)

A dictionary class for managing RC channel information associated with a *Vehicle*.

An object of this type is accessed through *Vehicle.channels*. This object also stores the current vehicle channel overrides through its *overrides* attribute.

For more information and examples see *Example: Channels and Channel Overrides*.

clear () → None. Remove all items from D.

copy () → a shallow copy of D

count

The number of channels defined in the dictionary (currently 8).

fromkeys ()

Create a new dictionary with keys from iterable and values set to value.

get ()

Return the value for key if key is in the dictionary, else default.

items () → a set-like object providing a view on D's items

keys () → a set-like object providing a view on D's keys

overrides

Attribute to read, set and clear channel overrides (also known as “rc overrides”) associated with a *Vehicle* (via *Vehicle.channels*). This is an object of type *ChannelsOverride*.

For more information and examples see *Example: Channels and Channel Overrides*.

To set channel overrides:

```
# Set and clear overrides using dictionary syntax (clear by setting override_
↳to none)
vehicle.channels.overrides = {'5':None, '6':None, '3':500}

# You can also set and clear overrides using indexing syntax
vehicle.channels.overrides['2'] = 200
vehicle.channels.overrides['2'] = None

# Clear using 'del'
del vehicle.channels.overrides['3']

# Clear all overrides by setting an empty dictionary
vehicle.channels.overrides = {}
```

Read the channel overrides either as a dictionary or by index. Note that you'll get a `KeyError` exception if you read a channel override that has not been set.

```
# Get all channel overrides
print " Channel overrides: %s" % vehicle.channels.overrides
# Print just one channel override
print " Ch2 override: %s" % vehicle.channels.overrides['2']
```

pop (k, d) $\rightarrow v$, remove specified key and return the corresponding value.

If key is not found, d is returned if given, otherwise `KeyError` is raised

popitem () $\rightarrow (k, v)$, remove and return some (key, value) pair as a 2-tuple; but raise `KeyError` if D is empty.

setdefault ()

Insert key with a value of default if key is not in the dictionary.

Return the value for key if key is in the dictionary, else default.

update ($[E], **F$) $\rightarrow \text{None}$. Update D from dict/iterable E and F.

If E is present and has a `.keys()` method, then does: for k in E: D[k] = E[k] If E is present and lacks a `.keys()` method, then does: for k, v in E: D[k] = v In either case, this is followed by: for k in F: D[k] = F[k]

values () \rightarrow an object providing a view on D's values

class `dronekit.ChannelsOverride` (*vehicle*)

A dictionary class for managing Vehicle channel overrides.

Channels can be read, written, or cleared by index or using a dictionary syntax. To clear a value, set it to `None` or use `del` on the item.

An object of this type is returned by `Vehicle.channels.overrides`.

For more information and examples see *Example: Channels and Channel Overrides*.

clear () $\rightarrow \text{None}$. Remove all items from D.

copy () \rightarrow a shallow copy of D

fromkeys ()

Create a new dictionary with keys from iterable and values set to value.

get ()

Return the value for key if key is in the dictionary, else default.

items() → a set-like object providing a view on D's items

keys() → a set-like object providing a view on D's keys

pop(*k*, *d*) → *v*, remove specified key and return the corresponding value.
If key is not found, *d* is returned if given, otherwise `KeyError` is raised

popitem() → (*k*, *v*), remove and return some (key, value) pair as a 2-tuple; but raise `KeyError` if D is empty.

setdefault()

Insert key with a value of default if key is not in the dictionary.

Return the value for key if key is in the dictionary, else default.

update(*E*, *F*)** → None. Update D from dict/iterable E and F.

If E is present and has a `.keys()` method, then does: for *k* in E: *D*[*k*] = *E*[*k*] If E is present and lacks a `.keys()` method, then does: for *k*, *v* in E: *D*[*k*] = *v* In either case, this is followed by: for *k* in F: *D*[*k*] = *F*[*k*]

values() → an object providing a view on D's values

class `dronekit.Command`(*target_system*, *target_component*, *seq*, *frame*, *command*, *current*, *autocontinue*, *param1*, *param2*, *param3*, *param4*, *x*, *y*, *z*)

A waypoint object.

This object encodes a single mission item command. The set of commands that are supported by ArduPilot in Copter, Plane and Rover (along with their parameters) are listed in the wiki article [MAVLink Mission Command Messages \(MAV_CMD\)](#).

For example, to create a `NAV_WAYPOINT` command:

```
cmd = Command(0,0,0, mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT,
              mavutil.mavlink.MAV_CMD_NAV_WAYPOINT, 0, 0, 0, 0, 0, 0, -34.364114, 149.166022,
              ↪ 30)
```

Parameters

- **target_system** – This can be set to any value (DroneKit changes the value to the MAVLink ID of the connected vehicle before the command is sent).
- **target_component** – The component id if the message is intended for a particular component within the target system (for example, the camera). Set to zero (broadcast) in most cases.
- **seq** – The sequence number within the mission (the autopilot will reject messages sent out of sequence). This should be set to zero as the API will automatically set the correct value when uploading a mission.
- **frame** – The frame of reference used for the location parameters (*x*, *y*, *z*). In most cases this will be `mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT`, which uses the WGS84 global coordinate system for latitude and longitude, but sets altitude as relative to the home position in metres (home altitude = 0). For more information [see the wiki here](#).
- **command** – The specific mission command (e.g. `mavutil.mavlink.MAV_CMD_NAV_WAYPOINT`). The supported commands (and command parameters are listed [on the wiki](#).
- **current** – Set to zero (not supported).
- **autocontinue** – Set to zero (not supported).
- **param1** – Command specific parameter (depends on specific [Mission Command \(MAV_CMD\)](#)).

- **param2** – Command specific parameter.
- **param3** – Command specific parameter.
- **param4** – Command specific parameter.
- **x** – (param5) Command specific parameter used for latitude (if relevant to command).
- **y** – (param6) Command specific parameter used for longitude (if relevant to command).
- **z** – (param7) Command specific parameter used for altitude (if relevant). The reference frame for altitude depends on the `frame`.

format_attr (*field*)
override field getter

class `dronekit.CommandSequence` (*vehicle*)

A sequence of vehicle waypoints (a “mission”).

Operations include ‘array style’ indexed access to the various contained waypoints.

The current commands/mission for a vehicle are accessed using the `Vehicle.commands` attribute. Waypoints are not downloaded from vehicle until `download()` is called. The download is asynchronous; use `wait_ready()` to block your thread until the download is complete. The code to download the commands from a vehicle is shown below:

```
#Connect to a vehicle object (for example, on com14)
vehicle = connect('com14', wait_ready=True)

# Download the vehicle waypoints (commands). Wait until download is complete.
cmds = vehicle.commands
cmds.download()
cmds.wait_ready()
```

The set of commands can be changed and uploaded to the client. The changes are not guaranteed to be complete until `upload()` is called.

```
cmds = vehicle.commands
cmds.clear()
lat = -34.364114,
lon = 149.166022
altitude = 30.0
cmd = Command(0,0,0, mavutil.mavlink.MAV_FRAME_GLOBAL_RELATIVE_ALT, mavutil.
↳mavlink.MAV_CMD_NAV_WAYPOINT,
    0, 0, 0, 0, 0, 0,
    lat, lon, altitude)
cmds.add(cmd)
cmds.upload()
```

add (*cmd*)

Add a new command (waypoint) at the end of the command list.

Note: Commands are sent to the vehicle only after you call `:upload()`.

Parameters `cmd` (`Command`) – The command to be added.

clear ()

Clear the command list.

This command will be sent to the vehicle only after you call `upload()`.

count

Return number of waypoints.

Returns The number of waypoints in the sequence.

download()

Download all waypoints from the vehicle. The download is asynchronous. Use `wait_ready()` to block your thread until the download is complete.

next

Get the currently active waypoint number.

upload(timeout=None)

Call `upload()` after *adding* or *clearing* mission commands.

After the return from `upload()` any writes are guaranteed to have completed (or thrown an exception) and future reads will see their effects.

Parameters **timeout** (*int*) – The timeout for uploading the mission. No timeout if not provided or set to `None`.

wait_ready(kwargs)**

Block the calling thread until waypoints have been downloaded.

This can be called after `download()` to block the thread until the asynchronous download is complete.

class `dronekit.GPSInfo` (*eph, epv, fix_type, satellites_visible*)

Standard information about GPS.

If there is no GPS lock the parameters are set to `None`.

Parameters

- **eph** (*Int*) – GPS horizontal dilution of position (HDOP).
- **epv** (*Int*) – GPS vertical dilution of position (VDOP).
- **fix_type** (*Int*) – 0-1: no fix, 2: 2D fix, 3: 3D fix
- **satellites_visible** (*Int*) – Number of satellites visible.

class `dronekit.Gimbal` (*vehicle*)

Gimbal status and control.

An object of this type is returned by `Vehicle.gimbal`. The gimbal orientation can be obtained from its `roll`, `pitch` and `yaw` attributes.

The gimbal orientation can be set explicitly using `rotate()` or you can set the gimbal (and vehicle) to track a specific “region of interest” using `target_location()`.

Note:

- The orientation attributes are created with values of `None`. If a gimbal is present, the attributes are populated shortly after initialisation by messages from the autopilot.
- The attribute values reflect the last gimbal setting-values rather than actual measured values. This means that the values won’t change if you manually move the gimbal, and that the value will change when you set it, even if the specified orientation is not supported.
- A gimbal may not support all axes of rotation. For example, the Solo gimbal will set pitch values from 0 to -90 (straight ahead to straight down), it will rotate the vehicle to follow specified yaw values, and will ignore roll commands (not supported).

pitch

Gimbal pitch in degrees relative to the vehicle (see diagram for [attitude](#)). A value of 0 represents a camera pointed straight ahead relative to the front of the vehicle, while -90 points the camera straight down.

Note: This is the last pitch value sent to the gimbal (not the actual/measured pitch).

release()

Release control of the gimbal to the user (RC Control).

This should be called once you've finished controlling the mount with either [rotate\(\)](#) or [target_location\(\)](#). Control will automatically be released if you change vehicle mode.

roll

Gimbal roll in degrees relative to the vehicle (see diagram for [attitude](#)).

Note: This is the last roll value sent to the gimbal (not the actual/measured roll).

rotate(pitch, roll, yaw)

Rotate the gimbal to a specific vector.

```
#Point the gimbal straight down
vehicle.gimbal.rotate(-90, 0, 0)
```

Parameters

- **pitch** – Gimbal pitch in degrees relative to the vehicle (see diagram for [attitude](#)). A value of 0 represents a camera pointed straight ahead relative to the front of the vehicle, while -90 points the camera straight down.
- **roll** – Gimbal roll in degrees relative to the vehicle (see diagram for [attitude](#)).
- **yaw** – Gimbal yaw in degrees relative to *global frame* (0 is North, 90 is West, 180 is South etc.)

target_location(roi)

Point the gimbal at a specific region of interest (ROI).

```
#Set the camera to track the current home location.
vehicle.gimbal.target_location(vehicle.home_location)
```

The target position must be defined in a [LocationGlobalRelative](#) or [LocationGlobal](#).

This function can be called in AUTO or GUIDED mode.

In order to clear an ROI you can send a location with all zeros (e.g. [LocationGlobalRelative](#)(0, 0, 0)).

Parameters **roi** – Target location in global relative frame.

yaw

Gimbal yaw in degrees relative to *global frame* (0 is North, 90 is West, 180 is South etc.).

Note: This is the last yaw value sent to the gimbal (not the actual/measured yaw).

class dronekit.**LocationGlobal** (*lat, lon, alt=None*)

A global location object.

The latitude and longitude are relative to the [WGS84 coordinate system](#). The altitude is relative to mean sea-level (MSL).

For example, a global location object with altitude 30 metres above sea level might be defined as:

```
LocationGlobal(-34.364114, 149.166022, 30)
```

An object of this type is owned by [Vehicle.location](#). See that class for information on reading and observing location in the global frame.

Parameters

- **lat** – Latitude.
- **lon** – Longitude.
- **alt** – Altitude in meters relative to mean sea-level (MSL).

class dronekit.**LocationGlobalRelative** (*lat, lon, alt=None*)

A global location object, with attitude relative to home location altitude.

The latitude and longitude are relative to the [WGS84 coordinate system](#). The altitude is relative to the *home position*.

For example, a `LocationGlobalRelative` object with an altitude of 30 metres above the home location might be defined as:

```
LocationGlobalRelative(-34.364114, 149.166022, 30)
```

An object of this type is owned by [Vehicle.location](#). See that class for information on reading and observing location in the global-relative frame.

Parameters

- **lat** – Latitude.
- **lon** – Longitude.
- **alt** – Altitude in meters (relative to the home location).

class dronekit.**LocationLocal** (*north, east, down*)

A local location object.

The north, east and down are relative to the EKF origin. This is most likely the location where the vehicle was turned on.

An object of this type is owned by [Vehicle.location](#). See that class for information on reading and observing location in the local frame.

Parameters

- **north** – Position north of the EKF origin in meters.
- **east** – Position east of the EKF origin in meters.
- **down** – Position down from the EKF origin in meters. (i.e. negative altitude in meters)

distance_home ()

Distance away from home, in meters. Returns 3D distance if *down* is known, otherwise 2D distance.

class dronekit.**Locations** (*vehicle*)

An object for holding location information in global, global relative and local frames.

Vehicle owns an object of this type. See *Vehicle.location* for information on reading and observing location in the different frames.

The different frames are accessed through the members, which are created with this object. They can be read, and are observable.

add_attribute_listener (*attr_name*, *observer*)

Add an attribute listener callback.

The callback function (*observer*) is invoked differently depending on the *type of attribute*. Attributes that represent sensor values or which are used to monitor connection status are updated whenever a message is received from the vehicle. Attributes which reflect vehicle “state” are only updated when their values change (for example *Vehicle.system_status*, *Vehicle.armed*, and *Vehicle.mode*).

The callback can be removed using *remove_attribute_listener()*.

Note: The *on_attribute()* decorator performs the same operation as this method, but with a more elegant syntax. Use *add_attribute_listener* by preference if you will need to remove the observer.

The argument list for the callback is *observer(object, attr_name, attribute_value)*:

- *self* - the associated *Vehicle*. This may be compared to a global vehicle handle to implement vehicle-specific callback handling (if needed).
- *attr_name* - the attribute name. This can be used to infer which attribute has triggered if the same callback is used for watching several attributes.
- *value* - the attribute value (so you don’t need to re-query the vehicle object).

The example below shows how to get callbacks for (global) location changes:

```
#Callback to print the location in global frame
def location_callback(self, attr_name, msg):
    print "Location (Global): ", msg

#Add observer for the vehicle's current location
vehicle.add_attribute_listener('global_frame', location_callback)
```

See *Observing attribute changes* for more information.

Parameters

- **attr_name** (*String*) – The name of the attribute to watch (or ‘*’ to watch all attributes).
- **observer** – The callback to invoke when a change in the attribute is detected.

global_frame

Location in global frame (a *LocationGlobal*).

The latitude and longitude are relative to the *WGS84 coordinate system*. The altitude is relative to mean sea-level (MSL).

This is accessed through the *Vehicle.location* attribute:

```
print "Global Location: %s" % vehicle.location.global_frame
print "Sea level altitude is: %s" % vehicle.location.global_frame.alt
```

Its `lat` and `lon` attributes are populated shortly after GPS becomes available. The `alt` can take several seconds longer to populate (from the barometer). Listeners are not notified of changes to this attribute until it has fully populated.

To watch for changes you can use `Vehicle.on_attribute()` decorator or `add_attribute_listener()` (decorator approach shown below):

```
@vehicle.on_attribute('location.global_frame')
def listener(self, attr_name, value):
    print " Global: %s" % value

#Alternatively, use decorator: ``@vehicle.location.on_attribute('global_frame
↪')``.
```

global_relative_frame

Location in global frame, with altitude relative to the home location (a *LocationGlobalRelative*).

The latitude and longitude are relative to the WGS84 coordinate system. The altitude is relative to *home location*.

This is accessed through the `Vehicle.location` attribute:

```
print "Global Location (relative altitude): %s" % vehicle.location.global_
↪relative_frame
print "Altitude relative to home_location: %s" % vehicle.location.global_
↪relative_frame.alt
```

local_frame

Location in local NED frame (a *LocationGlobalRelative*).

This is accessed through the `Vehicle.location` attribute:

```
print "Local Location: %s" % vehicle.location.local_frame
```

This location will not start to update until the vehicle is armed.

notify_attribute_listeners (attr_name, value, cache=False)

This method is used to update attribute observers when the named attribute is updated.

You should call it in your message listeners after updating an attribute with information from a vehicle message.

By default the value of `cache` is `False` and every update from the vehicle is sent to listeners (whether or not the attribute has changed). This is appropriate for attributes which represent sensor or heartbeat-type monitoring.

Set `cache=True` to update listeners only when the value actually changes (cache the previous attribute value). This should be used where clients will only ever need to know the value when it has changed. For example, this setting has been used for notifying mode changes.

See *Example: Create Attribute in App* for more information.

Parameters

- **attr_name** (*String*) – The name of the attribute that has been updated.
- **value** – The current value of the attribute that has been updated.
- **cache** (*Boolean*) – Set `True` to only notify observers when the attribute value changes.

on_attribute (name)

Decorator for attribute listeners.

The decorated function (`observer`) is invoked differently depending on the *type of attribute*. Attributes that represent sensor values or which are used to monitor connection status are updated whenever a message is received from the vehicle. Attributes which reflect vehicle “state” are only updated when their values change (for example `Vehicle.system_status()`, `Vehicle.armed`, and `Vehicle.mode`).

The argument list for the callback is `observer(object, attr_name, attribute_value)`

- `self` - the associated `Vehicle`. This may be compared to a global vehicle handle to implement vehicle-specific callback handling (if needed).
- `attr_name` - the attribute name. This can be used to infer which attribute has triggered if the same callback is used for watching several attributes.
- `msg` - the attribute value (so you don’t need to re-query the vehicle object).

Note: There is no way to remove an attribute listener added with this decorator. Use `add_attribute_listener()` if you need to be able to remove the `attribute listener`.

The code fragment below shows how you can create a listener for the attitude attribute.

```
@vehicle.on_attribute('attitude')
def attitude_listener(self, name, msg):
    print '%s attribute is: %s' % (name, msg)
```

See [Observing attribute changes](#) for more information.

Parameters

- **name** (*String*) – The name of the attribute to watch (or ‘*’ to watch all attributes).
- **observer** – The callback to invoke when a change in the attribute is detected.

remove_attribute_listener (*attr_name, observer*)

Remove an attribute listener (`observer`) that was previously added using `add_attribute_listener()`.

For example, the following line would remove a previously added vehicle ‘global_frame’ observer called `location_callback`:

```
vehicle.remove_attribute_listener('global_frame', location_callback)
```

See [Observing attribute changes](#) for more information.

Parameters

- **attr_name** (*String*) – The attribute name that is to have an observer removed (or ‘*’ to remove an ‘all attribute’ observer).
- **observer** – The callback function to remove.

class `dronekit.Parameters` (*vehicle*)

This object is used to get and set the values of named parameters for a vehicle. See the following links for information about the supported parameters for each platform: [Copter Parameters](#), [Plane Parameters](#), [Rover Parameters](#).

The code fragment below shows how to get and set the value of a parameter.

```
# Print the value of the THR_MIN parameter.
print "Param: %s" % vehicle.parameters['THR_MIN']
```

(continues on next page)

(continued from previous page)

```
# Change the parameter value to something different.
vehicle.parameters['THR_MIN']=100
```

It is also possible to observe parameters and to iterate the `Vehicle.parameters`.

For more information see [the guide](#).

add_attribute_listener (*attr_name*, *args, **kwargs)

Add a listener callback on a particular parameter.

The callback can be removed using `remove_attribute_listener()`.

Note: The `on_attribute()` decorator performs the same operation as this method, but with a more elegant syntax. Use `add_attribute_listener` only if you will need to remove the observer.

The callback function is invoked only when the parameter changes.

The callback arguments are:

- `self` - the associated `Parameters`.
- `attr_name` - the parameter name. This can be used to infer which parameter has triggered if the same callback is used for watching multiple parameters.
- `msg` - the new parameter value (so you don't need to re-query the vehicle object).

The example below shows how to get callbacks for the `THR_MIN` parameter:

```
#Callback function for the THR_MIN parameter
def thr_min_callback(self, attr_name, value):
    print " PARAMETER CALLBACK: %s changed to: %s" % (attr_name, value)

#Add observer for the vehicle's THR_MIN parameter
vehicle.parameters.add_attribute_listener('THR_MIN', thr_min_callback)
```

See [Observing parameter changes](#) for more information.

Parameters

- **attr_name** (*String*) – The name of the parameter to watch (or '*' to watch all parameters).
- **args** – The callback to invoke when a change in the parameter is detected.

clear () → None. Remove all items from D.

get (*k*, *d*) → D[k] if k in D, else d. d defaults to None.

items () → a set-like object providing a view on D's items

keys () → a set-like object providing a view on D's keys

notify_attribute_listeners (*attr_name*, *args, **kwargs)

This method is used to update attribute observers when the named attribute is updated.

You should call it in your message listeners after updating an attribute with information from a vehicle message.

By default the value of `cache` is `False` and every update from the vehicle is sent to listeners (whether or not the attribute has changed). This is appropriate for attributes which represent sensor or heartbeat-type monitoring.

Set `cache=True` to update listeners only when the value actually changes (cache the previous attribute value). This should be used where clients will only ever need to know the value when it has changed. For example, this setting has been used for notifying mode changes.

See [Example: Create Attribute in App](#) for more information.

Parameters

- **attr_name** (*String*) – The name of the attribute that has been updated.
- **value** – The current value of the attribute that has been updated.
- **cache** (*Boolean*) – Set `True` to only notify observers when the attribute value changes.

on_attribute (*attr_name, *args, **kwargs*)

Decorator for parameter listeners.

Note: There is no way to remove a listener added with this decorator. Use [add_attribute_listener\(\)](#) if you need to be able to remove the [listener](#).

The callback function is invoked only when the parameter changes.

The callback arguments are:

- `self` - the associated [Parameters](#).
- `attr_name` - the parameter name. This can be used to infer which parameter has triggered if the same callback is used for watching multiple parameters.
- `msg` - the new parameter value (so you don't need to re-query the vehicle object).

The code fragment below shows how to get callbacks for the `THR_MIN` parameter:

```
@vehicle.parameters.on_attribute('THR_MIN')
def decorated_thr_min_callback(self, attr_name, value):
    print " PARAMETER CALLBACK: %s changed to: %s" % (attr_name, value)
```

See [Observing parameter changes](#) for more information.

Parameters

- **attr_name** (*String*) – The name of the parameter to watch (or `*` to watch all parameters).
- **args** – The callback to invoke when a change in the parameter is detected.

pop (*k[, d]*) → *v*, remove specified key and return the corresponding value.

If key is not found, *d* is returned if given, otherwise `KeyError` is raised.

popitem () → (*k, v*), remove and return some (key, value) pair
as a 2-tuple; but raise `KeyError` if *D* is empty.

remove_attribute_listener (*attr_name, *args, **kwargs*)

Remove a parameter listener that was previously added using [add_attribute_listener\(\)](#).

For example to remove the `thr_min_callback()` callback function:

```
vehicle.parameters.remove_attribute_listener('thr_min', thr_min_callback)
```

See [Observing parameter changes](#) for more information.

Parameters

- **attr_name** (*String*) – The parameter name that is to have an observer removed (or '*' to remove an 'all attribute' observer).
- **args** – The callback function to remove.

setdefault (*k*, *d*) → *D.get(k,d)*, also set *D[k]=d* if *k* not in *D*

update (*[E]*, ***F*) → *None*. Update *D* from mapping/iterable *E* and *F*.

If *E* present and has a *.keys()* method, does: for *k* in *E*: *D[k] = E[k]* If *E* present and lacks *.keys()* method, does: for (*k*, *v*) in *E*: *D[k] = v* In either case, this is followed by: for *k*, *v* in *F.items()*: *D[k] = v*

values () → an object providing a view on *D*'s values

wait_ready (***kwargs*)

Block the calling thread until parameters have been downloaded

class `dronekit.Rangefinder` (*distance*, *voltage*)

Rangefinder readings.

An object of this type is returned by `Vehicle.rangefinder`.

Parameters

- **distance** – Distance (metres). *None* if the vehicle doesn't have a rangefinder.
- **voltage** – Voltage (volts). *None* if the vehicle doesn't have a rangefinder.

class `dronekit.SystemStatus` (*state*)

This object is used to get and set the current "system status".

An object of this type is returned by `Vehicle.system_status`.

state

The system state, as a string.

exception `dronekit.TimeoutError`

Raised by operations that have timeouts.

with_traceback ()

Exception.with_traceback(tb) – set self.__traceback__ to tb and return self.

class `dronekit.Vehicle` (*handler*)

The main vehicle API.

Vehicle state is exposed through 'attributes' (e.g. `heading`). All attributes can be read, and some are also settable (`mode`, `armed` and `home_location`).

Attributes can also be asynchronously monitored for changes by registering listener callback functions.

Vehicle "settings" (parameters) are read/set using the `parameters` attribute. Parameters can be iterated and are also individually observable.

Vehicle movement is primarily controlled using the `armed` attribute and `simple_takeoff()` and `simple_goto()` in GUIDED mode.

It is also possible to work with vehicle "missions" using the `commands` attribute, and run them in AUTO mode.

STATUSTEXT log messages from the autopilot are handled through a separate logger. It is possible to configure the log level, the formatting, etc. by accessing the logger, e.g.:

```
import logging
autopilot_logger = logging.getLogger('autopilot')
autopilot_logger.setLevel(logging.DEBUG)
```

The guide contains more detailed information on the different ways you can use the `Vehicle` class:

- *Vehicle State and Settings*
- *Guiding and Controlling Copter*
- *Missions (AUTO Mode)*

Note: This class currently exposes just the attributes that are most commonly used by all vehicle types. if you need to add additional attributes then subclass `Vehicle` as demonstrated in *Example: Create Attribute in App*.

Please then *contribute* your additions back to the project!

add_attribute_listener (*attr_name*, *observer*)

Add an attribute listener callback.

The callback function (*observer*) is invoked differently depending on the *type of attribute*. Attributes that represent sensor values or which are used to monitor connection status are updated whenever a message is received from the vehicle. Attributes which reflect vehicle “state” are only updated when their values change (for example `Vehicle.system_status`, `Vehicle.armed`, and `Vehicle.mode`).

The callback can be removed using `remove_attribute_listener()`.

Note: The `on_attribute()` decorator performs the same operation as this method, but with a more elegant syntax. Use `add_attribute_listener` by preference if you will need to remove the observer.

The argument list for the callback is `observer(object, attr_name, attribute_value)`:

- `self` - the associated *Vehicle*. This may be compared to a global vehicle handle to implement vehicle-specific callback handling (if needed).
- `attr_name` - the attribute name. This can be used to infer which attribute has triggered if the same callback is used for watching several attributes.
- `value` - the attribute value (so you don’t need to re-query the vehicle object).

The example below shows how to get callbacks for (global) location changes:

```
#Callback to print the location in global frame
def location_callback(self, attr_name, msg):
    print "Location (Global): ", msg

#Add observer for the vehicle's current location
vehicle.add_attribute_listener('global_frame', location_callback)
```

See *Observing attribute changes* for more information.

Parameters

- **attr_name** (*String*) – The name of the attribute to watch (or ‘*’ to watch all attributes).
- **observer** – The callback to invoke when a change in the attribute is detected.

add_message_listener (*name*, *fn*)

Adds a message listener function that will be called every time the specified message is received.

Tip: We recommend you use `on_message()` instead of this method as it has a more elegant syntax. This method is only preferred if you need to be able to *remove the listener*.

The callback function must have three arguments:

- `self` - the current vehicle.
- `name` - the name of the message that was intercepted.
- `message` - the actual message (a [pymavlink class](#)).

For example, in the fragment below `my_method` will be called for every heartbeat message:

```
#Callback method for new messages
def my_method(self, name, msg):
    pass

vehicle.add_message_listener('HEARTBEAT', my_method)
```

See [MAVLink Messages](#) for more information.

Parameters

- **name** (*String*) – The name of the message to be intercepted by the listener function (or '*' to get all messages).
- **fn** – The listener function that will be called if a message is received.

airspeed

Current airspeed in metres/second (double).

This attribute is settable. The set value is the default target airspeed when moving the vehicle using [simple_goto\(\)](#) (or other position-based movement commands).

arm(*wait=True, timeout=None*)

Arm the vehicle.

If `wait` is `True`, wait for arm operation to complete before returning. If `timeout` is nonzero, raise a `TimeoutError` if the vehicle has not armed after timeout seconds.

armed

This attribute can be used to get and set the armed state of the vehicle (boolean).

The code below shows how to read the state, and to arm/disarm the vehicle:

```
# Print the armed state for the vehicle
print "Armed: %s" % vehicle.armed

# Disarm the vehicle
vehicle.armed = False

# Arm the vehicle
vehicle.armed = True
```

attitude

Current vehicle attitude - pitch, yaw, roll ([Attitude](#)).

battery

Current system battery status ([Battery](#)).

capabilities

The autopilot capabilities in a [Capabilities](#) object.

New in version 2.0.3.

channels

The RC channel values from the RC Transmitter ([Channels](#)).

The attribute can also be used to set and read RC Override (channel override) values via `Vehicle.channels.override`.

For more information and examples see [Example: Channels and Channel Overrides](#).

To read the channels from the RC transmitter:

```
# Get all channel values from RC transmitter
print "Channel values from RC Tx:", vehicle.channels

# Access channels individually
print "Read channels individually:"
print " Ch1: %s" % vehicle.channels['1']
print " Ch2: %s" % vehicle.channels['2']
```

commands

Gets the editable waypoints/current mission for this vehicle (`CommandSequence`).

This can be used to get, create, and modify a mission.

Returns A `CommandSequence` containing the waypoints for this vehicle.

disarm (wait=True, timeout=None)

Disarm the vehicle.

If wait is True, wait for disarm operation to complete before returning. If timeout is nonzero, raise a `TimeoutError` if the vehicle has not disarmed after timeout seconds.

ekf_ok

True if the EKF status is considered acceptable, False otherwise (boolean).

flush()

Call `flush()` after *adding* or *clearing* mission commands.

After the return from `flush()` any writes are guaranteed to have completed (or thrown an exception) and future reads will see their effects.

Warning: This method is deprecated. It has been replaced by `Vehicle.commands.upload()`.

gimbal

Gimbal object for controlling, viewing and observing gimbal status (`Gimbal`).

New in version 2.0.1.

gps_0

GPS position information (`GPSInfo`).

groundspeed

Current groundspeed in metres/second (double).

This attribute is settable. The set value is the default target groundspeed when moving the vehicle using `simple_goto()` (or other position-based movement commands).

heading

Current heading in degrees - 0..360, where North = 0 (int).

home_location

The current home location (`LocationGlobal`).

To get the attribute you must first download the `Vehicle.commands()`. The attribute has a value of `None` until `Vehicle.commands()` has been downloaded **and** the autopilot has set an initial home location (typically where the vehicle first gets GPS lock).

```
#Connect to a vehicle object (for example, on com14)
vehicle = connect('com14', wait_ready=True)

# Download the vehicle waypoints (commands). Wait until download is complete.
cmds = vehicle.commands
cmds.download()
cmds.wait_ready()

# Get the home location
home = vehicle.home_location
```

The `home_location` is not observable.

The attribute can be written (in the same way as any other attribute) after it has successfully been populated from the vehicle. The value sent to the vehicle is cached in the attribute (and can potentially get out of date if you don't re-download `Vehicle.commands`):

Warning: Setting the value will fail silently if the specified location is more than 50km from the EKF origin.

`is_armable`

Returns `True` if the vehicle is ready to arm, `false` otherwise (Boolean).

This attribute wraps a number of pre-arm checks, ensuring that the vehicle has booted, has a good GPS fix, and that the EKF pre-arm is complete.

`last_heartbeat`

Time since last MAVLink heartbeat was received (in seconds).

The attribute can be used to monitor link activity and implement script-specific timeout handling.

For example, to pause the script if no heartbeat is received for more than 1 second you might implement the following observer, and use `pause_script` in a program loop to wait until the link is recovered:

```
pause_script=False

@vehicle.on_attribute('last_heartbeat')
def listener(self, attr_name, value):
    global pause_script
    if value > 1 and not pause_script:
        print "Pausing script due to bad link"
        pause_script=True;
    if value < 1 and pause_script:
        pause_script=False;
        print "Un-pausing script"
```

The observer will be called at the period of the messaging loop (about every 0.01 seconds). Testing on SITL indicates that `last_heartbeat` averages about .5 seconds, but will rarely exceed 1.5 seconds when connected. Whether heartbeat monitoring can be useful will very much depend on the application.

Note: If you just want to change the heartbeat timeout you can modify the `heartbeat_timeout` parameter passed to the `connect()` function.

location

The vehicle location in global, global relative and local frames (*Locations*).

The different frames are accessed through its members:

- `global_frame` (*LocationGlobal*)
- `global_relative_frame` (*LocationGlobalRelative*)
- `local_frame` (*LocationLocal*)

For example, to print the location in each frame for a vehicle:

```
# Print location information for `vehicle` in all frames (default printer)
print "Global Location: %s" % vehicle.location.global_frame
print "Global Location (relative altitude): %s" % vehicle.location.global_
↪relative_frame
print "Local Location: %s" % vehicle.location.local_frame      #NED

# Print altitudes in the different frames (see class definitions for other_
↪available information)
print "Altitude (global frame): %s" % vehicle.location.global_frame.alt
print "Altitude (global relative frame): %s" % vehicle.location.global_
↪relative_frame.alt
print "Altitude (NED frame): %s" % vehicle.location.local_frame.down
```

Note: All the location “values” (e.g. `global_frame.lat`) are initially created with value `None`. The `global_frame`, `global_relative_frame` latitude and longitude values are populated shortly after initialisation but `global_frame.alt` may take a few seconds longer to be updated. The `local_frame` does not populate until the vehicle is armed.

The attribute and its members are observable. To watch for changes in all frames using a listener created using a decorator (you can also define a listener and explicitly add it).

```
@vehicle.on_attribute('location')
def listener(self, attr_name, value):
    # `self`: :py:class:`Vehicle` object that has been updated.
    # `attr_name`: name of the observed attribute - 'location'
    # `value` is the updated attribute value (a :py:class:`Locations`). This_
    ↪can be queried for the frame information
    print " Global: %s" % value.global_frame
    print " GlobalRelative: %s" % value.global_relative_frame
    print " Local: %s" % value.local_frame
```

To watch for changes in just one attribute (in this case `global_frame`):

```
@vehicle.on_attribute('location.global_frame')
def listener(self, attr_name, value):
    # `self`: :py:class:`Locations` object that has been updated.
    # `attr_name`: name of the observed attribute - 'global_frame'
    # `value` is the updated attribute value.
    print " Global: %s" % value

#Or watch using decorator: ``@vehicle.location.on_attribute('global_frame')``.
```

message_factory

Returns an object that can be used to create ‘raw’ MAVLink messages that are appropriate for this vehicle. The message can then be sent using `send_mavlink(message)`.

Note: Vehicles support a subset of the messages defined in the MAVLink standard. For more information about the supported sets see wiki topics: [Copter Commands in Guided Mode](#) and [Plane Commands in Guided Mode](#).

All message types are defined in the central MAVLink github repository. For example, a Pixhawk understands the following messages (from `pixhawk.xml`):

```
<message id="153" name="IMAGE_TRIGGER_CONTROL">
  <field type="uint8_t" name="enable">0 to disable, 1 to enable</field>
</message>
```

The name of the factory method will always be the lower case version of the message name with `_encode` appended. Each field in the XML message definition must be listed as arguments to this factory method. So for this example message, the call would be:

```
msg = vehicle.message_factory.image_trigger_control_encode(True)
vehicle.send_mavlink(msg)
```

Some message types include “addressing information”. If present, there is no need to specify the `target_system` id (just set to zero) as DroneKit will automatically update messages with the correct ID for the connected vehicle before sending. The `target_component` should be set to 0 (broadcast) unless the message is to specific component. CRC fields and sequence numbers (if defined in the message type) are automatically set by DroneKit and can also be ignored/set to zero.

For more information see the guide topic: [Sending messages/commands](#).

mode

This attribute is used to get and set the current flight mode. You can specify the value as a `VehicleMode`, like this:

```
vehicle.mode = VehicleMode('LOITER')
```

Or as a simple string:

```
vehicle.mode = 'LOITER'
```

If you are targeting ArduPilot you can also specify the flight mode using a numeric value (this will not work with PX4 autopilots):

```
# set mode to LOITER
vehicle.mode = 5
```

mount_status

Warning: This method is deprecated. It has been replaced by `gimbal`.

Current status of the camera mount (gimbal) as a three element list: [`pitch`, `yaw`, `roll`].

The values in the list are set to `None` if no mount is configured.

notify_attribute_listeners(*attr_name*, *value*, *cache=False*)

This method is used to update attribute observers when the named attribute is updated.

You should call it in your message listeners after updating an attribute with information from a vehicle message.

By default the value of `cache` is `False` and every update from the vehicle is sent to listeners (whether or not the attribute has changed). This is appropriate for attributes which represent sensor or heartbeat-type monitoring.

Set `cache=True` to update listeners only when the value actually changes (cache the previous attribute value). This should be used where clients will only ever need to know the value when it has changed. For example, this setting has been used for notifying *mode* changes.

See *Example: Create Attribute in App* for more information.

Parameters

- **attr_name** (*String*) – The name of the attribute that has been updated.
- **value** – The current value of the attribute that has been updated.
- **cache** (*Boolean*) – Set `True` to only notify observers when the attribute value changes.

`on_attribute` (*name*)

Decorator for attribute listeners.

The decorated function (*observer*) is invoked differently depending on the *type of attribute*. Attributes that represent sensor values or which are used to monitor connection status are updated whenever a message is received from the vehicle. Attributes which reflect vehicle “state” are only updated when their values change (for example `Vehicle.system_status()`, `Vehicle.armed`, and `Vehicle.mode`).

The argument list for the callback is `observer(object, attr_name, attribute_value)`

- `self` - the associated *Vehicle*. This may be compared to a global vehicle handle to implement vehicle-specific callback handling (if needed).
- `attr_name` - the attribute name. This can be used to infer which attribute has triggered if the same callback is used for watching several attributes.
- `msg` - the attribute value (so you don’t need to re-query the vehicle object).

Note: There is no way to remove an attribute listener added with this decorator. Use `add_attribute_listener()` if you need to be able to remove the *attribute listener*.

The code fragment below shows how you can create a listener for the attitude attribute.

```
@vehicle.on_attribute('attitude')
def attitude_listener(self, name, msg):
    print '%s attribute is: %s' % (name, msg)
```

See *Observing attribute changes* for more information.

Parameters

- **name** (*String*) – The name of the attribute to watch (or `*` to watch all attributes).
- **observer** – The callback to invoke when a change in the attribute is detected.

`on_message` (*name*)

Decorator for message listener callback functions.

Tip: This is the most elegant way to define message listener callback functions. Use `add_message_listener()` only if you need to be able to *remove the listener* later.

A decorated message listener function is called with three arguments every time the specified message is received:

- `self` - the current vehicle.
- `name` - the name of the message that was intercepted.
- `message` - the actual message (a [pymavlink class](#)).

For example, in the fragment below `my_method` will be called for every heartbeat message:

```
@vehicle.on_message('HEARTBEAT')
def my_method(self, name, msg):
    pass
```

See [MAVLink Messages](#) for more information.

Parameters `name` (*String*) – The name of the message to be intercepted by the decorated listener function (or `*` to get all messages).

parameters

The (editable) parameters for this vehicle ([Parameters](#)).

play_tune (*tune*)

Play a tune on the vehicle

rangefinder

Rangefinder distance and voltage values ([Rangefinder](#)).

reboot ()

Requests an autopilot reboot by sending a MAV_CMD_PREFLIGHT_REBOOT_SHUTDOWN command.

remove_attribute_listener (*attr_name, observer*)

Remove an attribute listener (observer) that was previously added using [add_attribute_listener\(\)](#).

For example, the following line would remove a previously added vehicle `'global_frame'` observer called `location_callback`:

```
vehicle.remove_attribute_listener('global_frame', location_callback)
```

See [Observing attribute changes](#) for more information.

Parameters

- **attr_name** (*String*) – The attribute name that is to have an observer removed (or `*` to remove an 'all attribute' observer).
- **observer** – The callback function to remove.

remove_message_listener (*name, fn*)

Removes a message listener (that was previously added using [add_message_listener\(\)](#)).

See [MAVLink Messages](#) for more information.

Parameters

- **name** (*String*) – The name of the message for which the listener is to be removed (or `*` to remove an 'all messages' observer).
- **fn** – The listener callback function to remove.

send_calibrate_accelerometer (*simple=False*)

Request accelerometer calibration.

Parameters **simple** – if True, perform simple accelerometer calibration

send_calibrate_barometer()

Request barometer calibration.

send_calibrate_gyro()

Request gyroscope calibration.

send_calibrate_magnetometer()

Request magnetometer calibration.

send_calibrate_vehicle_level()

Request vehicle level (accelerometer trim) calibration.

send_capabilities_request(vehicle, name, m)

Request an AUTOPILOT_VERSION packet

send_capabilities_request(vehicle, name, m)

An alias for `send_capabilities_request`.

The word “capabilities” was misspelled in previous versions of this code. This is simply an alias to `send_capabilities_request` using the legacy name.

send_mavlink(message)

This method is used to send raw MAVLink “custom messages” to the vehicle.

The function can send arbitrary messages/commands to the connected vehicle at any time and in any vehicle mode. It is particularly useful for controlling vehicles outside of missions (for example, in GUIDED mode).

The `message_factory` is used to create messages in the appropriate format.

For more information see the guide topic: *[Sending messages/commands](#)*.

Parameters **message** – A `MAVLink_message` instance, created using `message_factory`. There is need to specify the system id, component id or sequence number of messages as the API will set these appropriately.

simple_goto(location, airspeed=None, groundspeed=None)

Go to a specified global location (`LocationGlobal` or `LocationGlobalRelative`).

There is no mechanism for notification when the target location is reached, and if another command arrives before that point that will be executed immediately.

You can optionally set the desired airspeed or groundspeed (this is identical to setting `airspeed` or `groundspeed`). The vehicle will determine what speed to use if the values are not set or if they are both set.

The method will change the `VehicleMode` to GUIDED if necessary.

```
# Set mode to guided - this is optional as the simple_goto method will change_
↳the mode if needed.
vehicle.mode = VehicleMode("GUIDED")

# Set the LocationGlobal to head towards
a_location = LocationGlobal(-34.364114, 149.166022, 30)
vehicle.simple_goto(a_location)
```

Parameters

- **location** – The target location (`LocationGlobal` or `LocationGlobalRelative`).

- **airspeed** – Target airspeed in m/s (optional).
- **groundspeed** – Target groundspeed in m/s (optional).

simple_takeoff (*alt=None*)

Take off and fly the vehicle to the specified altitude (in metres) and then wait for another command.

Note: This function should only be used on Copter vehicles.

The vehicle must be in GUIDED mode and armed before this is called.

There is no mechanism for notification when the correct altitude is reached, and if another command arrives before that point (e.g. `simple_goto()`) it will be run instead.

Warning: Apps should code to ensure that the vehicle will reach a safe altitude before other commands are executed. A good example is provided in the guide topic *Taking Off*.

Parameters **alt** – Target height, in metres.

system_status

System status (*SystemStatus*).

The status has a `state` property with one of the following values:

- UNINIT: Uninitialized system, state is unknown.
- BOOT: System is booting up.
- CALIBRATING: System is calibrating and not flight-ready.
- STANDBY: System is grounded and on standby. It can be launched any time.
- ACTIVE: System is active and might be already airborne. Motors are engaged.
- CRITICAL: System is in a non-normal flight mode. It can however still navigate.
- EMERGENCY: System is in a non-normal flight mode. It lost control over parts or over the whole airframe. It is in mayday and going down.
- POWEROFF: System just initialized its power-down sequence, will shut down now.

velocity

Current velocity as a three element list [`vx`, `vy`, `vz`] (in meter/sec).

version

The autopilot version and type in a *Version* object.

New in version 2.0.3.

wait_for (*condition*, *timeout=None*, *interval=0.1*, *errmsg=None*)

Wait for a condition to be True.

Wait for condition, a callable, to return True. If timeout is nonzero, raise a `TimeoutError(errmsg)` if the condition is not True after timeout seconds. Check the condition every interval seconds.

wait_for_alt (*alt*, *epsilon=0.1*, *rel=True*, *timeout=None*)

Wait for the vehicle to reach the specified altitude.

Wait for the vehicle to get within epsilon meters of the given altitude. If `rel` is `True` (the default), use the `global_relative_frame`. If `rel` is `False`, use the `global_frame`. If `timeout` is nonzero, raise a `TimeoutError` if the specified altitude has not been reached after `timeout` seconds.

wait_for_armable (*timeout=None*)

Wait for the vehicle to become armable.

If `timeout` is nonzero, raise a `TimeoutError` if the vehicle is not armable after `timeout` seconds.

wait_for_mode (*mode, timeout=None*)

Set the flight mode.

If `wait` is `True`, wait for the mode to change before returning. If `timeout` is nonzero, raise a `TimeoutError` if the flight mode hasn't changed after `timeout` seconds.

wait_ready (**types, **kwargs*)

Waits for specified attributes to be populated from the vehicle (values are initially `None`).

This is typically called “behind the scenes” to ensure that `connect()` does not return until attributes have populated (via the `wait_ready` parameter). You can also use it after connecting to wait on a specific value(s).

There are two ways to call the method:

```
#Wait on default attributes to populate
vehicle.wait_ready(True)

#Wait on specified attributes (or array of attributes) to populate
vehicle.wait_ready('mode', 'airspeed')
```

Using the `wait_ready(True)` waits on `parameters`, `gps_0`, `armed`, `mode`, and `attitude`. In practice this usually means that all supported attributes will be populated.

By default, the method will timeout after 30 seconds and raise an exception if the attributes were not populated.

Parameters

- **types** – `True` to wait on the default set of attributes, or a comma-separated list of the specific attributes to wait on.
- **timeout** (*int*) – Timeout in seconds after which the method will raise an exception (the default) or return `False`. The default timeout is 30 seconds.
- **raise_exception** (*Boolean*) – If `True` the method will raise an exception on timeout, otherwise the method will return `False`. The default is `True` (raise exception).

class `dronekit.VehicleMode` (*name*)

This object is used to get and set the current “flight mode”.

The flight mode determines the behaviour of the vehicle and what commands it can obey. The recommended flight modes for *DroneKit-Python* apps depend on the vehicle type:

- Copter apps should use `AUTO` mode for “normal” waypoint missions and `GUIDED` mode otherwise.
- Plane and Rover apps should use the `AUTO` mode in all cases, re-writing the mission commands if “dynamic” behaviour is required (they support only a limited subset of commands in `GUIDED` mode).
- Some modes like `RETURN_TO_LAUNCH` can be used on all platforms. Care should be taken when using manual modes as these may require remote control input from the user.

The available set of supported flight modes is vehicle-specific (see [Copter Modes](#), [Plane Modes](#), [Rover Modes](#)). If an unsupported mode is set the script will raise a `KeyError` exception.

The `Vehicle.mode` attribute can be queried for the current mode. The code snippet below shows how to observe changes to the mode and then read the value:

```
#Callback definition for mode observer
def mode_callback(self, attr_name):
    print "Vehicle Mode", self.mode

#Add observer callback for attribute `mode`
vehicle.add_attribute_listener('mode', mode_callback)
```

The code snippet below shows how to change the vehicle mode to AUTO:

```
# Set the vehicle into auto mode
vehicle.mode = VehicleMode("AUTO")
```

For more information on getting/setting/observing the `Vehicle.mode` (and other attributes) see the [attributes guide](#).

name

The mode name, as a string.

class `dronekit.Version` (*raw_version*, *autopilot_type*, *vehicle_type*)

Autopilot version and type.

An object of this type is returned by `Vehicle.version`.

The version number can be read in a few different formats. To get it in a human-readable format, just print `vehicle.version`. This might print something like “APM:Copter-3.3.2-rc4”.

New in version 2.0.3.

major

Major version number (integer).

patch

Patch version number (integer).

release

Release type (integer). See the enum `FIRMWARE_VERSION_TYPE`.

This is a composite of the product release cycle stage (rc, beta etc) and the version in that cycle - e.g. 23.

is_stable()

Returns True if the autopilot reports that the current firmware is a stable release (not a pre-release or development version).

release_type()

Returns text describing the release type e.g. “alpha”, “stable” etc.

release_version()

Returns the version within the release type (an integer). This method returns “23” for Copter-3.3rc23.

```
dronekit.connect(ip, _initialize=True, wait_ready=None, timeout=30,
                 still_waiting_callback=<function default_still_waiting_callback>,
                 still_waiting_interval=1, status_printer=None, vehicle_class=None, rate=4,
                 baud=115200, heartbeat_timeout=30, source_system=255, source_component=0,
                 use_native=False)
```

Returns a `Vehicle` object connected to the address specified by string parameter `ip`. Connection string parameters (`ip`) for different targets are listed in the [getting started guide](#).

The method is usually called with `wait_ready=True` to ensure that vehicle parameters and (most) attributes are available when `connect()` returns.

```
from dronekit import connect

# Connect to the Vehicle using "connection string" (in this case an address on_
↪network)
vehicle = connect('127.0.0.1:14550', wait_ready=True)
```

Parameters

- **ip** (*String*) – *Connection string* for target address - e.g. 127.0.0.1:14550.
- **wait_ready** (*Bool/Array*) – If True wait until all default attributes have downloaded before the method returns (default is None). The default attributes to wait on are: parameters, gps_0, armed, mode, and attitude.

You can also specify a named set of parameters to wait on (e.g. `wait_ready=['system_status', 'mode']`).

For more information see *Vehicle.wait_ready*.

- **status_printer** – (deprecated) method of signature `def status_printer(txt)` that prints STATUS_TEXT messages from the Vehicle and other diagnostic information. By default the status information is handled by the autopilot logger.
- **vehicle_class** (*Vehicle*) – The class that will be instantiated by the `connect()` method. This can be any sub-class of *Vehicle* (and defaults to *Vehicle*).
- **rate** (*int*) – Data stream refresh rate. The default is 4Hz (4 updates per second).
- **baud** (*int*) – The baud rate for the connection. The default is 115200.
- **heartbeat_timeout** (*int*) – Connection timeout value in seconds (default is 30s). If a heartbeat is not detected within this time an exception will be raised.
- **source_system** (*int*) – The MAVLink ID of the *Vehicle* object returned by this method (by default 255).
- **source_component** (*int*) – The MAVLink Component ID for the *Vehicle* object returned by this method (by default 0).
- **use_native** (*bool*) – Use precompiled MAVLink parser.

Note: The returned *Vehicle* object acts as a ground control station from the perspective of the connected “real” vehicle. It will process/receive messages from the real vehicle if they are addressed to this `source_system` id. Messages sent to the real vehicle are automatically updated to use the vehicle’s `target_system` id.

It is *good practice* to assign a unique id for every system on the MAVLink network. It is possible to configure the autopilot to only respond to guided-mode commands from a specified GCS ID.

The `status_printer` argument is deprecated. To redirect the logging from the library and from the autopilot, configure the `dronekit` and `autopilot` loggers using the Python logging module.

Returns A connected vehicle of the type defined in `vehicle_class` (a superclass of *Vehicle*).

d

dronekit, [149](#)

A

`add()` (*dronekit.CommandSequence* method), 154
`add_attribute_listener()` (*dronekit.Locations* method), 158
`add_attribute_listener()` (*dronekit.Parameters* method), 161
`add_attribute_listener()` (*dronekit.Vehicle* method), 164
`add_message_listener()` (*dronekit.Vehicle* method), 164
`airspeed` (*dronekit.Vehicle* attribute), 165
`APIException`, 149
`arm()` (*dronekit.Vehicle* method), 165
`armed` (*dronekit.Vehicle* attribute), 165
`Attitude` (class in *dronekit*), 149
`attitude` (*dronekit.Vehicle* attribute), 165

B

`Battery` (class in *dronekit*), 150
`battery` (*dronekit.Vehicle* attribute), 165

C

`Capabilities` (class in *dronekit*), 150
`capabilities` (*dronekit.Vehicle* attribute), 165
`Channels` (class in *dronekit*), 151
`channels` (*dronekit.Vehicle* attribute), 165
`ChannelsOverride` (class in *dronekit*), 152
`clear()` (*dronekit.Channels* method), 151
`clear()` (*dronekit.ChannelsOverride* method), 152
`clear()` (*dronekit.CommandSequence* method), 154
`clear()` (*dronekit.Parameters* method), 161
`Command` (class in *dronekit*), 153
`command_int` (*dronekit.Capabilities* attribute), 151
`commands` (*dronekit.Vehicle* attribute), 166
`CommandSequence` (class in *dronekit*), 154
`compass_calibration` (*dronekit.Capabilities* attribute), 151
`connect()` (in module *dronekit*), 175
`copy()` (*dronekit.Channels* method), 151

`copy()` (*dronekit.ChannelsOverride* method), 152
`count` (*dronekit.Channels* attribute), 151
`count` (*dronekit.CommandSequence* attribute), 155

D

`disarm()` (*dronekit.Vehicle* method), 166
`distance_home()` (*dronekit.LocationLocal* method), 157
`download()` (*dronekit.CommandSequence* method), 155
`dronekit` (module), 149

E

`ekf_ok` (*dronekit.Vehicle* attribute), 166

F

`flight_termination` (*dronekit.Capabilities* attribute), 151
`flush()` (*dronekit.Vehicle* method), 166
`format_attr()` (*dronekit.Command* method), 154
`fromkeys()` (*dronekit.Channels* method), 151
`fromkeys()` (*dronekit.ChannelsOverride* method), 152
`ftp` (*dronekit.Capabilities* attribute), 151

G

`get()` (*dronekit.Channels* method), 151
`get()` (*dronekit.ChannelsOverride* method), 152
`get()` (*dronekit.Parameters* method), 161
`Gimbal` (class in *dronekit*), 155
`gimbal` (*dronekit.Vehicle* attribute), 166
`global_frame` (*dronekit.Locations* attribute), 158
`global_relative_frame` (*dronekit.Locations* attribute), 159
`gps_0` (*dronekit.Vehicle* attribute), 166
`GPSInfo` (class in *dronekit*), 155
`groundspeed` (*dronekit.Vehicle* attribute), 166

H

`heading` (*dronekit.Vehicle* attribute), 166

`home_location` (*dronekit.Vehicle attribute*), 166

I

`is_armable` (*dronekit.Vehicle attribute*), 167
`is_stable`() (*dronekit.Version method*), 175
`items`() (*dronekit.Channels method*), 151
`items`() (*dronekit.ChannelsOverride method*), 152
`items`() (*dronekit.Parameters method*), 161

K

`keys`() (*dronekit.Channels method*), 151
`keys`() (*dronekit.ChannelsOverride method*), 153
`keys`() (*dronekit.Parameters method*), 161

L

`last_heartbeat` (*dronekit.Vehicle attribute*), 167
`local_frame` (*dronekit.Locations attribute*), 159
`location` (*dronekit.Vehicle attribute*), 167
`LocationGlobal` (*class in dronekit*), 156
`LocationGlobalRelative` (*class in dronekit*), 157
`LocationLocal` (*class in dronekit*), 157
`Locations` (*class in dronekit*), 157

M

`major` (*dronekit.Version attribute*), 175
`message_factory` (*dronekit.Vehicle attribute*), 168
`mission_float` (*dronekit.Capabilities attribute*), 150
`mission_int` (*dronekit.Capabilities attribute*), 151
`mode` (*dronekit.Vehicle attribute*), 169
`mount_status` (*dronekit.Vehicle attribute*), 169

N

`name` (*dronekit.VehicleMode attribute*), 175
`next` (*dronekit.CommandSequence attribute*), 155
`notify_attribute_listeners`()
 (*dronekit.Locations method*), 159
`notify_attribute_listeners`()
 (*dronekit.Parameters method*), 161
`notify_attribute_listeners`()
 (*dronekit.Vehicle method*), 169

O

`on_attribute`() (*dronekit.Locations method*), 159
`on_attribute`() (*dronekit.Parameters method*), 162
`on_attribute`() (*dronekit.Vehicle method*), 170
`on_message`() (*dronekit.Vehicle method*), 170
`overrides` (*dronekit.Channels attribute*), 151

P

`param_float` (*dronekit.Capabilities attribute*), 151
`param_union` (*dronekit.Capabilities attribute*), 151
`Parameters` (*class in dronekit*), 160
`parameters` (*dronekit.Vehicle attribute*), 171

`patch` (*dronekit.Version attribute*), 175
`pitch` (*dronekit.Gimbal attribute*), 156
`play_tune`() (*dronekit.Vehicle method*), 171
`pop`() (*dronekit.Channels method*), 152
`pop`() (*dronekit.ChannelsOverride method*), 153
`pop`() (*dronekit.Parameters method*), 162
`popitem`() (*dronekit.Channels method*), 152
`popitem`() (*dronekit.ChannelsOverride method*), 153
`popitem`() (*dronekit.Parameters method*), 162

R

`Rangefinder` (*class in dronekit*), 163
`rangefinder` (*dronekit.Vehicle attribute*), 171
`reboot`() (*dronekit.Vehicle method*), 171
`release` (*dronekit.Version attribute*), 175
`release`() (*dronekit.Gimbal method*), 156
`release_type`() (*dronekit.Version method*), 175
`release_version`() (*dronekit.Version method*), 175
`remove_attribute_listener`()
 (*dronekit.Locations method*), 160
`remove_attribute_listener`()
 (*dronekit.Parameters method*), 162
`remove_attribute_listener`()
 (*dronekit.Vehicle method*), 171
`remove_message_listener`() (*dronekit.Vehicle method*), 171
`roll` (*dronekit.Gimbal attribute*), 156
`rotate`() (*dronekit.Gimbal method*), 156

S

`send_calibrate_accelerometer`()
 (*dronekit.Vehicle method*), 171
`send_calibrate_barometer`() (*dronekit.Vehicle method*), 172
`send_calibrate_gyro`() (*dronekit.Vehicle method*), 172
`send_calibrate_magnetometer`()
 (*dronekit.Vehicle method*), 172
`send_calibrate_vehicle_level`()
 (*dronekit.Vehicle method*), 172
`send_capabilities_request`()
 (*dronekit.Vehicle method*), 172
`send_capabilities_request`() (*dronekit.Vehicle method*), 172
`send_mavlink`() (*dronekit.Vehicle method*), 172
`set_actuator_target` (*dronekit.Capabilities attribute*), 151
`set_altitude_target_global_int`
 (*dronekit.Capabilities attribute*), 151
`set_attitude_target` (*dronekit.Capabilities attribute*), 151
`set_attitude_target_local_ned`
 (*dronekit.Capabilities attribute*), 151
`setdefault`() (*dronekit.Channels method*), 152

`setdefault()` (*dronekit.ChannelsOverride method*),
153
`setdefault()` (*dronekit.Parameters method*), 163
`simple_goto()` (*dronekit.Vehicle method*), 172
`simple_takeoff()` (*dronekit.Vehicle method*), 173
`state` (*dronekit.SystemStatus attribute*), 163
`system_status` (*dronekit.Vehicle attribute*), 173
`SystemStatus` (*class in dronekit*), 163

T

`target_location()` (*dronekit.Gimbal method*), 156
`terrain` (*dronekit.Capabilities attribute*), 151
`TimeoutError`, 163

U

`update()` (*dronekit.Channels method*), 152
`update()` (*dronekit.ChannelsOverride method*), 153
`update()` (*dronekit.Parameters method*), 163
`upload()` (*dronekit.CommandSequence method*), 155

V

`values()` (*dronekit.Channels method*), 152
`values()` (*dronekit.ChannelsOverride method*), 153
`values()` (*dronekit.Parameters method*), 163
`Vehicle` (*class in dronekit*), 163
`VehicleMode` (*class in dronekit*), 174
`velocity` (*dronekit.Vehicle attribute*), 173
`Version` (*class in dronekit*), 175
`version` (*dronekit.Vehicle attribute*), 173

W

`wait_for()` (*dronekit.Vehicle method*), 173
`wait_for_alt()` (*dronekit.Vehicle method*), 173
`wait_for_armable()` (*dronekit.Vehicle method*),
174
`wait_for_mode()` (*dronekit.Vehicle method*), 174
`wait_ready()` (*dronekit.CommandSequence method*),
155
`wait_ready()` (*dronekit.Parameters method*), 163
`wait_ready()` (*dronekit.Vehicle method*), 174
`with_traceback()` (*dronekit.APIException method*),
149
`with_traceback()` (*dronekit.TimeoutError method*),
163

Y

`yaw` (*dronekit.Gimbal attribute*), 156