

To J328, Relay option header
Molex 26-60-4090 or 26-61-4090.
Can be used with 09-50-8091 or many others)

J328-2 (+)
J328-3 (-)
J328-6 (S+)
J328-7 (S-)
J328-9 (Shield)
Conn_01x04_Male

If you want to disable the back connector
and lower noise on the sense lines, then:
from main PCB, remove
R451
R435
R434
R449
R448
R454

Also see <https://www.barbouri.com/2021/04/23/hewlett-packard-agilent-6632b-upgrade/>


Cable used:

Option 1:

4 core, 0.75 mm², outer diameter <= 6.2 mm like
Belden 4GB-BC50 (Farnell 2892539) or Lapp Kabel 1312104 (Farnell 1491515),
50 cm length, remove 3.5 cm of the outer isolation on each side
before crimping.

Option 2:

2 times 3 conductor shielded 18AWG/0.75mm2 like TE 44A1231-18-0/2/9-9
one cable per polarity
per cable:
2 wires for (+ or -)
1 wire for sense (+ or -)
shield connected at one side only



Connect to the case with
15 cm of 0.5 mm² or more (AWG 20) wire.
a serrated washer and a pan head bolt
(M3x8 in a new hole or a short M5 to the side)

Not related to the front panel posts, but good to do anyway:
Replace the RIFA PME271 on the mains entry board if it has
not yet been replaced.

Licensed under CERN OHL v.1.2
Schema slightly, but PCB thoroughly adapted by Hans Boot
Copyright (©) 2020, Patrick Baus <patrick.baus@physik.tu-darmstadt.de>



Sheet: /
File: HP6632B_binding_posts.kicad_sch

Title: HP 6632B Front Panel Binding Posts PCB

Size: A4 Date: 2022-09-18

KiCad E.D.A. kicad 7.0.6-0

Rev: v2.0

Id: 1/1