

$P_t$  = Allowable tension service load from Table 1911.2, pounds (N).

$V_s$  = Applied shear service load, pounds (N).

$V_t$  = Allowable shear service load from Table 1911.2, pounds (N).