

UNIFORM PLUMBING CODE OF ABU DHABI:  
AN ENVIRONMENTAL GUIDE FOR WATER SUPPLY AND SANITATION

<b>Chapter 10 Traps and Interceptors</b> . . . . .	99	1017.0	Oil and Flammable Liquid Interceptors . . . . .	104
1001.0 Traps Required . . . . .	99	1017.1	Interceptors Required . . . . .	104
1002.0 Traps Protected by Vent Pipes . . . . .	99	1017.2	Design of Interceptors . . . . .	105
1003.0 Traps - Described . . . . .	99			
Table 10-1 Horizontal Lengths of Trap Arms (Except for water closets and similar fixtures) . . . . .	99	<b>Chapter 11 Storm Drainage</b> . . . . .	107	
1004.0 Traps - Prohibited . . . . .	100	1101.0	General . . . . .	107
1005.0 Trap Seals . . . . .	100	1101.1	Where Required . . . . .	107
1006.0 Floor Drain Traps . . . . .	100	1101.2	Storm Water Drainage to Sanitary Sewer Prohibited . . . . .	107
1007.0 Trap Seal Protection . . . . .	100	1101.3	Material Uses . . . . .	107
1008.0 Building Traps . . . . .	100	1101.4	Expansion Joints Required . . . . .	107
1009.0 Industrial Interceptors (Clarifiers) and Separators . . . . .	100	1101.5	Subsoil Drains . . . . .	107
1009.1 When Required . . . . .	100	1101.6	Building Subdrains . . . . .	108
1009.2 Approval . . . . .	100	1101.7	Areaway Drains . . . . .	108
1009.3 Design . . . . .	100	1101.8	Window Areaway Drains . . . . .	108
1009.4 Relief Vent . . . . .	100	1101.9	Filling Stations and Motor Vehicle Washing Establishments . . . . .	108
1009.5 Location . . . . .	100	1101.10	Paved Areas . . . . .	108
1009.6 Maintenance of Interceptors . . . . .	101	1101.11	Roof Drainage . . . . .	108
1009.7 Discharge . . . . .	101	1101.12	Cleanouts . . . . .	108
1010.0 Slaughterhouses, Packing Establishments, etc. . . . .	101	1102.0	Materials . . . . .	109
1011.0 Minimum Requirements for Auto Wash Racks . . . . .	101	1102.1	Conductors . . . . .	109
1012.0 Commercial and Industrial Laundries . . . . .	101	1102.2	Leaders . . . . .	109
1013.0 Bottling Establishments . . . . .	101	1102.3	Underground Building Storm Drains . . . . .	109
1014.0 Grease Interceptors . . . . .	101	1102.4	Building Storm Sewers . . . . .	109
1014.2 Hydromechanical Grease Interceptors . . . . .	101	1102.5	Subsoil Drains . . . . .	109
1014.3 Gravity Grease Interceptors . . . . .	102	1103.0	Traps on Storm Drains and Leaders . . . . .	109
Table 10-2 Hydromechanical Interceptor Sizing Using Gravity Flow Rates . . . . .	102	1103.1	Where Required . . . . .	109
Table 10-3 Gravity Interceptor Sizing . . . . .	103	1103.2	Where Not Required . . . . .	109
1015.0 FOG (Fats, Oils, and Greases) Disposal System . . . . .	104	1103.3	Trap Size . . . . .	109
1015.1 Purpose . . . . .	104	1103.4	Method of Installation of Combined Sewer . . . . .	109
1015.2 Scope . . . . .	104	1104.0	Leaders, Conductors, and Connections . . . . .	109
1015.3 Components, Materials, and Equipment . . . . .	104	1104.1	Improper Use . . . . .	109
1015.4 Sizing Application and Installation . . . . .	104	1104.2	Protection of Leaders . . . . .	109
1015.5 Performance . . . . .	104	1104.3	Combining Storm with Sanitary Drainage . . . . .	109
1016.0 Sand Interceptors . . . . .	104	1105.0	Roof Drains . . . . .	109
1016.1 Where Required . . . . .	104	1105.1	Material . . . . .	109
1016.2 Construction and Size . . . . .	104	1105.2	Dome or Strainer for General Use . . . . .	109
1016.3 Separate Use . . . . .	104	1105.3	Strainers for Flat Decks . . . . .	110
		1105.4	Roof Drain Flashings . . . . .	110