

ZMotion PC Library Programming Manual

Version 2.0

Copyright statement



This manual is copyrighted by Shenzhen Technology Co., Ltd. is moving to all, without our authorization, any person may not be reproduced, copied any of the contents of this handset.

Technology is moving the company reserves the prior notice, the right to modify the contents of this manual.



Debug the machine pay attention to safety! Be sure to design effective safety devices in the machine, and adding an error handler in software, or loss caused by being transportedAction Technology has no obligation or responsibility responsible.

table of Contents

The first chapter PC Programming Overview.....	1
Motion Controller 1.1 Features.....	1
1.2 Development Framework.....	1
1.3 Development steps.....	2
1.3.1 using VC development applications.....	2
1.4 packaging method library function.....	4
More than 1.5 Controller Link.....	6
The second chapter describes the basic functions.....	7
2.1 Controller Link.....	7
2.2 Basic initialization parameters shaft.....	8
2.3 Special IO settings.....	9
2.4 single-axis motion.....	10
2.4.1 uniaxial back to zero.....	10
2.4.2 uniaxial jog.....	11
2.4.3 uniaxial state.....	12
2.5 Multi-axis interpolation motion.....	13
2.5.1 Common interpolation motion.....	13
2.5.2 continuous interpolation motion.....	14
2.5.3 Automatic corner parameters.....	16
2.6 handwheel movement.....	17
2.7 IO and AD / DA setting the read.....	17
2.8 PC data exchange with the controller.....	18
Chapter III DLL function list.....	20
3.1 Introduction controller operates the function.....	20
3.2 Introduction movement command function.....	twenty three
3.2.1 assisted instruction.....	twenty three
3.2.2 Multi-axis linear interpolation.....	27
3.2.3 arc, ellipse, spiral interpolation.....	28
3.2.4 Special motion commands.....	41
3.2.5 synchronous motion commands.....	43
3.2.6 single-axis motion command.....	47
3.3 shaft axis parameter describes the state function.....	49
3.3.2 axis substantially parametric function.....	50
3.3.3 Other parameters function.....	63
3.3.4 Special function signal parameter(Origin, limit...) 73.....	
3.4 input and output functions Introduction.....	77
3.5 data communication function.....	82
Chapter IV direct serial control.....	88
4.1 Serial Port Command Control Mode.....	88

Chapter One PC Programming Overview

1.1 Motion Controller Features

ZMC PC motion controller supports direct online control, provided DLL libraries and VC, VB, C #, LABVIEW and other routines. Library also provides support of LINUX and WINCE. Library for all types of controllers.

ZMC-line control of the relative motion controller PCI has the following advantages:

- 1, the slot is not used, the stability is better.
- 2, reduce the requirements for the PC, no PCI slots.
- 3, can use a computer or MINI ARM industrial computers, reducing overall cost.
- 4, the controller directly to do wiring board, saving space.
- 5, the program can be run in parallel on the controller, and PC requires only simple interactions, reduce the complexity of PC software. In summary it can be seen, the choice of the motion controller Ethernet interface in place of PCI motion control card, can be

Save space, reduce costs, optimize procedures, wiring more convenient, which is more and more applications using Ethernet The reason network.

1.2 Development Framework




Figure 1.2 ZMC development Chart

1.2 part red bold line in FIG line PC program is interactive with the controller, the controller ZMC Ethernet, USB, serial / 485 is connected to the PC, and the PC program ZBASIC program can run simultaneously on the controller, improving the processing s efficiency.

1.3 Development steps


1.3.1 Develop applications using VC

- 1) Open the VC ++ 6.0.
- 2) Create a new project
- 3) Select MFC APPWizard (exe)
- 4) Select the path to save the project
- 5) Set project name, select OK



Figure 1.3-1 New Project


- 6) In the dialog box select the basic type of application. Completing the New
- 7) Zauxdll.h library functions to be provided, under zauxdll.lib, zauxdll.dll, and zmotion.dll into the project path (directly



or through zauxdll.cpp source code to join the project)

Figure 1.3-2 Adding Controls


- 8) Adding header files testDlg.cpp#include "zauxdll.h".
- 9) Add a link controller code ZAux_OpenEth
("192.168.0.11", & g_handle) in CTestDlg ::



OnInitDialog () function

Figure 1.3-3 Link Controller

- 10) Add a member function CTestDlg :: OnClose () in CTestDlg;
window for closing off controller link. Add ZAux_Close



(g_handle) in function; break the link.

Figure 1.3-4 off 窗 controller link

- 11) Double-click to start, stop adding the corresponding code in the corresponding
event function: ZAux_Direct_Singl_Vmove (g_handle, 0,1);
ZAux_Direct_Singl_Cancel (g_handle, 0,2);




Figure 1.3-5 call the function

After 12) compiler, run the program, press running at the interface, the axis O will be initialized by Super

Of forward rotation, stop the press, the axis 0 stops.

1.4 Packaging method library function

ZAux library package and set the basic parameters of the motion, so as to provide open source, details, see source.

ZAux library by sending commands directly ZBASIC ZAux_DirectCommand ZAux_Execute manner or mode to the controller, the corresponding function can ZBASIC manual commands corresponding description. If the command does not want the package or packages own function, or may be transmitted by ZAux_Execute ZAux_DirectCommand, or modify existing code increase reference to the corresponding function.

Send command string in two ways, direct mode and buffer mode.


Direct method: direct execution individual variables / array / parameters related commands, this time must pass all parameters

Specific numerical values shall be not an expression; see

ZAux_DirectCommand function. ZAux_DirectCommand (handle controller, the command string, the string returns, returns the character length) buffer system can execute all the commands and supports expressions as parameters, but the speed is slower; see

See ZAux_Execute function.

ZAux_Execute (handle controller, the command string, the string returns, returns the character length)



Adding 1.4-2 FIG function definition

c) increasing the corresponding function in the header file



Figure 1.4-3 Adding header files

d) generating a new compiler DLL

1.5 Multi-Link Controller

Positive motion controller can support one PC control a plurality of controllers, commonly used in the multi-axis, multi-line equipment, workshop or monitoring equipment. Usually a switch, provided by the controller to access each different IP address to the controller. Note: there are multiple devices on the Ethernet switch when, in addition to ensure a different IP address outside, to the MAC

Address may conflict (with n be moved by the auxiliary tool to modify

```
IP and MAC address) Controller Link Code: char * ip_list [4] =
{ "192.168.0.11", "192.168.0.12", "192.168.0.13", "192.168.0.14
"};
```

```
for (int i = 0; i < 4; i++)
{
```

```
    ZAux_OpenEth (ip_list [i], & g_card [i]);
```

}

Chapter two Basic Features

This chapter describes the basic motor function using the controller, and provides related routines, reference details PC Corresponding library routines.

2.1 Controller Link

Table 2.1-correlation function controller is connected

Function	Feature
ZAux_OpenCom	Serial Link Controller
ZAux_SetComDefaultBaud	Serial communication parameters
ZAux_OpenEth	Ethernet Link Controller
ZAux_SearchEthlist	Under the current search
ZAux_Close	Turn off the controller link

You must call the link function links the controller when the controller to operate successfully only when the link corresponding to the operation by the handle controller returned. To call when you close the application unlink function to releaselink.

Routine 2.1.1: Serial Link Controller

```

ZMC_HANDLE g_handle = NULL; //
Link returns a handle uint32 dwBaudRate =
38400; // 38400 baud rate
uint32 dwByteSize = 8; // 8 Data bits
uint32 dwParity = 0; // No parity
uint32 dwStopBits = 1; // 1 Stop bits
uint32 comid = 1; // Links COM port
ZAux_SetComDefaultBaud(dwBaudRate, dwByteSize, dwParity, dwStopBits); // set the serial
communication parameters
ZAux_OpenCom(comid, & g_handle); // COM1 Interface link controller

```

Routine 2.1.2: network interface controller link

```

ZMC_HANDLE g_handle = NULL; // Link
returns a handle char * ipaddr = "192.168.0.11";
// controller IP ZAux_OpenEth(ipaddr, &
g_handle); // Ethernet Link Controller

```



Detection function return value if the function succeeds, the

return 0 if successful, non-zero failed. Ethernet port link to return unsuccessful, check the transfer of IP is correct, and make sure your computer's IP address and the IP address of the controller on the same network segment.

2.2 The basic parameter initialization shaft

The basic parameters of the function shaft
Table 2.2

Function	Feature
ZAux_Direct_SetAtype	Set axis type
ZAux_Direct_SetUnits	Setting stem pulse equivalent
ZAux_Direct_SetInvertStep	Set pulse output mode
ZAux_Direct_SetSpeed	Set shaft speed
ZAux_Direct_SetAccel	Set-axis acceleration
ZAux_Direct_SetDecel	Setting the deceleration shaft
ZAux_Direct_SetSramp	S-curve time setting stem

2.2 routines: initialization parameters

```
ZAux_Direct_SetAtype(g_handle, 0, 1); // Set pulse output shaft axis 0
ZAux_Direct_SetUnits (G_handle, 0, 100); // Set parameters to the shaft
axis 0 100 units of pulses ZAux_Direct_SetInvertStep (g_handle, 0, 1);
// set the direction of the axis 0 + pulse mode ZAux_Direct_SetSpeed
(G_handle, 0, 200); // 0 Set speed shaft 200units /
s ZAux_Direct_SetAccel (g_handle, 0, 2000); // set acceleration
ZAux_Direct_SetDecel axis 0 of 2000units / s / s (g_handle, 0, 2000);
// set acceleration axis 0 of 2000units / s / s
ZAux_Direct_SetSramp (G_handle, 0, 0); // 0S time axis setting the curve (0-
trapezoidal acceleration and deceleration)
```


Highlights 2.2:

Shaft Type: 1-type common pulse output type (stepper / servo), 3- encoder input type (external encoder / encoder shaft itself), the shaft is configured corresponding to the type of the actual hardware. Virtual axis is an axis type internal analog program run, typically with the robot shaft for superimposing the case.

















Atype type	desc
0	Virtual axis;
1	Stepper or servo mode pulse direction
2	Servo control of the analog signal
3	Quadrature encoder
4	Stepper + Encoder
6	Direction encoder pulse mode, can be used
7	Pulse direction stepper or servo mode
8	ZCAN extended pulse direction with stepper
9	ZCAN extended orthogonal encoder.
10	ZCAN direction of extension encoder pulse
65	ECAT type of pulse

66	ECAT speed loop
67	ECAT closed-loop torque
70	ECAT custom action, only read the encoder.

FIG 2.2-1 axis
type

When the pulse amount: Pulse equivalent to the basic unit vector axis parameters, such as speed, acceleration, position When the set units. 1, unit speed pulse / S, when the mechanism is set to mobile units lmm desired number of pulses, the speed unit is mm./s.  Pulse equivalent must be modified, and then modify the speed, displacement parameters. Otherwise, when units change will lead to changes in speed, acceleration, location.

Pulse mode: Pulse plus direction mode 0-3, 4-7 for the double-pulse mode.

mod	Forward		Negative	
	Pulse	Direction	Pulse	Direction
0		High		Low
1		High		Low
2		Low		High
3		Low		High
4				
5	High			High
6		Low	Low	
7	Low			Low

2.2-2 pulse output mode of
FIG.

2.3 Special IO settings

Table 2.3 Special IO
functions

Function	Feature
ZAux_Direct_SetDatumIn	Axis origin signal is provided
ZAux_Direct_SetFwdIn	Axis positive limit signal
ZAux_Direct_SetRevIn	Axis negative limit signal
ZAux_Direct_SetAlmIn	Spindle servo alarm signal is
ZAux_Direct_SetInvertIn	Set input signal inverted state

N dedicated motion controller is not particular IO port, a special IO are designated assigned to the respective input and output by the general-purpose command, the special state when the IO configuration - 1 is a state corresponding to no.

Routine 2.3: Special IO Configuration

```
ZAux_Direct_SetDatumIn (g_handle, 0,1); // Set IN (1) of the axis origin signal 0  
ZAux_Direct_SetFwdIn (G_handle, 0,2); // Set IN (2) of axis positive limit 0  
ZAux_Direct_SetRevIn (G_handle, 0,1); // setPut IN (1) axis 0 The negative limit, a channel  
with the same originnumber
```

```
ZAux_Direct_SetAlmIn (g_handle, 0, -1); // Cancel 0 axis servo configuration alert
signal
ZAux_Direct_SetInvertIn (g_handle, 1,1); // Reverse IN (1) active high
```

Highlights 2.3:

Special IO ZMC series are considered valid when the OFF state, (i.e., corresponding to the positive input limit OFF state, corresponding to that encountered axis positive limit). Therefore, when the IO port for a particular type of sensor is normally open, corresponding to the input port needs to be inverted to the active high, normally closed by default it is active low.



ECI series of controllers with special signal ZMC series controller status is the opposite!

2.4 Single-axis motion

2.4.1 Uniaxial back to zero

Table 2.4-1 homing
motion functions


Functi	Featur
ZAux_Direct_Singl_Datum	Single-axis homing movement
ZAux_Direct_SetCreep	Set secondary creep speed back

2.4.1 Routine: Single back to zero

```
ZAux_Direct_SetDatumIn (g_handle, 0,1); // Set IN (0) axis origin of a
signal ZAux_Direct_SetSpeed 0 (G_handle, 0,100); // 0 Set speed
shaft 200units / s ZAux_Direct_SetCreep (g_handle, 0,10); // 0
creep speed of the shaft is provided 10units / s ZAux_Direct_Singl_Datum
(g_handle, 0,4); // 4-axis mode 0 according to the
reset to zero, to zero to the secondary negative feedback.
```

The motion controller provides several positive zero return, pass through zero return value selecting different modes direction corresponding manner.

Mode 1: Z-phase mode, the axis Z CREEP speed operation until the signal appears. DPOS correction value is automatically reset to 0 MPOS simultaneously. Only ATYPE to 7, and the corresponding valid access shaft encoder Z phase. Forward back to zero mode = 1, mode = negative return 0:02.



F

figure 2.4-1 Z-phase The first Z-phase signal
mode back to zero

Option 2:+ Trans origin find mode, the origin axis SPEED speed running, until it hits the home switch. Then CREEP shaft speed reverse movement until the switch from the origin. DPOS value is automatically reset to 0 while correcting MPOS, mode = 3 in the forward direction back to zero, when the 4 mode = negative back to zero.




Figure 2.4-2 + Anti-
origin back to zero

Mode 3: + Z + trans find the origin signal pattern, the origin axis SPEED speed running, until it hits the home switch. Then CREEP shaft speed reverse movement until the switch from the origin, and then continue to creep speed reverse signal Z until it hits. DPOS correction value is automatically reset to 0 MPOS simultaneously. Only ~~ATYPE to 7, and the corresponding valid access shaft encoder Z~~ phase. mode = 5 forward back to zero, mode = 6 negative to zero.




Figure 2.4-3 to find the origin of the anti-+ +
Z phase back to zero

Mode 4: The origin of a return to zero mode, the axis SPEED speed to run until it hits the home switch. DPOS correction value is automatically reset to 0 MPOS simultaneously. mode = 8 forward back to zero, mode = 9 negative to zero.




Figure 2.4-4 origin
back to zero again

Mode 5: For the case where the origin of the middle positive and negative limit, plus 10 in the respective modes, shown in the process of homing We encountered a limit not cancel exercise, but continue to look for the origin of the reverse.

2.4.2 Uniaxial jog

Table 2.4-2 uniaxial

jog function

Functi	Featur
ZAux_Direct_Singl_Vmove	Single-axis continuous motion
ZAux_Direct_Singl_Move	Single-axis motion relative
ZAux_Direct_Singl_MoveAbs	Single-axis movement absolute
ZAux_Direct_Singl_Cancel	Stop Motion

Each controller has its own separate shaft axis parameters, and the value of global motion parameters, i.e. speed, Acceleration of a change is effective immediately, the shift function can be achieved online.

Routine 2.4.2 single-axis motion

```

intrun_state          = 0; //          Axis motion
ZAux_Direct_SetSpeed (G_handle, 0,200); // 0 Set speed shaft 200units / s
ZAux_Direct_SetAccel (G_handle, 0,2000); //0 axis is set acceleration
2000units / s / s ZAux_Direct_SetDecel (G_handle, 0,2000); // 0 axis is
set acceleration 2000units / s / s ZAux_Direct_SetSramp (G_handle, 0,0);
//                               Set time curve 0 0S shaft
(trapezoidal acceleration and deceleration) ZAux_Direct_Singl_Move
(g_handle, 0,100); //          0 do shaft relative to the
current position 100 units
{
    ZAux_Direct_GetIfIdle (g_handle, 0, & run_state); // read the motion axis 0, 0 motion, stop -1
}
While (run_state == 0) //          Stop Waiting for axis 0

```

Highlights 2.4.2

When switching the direction of continuous motion can be called directly again **VMOVE direct replacement foregoing continuous motion, does not need to cancel the call.**

When the stop motion transfer cancel, deceleration is used ZAux_Direct_SetFastDec (DEFAULT value equal to the decel) value of the deceleration, fastdec may be set to a larger value when the EMERGENCY STOP.

2.4.3 Uniaxial state

Table 3.4-3 uniaxial
state function

Functi	Featur
ZAux_Direct_GetDpos	Axis coordinate reading
ZAux_Direct_GetIfIdle	Axis motion read
ZAux_Direct_GetAxisStatus	Status Read axis

Highlights 2.4.3

Analyzing the axis of motion

Function call ZAux_Direct_GetIfIdle axis motion determines the current state, IDLE state only returns 0, two kinds of values -1, 0 indicates the current axis is in motion, the current axis -1 indicates no motion, motion may be determined by ZAux_Direct_GetMtype whether the current state of the shaft IDLE state to achieve the same effect.

Analyzing the state of the shaft

ZAux_Direct_GetAxisStatus by calling function returns a 32-bit status value, a state value of each state represented by a different axis.

Table 2.4.3-1 axis
status

Place	value	significance
1	2	Overrun warning
2	4	Communication with the
4	16	Forward hardware limit
5	32	Negative alarm to the
6	64	To find the origin of
7	128	Velocity hold signal HOLD
8	256	Overrun Error Tracking
9	512	Forward soft limit
10	1024	Than negative soft
11	2048	CANCEL execution
12	4096	Pulse frequency
18	262144	Power anomalies
tw	4194304	Servo alarm signal
tw	8388608	Axis into the

2.5 Multi-axis interpolation motion

Positive motion controller can supportLinear, circular, spiral, space arcs, ellipses and elliptical other helical interpolation movement. And the shaft can be freely combined to make interpolated motion, the controller controls so as to achieve a multi-station.

2.5.1 Common interpolation motion

Table 2.5-1 Common interpolation motion
function

Functi	Featur
ZAux_Direct_Base	Motion axis settings list
ZAux_Direct_Move	Multi-axis relative linear
ZAux_Direct_MoveAbs	Absolute multi-axis linear
ZAux_Direct_MoveCirc2	Three two-axis relative to a given
ZAux_Direct_MoveCirc2Abs	Two-axis circular interpolation
ZAux_Direct_MSpherical	Space circular interpolation

Motion interpolation motion parameters are provided on the spindle, that is, `ZAux_Direct_Base`
(ZMC_HANDLE handle, int imaxaxes, int * piAxislist) instruction

list piAxislist axis of the first spindle axis. Spindle speed, acceleration, deceleration, ... synthesis parameters are interpolated motion vector direction of the shaft of participating parameters. Motion state is determined, the state of the spindle can be determined directly.

Routine 2.5.1 three-axis linear interpolation

```
int axislist [3] = {1,0,2}; //          BASE axis motion list, wherein the spindle
shaft 1
float poslist [3] = {200, 300}; //      Sports list, shaft 100, shaft 0-200, 2-300
shaft

ZAux_Direct_SetSpeed    (g_handle, axislist [0], 100); //      Interpolation speed
setting 100 provided on the spindle ZAux_Direct_SetAccel (g_handle, axislist [0],
1000); //              Set interpolation acceleration
1000

ZAux_Direct_Base (g_handle, 3, axislist); // Select the axis list ZAux_Direct_MoveAbs
(g_handle, 3, poslist); // call the movement, the axis absolute
position corresponding 0,1,2 go
```

Highlights 2.5.1

Space arc command only relative motion commands, generally corresponding to the axis of movement through the read command ZAux_Direct_GetEndMoveBuffer end position to the absolute coordinate into the relative spatial fairly be called an offset arc command.

2.5.2 Continuous interpolation motion

Table 2.5-2 continuous interpolation function associated

Funciti	Feat
ZAux_Direct_SetMerge	Continuous interpolation motion
ZAux_Direct_GetRemain_Buffer	The remaining number of read
ZAux_Direct_SetForceSpeed	SP movement speed
ZAux_Direct_SetStartMoveSpeed	Movement start speed SP
ZAux_Direct_GetEndMoveSpeed	SP movement end speed

ZMotion each axis the motion controller has a multistage buffering motion when the motion instruction currently being executed, the instruction calls back motion will fill the buffer, the buffer will empty automatically the current plane movement has been completed. Avoid blocking competition program. MOVE_DELAY delay can also be used to fill the instruction buffer, so that automatic delay between motion commands, or by inserting MOVE_OP IO operations in motion, when the continuous interpolation MERGE open switch, will automatically same spindle interpolation Games It is continuously up.

The next instruction
N TYPE Read type

Running command M
OVE_CURM ARK Read
identification M TYPE Read
type




FIG 2.5-2
motion buffer

All the interpolated motion has a corresponding custom speed SP sports, such as movesp, moveabssp ... and so on. Moving speed SP is no longer controlled by the speed of the global velocity, but set the start, run, the speed of the end of the corresponding segment by special speed command, such as movement into the movement speed is buffered together.

2.5.2 Continuous interpolation routine movement

```
int axislist [3] = {0,1,2}; //          BASE axis motion list
float poslist [3] = {0,0,0}; //        Sports list,
int iremain = 0; //          The remaining
buffer

ZAux_Direct_Base (g_handle, 3, axislist); // Select the axis list ZAux_Direct_SetMerge
(g_handle, axislist [0], 1); //          Continuous interpolation switch
ZAux_Direct_SetStartMoveSpeed (g_handle, axislist [0], 1000); // set a
larger value than the maximum FORCE_SPEED, represents the starting velocity is
not enabled
ZAux_Direct_GetEndMoveSpeed(G_handle, axislist [0], 1000);
for (int i = 0; i < 100; i++)
{
    poslist [0] = i *
    2; poslist [1] = i
    * 3; poslist [2]
    = i * 5; do
    {
        ZAux_Direct_GetRemain_Buffer (g_handle, 0, & iremain); // read the remaining
        buffer
    }
    While (iremain < 1)          Wait for the remaining buffer

    ZAux_Direct_SetForceSpeed (g_handle, axislist [0], i + 10); // Set
    speed ZAux_Direct_MoveAbsSp (g_handle, 3, poslist );// Call SP
    Sport
}
```

Highlights 2.5.2

Continuously transmitting motion before interpolation (including move_op, move_delay instructions) need to first determine whether there is movement of the spindle buffer vacant, then the motion transmission, the transmission buffer is full when the motion to the controller, the commands sent

returns an error, the motion can not be filled into the buffer. Of course, different motion commands occupy buffer size is inconsistent. ZAux_Direct_GetRemain_Buffer is accounted for by the maximum buffer space arc return instruction. It indicates the number of remaining space can fill the discharge arc command.

2.5.3 Automatic corner parameter settings

Table 2.5-3 corner
setters

Function	Feature
ZAux_Direct_SetCornerMode	Set corner deceleration mode
ZAux_Direct_SetDecelAngle	Setting the deceleration start
ZAux_Direct_SetStopAngle	Set stop angle corner
ZAux_Direct_SetFullSpRadius	Set small round speed limit
ZAux_Direct_SetZsmooth	Set automatic fillet radius

The device produces Qiang Lie vibrations around the corner running at high speed, then generally needs to be done at the turn of the deceleration processing. It can be done by the automatic deceleration processing corresponding to the corner on the controller mode. CornerMode different bit patterns corresponding to different deceleration, the deceleration setting means is not 0 corners.


2.5.3 corner deceleration setting routine

```
int axislist[4] = {0,1,2,3}; // BASE axis motion list
int corner_mode = 2 + 4 + 32; // corner mode automatically chamfered
corner + small round speed limit + float m_startang = 3.14 * 15/180; //
// Corner deceleration start angle
float m_stopang = 90 * 3.14 / 180; // corner deceleration
stop angle float m_fullradius = 5; // Small round
radius
floatm_zsmooth // 5 Fillet radius

ZAux_Direct_SetLspeed (g_handle, axislist [0], 0); // Set the start speed
ZAux_Direct_SetCornerMode (g_handle, axislist [0], corner_mode); // Set the corner
mode ZAux_Direct_SetDecelAngle (g_handle, axislist [0], m_startang); // set the
deceleration start angle ZAux_Direct_SetStopAngle (g_handle, axislist [0],
m_stopang); // set the deceleration start
angle ZAux_Direct_SetFullSpRadius (g_handle, axislist [0], m_fullradius); // set
small circle radius ZAux_Direct_SetZsmooth (g_handle, axislist [0], m_zsmooth); //
set chamfer radius
```

Highlights 2.5.3

When automatic corner deceleration, velocity vector direction is decelerated by the size of the corner, the angle from the start of deceleration to stop decelerating the angle between the linearly



decelerating, the deceleration to a stop when the corner angle, speed reduced to speed set value. Relationship as shown in FIG.

2.5-3 corner
deceleration FIG.

2.6 Hand wheel movement

Table 2.6-1 handwheel motion functions

Functi	Feat
ZAux_Direct_Connect	Synchronization follow
ZAux_Direct_SetClutchRate	Connection rate setting

A handwheel external to the encoder shaft, will occupy an encoder interface controller. Handwheel pulse movementRed scale disposed synchronization follow handwheel movement, when connected by the movement speed is normally set to 0, it indicates / acceleration parameter to track connection according to the speed of the shaft.

2.6 Routine hand wheel movement

```
ZAux_Direct_SetAtype (g_handle, 4,3); //      Hand axle shaft 4 is arranged
ZAux_Direct_SetUnits (g_handle, 4,100); //    Pulse equivalent

int m_naxis = 0; //                          The current pulse axis
float m_radio = 1; //                        Magnification
ZAux_Direct_SetClutchRate (g_handle, m_naxis, 0); // Set connection rate
ZAux_Direct_Connect (g_handle, m_radio, 4, m_naxis); // handwheel
synchronized movement, the shaft 4 following axis 0 motion
```

Highlights 2.6

Postamble connecting two shafts, with the need to cancel cancel instruction to cancel the current synchronized movement of the shaft, then call other sports, when the synchronization ratio can call handover to replace the preceding CONNECT CONNECT command.

2.7 IO and AD / DA setting the read

Table 2.7-1 input and output functions

Functi	Features
ZAux_Direct_GetIn	Reading the state
ZAux_Direct_SetOp	Providing a single
ZAux_Direct_GetOp	A single output
ZAux_Direct_GetAD	Read a single
ZAux_Direct_SetDA	Providing a single
ZAux_Direct_GetDA	Read a single

Above it is for a single input and output ports operate during

actual operation to improve efficiency may be simultaneously with a plurality of IO read or set, the operation may be directly continuous operation corresponding to a plurality of IO registers MODBUS, or AD, DA.

Routine 2.7

```

uint32 iostatus = 0; ZAux_Direct_SetOp (g_handle,
0,1); //                                Open
output 0
ZAux_Direct_GetIn (g_handle, 1, & iostatus); // Read Input Status 1
ZAux_Direct_SetDA (g_handle, 0, 2048); // Output Set da da (0) =
2047, 5V uint8 iostate1 [2] = {0};
ZAux_Modbus_Get0x (g_handle, 10000,16, & iostate1 [0]); //      Read in (0-15) state,
wherein
iostate1 [0] represents 0-7, iostate1 [1] indicates the status of 8-15.

```

Highlights 2.7

Input and output, there is a corresponding analog Operation modbus registers for input and output may operate directly modbus register.

Modbus_bit (10000) above the mapping in (0) above, namely 0x (10000) - in (0) ... Modbus_bit (20000) above mapping out (0) above, namely 0x (20000) - out (0) ... Modbus_reg (13000) above mapping DA (0) above, i.e., 4x (13000) - above ad (0) Modbus_reg (14000) mapping AD (0) above, i.e., 4x (14000) - da (0)

2.8PC Interact with the data controller

Table 2.8-1 data exchange related functions

Funci	Featur
ZAux_Modbus_Set0x	Modbus register bit set
ZAux_Modbus_Set4x	Word register set modbus
ZAux_Direct_SetTable	System register set table
ZAux_Direct_SetVrf	Set VR register
ZAux_FlashWritef	Write controller FLASH space
ZAux_Direct_GetVariablef	Reading on the controller global
ZAux_Direct_GetVariableInt	Reading the global variable
For more details refer to	

Routine 2.8

```

float array [2];
array [0] = 10.5;

array [1] = 12.14;      ZAux_Modbus_Set4x_Float
(g_handle, 20,2, & array [0]);
//Send data modification      modbus_ieee (20), modbus_ieee (22) value
CString strdata1;
strdata1.Format ( "data1 =%.2f", array [0]);

```

// string command mode, press the command BASIC commands sent down format. May operate a global function or global variable or parameter, modify the value of the global variable control of data1

ZAux_DirectCommand (g_handle, strdata1, NULL, 0);

Highlights 2.8

When operating modbus_ieee modbus_long and will occupy two registers 4X, attention spaced address.

by **ZAux_DirectCommand** or **ZAux_Execute** access variables on the controller or modification

Basic program can only access controller inside the SUB SUB when global variables or global function.

third chapterDLL function list

3.1 Controller Operation Function Descriptions

3.1.1.1 ZAux_OpenCom

Function: Serial link controller.

prototype: int32 stdcall ZAux_OpenCom (uint32 comid, ZMC_HANDLE * phandle)

Input parameters:

Comid	Links COM port
number	Output parameters:
phandle	Link To handle
the return value:	error code

3.1.1.2 ZAux_SearchAndOpenCom

Function: Automatic Search and serial link controller.

prototype: int32 stdcall ZAux_SearchAndOpenCom (uint32 uimincomidfind, uint32 uimaxcomidfind, uint * pcomid, uint32 uims, ZMC_HANDLE * phandle)

Input parameters:

uimincomidfind	Search minimum COM port number
uimaxcomidfind	The maximum number of search COM
port	
uims	MS response time link
Output parameters:	
Pcomid	COM port number to search
phandle	Link returns a handle
return value:	error code

3.1.1.3 ZAux_SetComDefaultBaud

Function: Set serial communication parameters

prototype: int32 stdcall ZAux_SetComDefaultBaud (uint32 dwBaudRate, uint32 dwByteSize, uint32 dwParity, uint32 dwStopBits)

Input parameters:

dwBaudRate	The default baud rate:
	38400 dwByteSize The

default size of the data bits: **8 dwParity**
 Check digit Default:
0 no parity dwStopBits Stop
 bits default :1 Place

loseThe
parameters of:
Return
Value:error
code

3.1.1.4 ZAux_SetIp

Function: Set the controller IP address
prototype: int32 stdcall ZAux_SetIp (ZMC_HANDLE handle, char * ipaddress)
Input
parameters:
 handle Link Handle
 ipaddress IP address
values of the output parameters:
return value: error code

3.1.1.5 ZAux_OpenEth

Function: Ethernet Link Controller
prototype: int32 stdcall ZAux_OpenEth (char * ipaddr, ZMC_HANDLE * phandle)
Input
parameters:
 ipaddr The IP
address of the link output parameters:
 Phandle Links returned
handle the return value: error code

3.1.1.6 ZAux_SearchEthlist

IP addresses under the current search segment: Function
prototype: int32 stdcall ZAux_SearchEthlist (char * ipaddrlist, uint32
addrbufflength, uint32 uims)
Input
parameters:
 addrbufflength The search returns the IP address
 of the total length
 uims Search timeout
Output
parameters:
 ipaddrlist Search the IP

address to return value: error code

3.1.1.7 ZAux_SearchEth

Function: to search the current IP address is the network segment

prototype: int32 stdcall ZAux_SearchEth (const char * Ipaddress, uint32 uims)

Input

parameters:

ipaddress

IP address search judgments

```

uims
Search timeout
Output
Parameters:
Return
Value:error
code

```

3.1.1.8 ZAux_Close

Function: Turn off the controller link

prototype: int32 stdcall ZAux_Close (ZMC_HANDLE handle)

Input parameters:

handle	Link Handle
--------	-------------

Output

Parameters:

Return

Value: error code

3.1.1.9 ZAux Pause

```
Function: Pause internal operation of the
controller of the BASIC program prototype:int32
stdcall ZAux_Pause (ZMC_HANDLE handle) Input parameters:
        handle                Link Handle

Output
Parameters:
Return
Value:error
code
```

3.1.1.10 ZAux Resume

```
Function Function: BASIC prototype program
continues to run internal controller:int32 stdcall
ZAux_Resume (ZMC_HANDLE handle) Input parameters:
        handle                Link Handle

Output
Parameters:
Return
Value:error
code
```

3.1.1.11 ZAux_BasDown

Function: single BAS file generated and downloaded to the controller running ZAR

prototype: int32 stdcall ZAux_BasDown (ZMC_HANDLE handle, const char

* Filename, uint32 run_mode)

Input parameters:

handle

Link Handle

FilenameBAS

File name with path

run_mode

Download Mode 0-RAM 1-ROM

Output parameters:

returnReturnvalue:error code

3.1.1.12 ZAux_Execute

Function: string command sent to the controller

prototype: int32 stdcall ZAux_Execute (ZMC_HANDLE handle, const char * pszCommand, char * psResponse, uint32 uiResponseLength)

Input

parameters:

handle	Link Handle
pszCommand	Send the command string
uiResponseLength	Returns the

character length of the output parameters:

psResponse	String
------------	--------

Return Return Value: Error Code

3.1.1.13 ZAux_DirectCommand

Function: string command sent to the controller

prototype: int32 stdcall ZAux_DirectCommand (ZMC_HANDLE handle, const char * pszCommand, char * psResponse, uint32 uiResponseLength)

Input

parameters:

handle	Link Handle
pszCommand	Send the command string
uiResponseLength	Returns the

character length of the output parameters:

psResponse	String
------------	--------

Return Return Value: Error Code

3.2 Movement command function introduced

3.2.1. Assisted

instruction

3.2.1.1 ZAux_Direct_Base

Function: Select the BASE axis list, see Software Manual inside

the "BASE" command. Prototype: int32 stdcall ZAux_Direct_Base
(ZMC_HANDLE handle, int imaxaxes,
int * piAxislist)
Input
parameters:

handle	Markup
imaxaxes	Number of axes
piAxislist	Axis
number list	Return Value: Error
Code	

3.2.1.2 ZAux_Direct_Defpos

Function Function: BASE axis list defines the current position as a new absolute position value, see Software Manual inside the "DEFPOS" command.

prototype: int32 stdcall ZAux_Direct_Defpos (ZMC_HANDLE handle, int imaxaxes, float * pfDposlist)

Input parameters:

handle	Markup
imaxaxes	The total number of axes modified
pfDposlist	Coordina
te list	Return value: error
code	

3.2.1.3 ZAux_Direct_MovePause

Functions Function: BASE axis motion suspend, valid only in single- or multi-interpolated motion, when the multi-axis suspended together.

prototype: int32 stdcall ZAux_Direct_MovePause (ZMC_HANDLE handle, int imode)

Input parameters:

handle	Markup
imode	Pause mode:

0 Pause the current motion.

Pause 1 after the completion of the current movement is ready to execute the next motion command.

2 is completed after the current exercise is ready to execute the next motion command, pause and MARK identified two instructions are not the same. This mode can be used when a plurality of instructions implemented by the operation, after a pause in the entire operation is

completed.

return value:error code

3.2.1.4 ZAux_Direct_MoveResume

Function: When the BASE axis Pause, continues to move.

prototype: int32 stdcall ZAux_Direct_MoveResume (ZMC_HANDLE handle)

loseThe parameters:
 handle Markup
 return value: error code

3.2.1.5 ZAux_Direct_Rapidstop

Function: list of all axes stop immediately, if the axes involved in the interpolation, the interpolation stopped movement.

prototype: int32 stdcall ZAux_Direct_Rapidstop (ZMC_HANDLE handle, int imode)

Input parameters:

handle	Markup
imode	mode
0	Cancel the current movement
1	Cancel buffer sports
2	Cancel the current buffer sports and sports

return value:error code

3.2.1.6 ZAux_Direct_CancelAxisList

Function: list of all axes stop immediately, if the axes involved in the interpolation, the interpolation stopped movement.

prototype:int32 stdcall ZAux_Direct_CancelAxisList (ZMC_HANDLE handle, int imaxaxes, int * piAxislist, int imode)

Input parameters:

handle	Markup
imaxaxes	The total
number of axes of movement	
piAxislist	Axis
list imode	mode
0	cancel the current movement
1	Cancel buffer sports
2	Cancels the current buffer sports and sports

return value:error code

3.2.1.7 ZAux_Direct_Regist

Function: latching position, see Software Manual inside the
 "REGIST" command. prototype: int32 stdcall ZAux _Direct_Regist
 (ZMC_HANDLE handle, int imode) Input parameters:

handle	Markup
imode	Latch mode

- 1 When the absolute position of the rising edge of the pulse to the Z REG_POS
- 2 When the absolute position of the falling edge of the pulse to the Z REG_POS
- 3 When the absolute position of the rising edge of the input signal R0 to REG_POS
- 4 When the absolute position of the falling edge of the input signal to the R0 REG_POS
- 6 input signal Rising edge of the absolute position R0 to REG_POS, absolute position signal to the rising edge Z REG_POSB
- 7 input signal Rising edge of the absolute position R0 to REG_POS, the absolute position of the falling edge to the Z REG_POSB
- 8 input signal R0 to the absolute position of the falling edge REG_POS, absolute position signal to the rising edge Z REG_POSB
- 9 input signal R0 to the absolute position of the falling edge REG_POS, the absolute position of the falling edge to the Z REG_POSB
- 10 input signal Rising edge of the absolute position R0 to REG_POS, the absolute position of the rising edge of the input signal R1 to REG_POSB
- 11 R0 absolute position input signal to the rising edge of REG_POS, the absolute position of the edge of the input signal R1 to REG_POSB
- 12 input signal Absolute position R0 to the falling edge of the REG_POS, the absolute position of the rising edge of the input signal R1 to REG_POSB
- 13 input signal R0 to the absolute position of the falling edge REG_POS, the absolute position of the falling edge of the input signal to R1 REG_POSB

return value:error code

3.2.1.8 ZAux_Direct_EncoderRatio

Function: Electronic gear ratio setting, refer to the software manual "ENCODER_RATIO" Instruction Prototype:.. Int32 stdcall
 ZAux_Direct_EncoderRatio (ZMC_HANDLE handle, int imposcount, int inputcount)

Input parameters:

handle	Markup
imposcount	molecular
inputcount	
	Deno

minator Return Value:

3.2.1.9 ZAux_Direct_StepRatio

Function: Set a stepping output gear ratio, the reference
software manual "STEP_RATIO "Instruction Prototype: Int32 stdcall
ZAux_Direct_StepRatio (ZMC_HANDLE handle, int ioutcount, int idposcount)

Input parameters:

handle

Markup

ioutcount molecular
 idposcount
 Deno
 minator Return Value:
 Error code

3.2.2. Multi-axis linear interpolation

The multi-axis interpolation is a motion in front of the current motion "ZAux_Direct_Base" function Axis list to select the corresponding base of the axes involved, the spindle base parameters of a spindle axis interpolated motion, the motion parameters are used for interpolation. Movement divided fairly and absolute motions (ABS suffix), and can specify the current movement of the SP movement. SP Sport can refer to the software manual "* SP" instruction.

3.2.2.1 ZAux_Direct_Move

:: relative function-linear interpolation, the movement shaft is a listing of previously defined BASE. Prototype: int32 stdcall ZAux_Direct_Move (ZMC_HANDLE handle, int imaxaxes, float * pfDisancelist)

Input parameters:

handle	Markup
imaxaxes	Axes of Motion
pfDisancelist	The return
value from the list of sports: error	
code	

3.2.2.2 ZAux_Direct_MoveSp

Function: SP relative movement corresponding to linear interpolation instructions, which army Software Manual "* SP" instruction.

prototype: int32 stdcall ZAux_Direct_MoveSp (ZMC_HANDLE handle, int imaxaxes, float * pfDisancelist)

Input parameters:

handle	Markup
imaxaxes	Axes of Motion
pfDisancelist	The return
value from the list of sports: error	

code

3.2.2.3 ZAux_Direct_MoveAbs

Function: Absolute linear interpolation, a list BASE axis motion axis is defined in advance.

prototype: int32 stdcall ZAux_Direct_MoveAbs (ZMC_HANDLE handle, int imaxaxes, float * pfDisancelist)

Input parameters:

handle	Markup
imaxaxes	Axes of Motion
pfDisancelist	The return
value from the list of sports: error	
code	

3.2.2.4 ZAux_Direct_MoveAbsSp

Function: Absolute linear interpolation motion command corresponding to SP, which the army Software Manual “* SP” instruction.

prototype: int32 stdcall ZAux_Direct_MoveAbsSp (ZMC_HANDLE handle, int imaxaxes, float * pfDisancelist)

Input parameters:

handle	Markup
imaxaxes	Axes of Motion
pfDisancelist	The return
value from the list of sports: error	
code	

3.2.2.5 ZAux_Direct_MoveModify

Function: to modify the target position on a movement when there is no movement in front of the MOVEABS the same effect, refer to the software manual in the “MOVEMODIFY” command. Use MOVEMODIFY speed will destroy the continuity of the continuous interpolation; MOVEMODIFY while not necessarily a linear interpolation of multi-axial movement.

prototype: int32 stdcall ZAux_Direct_MoveModify (ZMC_HANDLE handle, int imaxaxes, float * pfDisancelist)

Input parameters:

handle	Markup
imaxaxes	Axes of Motion
pfDisancelist	The return
value from the list of sports: error code	

3.2.3 Arc, ellipse, spiral interpolation

The multi-axis interpolation is a motion in front of the current motion “ZAux_Direct_Base” function Axis list to select the corresponding base of the axes involved, the spindle base parameters of a spindle axis

interpolated motion, the motion parameters are used for interpolation. Movement divided fairly and absolute motions (ABS suffix), and can specify the current movement of the SP movement. SP Sport can refer to the software manual "* SP" instruction. And a complete circle arc instruction has three points define two ways and given center circle. 3:00 specifies a point on the circle and intermediate to the end point timing round. Videos may be a full circle or a space by calling the center circle arc corresponding to the selected mode is implemented.

3.2.3.1 ZAux_Direct_MoveCirc

Function Function: BASE The first and second axes circular interpolation, relatively movable manner. See Software Manual inside the "MOVECIRC" command.

prototype: int32 stdcall ZAux_Direct_MoveCirc (ZMC_HANDLE handle, float fend1, float fend2, float fcenter1, float fcenter2, int idirection);

Input parameters:

handle	Markup
fend1	A first coordinate axis motion
fend2	The second motion axis coordinate
fcenter1	The first center axis motion, relative to the starting point
fcenter2	The second center axis motion, relative to the starting point
idirection0-	Counterclockwise, clockwise 1-
Return Value: Error Code	

3.2.3.2 ZAux_Direct_MoveCircSp

Function: SP motion instructions corresponding to the relative movement, which army Software Manual "* SP" instruction.

prototype: int32 stdcall ZAux_Direct_MoveCircSp (ZMC_HANDLE handle, float fend1, float fend2, float fcenter1, float fcenter2, int idirection);

Input parameters:

handle	Markup
fend1	A first coordinate axis motion
fend2	The second motion axis coordinate
fcenter1	The first center axis motion, relative to the starting point
fcenter2	The second center axis motion, relative to the starting point
idirection0-	Counterclockwise, clockwise 1-
Return Value: Error Code	

3.2.3.3 ZAux_Direct_MoveCircAbs

Function Function: BASE The first and second axes circular interpolation absolute move mode, see inside the software manual "MOVECIRCABS" instruction.

prototype: int32 stdcall ZAux_Direct_MoveCircAbs (ZMC_HANDLE handle, float fend1, float fend2, float fcenter1, float fcenter2, int idirection);

Input parameters:

handle	Markup
fend1	The first movement coordinate axis,
absolute position	
fend2	The second motion coordinate axes, the
absolute position	
fcentre1	The first movement of the center axis,
absolute position	
fcentre2	The second movement of the center axis,
absolute position	
idirection0-	Counterclockwise, clockwise 1-

returnReturn value:error code

3.2.3.4 ZAux_Direct_MoveCircAbsSp

Function: Absolute arc motion correspondence **SP motion commands, which join the army Software Manual "* SP" instruction.**

prototype: int32 stdcall ZAux_Direct_MoveCircAbsSp (ZMC_HANDLE handle, float fend1, float fend2, float fcenter1, float fcenter2, int idirection);

Input parameters:

handle	Markup
fend1	The first movement coordinate axis,
absolute position	
fend2	The second motion coordinate axes, the
absolute position	
fcentre1	The first movement of the center axis,
absolute position	
fcentre2	The second movement of the center axis,
absolute position	
idirection0-	Counterclockwise,
clockwise 1-	Return Value: Error Code

3.2.3.5 ZAux_Direct_MoveCirc2

Function: circular interpolation, the first and second shafts BASE circular interpolation, relatively movable manner, see inside the software manual "MOVECIRC2" instruction.

prototype: int32 stdcall ZAux_Direct_MoveCirc2 (ZMC_HANDLE handle, float fmid1, float fmid2, float fend1, float fend2);

Input parameters:

handle	Markup
fmid1	A point intermediate the first axis,
starting from the opposite	
fmid2	The second axis intermediate point,
starting from the opposite	
fend1	The first shaft end point, starting
from the opposite	
fend2	The second shaft end points,
starting from the relative return value:	error code

3.2.3.6 ZAux_Direct_MoveCirc2Sp

Function: SP motion instructions corresponding to the relative

movement, which army Software Manual **"* SP"** instruction.
 prototype: int32 stdcall ZAux_Direct_MoveCirc2Sp (ZMC_HANDLE handle,
 float fmid1, float fmid2, float fend1, float fend2);

Input parameters:

handle	Markup
fmid1	A point intermediate the first axis, starting from the opposite
fmid2	The second axis intermediate point, starting from the opposite
fend1	The first shaft end point, starting from the opposite
fend2	The second shaft end points, starting from the opposite

return Return value:error code

3.2.3.7 ZAux_Direct_MoveCirc2Abs

Function: circular interpolation, the first and second shafts
BASE circular interpolation, absolute moves, see inside the
software manual "ZAux_MoveCirc2Abs" instruction.

prototype: int32 stdcall ZAux_Direct_MoveCirc2Abs (ZMC_HANDLE handle,
float fmid1, float fmid2, float fend1, float fend2);

Input parameters:

handle	Markup
fmid1	A first axis intermediate point, the
absolute position	
fmid2	The second axis
intermediate point, the absolute position	fend1
	The first axis end point,
the absolute position	fend2
end point, the absolute position	The second axis

return value:error code

3.2.3.8 ZAux_Direct_MoveCirc2AbsSp

Function: Absolute arc motion correspondence **SP motion commands,**
which join the army Software Manual "* SP" instruction.

prototype: int32 stdcall ZAux_Direct_MoveCirc2AbsSp (ZMC_HANDLE
handle, float fmid1, float fmid2, float fend1, float fend2);

Input parameters:

handle	Markup
fmid1	A first axis intermediate point, the
absolute position	
fmid2	The second axis
intermediate point, the absolute position	fend1
	The first axis end point,
the absolute position	fend2
end point, the absolute position	The second axis

return value:error code

3.2.3.9 ZAux_Direct_MHelical

Functions Function: BASE of the first and second axes circular
interpolation axis of the third coil, relative to the starting
point.

prototype: int32 stdcall ZAux_Direct_MHelical (ZMC_HANDLE handle, float fend1, float fend2, float fcenter1, float fcenter2, int idirection, float fDistance3, int imode);

Input parameters:

handle	Markup
fend1	A first coordinate axis motion
fend2	The second motion axis coordinate
fcentre1	The first center axis motion, relative to the starting point

fcentre2 The second center axis motion, relative to the starting point
idirection0- Counterclockwise, clockwise 1-
fdistance3 The third axis movement distance.
imode Calculating speed of the third shaft:
 0 (default) Participation third shaft speed calculation.
 1 Third shaft does not participate in the velocity calculation.
return value:error code

3.2.3.10 ZAux_Direct_MHelicalSp

Function: SP motion instructions corresponding to the relative movement, which army Software Manual "* SP" instruction.
 prototype: int32 stdcall ZAux_Direct_MHelicalSp (ZMC_HANDLE handle, float fend1, float fend2, float fcenter1, float fcenter2, int idirection, float fDistance3, int imode);

parameter:

handle Markup
fend1 A first coordinate axis motion
fend2 The second motion axis coordinate
fcentre1 The first center axis motion, relative to the starting point
fcentre2 The second center axis motion, relative to the starting point
idirection0- Counterclockwise, clockwise 1-
fdistance3 The third axis movement distance.
imode Calculating speed of the third shaft:
 0 (default) Participation third shaft speed calculation.
 1 Third shaft does not participate in the velocity calculation.
return value:error code

3.2.3.11 ZAux_Direct_MHelicalAbs

Function Function: BASE The first and second axes circular interpolation, a third helical axis, absolute moves.
 prototype: int32 stdcall ZAux_Direct_MHelicalAbs (ZMC_HANDLE handle, float fend1, float fend2, float fcenter1, float fcenter2, int idirection, float fDistance3, int imode);

Input parameters:

handle	Markup
fend1 coordinate	The first axis motion coordinate, absolute
fend2 coordinates	The second axis motion coordinate absolute
fcentre1 coordinates	The first center axis motion, absolute
fcentre2 coordinates	The second center axis motion, absolute
idirection0-	Counterclockwise, clockwise 1-
fdistance3 coordinates	The third axis movement distance. Absolute

imode Calculating speed of the third shaft:
0 (default) Participation third shaft speed
 calculation.
1 Third shaft does not
 participate in the velocity calculation.
return value:error code

3.2.3.12 ZAux_Direct_MHelicalAbsSp

Function: SP motion instructions corresponding to the relative movement, which army Software Manual "* SP" instruction.
prototype: int32 stdcall ZAux_Direct_MHelicalAbsSp (ZMC_HANDLE handle, float fend1, float fend2, float fcenter1, float fcenter2, int idirection, float fDistance3, int imode);

Input parameters:

handle	Markup
fend1	The first axis motion coordinate, absolute
coordinate	
fend2	The second axis motion coordinate absolute
coordinates	
fcentre1	The first center axis motion, absolute
coordinates	
fcentre2	The second center axis motion, absolute
coordinates	
idirection0-	Counterclockwise, clockwise 1-
fdistance3	The third axis movement distance. Absolute
coordinates	
imode	Calculating speed of the third shaft: 0 (default) Participation third shaft speed calculation. 1 Third shaft does not participate in the velocity calculation.

return value:error code

3.2.3.13 ZAux_Direct_MHelical2

Functions Function: BASE of the first and second axes circular interpolation axis of the third coil, the relative movement mode.

prototype: int32 stdcall ZAux_Direct_MHelical2 (ZMC_HANDLE handle, float fmid1, float fmid2, float fend1, float fend2, float fDistance3, int imode);

Input parameters:

handle	Markup
fmid1	A first intermediate point coordinate axis,

relative to the starting point

fmid2 The second intermediate point coordinate axes, as opposed to the starting point

fend1 The first axis end point coordinates, relative to the starting point

fend2 Second axis end point coordinates, relative to the starting point

fdistance3 The third axis movement distance.

imode Calculating speed of the third shaft:

0 (default) Participation third shaft speed calculation.

1 Third shaft does not participate in the velocity calculation.

return value:error code

3.2.3.14 ZAux_Direct_MHelical2Sp

Function: SP motion instructions corresponding to the relative movement, which army Software Manual "* SP" instruction.

prototype: int32 stdcall ZAux_Direct_MHelical2Sp (ZMC_HANDLE handle, float fmid1, float fmid2, float fend1, float fend2, float fDistance3, int imode);

Input parameters:

handle	Markup
fmid1	A first intermediate point coordinate axis, relative to the starting point
fmid2	The second intermediate point coordinate axes, as opposed to the starting point
fend1	The first axis end point coordinates, relative to the starting point
fend2	Second axis end point coordinates, relative to the starting point
fdistance3	The third axis movement distance.
imode	Calculating speed of the third shaft: 0 (default) Participation third shaft speed calculation. 1 Third shaft does not participate in the velocity calculation.

return value: error code

3.2.3.15 ZAux_Direct_MHelical2Abs

Functions Function: BASE of the first and second axes circular interpolation axis of the third coil, the absolute moves.

prototype: int32 stdcall ZAux_Direct_MHelical2Abs (ZMC_HANDLE handle, float fmid1, float fmid2, float fend1, float fend2, float fDistance3, int imode);

Input parameters:

handle	Markup
fmid1	A first intermediate shaft coordinates, absolute coordinates
fmid2	The second intermediate shaft coordinates, absolute coordinates
fend1	The first axis end point coordinates, absolute coordinates
fend2	The second axis end point coordinates, absolute coordinates
fdistance3	The third axis movement distance.
imode	Calculating speed of the third shaft: 0 (default) Participation third shaft speed

calculation.

1 Third shaft does not
participate in the velocity calculation.

return value:error code

3.2.3.16 ZAux_Direct_MHelical2AbsSp

Function: Absolute movement corresponding to the SP sports
instruction, which the army Software Manual "* SP" instruction.

prototype: int32 stdcall ZAux_Direct_MHelical2AbsSp (ZMC_HANDLE
handle, float fmid1, float fmid2, float fend1, float fend2, float fDistance3, int
imode); Input parameters:

handle Markup

fmid1 A first intermediate shaft coordinates, absolute coordinates
fmid2 The second intermediate shaft coordinates, absolute coordinates
fend1 The first axis end point coordinates, absolute coordinates
fend2 The second axis end point coordinates, absolute coordinates
fdistance3 The third axis movement distance.
imode Calculating speed of the third shaft:
 0 (default) Participation third shaft speed calculation.
 1 Third shaft does not participate in the velocity calculation.
return value:error code

3.2.3.17 ZAux_Direct_MEclipse

Function Function: BASE The first and second shafts elliptical interpolation, relatively movable manner, see inside the software manual "MECLIPSE" instruction.

prototype: int32 stdcall ZAux_Direct_MEclipse (ZMC_HANDLE handle, float fend1, float fend2, float fcenter1, float fcenter2, int idirection, float fADis, float fBDis);

Input parameters:

handle Markup
fend1 A first coordinate axis motion
fend2 The second motion axis coordinate
fcentre1 The first center axis motion, relative to the starting point
fcentre2 The second center axis motion, relative to the starting point
idirection0- Counterclockwise, clockwise 1-
fADis Elliptical radius of the first shaft, can be semi-major axis or minor axis half
fBDis Elliptical radius of the second shaft can be semi-major axis or minor axis half, AB
 Automatically equal arc or spiral.
return value:error code

3.2.3.18 ZAux_Direct_MEclipseSp

Function: SP motion instructions corresponding to the relative

movement, which army Software Manual “* SP” instruction.
prototype: int32 stdcall ZAux_Direct_MEclipseSp (ZMC_HANDLE handle,
float fend1, float fend2, float fcenter1, float fcenter2, int idirection, float fADis,
float fBDis);

Input parameters:

handle	Markup
fend1	A first coordinate axis motion
fend2	The second motion axis coordinate
fcentre1	The first center axis motion, relative to the starting point
fcentre2	The second center axis motion, relative to the starting point
idirection0-	Counterclockwise, clockwise 1-

fADis Elliptical radius of the first shaft, can be semi-major axis or minor axis half
fBDis Elliptical radius of the second shaft can be semi-major axis or minor axis half, AB
Automatically equal arc or spiral.
return value:error code

3.2.3.19 ZAux_Direct_MEclipseAbs

Function Function: BASE The first and second shafts elliptical interpolation absolute move mode, see inside the software manual "MEclipseAbs" instruction.

prototype:int32 stdcall ZAux_Direct_MEclipseAbs (ZMC_HANDLE handle, float fend1, float fend2, float fcenter1, float fcenter2, int idirection, float fADis, float fBDis);

Input parameters:

handle	Markup
fend1	The first coordinate axis movement absolute coordinates
fend2	The second axis motion coordinate absolute coordinates
fcentre1	The first center axis motion, absolute coordinates
fcentre2	The second center axis motion, absolute coordinates
idirection0-	Counterclockwise, clockwise 1-
fADis	Elliptical radius of the first shaft, can be semi-major axis or minor axis half
fBDis	Elliptical radius of the second shaft can be semi-major axis or minor axis half, AB Automatically equal arc or spiral.

return value:error code

3.2.3.20 ZAux_Direct_MEclipseAbsSp

Function: Absolute movement corresponding to the SP sports instruction, which the army Software Manual "* SP" instruction.

prototype:int32 stdcall ZAux_Direct_MEclipseAbsSp (ZMC_HANDLE handle, float fend1, float fend2, float fcenter1, float fcenter2, int idirection, float fADis, float fBDis);

Input parameters:

handle	Markup
fend1	The first coordinate axis movement

absolute coordinates
fend2 The second axis motion coordinate absolute
coordinates
fcentre1 The first center axis motion, absolute
coordinates
fcentre2 The second center axis motion, absolute
coordinates
idirection0- Counterclockwise, clockwise 1-
fADis Elliptical radius of the first shaft, can be
semi-major axis or minor axis half
fBDis Elliptical radius of the second shaft can be
semi-major axis or minor axis half, AB
Automatically equal arc or spiral.
return value:error code

3.2.3.21 ZAux_Direct_MEclipseHelical

Function: The first and second shafts BASE elliptical interpolation moves relative to the third axis Synchronization spiral

prototype: int32 stdcall ZAux_Direct_MEclipseHelical (ZMC_HANDLE handle, float fend1, float fend2, float fcenter1, float fcenter2, int idirection, float fADis, float fBDis, float fDistance3);

Input parameters:

handle	Markup
fend1	A first coordinate axis motion
fend2	The second motion axis coordinate
fcentre1	The first center axis motion, relative to the starting point
fcentre2	第二个轴运动圆心，相对与起始点
idirection0-	逆时针，1-顺时针
fADis	第一轴的椭圆半径，半长轴或者半短轴都可
fBDis	第二轴的椭圆半径，半长轴或者半短轴都可，AB 相等时自动为圆弧或螺旋。
fDistance3	第三个轴的运动坐标

返回值：错误码

3.2.3.22 ZAux_Direct_MEclipseHelicalSp

函数功能: 相对运动对应 SP 运动指令，参军软件手册里面 “*SP” 指令。

原 型： int32 stdcall ZAux_Direct_MEclipseHelicalSp(ZMC_HANDLE handle, float fend1, float fend2, float fcenter1, float fcenter2, int idirection, float fADis,

float fBDis, float fDistance3);

输入参数:

handle	链接标识
fend1	第一个轴运动坐标
fend2	第二个轴运动坐标
fcentre1	第一个轴运动圆心，相对与起始点
fcentre2	第二个轴运动圆心，相对与起始点
idirection0-	逆时针，1-顺时针
fADis	第一轴的椭圆半径，半长轴或者半短轴都可
fBDis	第二轴的椭圆半径，半长轴或者半短轴都可，AB 相等时自动为圆弧或螺旋。
fDistance3	第三个轴的运动坐标

返回值：错误码

3.2.3.23 ZAux_Direct_MEclipseHelicalAbs

函数功能: BASE
轴

第一轴和第二轴进行椭圆插补, 绝对移动方式, 第三个

同步螺旋

原 型 : int32 stdcall ZAux_Direct_MEclipseHelicalAbs(ZMC_HANDLE handle, float fend1, float fend2, float fcenter1, float fcenter2, int idirection, float fADis, float fBDis, float fDistance3);

输入参数:

handle	链接标识
fend1	第一个轴运动坐标, 绝对坐标
fend2	第二个轴运动坐标, 绝对坐标
fcentre1	第一个轴运动圆心, 绝对坐标
fcentre2	第二个轴运动圆心, 绝对坐标
idirection0-	逆时针, 1-顺时针
fADis	第一轴的椭圆半径, 半长轴或者半短轴都可
fBDis	第二轴的椭圆半径, 半长轴或者半短轴都可, AB 相等时自动为圆弧或螺旋。
fDistance3	第三个轴的运动坐标

返回值: 错误码

3.2.3.24 ZAux_Direct_MEclipseHelicalAbsSp

函数功能: 绝对运动对应 SP 运动指令, 参军软件手册里面 “*SP” 指令。

原 型 : int32 stdcall ZAux_Direct_MEclipseHelicalAbsSp (ZMC_HANDLE handle, float fend1, float fend2, float fcenter1, float fcenter2, int idirection, float fADis, float fBDis, float fDistance3);

Input parameters:

handle	Markup
fend1	The first axis motion coordinate, absolute coordinate
fend2	The second axis motion coordinates, absolute coordinates
fcentre1	The first center axis motion, absolute coordinates
fcentre2	The second center axis motion, absolute coordinates
idirection0-	Counterclockwise, clockwise 1-
fADis	Elliptical radius of the first shaft, can be semi-major axis or minor axis half
fBDis	Elliptical radius of the second shaft can be semi-major axis or minor axis half, AB Automatically equal arc or spiral.
fDistance3	Movement of the

third axis coordinate value returns:

Error Code

3.2.3.25 ZAux_Direct_MSpherical

Function: space inside circular interpolation motion relative movement mode, see Software Manual "MSPHERICAL".

prototype: int32 stdcall ZAux_Direct_MSpherical (ZMC_HANDLE handle, float

fend1, float fend2, float fend3, float fcenter1, float fcenter2, float fcenter3, int imode, float fcenter4, float fcenter5)

Input parameters:

handle	Markup
fend1	A first motion axis distance parameter 1
fend2	The second motion axis distance parameter 1
fend3	The third axis motion distance parameter 1
fcentre1	A first motion axis distance parameter 2
fcentre2	The second axis motion distance parameter 2
fcentre3	The third axis motion distance parameter 2
imode	Front meaning specified parameters

0 current point, intermediate point, the end point of the arc is three,

Parameter 1 is the distance from the end point, the distance parameter 2

Distance of the intermediate point.

1 take the minimum arc, distance from the end of the parameter 1

Away from the center of the distance parameter 2.

2 the current point, intermediate point, end three fixed circle, from

From parameters 1 as the end point distance, a distance parameter 2

Distance of the intermediate point.

3 go first smallest arc, and then continue to go full circle, from

End at a distance parameter 1, parameter 2 as the center distance distance

Fcentre4 Fourth helical axis distance

Fcentre5 Fifth shaft

helical distance Return Value: Error

Code

3.2.3.26 ZAux_Direct_MSphericalSp

Function: SP motion instructions corresponding to the relative movement, which army Software Manual "* SP" instruction.
 prototype: int32 stdcall ZAux_Direct_MSphericalSp (ZMC_HANDLE handle, float fend1, float fend2, float fend3, float fcenter1, float fcenter2, float fcenter3, int imode, float fcenter4, float fcenter5)

Input parameters:

handle	Markup
fend1	A first motion axis distance parameter 1
fend2	The second motion axis distance parameter 1
fend3	The third axis motion distance parameter 1
fcentre1	A first motion axis distance parameter 2
fcentre2	The second axis motion distance parameter 2
fcentre3	The third axis motion distance parameter 2
imode	Front meaning specified parameters

0 current point, intermediate point, the end point of the arc is three,

Parameter 1 is the distance from the end point, the distance parameter 2 Distance of the intermediate point.

1 take the minimum arc, distance from the end of the parameter 1

Away from the center of the distance parameter 2.

2 the current point, intermediate point, end three fixed circle, from

From parameters 1 as the end point distance, a distance parameter 2 Distance of the intermediate point.

3 go first smallest arc, and then continue to go full circle,

Parameter 1 is the distance from the end point, the distance parameter 2

As the center distance

Fcentre4 Fourth helical axis distance

Fcentre5 Fifth shaft

helical distance Return Value: Error

Code

3.2.3.27 ZAux_Direct_MoveSpiral

Function: involute circular interpolation, relatively movable manner, when starting radius **0 direct diffusion**

0 point of view from the beginning, the army inside the software manual "MOVESPIRAL "Instruction Prototype: int32 stdcall

ZAux_Direct_MoveSpiral (ZMC_HANDLE handle, float centre1, float centre2, float circles, float pitch, float distance3, float distance4); Input parameters:

handle Markup

centre1 The center axis of the first relative

distance

centre2 The center of the second shaft relative

distance

circles Number of turns to rotate, can be a decimal circle, a negative number indicates clockwise

<p>pitch</p> <p>distance3</p> <p>distance4</p> <p>return value:error code</p>	<p>The diffusion distance per lap, can be negative.</p> <p>Third shaft spiral function, the relative distance specified third axis, this axis does not participate in the velocity calculation.</p> <p>Spiral shaft 4 functions specify the relative distance between the first axis 4, this axis does not participate in the velocity calculation.</p>
---	---

3.2.3.28 ZAux_Direct_MoveSpiralSp

Function: SP motion instructions corresponding to the relative movement, which army Software Manual "* SP" instruction.
 prototype: int32 stdcall ZAux_Direct_MoveSpiralSSp (ZMC_HANDLE handle, float centre1, float centre2, float circles, float pitch, float distance3, float distance4);

Input parameters:

handle	Markup
--------	--------

centre1 The center axis of the first relative distance

centre2 The center of the second shaft relative distance

circles Number of turns to rotate, can be a decimal circle, a negative number indicates clockwise

pitch The diffusion distance per lap, can be negative.

distance3 Third shaft spiral function, the relative distance specified third axis, this axis does not participate in the velocity calculation.

distance4 Spiral shaft 4 functions specify the relative distance between the first axis 4, this axis does not participate in the velocity calculation.

return value:error code

3.2.4 Special motion commands

3.2.4.1 ZAux_Direct_MoveLimit

Function: the increase in the current movement position of the end of the speed limit, for forcibly corner deceleration, see inside the software manual "MOVELIMIT" instruction.

prototype: int32 stdcall ZAux_Direct_MoveLimit (ZMC_HANDLE handle, float limitspeed);

Input parameters:

handle Markup

limitspeed To limit the

speed Return Value: Error Code

3.2.4.2 ZAux_Direct_MoveOp

Function: The command output is written to buffer movement inside, see Software Manual inside the "MOVE_OP" command.

prototype: int32 stdcall ZAux_Direct_MoveOp (ZMC_HANDLE handle, int ioutnum, int ivalue);

Input parameters:

handle	Markup
ioutnumIO	Numbering
ivaluelO	status
return value:	error code

3.2.4.3 ZAux_Direct_MoveOpMulti

Function: The command output is written to buffer movement inside, see Software Manual inside the "MOVE_OP" command.

prototype: int32 stdcall ZAux_Direct_MoveOpMulti (ZMC_HANDLE handle, int ioutnumfirst, int ioutnumend, int ivalue);

Input parameters:

handle	Markup
ioutnumfirst	A first output channel
to be operated ioutnumend	The last output
channel to operate ivalueIO	status

return value: error code

3.2.4.4 ZAux_Direct_MoveOp2

Function: The command output is written to buffer movement inside, see Software Manual inside the "MOVE_OP2" command.

prototype: int32 stdcall ZAux_Direct_MoveOp2 (ZMC_HANDLE handle, int ioutnum, int ivalue, int iofftimems);

Input parameters:

handle	Markup
ioutnumIO	Numbering
ivalueIO	status
iofftimemssms	After inversion time, to generate

a pulse output results Return value: Error Code

3.2.4.5 ZAux_Direct_MoveAout

Function: the analog output motion command written to the buffer inside, see Software Manual inside "MOVE_AOUT" command.

prototype: int32 stdcall ZAux_Direct_MoveAout (ZMC_HANDLE handle, int ioutnum, float fvalue);

Input parameters:

handle	Markup
ioutnumAOUT	Numbering
fvalue	Output analog

value Return value: Error Code

3.2.4.6 ZAux_Direct_MoveDelay

Function: the delay instruction buffer is written to the movement inside, see Software Manual inside the "MOVE_DELAY"

prototype: int32 stdcall ZAux_Direct_MoveDelay (ZMC_HANDLE handle, int itimems);

Input parameters:

handle	Markup
itimems	Time

delay return value: error code

3.2.5 Synchronous motion commands

3.2.5.1 ZAux_Direct_Cam

Function: electronic cam, CAM command according to the data stored in the TABLE to determine the shaft Sports, see Software Manual inside the "CAM" command.

prototype: int32 stdcall ZAux_Direct_Cam (ZMC_HANDLE handle, int istartpoint, int iendpoint, float ftablemulti, float fDistance);

Input parameters:

handle	Markup
istartpoint	TABLE numbered starting position, the first point is stored
iendpoint	TABLE end point number
ftablemulti	This ratio is multiplied by a position, a pulse is generally equivalent.
fDistance	Reference movement distance, to calculate the total exercise time. Return value: error code

3.2.5.2 ZAux_Direct_Cambox

Function: electronic cam, CAMBOX instructions to determine the movement of the shaft, see the inside of the software manual "CAMBOX" instruction data stored in the TABLE.

prototype: int32 stdcall ZAux_Direct_Cambox (ZMC_HANDLE handle, int istartpoint, int iendpoint, float ftablemulti, float fDistance, int ilinkaxis, int ioption, float flinkstartpos);

Input parameters:

handle	Markup
istartpoint	TABLE numbered starting position, the first point is stored
iendpoint	TABLE end point number
ftablemulti	This ratio is multiplied by a position, a pulse is generally equivalent.
fDistance	Reference movement distance, to calculate the total exercise time.

llinkaxis Reference axis.

loption Connection with the reference axis,
different bits represent different significance

When Bit 0 latch signal when the
reference axis (the Regist) event
is triggered, the current axis
motion reference axis make the
connection.

When Bit 1 is set to the reference axis
motion absolute position, the
reference axis current axis
connecting motion starts.

Bit 2 auto-repeat continuous two-way
operation. (By setting
REP_OPTION = 1, can be
canceled repeat)

Bit 5 only forward motion of the reference
axis is connected only

Flinkstartpos When loption parameter is set to 2, the
parameter indicates the absolute position of the connection
started

return value:error code

3.2.5.3 ZAux_Direct_Connpath

Function: electronic gear, the position of the interpolation
vector of the target current idringaxis axis length of the shaft
are connected by an electronic gear. See Software Manual inside
the "CONNPATH" command. prototype: int32 stdcall ZAux_Direct_Connpath
(ZMC_HANDLE handle, float ratio, int link_axis, int move_axis);

Input

parameters:

handle	Markup
fratio	Rate, either positive or negative, note the number of pulses proportional
idringaxis shaft	Number shaft (spindle) of the connecting shaft
moveaxis	No movement

of the shaft axis Return Value:

Error Code

3.2.5.4 ZAux_Direct_Connect

Function: electronic gear, the position of the interpolation vector of the target current idringaxis axis length of the shaft are connected by an electronic gear. See Software Manual inside the "CONNECT" command. prototype: int32 stdcall ZAux_Direct_Connect (ZMC_HANDLE handle, float ratio, int link_axis, int move_axis);

Input

parameters:

handle	Markup
fratio	Rate, either positive or negative, note the number of pulses proportional
idringaxis	Number shaft (spindle) of the connecting shaft
moveaxis	No movement of the shaft axis

returnReturn value:error code

3.2.5.5 ZAux_Direct_Movelink

Function: Self camming defined, with acceleration and deceleration of the stage movement can be provided, see Software Manual inside the "MOVELINK" command.

prototype: int32 stdcall ZAux_Direct_Movelink (ZMC_HANDLE handle, float fDistance, float fLinkDis, float fLinkAcc, float fLinkDec, int iLinkaxis, int ioption, float flinkstartpos);

Input parameters:

handle	Markup
fDistance	Starting from the end connected to the current distance of the axis, by using Family units
fLinkDis	Moving throughout the process connection from the forward reference axis, with units units.
fLinkAcc	In the acceleration phase of current axis, a forward movement distance of the reference axis, with units units.
fLinkDec	In the current deceleration phase axis, a forward movement distance of the reference axis, with units units.
iLinkaxis	Reference numbers shaft axis.
ioption	Connection mode options, different representatives of different binary significance.
	1 Bit 0 is connected to a precise time reference axis regist start event is triggered.
	2 Bit 1, the reference axis of a connection start position absolute arrival.
	4 Bit 2, when this is set, MOVELINK automatically and repeatedly performed may be reversed.
Flinkstartpos	When the link options parameter is set to 2, the reference axis parameter indicates the position at which the absolute value of the connection start

return value:error code

3.2.5.6 ZAux_Direct_Moveslink

Function: Self camming defined, with acceleration and deceleration of the stage movement can be provided, see Software Manual inside the "MOVESLINK" command.

prototype: int32 stdcall ZAux_Direct_Moveslink (ZMC_HANDLE handle, float fDistance, float fLinkDis, float startsp, float endsp, int iLinkaxis, int ioption, float flinkstartpos)

Input parameters:

handle	Markup
fDistance	Starting from the end connected to the current distance of the axis, by using

Householdunit

fLinkDis Moving throughout the process connection
from the forward reference axis, with

units units.

startsp When starting the main motion of the shaft
speed ratio.

endsp At the end of the movement of the main shaft
speed ratio.

iLinkaxis Reference numbers shaft axis.

loption Connection mode options, different
representatives of different binary significance.

3 Bit 0 is connected to a precise time
reference axis regist start event
is triggered.

4 Bit 1, the reference axis of a
connection start position absolute
arrival.

5 Bit 2, when this is set, MOVELINK
automatically and repeatedly performed
may be reversed.

Flinkstartpos When the link options parameter is set to 2,
the reference axis parameter indicates the
position at which the absolute value of the
connection start

return value:error code

3.2.5.7 ZAux_Direct_Connframe

Function: robot instructions, see Software Manual inside the
"CONNFRAME" command. prototype: int32 stdcall ZAux_Direct_Connframe
(ZMC_HANDLE handle, int frame, int tablenum, int imaxaxes, int *
piAxislist);

Input parameters:

handle Markup

frame Robot Type 1-scara3-Stacking....

Tablenum TABLE robot parameters stored

starting point imaxaxes The number of
associated virtual axis

piAxislist Virtual Axis

list associated with the return value:

error code

3.2.5.8 ZAux_Direct_Connreframe

Function: robot instructions, see Software Manual inside the
"CONNREFRAME" command. prototype: int32 stdcall

ZAux_Direct_Connreframe (ZMC_HANDLE handle, int frame, int tablenum, int
imaxaxes, int * piAxislist);

Input parameters:

handle Markup

handle Markup

frame Robot Type 1-scara3-Stacking....

Tablenum TABLE robot parameters stored

starting point imaxaxes The number of

associated joint axis

piAxislist A list of
associated joint axis Return Value:
Error Code

3.2.6 Single-axis motion command

3.2.6.1 ZAux_Direct_Singl_Addax

Function: sports overlay.

prototype: int32 stdcall ZAux_Direct_Singl_Addax (ZMC_HANDLE handle,
int iaxis, int iaddaxis);

Input parameters:

handle	Markup
iaxis	Axis number
iaddaxis	Axis

number superimposed Return Value:

Error Code

3.2.6.2 ZAux Direct_Singl_Cancel

Function: uniaxial decelerated to a stop.

prototype: int32 stdcall ZAux Direct_Singl_Cancel (ZMC_HANDLE handle, int
iaxis, int imode);

Input parameters:

handle	Markup
iaxis	Axis number
imode	mode
	0 Cancel the current movement
	1 Cancel buffer sports
	2 Cancel the current buffer sports and sports

return value: error code

3.2.6.3 ZAux_Direct_Singl_Vmove

functionFunction: Single Instruction, continuous movement in one direction, see Software Manual inside the "VMOVE" instruction.

prototype: int32 stdcall ZAux_Direct_Singl_Vmove (ZMC_HANDLE handle, int iaxis, int idir);

loseThe parameters:

handle	Markup
iaxis	Axis number
idir	-1- negative direction,
1- Forward Return Value: Error Code	

3.2.6.4 ZAux_Direct_Singl_Move

Function: single-axis relative motion.

prototype: int32 stdcall ZAux_Direct_Singl_Move (ZMC_HANDLE handle, int iaxis, float fdistance)

Input parameters:

handle	Markup
iaxis	Axis number
fdistance	distance
return value:error code	

3.2.6.5 ZAux_Direct_Singl_MoveAbs

Function: single-axis absolute motion

prototype: int32 stdcall ZAux_Direct_Singl_MoveAbs (ZMC_HANDLE handle, int iaxis, float fdistance);

Input parameters:

handle	Markup
iaxis	Axis number
fdistance	Absolute
distance Return Value: Error code	

3.2.6.6 ZAux_Direct_Singl_Datum

Function: single-axis homing command.

prototype: int32 stdcall ZAux_Direct_Singl_Datum (ZMC_HANDLE handle, int iaxis, int imode);

Input parameters:

handle	Markup
iaxis	Axis number
imode	mode
0	Clear the error status of all axes.
1	CREEP shaft speed forward run until the DPOS signal value Z is

reset to 0 while correcting MPOS.

- 2 CREEP axis Z to run until the reverse speed signal appears. DPOS value is reset to 0 while correcting MPOS.
- 3 runs forward at the shaft speed SPEED, until it hits the home switch. Then CREEP shaft speed reverse movement until the switch from the origin. DPOS value is reset to 0 while correcting MPOS
- In reverse operation shaft 4 SPEED speed until hitting the home switch. Then CREEP axis from the origin until the speed of forward motion switch. DPOS value is reset to 0 while correcting MPOS.
- 5 SPEED axis runs forward at speed, until it hits the home switch. Then CREEP shaft speed reverse movement until the switch from the origin, and then continue to creep speed reverse signal Z until it hits. DPOS value is reset to 0 while correcting MPOS
- 6 SPEED-axis inverted run at speed until hitting the home switch. Then CREEP axis from the origin until the speed of forward motion switch, and then continuing until the forward creep speed signal Z encountered. DPOS value is reset to 0 while correcting MPOS.

return value:error code

3.3 Introduction state function parameters shaft axis

3.3.1.1 ZAux_Direct_SetParam

Function: Review axis parameter, the parameter corresponding axis by sending the read command basic

prototype: int32 stdcall ZAux_Direct_SetParam (ZMC_HANDLE handle, const char * sParam, int iaxis, float fset);

Input parameters:

handle	Markup
sParam	String name of the parameter
iaxis	Axis number

fset Parameter Value
return value:error code

3.3.1.2 ZAux_Direct_GetParam

Function: read axis parameter

prototype: int32 stdcall ZAux_Direct_GetParam (ZMC_HANDLE handle,
const char * sParam, int iaxis, float * pfValue);

loseThe parameters:

handle Markup
 sParam String name of the parameter
 iaxis Axis number
 pfValue Return
 value Return value: error code

3.3.2 The basic parameters of the function shaft

3.3.2.1 ZAux_Direct_SetAtype

Function: Set axis type, see inside the software manual "ATYPE" instruction. prototype: int32 stdcall ZAux_Direct_SetAtype (ZMC_HANDLE handle, int iaxis, int iValue);

Input parameters:

handle Markup
 iaxis Axis number
 fset Types of

Atype type	desc
0	Virtual axis;
1	Stepper or servo mode pulse
2	Servo control of the analog signal
3	Quadrature encoder
4	Stepper + Encoder
6	Direction encoder pulse mode, can be used to input hand wheel
7	Pulse direction stepper or servo
8	ZCAN extended pulse direction with
9	ZCAN extended orthogonal encoder.
10	ZCAN direction of extension encoder

returnReturn value:error code

3.3.2.2 ZAux_Direct_GetAtype

Function: read axis parameter

prototype: int32 stdcall ZAux_Direct_GetAtype (ZMC_HANDLE handle, int iaxis, int * piValue);

Input parameters:

handle Markup
iaxis Axis number

Output parameters:

piValue Return

Value Returns axis type: Error

Code

3.3.2.3 ZAux_Direct_SetInvertStep

Function: Set pulse output mode, see inside the software manual "INVERT_STEP" instruction.

prototype: int32 stdcall ZAux_Direct_SetInvertStep (ZMC_HANDLE handle, int iaxis, int iValue);

parameter:

handle Markup
iaxis Axis number
iValue Default mode type 0

低8位（位0-位7）表示的模式如下。

0-3 脉冲方向模式。

4-7 双脉冲方式（部分控制器版本不支持，详细咨询厂商）

各个模式对应的电平如下：

模式	正向运动		负向运动	
	脉冲线	方向线	脉冲线	方向线
0		High		Low
1		High		Low
2		Low		High
3		Low		High
4		High	High	
5	High			High
6		Low	Low	
7	Low			Low

高8位（位8-位15）表示方向变化保护时间，单位微秒：0-255

如果模式设定不正确，步进马达可能会在换向时丢失一步的位置，当不确定步进马达的设置时，可以设置100微秒左右的保护时间。

return value:error code

3.3.2.4 ZAux_Direct_GetInvertStep

Function: reading pulse output mode

prototype: int32 stdcall ZAux_Direct_GetInvertStep (ZMC_HANDLE handle, int iaxis, int * piValue);

Input parameters:

handle	Markup
iaxis	Axis number

Input parameters:

piValue	Returns the
current mode	Return value: error
code	

3.3.2.5 ZAux_Direct_SetUnits

Function: Set pulse equivalent, see inside the software manual "UNITS" instruction. When set 1 is expressed in units of one pulse.

prototype: int32 stdcall ZAux_Direct_SetUnits (ZMC_HANDLE handle, int iaxis, float fValue);

handle	Markup
iaxis	Axis number
fValue	Pulse

equivalent set return value: error code

3.3.2.6 ZAux_Direct_GetUnits

Function: read pulse equivalent

prototype: int32 stdcall ZAux_Direct_GetUnits (ZMC_HANDLE handle, int iaxis, float * pfValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

pfValue	Axis pulse
equivalent return	Return Value:
Error Code	

3.3.2.7 ZAux_Direct_SetAccel

Function: an acceleration unit units / s / s, see Software Manual inside the "ACCEL" instruction.

prototype: int32 stdcall ZAux_Direct_SetAccel (ZMC_HANDLE handle, int iaxis,

```
float fValue);
Input parameters:
    handle           Markup
    iaxis            Axis number
    pfValue          Acceleration
settings return value: error
code
```

3.3.2.8 ZAux_Direct_GetAccel

Function: read acceleration
 prototype: int32 stdcall ZAux_Direct_GetAccel (ZMC_HANDLE handle, int iaxis, float * pfValue);
 Input parameters:
 handle Markup
 iaxis Axis number
 Output parameters:
 pfValue Acceleration
 of the return value is returned:
 error code

3.3.2.9 ZAux_Direct_SetDecel

Function: Set the deceleration units units / s / s, see inside the software manual "DECEL" instruction.
 prototype: int32 stdcall ZAux_Direct_SetDecel (ZMC_HANDLE handle, int iaxis, float fValue);
 Input parameters:
 handle Markup
 iaxis Axis number
 pfValue Deceleration
 set return value: error code

3.3.2.10 ZAux_Direct_GetDecel

Function: reading deceleration
 prototype: int32 stdcall ZAux_Direct_SetFastDec (ZMC_HANDLE handle, int iaxis, float fValue);
 Output parameters:
 handle Markup
 iaxis Axis number
 pfValue Return Value

Returns deceleration: error code

3.3.2.11 ZAux_Direct_SetFastDec

Function: rapid deceleration, the unit is **units / s / s**, is automatically adopted in the **CANCEL**, or abnormally stops, when the value is set to 0 automatically **DECEL**, see inside the software manual "**FASTDEC**" instruction.

prototype: int32 stdcall ZAux_Direct_SetFastDec (ZMC_HANDLE handle, int iaxis, float fValue);

Input parameters:

handle	Markup
iaxis	Axis number
pfValue	Rapid

deceleration set return value: error code

3.3.2.12 ZAux_Direct_GetFastDec

Function: rapid deceleration reading

prototype: int32 stdcall ZAux_Direct_GetFastDec (ZMC_HANDLE handle, int iaxis, float * pfValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

pfValue	Rapid
---------	-------

deceleration return Return value:
Error Code

3.3.2.13 ZAux_Direct_SetSpeed

Function: an acceleration unit units / s, see Software Manual inside the "**SPEED**" instruction.

prototype: int32 stdcall ZAux_Direct_SetSpeed (ZMC_HANDLE handle, int iaxis, float fValue);

Input parameters:

handle	Markup
iaxis	Axis number
pfValue	Shaft speed

set return value: error code

3.3.2.14 ZAux_Direct_GetSpeed

Function: read acceleration

prototype: int32 stdcall ZAux_Direct_GetSpeed (ZMC_HANDLE handle,
int iaxis,

```
float * PfValue);
Input parameters:
    handle          Markup
    iaxis           Axis number
Output parameters:
    pfValue         Shaft speed
returns the return value: error
code
```

3.3.2.15 ZAux_Direct_SetCreep

Function: Set 2 crawling back to zero speed in units / s, see Software Manual inside the "CREEP" command.
 prototype: int32 stdcall ZAux_Direct_SetCreep (ZMC_HANDLE handle, int iaxis, float fValue);
 Input parameters:
 handle Markup
 iaxis Axis number
 pfValue Crawling speed
 setting return value: error code

3.3.2.16 ZAux_Direct_GetCreep

Function: read 2 times the speed of crawling back to zero
 prototype: int32 stdcall ZAux_Direct_GetCreep (ZMC_HANDLE handle, int iaxis, float * pfValue);
 Input parameters:
 handle Markup
 iaxis Axis number
 Output parameters:
 pfValue Return creep
 speed the return value: error code

3.3.2.17 ZAux_Direct_SetLspeed

Function: Set the start speed in units / s, see inside the software manual "LSPEED" instruction.
 prototype: int32 stdcall ZAux_Direct_SetLspeed (ZMC_HANDLE handle, int iaxis, float fValue);
 Input parameters:
 handle Markup
 iaxis Axis number

pfValue

Initial speed setting

returnvalue:error code

3.3.2.18 ZAux_Direct_GetLspeed

Function: read start speed

originaltype:int32 stdcall ZAux_Direct_GetLspeed (ZMC_HANDLE handle, int iaxis, float * pfValue);

Input

parameters:

handle	Markup
iaxis	Axis number

Output

parameters:

pfValue	Return Value
---------	--------------

Returns the initial velocity:

error code

3.3.2.19 ZAux_Direct_SetMerge

Function: Set continuous interpolation switches, software manual

see inside "MERGE" command. prototype:int32 stdcall

ZAux_Direct_SetMerge (ZMC_HANDLE handle, int iaxis, int iValue);

Input

parameters:

handle	Markup
iaxis	Axis number
iValue	Close 0-, 1- open

Return Value: Error Code

3.3.2.20 ZAux_Direct_GetMerge

Function: Continuous interpolation read switch status

prototype:int32 stdcall ZAux_Direct_GetMerge (ZMC_HANDLE handle, int iaxis, int * piValue);

Input

parameters:

handle	Markup
iaxis	Axis number

Output

parameters:

piValue	Returns status 0 - 1-
---------	-----------------------

Open Close Return Value: Error Code

3.3.2.21 ZAux_Direct_SetSramp

Function: S-curve setting unit ms, 0 indicates when the trapezoidal acceleration and deceleration. See Software Manual inside the "SRAMP" command.

prototype: `int32 stdcall ZAux_Direct_SetS ramp (ZMC_HANDLE handle, int iaxis, float fValue);`
Input parameters:

handle	Markup
iaxis	Axis number
pfValue	S curve set

return value: error code

3.3.2.22 ZAux_Direct_GetS ramp

Function: read the S-curve provided
prototype: `int32 stdcall ZAux_Direct_GetS ramp (ZMC_HANDLE handle, int iaxis, float * pfValue);`
parameter:

handle	Markup
iaxis	Axis number

Output parameters:

pfValue	S curve value
---------	---------------

returned Return Value: Error Code

3.3.2.23 ZAux_Direct_SetDpos

Function: Set the current position of the axis, units units. See Software Manual inside the "DPOS" instruction.
prototype: `int32 stdcall ZAux_Direct_SetDpos (ZMC_HANDLE handle, int iaxis, float fValue);`
Input parameters:

handle	Markup
iaxis	Axis number
pfValue	Current

axis position value return:
error code

3.3.2.24 ZAux_Direct_GetDpos

Function: Read the current position
prototype: `int32 stdcall ZAux_Direct_GetDpos (ZMC_HANDLE handle, int iaxis, float * pfValue);`
Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

pfValue Returns the current position

returnvalue:error code

3.3.2.25 ZAux_Direct_SetMpos

Function: Set axis measuring position feedback units units. See Software Manual inside the "MPOS" instruction.

prototype: int32 stdcall ZAux_Direct_SetMpos (ZMC_HANDLE handle, int iaxis, float fValue);

Input parameters:

handle	Markup
iaxis	Axis number
pfValue	Current

axis position value return:

error code

3.3.2.26 ZAux_Direct_GetMpos

Function: reading the position feedback

prototype: int32 stdcall ZAux_Direct_GetMpos (ZMC_HANDLE handle, int iaxis, float * pfValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

pfValue	Returns the
---------	-------------

current position of the return
value: error code

3.3.2.27 ZAux_Direct_GetEndMove

Function: read the current movement of the final position, the unit units, see Software Manual inside the "ENDMOVE" command.

prototype: int32 stdcall ZAux_Direct_GetEndMove (ZMC_HANDLE handle, int iaxis, float * pfValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

pfValue	Return
---------	--------

coordinate value Return Value:
Error code

3.3.2.28 ZAux_Direct_GetEndMoveBuffer

Function: the final position of the current read buffer and the movement can be used to convert the relative absolute, Units units, see the software manual inside. "ENDMOVE_BUFFER

"Instruction Prototype:.. Int32 stdcall ZAux_Direct_GetEndMoveBuffer (ZMC_HANDLE handle, int iaxis, float * pfValue)

Input

parameters:

handle	Markup
iaxis	Axis number

Output

parameters:

pfValue	Return
coordinate value	Return Value:
Error code	

3.3.2.29 ZAux_Direct_SetFsLimit

Function: Set axis positive soft limit, set to a larger value when the cancel soft limit. singleBit units. See Software Manual inside the "FS_LIMIT" command.

prototype: int32 stdcall ZAux_Direct_SetFsLimit (ZMC_HANDLE handle, int iaxis, float fValue);

Input

parameters:

handle	Markup
iaxis	Axis number
pfValue	Positive limit
value of the return	value: error
code	

3.3.2.30 ZAux_Direct_GetFsLimit

Function: read the positive soft limit value

prototype: int32 stdcall ZAux_Direct_GetFsLimit (ZMC_HANDLE handle, int iaxis, float * pfValue);

Input

parameters:

handle	Markup
iaxis	Axis number

Output

parameters:

pfValue Returns the
current position of the return
value: error code

3.3.2.31 ZAux_Direct_SetRsLimit

Function: Set axis negative soft limit, set to a larger value
when the cancel soft limit. single

Bit units. See Software Manual inside the "RS_LIMIT" command.

prototype: int32 stdcall ZAux_Direct_SetRsLimit (ZMC_HANDLE handle, int iaxis, float fValue);

Input parameters:

handle	Markup
iaxis	Axis number
pfValue	Setting the
limit value to the negative return	
value:	Error Code

3.3.2.32 ZAux_Direct_GetRsLimit

Function: read the positive soft limit value

prototype: int32 stdcall ZAux_Direct_GetRsLimit (ZMC_HANDLE handle, int iaxis, float * pfValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

pfValue	Returns the
current position of the return	
value:	error code

3.3.2.33 ZAux_Direct_GetIfIdle

Function: Read current axis motion has ended, see Software Manual inside the "IDLE" command. prototype: int32 stdcall ZAux_Direct_GetIfIdle (ZMC_HANDLE handle, int iaxis, int * piValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

piValue	Returns status 0 - not completed, -
1-- motion completion Return Value: Error Code	

3.3.2.34 ZAux_Direct_GetLoaded

Function: Are there buffer after reading the current movement, which refer to the software manual "LOADED" instruction.

prototype: int32 stdcall ZAux_Direct_GetIfIdle (ZMC_HANDLE handle, int iaxis, int * piValue);

Input parameters:

handle	Markup
--------	--------

iaxis

Axis number

Exportparameter:

piValue Returns status 0 – there is a
buffer -1 – None Return Value: Error Code

3.3.2.35 ZAux_Direct_GetMspeed

Function powerCan: read the current speed feedback unit **unitsSee Software Manual inside the "MSPEED" command.**

prototype: int32 stdcall ZAux_Direct_GetMspeed (ZMC_HANDLE handle, int iaxis, float * pfValue);

Input parameters:

handle Markup
iaxis Axis number

Output parameters:

pfValue Return Value
Returns speed feedback: error code

3.3.2.36 ZAux_Direct_GetMtype

Function: read the current movement instruction type, see Software Manual inside the "MTYPE" command. prototype: int32 stdcall

ZAux_Direct_GetMtype (ZMC_HANDLE handle, int iaxis, int * piValue);

Input parameters:

handle Markup
iaxis Axis number

Output parameters:

piValue Return
type Return value: error code

3.3.2.37 ZAux_Direct_GetNtype

Function: read the current movement of the next movement instruction type, see Software Manual inside the "NTYPE" command.

prototype: int32 stdcall ZAux_Direct_GetNtype (ZMC_HANDLE handle, int iaxis, int * piValue);

Input parameters:

handle Markup
iaxis Axis number

Output parameters:

piValue Return
type Return value: error code

3.3.2.38 ZAux_Direct_GetRemain

Function: Reads the current remaining movement distance in **units**, see **Software Manual inside the "REMAIN" command**.

prototype: int32 stdcall ZAux_Direct_GetRemain (ZMC_HANDLE handle, int iaxis, float * pfValue);

Input

parameters:

handle	Markup
iaxis	Axis number

Output

parameters:

pfValue	Return Value
---------	--------------

Returns the remaining distance:

error code

3.3.2.39 ZAux_Direct_VectorBuffered

Function: read the current buffer and the remaining movement distance in Units, see inside the software manual "VECTOR_BUFFERED" instruction.

prototype: int32 stdcall ZAux_Direct_VectorBuffered (ZMC_HANDLE handle, int iaxis, float * pfValue);

Input

parameters:

handle	Markup
iaxis	Axis number

Output

parameters:

pfValue	Return Value
---------	--------------

Returns the remaining distance:

error code

ZAux_Direct_GetVpSpeed letterNumber Function: read velocity axis, units **units / s**,

See Software Manual inside the "VP_SPEED" command.

prototype: int32 stdcall ZAux_Direct_GetVpSpeed (ZMC_HANDLE handle, int iaxis, float * pfValue);

Input

parameters:

handle	Markup
iaxis	Axis number

Output

parameters:

pfValue Returns the
current speed of the return value:
error code

3.3.2.40 ZAux_Direct_AxisStatus

Function: read the status of the current axis, "AXISSTATUS"
instruction.

prototype: int32 stdcall ZAux_Direct_GetAxisStatus (ZMC_HANDLE handle,
int iaxis, int * piValue);

loseThe parameters:

handle	Markup
iaxis	Axis number

Output parameters:

piValue Return status value, the
corresponding bit indicates different states of the
return value: error code

3.3.3 Other function parameters

3.3.3.1 ZAux_Direct_GetAddax

Function: Reads the current **No. ADDAX axis command superimposed axis and -1 is not superimposed. See Software Manual inside the "ADDAX_AXIS" command.**

prototype: int32 stdcall ZAux_Direct_GetRevIn (ZMC_HANDLE handle, int iaxis, int * piValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

piValue Returns the number corresponding to
the superposition of the shaft, -1-- axis overlay
no return value: error code

3.3.3.2 ZAux_Direct_SetAxisAddress

Function: the shaft extension axis address configuration, see inside the software manual "AXIS_ADDRESS" instruction.

prototype: int32 stdcall ZAux_Direct_SetAxisAddress (ZMC_HANDLE handle, int iaxis, int iValue);

Input parameters:

handle	Markup
iaxis	Axis number
iValue	Address

configuration return value:
error code

3.3.3.3 ZAux_Direct_GetAxisAddress

Function: the read address of the current axis of the shaft

```
prototype: int32 stdcall ZAux_Direct_GetAxisAddress (ZMC_HANDLE  
handle, int iaxis, int * piValue);
```

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

piValue	Return
---------	--------

Value Returns axis address:
Error Code

3.3.3.4 ZAux_Direct_SetClutchRate

Function: Speed connect connection, ratio / sec; When set to 0, to track connection according shaft speed / acceleration parameter, more suitable handwheel movement (when the speed is high enough may cause to continue moving for some time to end). See Software Manual inside the "CLUTCH_RATE" command.

prototype: int32 stdcall ZAux_Direct_SetClutchRate (ZMC_HANDLE handle, int iaxis, float fValue);

Input parameters:

handle	Markup
iaxis	Axis number
pfValue	Current

axis position value return:
error code

3.3.3.5 ZAux_Direct_GetClutchRate

Function: reading the position feedback

prototype: int32 stdcall ZAux_Direct_GetClutchRate (ZMC_HANDLE handle, int iaxis, float * pfValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

pfValue	Returns the
---------	-------------

current position of the return
value: error code

3.3.3.6 ZAux_Direct_SetCornerMode

Function: corner deceleration mode settings, see Software Manual inside the "CORNER_MODE" instruction.

prototype: int32 stdcall ZAux_Direct_SetCornerMode (ZMC_HANDLE handle, int iaxis, int iValue);

Input parameters:

handle	Markup
iaxis	Axis number
iValue	Mode setting

mode: 不同的位代表不同的意义。

位	值	描述
0	1	预留
1	2	自动拐角减速
2	4	预留
3	8	自动小圆限速

returnReturn value:error code

3.3.3.7 ZAux_Direct_GetCornerMode

Function: Reads the current corner mode.

prototype: int32 stdcall ZAux_Direct_GetCornerMode (ZMC_HANDLE handle, int iaxis, int * piValue);

Input parameters:

handle Markup
iaxis Axis number

Output parameters:

piValue Returns the
current corner mode Return Value:
Error code

3.3.3.8 ZAux_Direct_SetDecelAngle

Function: Minimum corner deceleration start, see the software manual inside "DECEL_ANGLE" instruction.

prototype: int32 stdcall ZAux_Direct_SetDecelAngle (ZMC_HANDLE handle, int iaxis, float fValue);

Input parameters:

handle Markup
iaxis Axis number
pfValue Deceleration

start angle Return Value: Error
Code

3.3.3.9 ZAux_Direct_GetDecelAngle

Function: reading the minimum deceleration start corner,

prototype: int32 stdcall ZAux_Direct_GetDecelAngle (ZMC_HANDLE handle, int iaxis, float * pfValue);

Input parameters:

handle

Markup

iaxis Axis number
Output parameters:
 pfValue Return Value
 Returns corner deceleration angle:
 error code

3.3.3.10 ZAux_Direct_SetStopAngle

Function: slow down to the lowest minimum corner in radians. See Software Manual inside "STOP_ANGLE" command.
 prototype: int32 stdcall ZAux_Direct_SetStopAngle (ZMC_HANDLE handle, int iaxis, float pfValue);
Input parameters:
 handle Markup
 iaxis Axis number
 pfValue Angular stop
 deceleration Return Value: Error
 Code

3.3.3.11 ZAux_Direct_GetStopAngle

Function: Stop reading angle corner deceleration
 prototype: int32 stdcall ZAux_Direct_GetStopAngle (ZMC_HANDLE handle, int iaxis, float * pfValue);
Input parameters:
 handle Markup
 iaxis Axis number
Output parameters:
 pfValue Back stop angle
 corner deceleration Return Value: Error
 Code

3.3.3.12 ZAux_Direct_SetZsmooth

Function: fillet radius. See Software Manual inside the "ZSMOOTH" command.
 prototype: int32 stdcall ZAux_Direct_SetZsmooth (ZMC_HANDLE handle, int iaxis, float pfValue);
Input parameters:
 handle Markup
 iaxis Axis number

pfValue Fillet
radius Return Value: Error
Code

3.3.3.13 ZAux_Direct_GetZsmooth

Function: Stop reading angle corner deceleration

prototype: int32 stdcall ZAux_Direct_GetZsmooth (ZMC_HANDLE handle, int iaxis, float * pfValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

pfValue	Fillet
---------	--------

radius Return Value: Error Code

3.3.3.14 ZAux_Direct_SetFullSpRadius

Function: the maximum speed of the small circular arc radius, the unit is **units**. See **Software Manual inside the "FULL_SP_RADIUS" command**.

prototype: int32 stdcall ZAux_Direct_SetFullSpRadius (ZMC_HANDLE handle, int iaxis, float fValue);

Input parameters:

handle	Markup
iaxis	Axis number
fValue	radius

return value:error code

3.3.3.15 ZAux_Direct_GetFullSpRadius

Function: the maximum reading speed small circular arc radius

prototype: int32 stdcall ZAux_Direct_GetFullSpRadius (ZMC_HANDLE handle, int iaxis, float * fValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

pfValue	Return
---------	--------

Value Returns radius value:
Error Code

3.3.3.16 ZAux_Direct_SetStartMoveSpeed

Function: the movement from the starting speed of the defined speed SP, the movement parameter is brought into the buffer units units / s. See Software Manual inside the "STARTMOVE_SPEED" command.

```

prototype: int32 stdcall ZAux_Direct_SetStartMoveSpeed
    (ZMC_HANDLE handle,
int iaxis, float fValue);
Input
parameters:
    handle           Markup
    iaxis            Axis number
    fValue           speed
return value: error code
    
```

3.3.3.17 ZAux_Direct_GetStartMoveSpeed

Function: starting reading speed custom moving speed SP

```

prototype: int32 stdcall ZAux_Direct_GetStartMoveSpeed
    (ZMC_HANDLE handle, int iaxis, float fValue);
    
```

Input

parameters:

```

    handle           Markup
    iaxis            Axis number
    
```

Output

parameters:

```

    pfValue          The rate
of return return value: error
code
    
```

3.3.3.18 ZAux_Direct_SetForceSpeed

Function: SP moving speed from the defined speed, the movement parameter is brought into the buffer, in units units / s. See Software Manual inside the "FORCE_SPEED" Instruction
 Prototype: int32 stdcall ZAux_Direct_SetForceSpeed (ZMC_HANDLE handle, int iaxis, float fValue);.

Input

parameters:

```

    handle           Markup
    iaxis            Axis number
    fValue           speed
    
```

return value: error code

3.3.3.19 ZAux_Direct_GetForceSpeed

Function: starting reading speed custom moving speed SP

```

prototype: int32 stdcall ZAux_Direct_GetForceSpeed (ZMC_HANDLE
    
```

handle, int iaxis, float fValue);

Input

parameters:

handle	Markup
iaxis	Axis number

Output

parameters:

pfValue	Return speed
---------	--------------

returnvalue:error code

3.3.3.20 ZAux_Direct_SetEndMoveSpeed

Function: SP moving speed of since the end of the defined velocity, the movement parameter is brought into the buffer, in units units / s. See Software Manual inside the

"ENDMOVE_SPEED" Instruction Prototype: int32 stdcall

ZAux_Direct_SetEndMoveSpeed (ZMC_HANDLE handle, int iaxis, float fValue);

Input

parameters:

handle	Markup
iaxis	Axis number
fValue	speed

return value:error code

3.3.3.21 ZAux_Direct_GetEndMoveSpeed

Function: the end of the reading speed custom moving speed SP

prototype:int32 stdcall ZAux_Direct_GetEndMoveSpeed

(ZMC_HANDLE handle, int iaxis, float fValue);

Input

parameters:

handle	Markup
iaxis	Axis number

Output

parameters:

pfValue	Return
---------	--------

rate of return value: error
code

3.3.3.22 ZAux_Direct_SetInterpFactor

Function: When the axis is involved in interpolation rate, the default involved in (1), see the software manual inside.

"INTERP_FACTOR" command.

prototype:int32 stdcall ZAux_Direct_SetInterpFactor (ZMC_HANDLE handle, int iaxis, int iValue);

Input

parameters:

handle	Markup
iaxis	Axis number

iValue Mode setting 0 - 1-
participation is not involved in the return
value: error code

3.3.3.23 ZAux_Direct_GetInterpFactor

Function: when the reading speed calculating interpolation axis
is involved.

prototype: int32 stdcall ZAux_Direct_GetInterpFactor (ZMC_HANDLE handle, int iaxis, int iValue);
 Input parameters:
 handle Markup
 iaxis Axis number
 Output parameters:
 piValue Mode setting 0 - 1-
 participation is not involved in the return
 value: error code

3.3.3.24 ZAux_Direct_GetMark

Function: Returns the latch event is generated, see Software Manual inside the "MARK" command.
 prototype: int32 stdcall ZAux_Direct_GetMark (ZMC_HANDLE handle, int iaxis, int * piValue);
 Input parameters:
 handle Markup
 iaxis Axis number
 Output parameters:
 piValue Mode setting 0 - no
 occurrence -1- occur Return Value: Error Code

3.3.3.25 ZAux_Direct_GetMarkB

Function: Returns the latch event is generated, see Software Manual inside the "MARKB" command.
 prototype: int32 stdcall ZAux_Direct_GetMarkB (ZMC_HANDLE handle, int iaxis, int * piValue);
 Input parameters:
 handle Markup
 iaxis Axis number
 Output parameters:
 piValue Mode setting 0 - no
 occurrence -1- occur Return Value: Error Code

3.3.3.26 ZAux_Direct_GetRegPos

Function: Returns the latched position measurement feedback (MPOS) units units, software manual see inside "REG_POS" instruction.
 prototype: int32 stdcall ZAux_Direct_GetRegPos (ZMC_HANDLE handle, int iaxis, float * pfValue);
 Input parameters:

handle

Markup

iaxis Axis number
Output
parameters:
 pfValue Feedback
 position coordinates Return Value:
 Error Code

3.3.3.27 ZAux_Direct_GetRegPosB

Function: Returns the latched position measurement feedback (MPOS) units units, software manual see inside "REG_POSB" instruction.
prototype: int32 stdcall ZAux_Direct_GetRegPosB (ZMC_HANDLE handle, int iaxis, float * pfValue);
Input
parameters:
 handle Markup
 iaxis Axis number
Output
parameters:
 pfValue Feedback
 position coordinates Return Value:
 Error Code

3.3.3.28 ZAux_Direct_SetOffpos

Function: All modifications offset coordinates, which will not have an impact movement. When you modifyAfter into, OFFPOS reduced to 0. See Software Manual inside the "OFFPOS" command.
prototype: int32 stdcall ZAux_Direct_SetOffpos (ZMC_HANDLE handle, int iaxis, float fValue);
Input
parameters:
 handle Markup
 iaxis Axis number
 pfValue Offset
 distance Return Value: Error
 Code

3.3.3.29 ZAux_Direct_GetOffpos

Function: the offset distance read
prototype: int32 stdcall ZAux_Direct_GetOffpos (ZMC_HANDLE handle, int iaxis, float fValue);

Input**parameters:**

handle	Markup
iaxis	Axis number

Output**parameters:**

pfValue	Offset
---------	--------

distance Return Value: Error
Code

3.3.3.30 ZAux_Direct_SetMaxSpeed

Function: the maximum output pulse frequency limit, if it is found over this setting forces, and is provided AXISSTATUS, see inside the software manual "MAX_SPEED" instruction.

prototype: int32 stdcall ZAux_Direct_SetMaxSpeed (ZMC_HANDLE handle, int iaxis, int iValue);

Input parameters:

handle	Markup
iaxis	Axis number
iValue	Settings
return value:	error code

3.3.3.31 ZAux_Direct_GetMaxSpeed

Function: Returns the current maximum limit frequency of the pulse output shaft.

prototype: int32 stdcall ZAux_Direct_GetMaxSpeed (ZMC_HANDLE handle, int iaxis, int * piValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

piValue	The highest frequency return
return value:	error code

3.3.3.32 ZAux_Direct_SetMovemark

Function Function: MARK label movement of the next instruction to be called, will write the label instructions and sports movement with buffer, see Software Manual inside the "MOVE_MARK" command.

prototype: int32 stdcall ZAux_Direct_SetMovemark (ZMC_HANDLE handle, int iaxis, int iValue);

Input parameters:

handle	Markup
iaxis	Axis number
iValue	Settings
return value:	error code

3.3.3.33 ZAux_Direct_GetMoveCurmark

Function: Returns the current instruction is moving axis
MOVE_MARK label. See Software Manual inside the
"MOVE_CURMARK" command.

prototype: int32 stdcall ZAux_Direct_GetMoveCurmark (ZMC_HANDLE
handle,

```
int iaxis, int * piValue);
```

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

piValue	Returns the current MARK
---------	--------------------------

return value:error code

3.3.3.34 ZAux_Direct_GetRemain_LineBuffer

Function: the remaining buffer shaft, calculated by straight line segments. See Software Manual inside the "REMAIN_BUFFER" command.

prototype: int32 stdcall ZAux_Direct_GetRemain_LineBuffer

(ZMC_HANDLE handle, int iaxis, int * piValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

piValue	Returns the number of
---------	-----------------------

remaining linear motion put Return Value:

Error Code

3.3.3.35 ZAux_Direct_GetRemain_Buffer

Function: the remaining buffer shaft, according to the most complex spatial arc calculated.

prototype: int32 stdcall ZAux_Direct_GetRemain_Buffer (ZMC_HANDLE handle, int iaxis, int * piValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

piValue	Returns the number of
---------	-----------------------

remaining arc discharge space Return Value:

Error Code

3.3.4 Special function signal parameter (origin, limit ...)

DATUM_IN, JOG, FWD_IN, REV_IN, F_HOLD_IN other special input signals, when input is OFF, the input signal is considered to be the opposite effect can be

reversed by INVERT_IN (except ECI series controller).

3.3.4.1 ZAux_Direct_SetInvertIn

Function: Set the inverting input status, see the software manual inside "INVERT_IN" command. prototype: int32 stdcall

ZAux_Direct_SetInvertIn (ZMC_HANDLE handle, int ionum, int bifInvert);

Input parameters:

handle	Markup
iaxis	Axis number
bifInvert	State 0-Normally
open	1- NC Return Value:
Error Code	

3.3.4.2 ZAux_Direct_GetInvertIn

Function: read the status inverting input

prototype: int32 stdcall ZAux_Direct_GetInvertIn (ZMC_HANDLE handle, int iaxis, int iValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

iValue	Return Value
--------	--------------

Returns status values: Error
Code

3.3.4.3 ZAux_Direct_SetAlmIn

Function: Set axis alarm signal -1 is canceled, see inside the software manual "ALM_IN" instruction.

prototype: int32 stdcall ZAux_Direct_SetAlmIn (ZMC_HANDLE handle, int iaxis, int iValue);

Input parameters:

handle	Markup
iaxis	Axis number
iValue	IO port number, -1 is unset

Return Value: Error Code

3.3.4.4 ZAux_Direct_GetAlmIn

Function: the alarm signal corresponding to the read input shaft

prototype: int32 stdcall ZAux_Direct_GetMerge (ZMC_HANDLE handle, int iaxis,

int * PiValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

piValue	Returns the number corresponding to
the input port,	-1-- not set return value: error code

3.3.4.5 ZAux_Direct_SetDatumIn

Function: Set-axis origin signal -1 is canceled, see inside the software manual "DATUM_IN" instruction.

prototype: int32 stdcall ZAux_Direct_SetDatumIn (ZMC_HANDLE handle, int iaxis, int iValue);

Input parameters:

handle	Markup
iaxis	Axis number
iValue	IO port number, -1 is unset

Return Value: Error Code

3.3.4.6 ZAux_Direct_GetDatumIn

Function: the read signal corresponding to the input axis origin

prototype: int32 stdcall ZAux_Direct_GetDatumIn (ZMC_HANDLE handle, int iaxis, int * piValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

piValue	Returns the number corresponding to
the input port,	-1-- not set return value: error code

3.3.4.7 ZAux_Direct_SetFwdIn

functionFunction: Set the forward limit signal -1 is canceled, see Software Manual inside the "FWD_IN "command.

prototype: int32 stdcall ZAux_Direct_SetFwdIn (ZMC_HANDLE handle, int iaxis, int iValue);

Input parameters:

handle	Markup
iaxis	Axis number
iValue	IO port number, -1 to unset

returnReturn value:error code

3.3.4.8 ZAux_Direct_GetFwdIn

Function: Limit the read signal corresponding to the positive input port

prototype: int32 stdcall ZAux_Direct_GetFwdIn (ZMC_HANDLE handle, int iaxis, int * piValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

piValue	Returns the number corresponding to the input port,
-1--	not set return value: error code

3.3.4.9 ZAux_Direct_SetRevIn

functionFunction: Set the forward limit signal -1 is canceled, see Software Manual inside the "REV_IN "command.

prototype: int32 stdcall ZAux_Direct_SetRevIn (ZMC_HANDLE handle, int iaxis, int iValue);

Input parameters:

handle	Markup
iaxis	Axis number
iValue	IO port number, -1 is unset

Return Value: Error Code

3.3.4.10 ZAux_Direct_GetRevIn

Function: Limit the read signal corresponding to the positive input port

prototype: int32 stdcall ZAux_Direct_GetRevIn (ZMC_HANDLE handle, int iaxis, int * piValue);

Input parameters:

handle	Markup
iaxis	Axis number

Output parameters:

piValue	Returns the number corresponding to the input port,
-1--	not set return value: error code

3.4 Input and output functions Introduction

3.4.1.1 ZAux_Direct_SetInvertIn

Function: Set the inverting input status, see the software manual inside "INVERT_IN" command. prototype: int32 stdcall ZAux_Direct_SetInvertIn (ZMC_HANDLE handle, int ionum, int bifInvert);
Input parameters:

handle	Markup
ionumIO	Port number
bifInvert	State 0-Normally
open	1- NC Return Value:
Error Code	

3.4.1.2 ZAux_Direct_GetInvertIn

Function: read the status inverting input
prototype: int32 stdcall ZAux_Direct_GetInvertIn (ZMC_HANDLE handle, int ionum, int * piValue);
Input parameters:

handle	Markup
ionumIO	Port number

Output parameters:

piValue	Return Value
---------	--------------

Returns status values: Error
Code

3.4.1.3 ZAux_Direct_GetIn

Function: reading input status, see Software Manual inside the "IN" instruction. prototype: int32 stdcall ZAux_Direct_GetIn (ZMC_HANDLE handle, int ionum, uint32 * piValue);

Input parameters:

handle	Markup
ionumIO	Port

number Output parameters:

piValue	Return
---------	--------

Value Returns status values:
Error Code

3.4.1.4 ZAux_Direct_SetOp

Function: Open the output port, refer to the software manual inside the "OP" instruction.

prototype: int32 stdcall ZAux_Direct_SetOp (ZMC_HANDLE handle, int ionum, uint32 iValue);

Input parameters:

handle	Markup
ionumIO	Port number
iValue	Set the value 0-shut
down	1- Open Return Value:
Error Code	

3.4.1.5 ZAux_Direct_GetOp

Function: read the status of the output port, see Software Manual inside the "OP" instructions.

prototype: int32 stdcall ZAux_Direct_GetOp (ZMC_HANDLE handle, int ionum, uint32 * piValue);

Input parameters:

handle	Markup
ionumIO	Port
number	Output parameters:
piValue	Return
Value	Returns status values:
Error Code	

3.4.1.6 ZAux_Direct_GetAD

Function: read the analog input values, which refer to the software manual "AIN" instruction.

prototype: int32 stdcall ZAux_Direct_GetAD (ZMC_HANDLE handle, int ionum, float * pfValue);

Input parameters:

handle	Markup
ionumIO	Port
number	Output parameters:
pfValue	Back analog
value	Return value: Error Code

3.4.1.7 ZAux_Direct_SetDA

Function: turn on the analog output, see inside the software manual "AOUT" instruction.

prototype: int32 stdcall ZAux_Direct_SetDA

(ZMC_HANDLE handle, int ionum, float fValue);

Input parameters:

handle Markup
 ionumIO Port number
 fValue Settings
 return value:error code

3.4.1.8 ZAux_Direct_GetDA

Function: read the analog input values, which refer to the software manual "AOUT" instruction. prototype: int32 stdcall
 ZAux_Direct_GetDA (ZMC_HANDLE handle, int ionum, float * pfValue);

Input parameters:

handle Markup
 ionumIO Port

number Output parameters:

pfValue Returns the
 output value provided Return Value:
 Error Code

3.4.1.9 ZAux_Direct_SetPwmFreq

Function Function: pwm frequency settings, see Software Manual inside the "PWM_FREQ" command. prototype: int32 stdcall
 ZAux_Direct_SetPwmFreq (ZMC_HANDLE handle, int ionum, float fValue);

Input parameters:

handle Markup
 ionumPWM Port number
 fValue Settings

return value:error code

3.4.1.10 ZAux_Direct_GetPwmFreq

Functions Function: pwm frequency read
 prototype: int32 stdcall ZAux_Direct_GetPwmFreq (ZMC_HANDLE handle, int ionum, float * pfValue);

Input parameters:

handle Markup
 ionumPWM Port

number Output parameters:

pfValue Returns the
 output value provided Return Value:
 Error Code

3.4.1.11 ZAux_Direct_SetPwmDuty

Function Function: pwm duty cycle setting, see Software Manual inside the "PWM_DUTY" command. prototype: int32 stdcall

ZAux_Direct_SetPwmDuty (ZMC_HANDLE handle, int ionum, float fValue);

Input parameters:

handle	Markup
ionumPWM	Port number
fValue	Settings

return value:error code

3.4.1.12 ZAux_Direct_GetPwmDuty

Function Function: pwm duty cycle of reading

prototype: int32 stdcall ZAux_Direct_GetPwmDuty (ZMC_HANDLE handle, int ionum, float * pfValue);

Input parameters:

handle	Markup
ionumPWM	Port

number Output parameters:

pfValue	Returns the
---------	-------------

output value provided Return Value:

Error Code

3.4.1.13 ZAux_GetModbusIn

Function: a plurality of input quickly read, returns the value of each bit indicates the state of the input port.

prototype: int32 stdcall ZAux_GetModbusIn (ZMC_HANDLE handle, int ionumfirst, int ionumend, uint8 * pValueList);

Input parameters:

handle	Markup
ionumfirst	The read start input
ionumend	Output end of

the input port of the read parameters:

pValueList	Returns the
------------	-------------

corresponding input port status return

values: Error Code

3.4.1.14 ZAux_GetModbusOut

Function: a plurality of Fast Read the current output, the return value of each bit indicates the output port state.

original type: int32stdcall ZAux_GetModbusOut (ZMC_HANDLE handle, int ionumfirst, int ionumend, uint8 * pValueList);

Input parameters:

handle	Markup
ionumfirst	Outputs the read start
ionumend	The output end

of the output port parameters read:

pValueList	Returns the
------------	-------------

corresponding output port status return values: Error Code

3.4.1.15 ZAux_GetModbusDpos

Function: Quick read more current DPOS.

prototype: int32 stdcall ZAux_GetModbusDpos (ZMC_HANDLE handle, int imaxaxes, float * pValueList);

Input parameters:

handle	Markup
imaxaxes	Outp

ut axes parameters:

pValueList	Returns the
------------	-------------

corresponding list of coordinate axis

Return Value: Error Code

3.4.1.16 ZAux_GetModbusMpos

Function: Quick read more current MPOS

prototype: int32 stdcall ZAux_GetModbusMpos (ZMC_HANDLE handle, int imaxaxes, float * pValueList);

Input parameters:

handle	Markup
imaxaxes	Outp

ut axes parameters:

pValueList	Returns the
------------	-------------

corresponding list of coordinate axis

Return Value: Error Code

3.4.1.17 ZAux_GetModbusCurSpeed

Function: read more current rapid rate.

```

prototype: int32 stdcall ZAux_GetModbusCurSpeed (ZMC_HANDLE
handle, int imaxaxes, float * pValueList);
    
```

Input parameters:

handle	Markup
imaxaxes	Number of axes

loseThe parameters:

pValueList Shaft speed
returns the corresponding list Return
Value:

3.5 Data communication function

3.5.1.1 ZAux_Direct_GetVariablef

Function: float global variables to read, it can be parameters, etc.

prototype: int32 stdcall ZAux_Direct_GetVariablef (ZMC_HANDLE handle, const char * pname, float * pfValue);

Input parameters:

handle Markup
pname Variable or
parameter name output parameters:
pfValue Return

The return value: error
code

3.5.1.2 ZAux_Direct_GetVariableInt

Function: shaping global variable read, etc. can also be a parameter.

prototype: int32 stdcall ZAux_Direct_GetVariableInt (ZMC_HANDLE handle, const char * Pname, int * PiValue);

Input parameters:

handle Markup
pname Variable or
parameter name output parameters:
piValue Return

The return value: error
code

3.5.1.3 ZAux_Direct_SetVrf

Function: write VR

prototype: int32 stdcall ZAux_Direct_SetVrf (ZMC_HANDLE handle, int vrstartnum, int numes, float *
PfValue);

parameter:

handle	Markup
vrstartnum	VR started operation starting number
numes	Write the number
pfValue	Data

List Return value: error
code

3.5.1.4 ZAux_Direct_GetVrf

Function: Reading floating point format VR

prototype: int32 stdcall ZAux_Direct_GetVrf (ZMC_HANDLE handle, int vrstartnum, int numes, float * pfValue)

parameter:

handle	Markup
vrstartnum	VR started operation starting number
numes	Read number
pfValue	Data

List Return value: error
code

3.5.1.5 ZAux_Direct_GetVrInt

Function: Shaping read VR format

prototype: int32 stdcall ZAux_Direct_GetVrInt (ZMC_HANDLE handle, int vrstartnum, int numes, int * piValue)

Input

parameters:

handle	Markup
vrstartnum	VR started operation starting number
numes	Read the

number of output parameters:

piValue	Data
---------	------

List Return value: error
code

3.5.1.6 ZAux_Direct_SetTable

Function: Set TABLE array

originaltype: int32 stdcall ZAux_Direct_SetTable (ZMC_HANDLE handle, int tabstart, int numes, float * pfValue)

Input

parameters:

handle	Markup
tabstart	TABLE beginning of the operation starting number
numes	Write the number
pfValue	Data

List Return value: error
code

3.5.1.7 ZAux_Direct_GetTable

Function: Array read TABLE

prototype: int32 stdcall ZAux_Direct_GetTable (ZMC_HANDLE handle, int

tabstart, int numes, float * pfValue)

Input parameters:

handle Markup

tabstart TABLE beginning of the operation starting number

numes Read the

number of output parameters:

pfValue Data

List Return value: error

code

3.5.1.8 ZAux_Modbus_Set0x

Function: bit register setting modbus

prototype: int32 stdcall ZAux_Modbus_Set0x (ZMC_HANDLE handle, uint16 start, uint16 inum, uint8 * pdata)

Input parameters:

handle Markup

start Operating modbus_bit starting number

inum Write the number

pdata Data List

return value:error code

3.5.1.9 ZAux_Modbus_Get0x

Function: bit register read modbus

prototype: int32 stdcall ZAux_Modbus_Get0x (ZMC_HANDLE handle, uint16 start, uint16 inum, uint8 * pdata)

Input parameters:

handle Markup

start Operating modbus_bit starting number

inum Read number

Output parameters:

pdata Data List

return value:error code

3.5.1.10 ZAux_Modbus_Set4x

Function: Set modbus word register

prototype: int32 stdcall ZAux_Modbus_Set4x (ZMC_HANDLE handle, uint16 start, uint16 inum, uint16 * pdata)

Input parameters:

handle Markup

start

Operating modbus_reg starting number

inum The number of settings
pdata Data List
return value:error code

3.5.1.11 ZAux_Modbus_Get4x

Function: read word register modbus

prototype: int32 stdcall ZAux_Modbus_Get4x (ZMC_HANDLE handle, uint16 start, uint16 inum, uint16 * pdata)

Input parameters:

handle Markup
start Operating modbus_reg starting number
inum The number

of output parameters read:

pdata Data List

return value:error code

3.5.1.12 ZAux_Modbus_Set4x_Float

Function: Set floating point data word to modbus register

prototype: int32 stdcall ZAux_Modbus_Set4x_Float (ZMC_HANDLE handle, uint16 start, uint16 inum, float * pfddata)

Input parameters:

handle Markup
start Operating modbus_ieee starting number
inum Write the number
pfddata Data

List Return value: error
code

3.5.1.13 ZAux_Modbus_Get4x_Float

Function: read the floating point data word register modbus

prototype: int32 stdcall ZAux_Modbus_Get4x_Float (ZMC_HANDLE handle, uint16 start, uint16 inum, float * pfddata)

Input parameters:

handle Markup
start Operating modbus_ieee starting number
inum Read number

Output parameters:

pfdata

Data List

returnvalue:error code

3.5.1.14 ZAux_Modbus_Set4x_Long

Function: Set shaping to modbus data word register

prototype: int32 stdcall ZAux_Modbus_Set4x_Long (ZMC_HANDLE handle, uint16 start, uint16 inum, int32 * pidata)

Input parameters:

handle	Markup
start	Operating modbus_ieee starting number
inum	Write the number
pidata	Data

List Return value: error
code

3.5.1.15 ZAux_Modbus_Get4x_Long

Function: integer data read word register modbus

prototype: int32 stdcall ZAux_Modbus_Get4x_Long (ZMC_HANDLE handle, uint16 start, uint16 inum, int32 * pidata)

Input parameters:

handle	Markup
start	Operating modbus_ieee starting number
inum	Read number

Output parameters:

pidata	Data
--------	------

List Return value: error
code

3.5.1.16 ZAux_FlashWritef

Function: write data to floating point FLASH

prototype: int32 stdcall ZAux_FlashWritef (ZMC_HANDLE handle, uint16 uiflashid, uint32 uinumes, float * pfvlu)

Input parameters:

handle	Markup
uiflashidFLASH	Block number
uinumes	Write the number
pfvlue	Data List

return value:error code

3.5.1.17 ZAux_FlashReadf

Function: floating-point data read from the FLASH

prototype: int32 stdcall ZAux_FlashReadf (ZMC_HANDLE handle, uint16 uiflashid, uint32 uibuffnum, float * pfvlu, uint32 * puinumesread)

Input parameters:

handle	Markup
uiflashid	FLASH Block number
uibuffnum	The number

of buffer variable output parameters:

pfvlu	Data List
puinumesread	The number of

variables to read Return Value: Error Code

3.5.1.18 ZAux_WriteUFile

Function Function: **float variable into a file format list, the controller and the disk file format consistent U**

prototype: int32 stdcall ZAux_WriteUFile (const char * sFilename, float * pVarlist, int inum)

Input parameters:

sFilename	file name
pVarlist	Data List
inum	The number of

return value: error code

3.5.1.19 ZAux_ReadUFile

Function: read float format variable list, and U disk file

controller prototype formats consistent: int32 stdcall ZAux_ReadUFile (const char * sFilename, float * pVarlist, int * pinum)

Input parameters:

sFilename	file name
-----------	-----------

Output parameters:

pVarlist	Data List
inum	The number of

return value: error code

Chapter Four Direct serial control

4.1 Serial Port Command Control Mode

MODBUS protocol controller from the serial default mode, 38400 baud, no parity. You can modify the serial mode SETCOM command: See "ZBASIC Software Manual." SETCOM (baudrate, databits, stopbits, parity, port [, mode] [, variable] [, timeout])

When the mode 15 is configured as a direct mode command, this time directly from the serial input command string (newline).

This model is particularly suitable for embedded serial board to the control of the motion controller.

Example:

The first step: first implementation setcom (38400, 8,1,0,0,15,2) serial port causes the controller to enter commands directly control mode, if the power controller will need to enter this mode, this command may be written to the program file, to download controller ROM.

Step two: through the serial port software and controller interaction:

Note 1: To set the ASCII character mode, do not use HEX mode. Note 2: the end of the line feed character, so that the controller can distinguish the command.

