

maxon motor

maxon motor control

EPOS Positioning Controller

EPOS Command Library

February 2011 Edition

EPOS

Positioning Controller

Documentation

EPOS Command Library

maxon document number: rel1836

TABLE OF CONTENTS

| | | |
|--------|--|----|
| 1 | Introduction | 5 |
| 2 | Third Party Products | 7 |
| 2.1 | IXXAT | 7 |
| 2.2 | Vector | 7 |
| 2.3 | National Instruments | 7 |
| 3 | How to use this Guide | 8 |
| 3.1 | General Information | 8 |
| 3.2 | Communication Structure Windows | 8 |
| 3.3 | Communication Structure Linux | 9 |
| 3.4 | Data Type Definitions | 10 |
| 4 | Initialization Functions | 11 |
| 4.1 | Communication | 11 |
| 4.1.1 | Open Device | 11 |
| 4.1.2 | Open Device Dialog | 11 |
| 4.1.3 | Get Protocol Stack Settings | 12 |
| 4.1.4 | Set Protocol Stack Settings | 12 |
| 4.1.5 | Find Device Communication Settings | 12 |
| 4.1.6 | Close All Devices | 13 |
| 4.1.7 | Close Device | 13 |
| 4.2 | Info | 13 |
| 4.2.1 | Get Error Info | 13 |
| 4.2.2 | Get Driver Info | 14 |
| 4.2.3 | Get Version | 14 |
| 4.3 | Advanced Functions | 14 |
| 4.3.1 | Get Device Name Selection | 14 |
| 4.3.2 | Get Protocol Stack Name Selection | 15 |
| 4.3.3 | Get Interface Name Selection | 15 |
| 4.3.4 | Get Port Name Selection | 16 |
| 4.3.5 | Get Baud Rate Selection | 16 |
| 4.3.6 | Programming Example | 17 |
| 4.3.7 | Get Key Handle | 17 |
| 4.3.8 | Get Device Name | 17 |
| 4.3.9 | Get Protocol Stack Name | 18 |
| 4.3.10 | Get Interface Name | 18 |
| 4.3.11 | Get Port Name | 18 |
| 5 | Configuration Functions | 19 |
| 5.1 | General | 19 |
| 5.1.1 | Import Parameter | 19 |
| 5.1.2 | Export Parameter | 19 |
| 5.1.3 | Set Object | 20 |
| 5.1.4 | Get Object | 20 |
| 5.1.5 | Restore | 21 |
| 5.1.6 | Store | 21 |
| 5.2 | Advanced Functions | 21 |
| 5.2.1 | Motor | 21 |
| 5.2.2 | Sensor | 24 |
| 5.2.3 | Safety | 27 |
| 5.2.4 | Position Regulator | 29 |
| 5.2.5 | Velocity Regulator | 31 |
| 5.2.6 | Current Regulator | 31 |
| 5.2.7 | Inputs/Outputs | 32 |
| 5.2.8 | Units | 34 |
| 6 | Operation Functions | 36 |
| 6.1 | Operation Mode | 36 |
| 6.1.1 | Set Operation Mode | 36 |
| 6.1.2 | Get Operation Mode | 36 |
| 6.2 | State Machine | 37 |
| 6.2.1 | Reset Device | 37 |
| 6.2.2 | Set State | 37 |
| 6.2.3 | Set Enable State | 37 |
| 6.2.4 | Set Disable State | 38 |
| 6.2.5 | Set Quick Stop State | 38 |
| 6.2.6 | Clear Fault | 38 |
| 6.2.7 | Get State | 39 |
| 6.2.8 | Get Enable State | 39 |
| 6.2.9 | Get Disable State | 39 |
| 6.2.10 | Get Quick Stop State | 40 |

| | | |
|--------|--|----|
| 6.2.11 | Get Fault State..... | 40 |
| 6.3 | Error Handling..... | 40 |
| 6.3.1 | Get Number of Device Error..... | 40 |
| 6.3.2 | Get Device Error Code..... | 41 |
| 6.3.3 | Programming Example..... | 41 |
| 6.4 | Motion Info..... | 42 |
| 6.4.1 | Get Movement State | 42 |
| 6.4.2 | Get Position Is..... | 42 |
| 6.4.3 | Get Velocity Is..... | 42 |
| 6.4.4 | Get Current Is | 43 |
| 6.4.5 | Wait For Target Reached | 43 |
| 6.5 | Profile Position Mode..... | 43 |
| 6.5.1 | Activate Profile Position Mode..... | 43 |
| 6.5.2 | Set Position Profile..... | 44 |
| 6.5.3 | Get Position Profile | 44 |
| 6.5.4 | Move To Position | 45 |
| 6.5.5 | Get Target Position | 45 |
| 6.5.6 | Halt Position Movement | 45 |
| 6.5.7 | Advanced Functions | 46 |
| 6.6 | Profile Velocity Mode..... | 46 |
| 6.6.1 | Activate Profile Velocity Mode..... | 46 |
| 6.6.2 | Set Velocity Profile..... | 47 |
| 6.6.3 | Get Velocity Profile | 47 |
| 6.6.4 | Move With Velocity | 47 |
| 6.6.5 | Get Target Velocity | 48 |
| 6.6.6 | Halt Velocity Movement | 48 |
| 6.6.7 | Advanced Functions | 48 |
| 6.7 | Homing Mode | 49 |
| 6.7.1 | Activate Homing Mode | 49 |
| 6.7.2 | Set Homing Parameter..... | 49 |
| 6.7.3 | Get Homing Parameter | 50 |
| 6.7.4 | Find Home | 50 |
| 6.7.5 | Stop Homing | 51 |
| 6.7.6 | Define Position..... | 52 |
| 6.8 | Interpolated Position Mode (IPM) | 52 |
| 6.8.1 | Activate Interpolated Position Mode..... | 52 |
| 6.8.2 | Set IPM Buffer Parameter | 52 |
| 6.8.3 | Get IPM Buffer Parameter..... | 53 |
| 6.8.4 | Clear IPM Buffer | 53 |
| 6.8.5 | Get Free IPM Buffer Size | 53 |
| 6.8.6 | Add PVT Value To IPM Buffer..... | 54 |
| 6.8.7 | Start IPM Trajectory | 54 |
| 6.8.8 | Stop IPM Trajectory | 54 |
| 6.8.9 | Get IPM Status..... | 55 |
| 6.9 | Position Mode | 55 |
| 6.9.1 | Activate Position Mode..... | 55 |
| 6.9.2 | Set Position Must..... | 56 |
| 6.9.3 | Get Position Must..... | 56 |
| 6.9.4 | Advanced Functions | 56 |
| 6.10 | Velocity Mode | 58 |
| 6.10.1 | Activate Velocity Mode..... | 58 |
| 6.10.2 | Set Velocity Must | 58 |
| 6.10.3 | Get Velocity Must..... | 58 |
| 6.10.4 | Advanced Functions | 59 |
| 6.11 | Current Mode..... | 60 |
| 6.11.1 | Activate Current Mode | 60 |
| 6.11.2 | Get Current Must | 60 |
| 6.11.3 | Set Current Must | 61 |
| 6.11.4 | Advanced Functions | 61 |
| 6.12 | Master Encoder Mode | 62 |
| 6.12.1 | Activate Master Encoder Mode | 62 |
| 6.12.2 | Set Master Encoder Parameter..... | 63 |
| 6.12.3 | Get Master Encoder Parameter | 63 |
| 6.13 | Step Direction Mode | 64 |
| 6.13.1 | Activate Step Direction Mode..... | 64 |
| 6.13.2 | Set Step Direction Parameter..... | 64 |
| 6.13.3 | Get Step Direction Parameter | 65 |
| 6.14 | Inputs Outputs | 65 |
| 6.14.1 | Get All Digital Inputs | 65 |
| 6.14.2 | Get All Digital Outputs..... | 66 |
| 6.14.3 | Set All Digital Outputs | 66 |
| 6.14.4 | Get Analog Input..... | 66 |

| | | |
|-----------|--|-----------|
| 6.14.5 | Set Analog Output..... | 67 |
| 6.14.6 | Position Compare | 67 |
| 6.14.7 | Position Marker | 70 |
| 7 | Data Recording Functions..... | 74 |
| 7.1 | Data Recorder Setup | 74 |
| 7.1.1 | Set Recorder Parameter | 74 |
| 7.1.2 | Get Recorder Parameter | 74 |
| 7.1.3 | Enable Trigger | 75 |
| 7.1.4 | Disable all Triggers | 75 |
| 7.1.5 | Activate Channel | 76 |
| 7.1.6 | Deactivate all Channels | 76 |
| 7.2 | Data Recorder Status | 77 |
| 7.2.1 | Start Recorder..... | 77 |
| 7.2.2 | Stop Recorder | 77 |
| 7.2.3 | Force Trigger | 77 |
| 7.2.4 | Is Recorder Running | 78 |
| 7.2.5 | Is Recorder Triggered | 78 |
| 7.3 | Data Recorder Data | 79 |
| 7.3.1 | Read Channel Vector Size | 79 |
| 7.3.2 | Read Channel Data Vector | 79 |
| 7.3.3 | Show Channel Data Dialog | 80 |
| 7.3.4 | Export Channel Data to File | 80 |
| 7.4 | Advanced Functions | 81 |
| 7.4.1 | Read Data Buffer | 81 |
| 7.4.2 | Extract Channel Data Vector | 81 |
| 8 | Low Layer Functions | 82 |
| 8.1 | Send CAN Frame | 82 |
| 8.2 | Read CAN Frame | 82 |
| 8.3 | Request CAN Frame | 82 |
| 8.4 | Send NMT Service..... | 83 |
| 9 | Error Overview | 84 |
| 9.1 | Overview Communication Errors | 84 |
| 9.2 | Overview „EPOS Command Library” specified Errors | 85 |
| 9.2.1 | General Errors | 85 |
| 9.2.2 | Interface Layer Errors | 85 |
| 9.2.3 | Interface Layer 'RS232' Errors | 85 |
| 9.2.4 | Interface Layer 'CAN' Errors..... | 85 |
| 9.2.5 | Interface Layer 'USB' Errors..... | 85 |
| 9.2.6 | Protocol Layer 'MaxonRS232' Errors | 86 |
| 9.2.7 | Protocol Layer 'CANopen' Errors | 86 |
| 9.2.8 | Protocol Layer 'USB' Errors | 86 |
| 10 | Version History..... | 87 |

1 Introduction

The present documentation “EPOS Command Library” provides instructions on the implemented functions of the Windows dynamic link libraries “EposCmd.dll”, “EposCmd64.dll” and Linux 32-bit shared object library “libEposCmd.so”, which can be used for devices **EPOS** and **EPOS2**.

The library is arranged in groups of functions and is intended to assist in programming of the control software based on Microsoft Windows® and 32-bit Linux platform.

This document describes the interface between a program and the “EPOS Command Libraries”. This libraries support devices of the EPOS family, which are attached to a **serial interface RS232, USB** on the Windows and Linux platform or to a **CAN board by IXXAT, Vector or National Instruments** available for the Windows systems. All other CANopen products of other manufacturers can also be used; however no motion control library is available.

| Interface \ OS | | 32-Bit | | 64-Bit |
|----------------|--------|---------|-------|---------|
| | | Windows | Linux | Windows |
| | RS-232 | X | X | X |
| | USB | X | X | X |
| CAN Board | IXXAT | X | - | X |
| | NI | X | - | - |
| | Vector | X | - | X |

Table 1: Supported platforms

The parameters of the 32-bit and 64-bit interfaces are the same.

The “EPOS Command Libraries” support the SDO protocol by CANopen but the “EPOS Command Libraries” are not suitable for real-time communication.

Additional information is available in the following documents:

- “EposCmd.Net.chm”
The document “EposCmd.Net.chm” describes the implementation for **.NET** applications. Examples for **VB.Net** and **C#** are available.
- „DLL Integration into MS VC++”
The document „DLL Integration into MS VC++” describes implementation and structure for **Microsoft Visual C++** in detail.
- „DLL Integration into MS Visual Basic”
The document „DLL Integration into MS Visual Basic” describes implementation and structure for **Microsoft Visual Basic** in detail.
- „DLL Integration into Borland C++”
The document „DLL Integration into Borland C++” describes implementation and structure for **Borland C++ Builder** in detail.
- „DLL Integration into Borland Delphi”
The document „DLL Integration into Borland Delphi” describes implementation and structure for **Borland Delphi** in detail.
- „DLL Integration into LabVIEW”
The document „DLL Integration into LabVIEW” describes implementation and structure for **National Instruments LabVIEW** in detail.
- „DLL Integration into National Instruments LabWindows/CVI”
The document „DLL Integration into National Instruments LabWindows/CVI” describes implementation and structure for **National Instruments LabWindows/CVI** in detail.
- “Linux shared library Integration into Eclipse C++/QT”
The document „Linux shared library Integration into Eclipse C++/QT” describes implementation and structure for **Eclipse IDE for C/C++** in detail.

For a number of high-level languages an applicable example, including respective documentation, is available.

This library is intended to cover most applications used in automation.

It is based on the experience of maxon motor control. maxon motor control certifies that the content of this library is correct according to the best of their knowledge.

BECAUSE THIS LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THIS LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM „AS IS“ WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THIS LIBRARY IS WITH YOU. SHOULD THIS LIBRARY PROVE DEFECTIVE OR INSUFFICIENT, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION

The latest edition of these „EPOS Command Library“, additional documentation and software to the EPOS positioning controller may also be found in the internet under www.maxonmotor.com category <Service & Downloads> or in the maxon motor e-shop <http://shop.maxonmotor.com>.

2 Third Party Products

Use one of the listed PC CANopen interface cards. For all of these manufacturers motion control libraries (example and documentation) are available.

All other CANopen products of other manufacturers can also be used; however no motion control library is available.

2.1 IXXAT

All IXXAT CANopen interfaces can be operated with the hardware-independent VCI driver V3 (Virtual CAN Interface). The older version VCI driver V2 (2.16 and higher) is still supported but should not be used because of lower performance.

See addresses below for ordering CANopen boards and further details of the driver.

Distributors

- www.ixxat.de

2.2 Vector

For use of Vector CANopen cards, the 'XL Driver Library' will be required. The installed edition of this library must be installed manually in the appropriate working directory (or system directory). With this library, it is possible to write own CANopen applications based on Vector's XL hardware.

See address below for ordering CANopen boards and further details of the driver.

Distributors

- www.vector-informatik.com

2.3 National Instruments

CAN Interfaces of National Instruments are supported. The NI-CAN software and hardware must be installed.

See address below for ordering CANopen boards and further details of the driver.

Contact

- www.ni.com/can

3 How to use this Guide




Figure 1: EPOS documentation hierarchy

3.1 General Information

- For detailed descriptions on used objects (Index-SubIndex), please refer to separate document **Firmware Specification**.
- The units of measurement for the parameters are not being mentioned. They depend on the notation index (position, velocity and acceleration). For details please refer to separate document **Firmware Specification**.

3.2 Communication Structure Windows




Figure 2: Example Windows communication structure

3.3 Communication Structure Linux




Figure 3: Example Linux communication structure

3.4 Data Type Definitions

Below is a table of all used data types.

| Name | Data type | Size bits | Size bytes | Range |
|--------------|----------------------|-----------|------------|-----------------------------------|
| char, __int8 | signed integer | 8 | 1 | – 128 ... 127 |
| BYTE | unsigned integer | 8 | 1 | 0 ... 256 |
| short | signed integer | 16 | 2 | – 32'768 ... 32'767 |
| WORD | unsigned integer | 16 | 2 | 0 ... 65'535 |
| long | signed integer | 32 | 4 | – 2'147'483'648 ... 2'147'483'647 |
| DWORD | unsigned integer | 32 | 4 | 0 ... 4'294'967'295 |
| BOOL | signed integer | 32 | 4 | TRUE = 1 FALSE = 0 |
| HANDLE | pointer to an object | 32 | 4 | 0 ... 4'294'967'295 |

Table 2: Data type definitions

4 Initialization Functions

4.1 Communication

4.1.1 Open Device

Function

HANDLE **VCS_OpenDevice** (char *DeviceName, char *ProtocolStackName, char *InterfaceName, char *PortName, DWORD *pErrorCode)

Description

Function „VCS_OpenDevice“ opens the port for sending and receiving commands. This function opens interfaces with the RS232, the USB and with CANopen boards.

For correct designations on DeviceName, ProtocolStackName, InterfaceName and PortName use the functions [Get Device Name Selection](#), [Get Protocol Stack Name Selection](#), [Get Interface Name Selection](#) and [Get Port Name Selection](#).

Parameters

| | | |
|-------------------|-------|--|
| DeviceName | char* | Name of connected device: EPOS, EPOS2 |
| ProtocolStackName | char* | Name of used bus system: MAXON_RS232, MAXON SERIAL V2, CANopen |
| InterfaceName | char* | Name of used interface: MAXON_RS232: RS232 MAXON SERIAL V2: USB CANopen: Is composed of: Manufacturer_BoardName DeviceNumber <i>Examples:</i> IXXAT_USB-to-CAN compact 0, ... Vector_CANcaseXL Channel 1, ... NI_PCI-CAN 0, ... |
| PortName | char* | Name of port: RS232: COM1, COM2, ... CANopen: CAN0, CAN1, ... USB: USB0, USB1, ... |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | HANDLE | Handle for port access. Nonzero if successful; otherwise 0 |

4.1.2 Open Device Dialog

Function

HANDLE **VCS_OpenDeviceDlg** (DWORD *pErrorCode)

Description

The function „VCS_OpenDeviceDlg“ registers available interfaces with which the EPOS can be operated and opens the selected interface for communication.

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | HANDLE | Handle for port access. Nonzero if successful; otherwise 0 |

Additional informations

Function is not available in the Linux library

4.1.3 Get Protocol Stack Settings

Function

BOOL **VCS_GetProtocolStackSettings** (HANDLE KeyHandle, DWORD *pBaudrate, DWORD *pTimeout, DWORD *pErrorCode)

Description

Function „VCS_GetProtocolStackSettings“ returns the communication parameters baud rate and timeout.

Parameter

| | | |
|-----------|--------|------------------------|
| KeyHandle | HANDLE | Handle for port access |
|-----------|--------|------------------------|

Return Parameters

| | | |
|---------------------|--------|---|
| pBaudrate | DWORD* | Actual baud rate from opened port [Bit/s] |
| pTimeout | DWORD* | Actual timeout from opened port [ms] |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

4.1.4 Set Protocol Stack Settings

Function

BOOL **VCS_SetProtocolStackSettings** (HANDLE KeyHandle, DWORD Baudrate, DWORD Timeout, DWORD *pErrorCode)

Description

With function „VCS_SetProtocolStackSettings“ it is possible to write the communication parameters. For exact values of available baud rates use the function [Get Baudrate Selection](#).

Parameters

| | | |
|-----------|--------|---|
| KeyHandle | HANDLE | Handle for port access |
| Baudrate | DWORD | Actual baud rate from opened port [Bit/s] |
| Timeout | DWORD | Actual timeout from opened port [ms] |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Remark

For correct communication use the same baud rate as on the connected device.

4.1.5 Find Device Communication Settings

Function

BOOL **VCS_FindDeviceCommunicationSettings** (HANDLE KeyHandle, char *pDeviceName, char *pProtocolStackName, char *pInterfaceName, char *pPortName, WORD SizeName, DWORD *pBaudrate, DWORD *pTimeout, WORD *pNodeId, int DialogMode, DWORD *pErrorCode)

Description

With function „VCS_FindDeviceCommunicationSettings“ it is possible to search the communication setting parameters.

Remark

To accelerate the process some parameters can be defined.

Parameters

| | | |
|--------------------|--------|---|
| KeyHandle | HANDLE | Handle for port access |
| pDeviceName | char* | Device name |
| pProtocolStackName | char* | Protocol stack name |
| pInterfaceName | char* | Interface name |
| pPortName | char* | Port name |
| SizeName | WORD | Reserved memory size for return parameters |
| DialogMode | int | 0: Show Progress Dialog 1: Show Progress and Confirmation Dialog |

| | | |
|---------|-------|---|
| | | 2: Show Confirmation Dialog 3: Don't show any Dialog |
| Timeout | DWORD | Actual timeout from opened port [ms] |

Return Parameters

| | | |
|---------------------|--------|---|
| pDeviceName | char* | Device name |
| pProtocolStackName | char* | Protocol stack name |
| pInterfaceName | char* | Interface name |
| pPortName | char* | Port name |
| pBaudrate | DWORD | Baud rate |
| pTimeout | DWORD | Timeout |
| pNodeId | WORD | Node ID |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Additional informations

Function is not available in the Linux library

4.1.6 Close All Devices

Function

BOOL **VCS_CloseAllDevices** (DWORD *pErrorCode)

Description

Function „VCS_CloseAllDevices“ closes all opened ports and releases it for other applications.

Return Parameter

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

4.1.7 Close Device

Function

BOOL **VCS_CloseDevice** (HANDLE KeyHandle, DWORD *pErrorCode)

Description

Function „VCS_CloseDevice“ closes the port and releases it for other applications.

Parameters

| | | |
|-----------|--------|------------------------|
| KeyHandle | HANDLE | Handle for port access |
|-----------|--------|------------------------|

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

4.2 Info

4.2.1 Get Error Info

Function

BOOL **VCS_GetErrorInfo** (DWORD ErrorCodeValue, char *pErrorInfo, WORD MaxStrSize)

Description

Function „VCS_GetErrorInfo“ returns the error information about the executed function from a received error code. The function returns [communication and library errors](#) but no device errors descriptions.

Parameters

| | | |
|----------------|-------|-----------------------------|
| ErrorCodeValue | DWORD | Received error code |
| MaxStrSize | WORD | Max. length of error string |

Return Parameters

| | | |
|---------------------|-------|---|
| pErrorInfo | char* | Error string |
| | | |
| Return Value | BOOL | Nonzero if error information found; otherwise 0 |

4.2.2 Get Driver Info

Function

BOOL **VCS_GetDriverInfo** (char *pLibraryName, WORD MaxStrNameSize, char *pLibraryVersion, WORD MaxStrVersionSize, DWORD *pErrorCode)

Description

Function „VCS_GetDriverInfo” returns the name and version from the “EPOS Command DLL”.

Parameters

| | | |
|-------------------|------|--------------------------------------|
| MaxStrNameSize | WORD | Reserved memory size for the name |
| MaxStrVersionSize | WORD | Reserved memory size for the version |

Return Parameters

| | | |
|---------------------|--------|---|
| pLibraryName | char* | Name from DLL |
| pLibraryVersion | char* | Version from DLL |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Additional informations

Function is not available in the Linux library

4.2.3 Get Version

Function

BOOL **VCS_GetVersion** (HANDLE KeyHandle, WORD NodeId, WORD *pHardwareVersion, WORD *pSoftwareVersion, WORD *pApplicationNumber, WORD *pApplicationVersion, DWORD *pErrorCode)

Description

„VCS_GetVersion” returns the firmware version.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|---------------------|--------|---|-------------------|
| pHardwareVersion | WORD* | Hardware version | Object: 0x2003-01 |
| pSoftwareVersion | WORD* | Software version | Object: 0x2003-02 |
| pApplicationNumber | WORD* | Application number | Object: 0x2003-03 |
| pApplicationVersion | WORD* | Application version | Object: 0x2003-04 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

4.3 Advanced Functions

This group defines all required functions to get additional information:

4.3.1 Get Device Name Selection

Function

BOOL **VCS_GetDeviceNameSelection** (BOOL StartOfSelection, char *pDeviceNameSel, WORD MaxStrSize, BOOL *pEndOfSelection, DWORD *pErrorCode)

Description

Function „VCS_GetDeviceNameSelection” returns all available device names.

Parameters

| | | |
|------------------|------|--|
| StartOfSelection | BOOL | True: Get first selection string False: Get next selection string |
| MaxStrSize | WORD | Reserved memory size for the device name |

Return Parameters

| | | |
|---------------------|--------|---|
| pDeviceNameSel | char* | Device name |
| pEndOfSelection | BOOL* | 1: No more selection string available 0: More string available |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Go to [Programming Example](#)

4.3.2 Get Protocol Stack Name Selection**Function**

BOOL **VCS_GetProtocolStackNameSelection** (char *DeviceName, BOOL StartOfSelection, char *pProtocolStackNameSel, WORD MaxStrSize, BOOL *pEndOfSelection, DWORD *pErrorCode)

Description

Function „VCS_GetProtocolStackNameSelection” returns all available protocol stack names.

Parameters

| | | |
|------------------|-------|---|
| DeviceName | char* | Device name |
| StartOfSelection | BOOL | 1: Get first selection string 0: Get next selection string |
| MaxStrSize | WORD | Reserved memory size for the name |

Return Parameters

| | | |
|-----------------------|--------|---|
| pProtocolStackNameSel | char* | Pointer to available protocol stack name |
| pEndOfSelection | BOOL* | 1: No more string available 0: More string available |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Go to [Programming Example](#)

4.3.3 Get Interface Name Selection**Function**

BOOL **VCS_GetInterfaceNameSelection** (char *DeviceName, char *ProtocolStackName, BOOL StartOfSelection, char *pInterfaceNameSel, WORD MaxStrSize, BOOL *pEndOfSelection, DWORD *pErrorCode)

Description

Function „VCS_GetInterfaceNameSelection” returns all available interface names.

Parameters

| | | |
|-------------------|-------|---|
| DeviceName | char* | Device name |
| ProtocolStackName | char* | Protocol stack name |
| StartOfSelection | BOOL | 1: Get first selection string 0: Get next selection string |
| MaxStrSize | WORD | Reserved memory size for the interface name |

Return Parameters

| | | |
|---------------------|--------|---|
| pInterfaceNameSel | char* | Name from interface |
| pEndOfSelection | BOOL* | 1: No more string available 0: More string available |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Go to [Programming Example](#)

4.3.4 Get Port Name Selection

Function

BOOL **VCS_GetPortNameSelection** (char *DeviceName, char *ProtocolStackName, char *InterfaceName, BOOL StartOfSelection, char *pPortSel, WORD MaxStrSize, BOOL *pEndOfSelection, DWORD *pErrorCode)

Description

Function „VCS_GetPortNameSelection” returns all available port names.

Parameters

| | | |
|-------------------|-------|---|
| DeviceName | char* | Device name |
| ProtocolStackName | char* | Protocol stack name |
| InterfaceName | char* | Interface name |
| StartOfSelection | BOOL | 1: Get first selection string 0: Get next selection string |
| MaxStrSize | WORD | Reserved memory size for the port name |

Return Parameters

| | | |
|---------------------|--------|---|
| pPortSel | char* | Pointer to port name |
| pEndOfSelection | BOOL* | 1: No more string available 0: More string available |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Go to [Programming Example](#)

4.3.5 Get Baud Rate Selection

Function

BOOL **VCS_GetBaudrateSelection** (char *DeviceName, char *ProtocolStackName, char *InterfaceName, char *PortName, BOOL StartOfSelection, DWORD *pBaudrateSel, BOOL *pEndOfSelection, DWORD *pErrorCode)

Description

Function „VCS_GetBaudrateSelection” returns all available baud rates for the connected port.

Parameters

| | | |
|-------------------|-------|---|
| DeviceName | char* | Name of device |
| ProtocolStackName | char* | Name of protocol stack |
| InterfaceName | char* | Interface name |
| PortName | char* | Port name |
| StartOfSelection | BOOL | 1: Get first selection value 0: Get next selection value |

Return Parameters

| | | |
|---------------------|--------|---|
| pBaudrateSel | DWORD* | Pointer to baud rate [Bit/s] |
| pEndOfSelection | BOOL* | 1: No more value available 0: More value available |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Go to [Programming Example](#)

4.3.6 Programming Example

The example shows how to read all protocol stack names of the available interfaces.
Programming language: C++

```
const WORD maxStrSize = 100;

char *strDeviceName = "EPOS";
char *strProtocolStackName[maxStrSize];
BOOL endOfSel;
DWORD errorCode;

//get first protocol stack name
if(VCS_GetProtocolStackNameSelection(strDeviceName, TRUE,
strProtocolStackName, maxStrSize, &endOfSel, &errorCode))
{
    //get next protocol stack name (as long as endOfSel == FALSE)
    while(!endOfSel)
    {
        VCS_GetProtocolStackNameSelection (strDeviceName, FALSE,
        strProtocolStackName, maxStrSize, &endOfSel, &errorCode);
    }
}
```

4.3.7 Get Key Handle

Function

BOOL **VCS_GetKeyHandle** (char *DeviceName, char *ProtocolStackName, char *InterfaceName, char *PortName, HANDLE *pKeyHandle, DWORD *pErrorCode)

Description

Function „VCS_GetKeyHandle” returns the key handle from the opened interface.

Parameters

| | | |
|-------------------|-------|---------------------|
| DeviceName | char* | Device name |
| ProtocolStackName | char* | Protocol stack name |
| InterfaceName | char* | Interface name |
| PortName | char* | Port name |

Return Parameters

| | | |
|---------------------|---------|--|
| pKeyHandle | HANDLE* | Handle for port access, if parameters are correct; otherwise 0 |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

4.3.8 Get Device Name

Function

BOOL **VCS_GetDeviceName** (HANDLE KeyHandle, char *pDeviceName, WORD MaxStrSize, DWORD *pErrorCode)

Description

Function „VCS_GetDeviceName” returns the device name to corresponding handle.

Parameters

| | | |
|------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| MaxStrSize | WORD | Reserved memory size for the device name |

Return Parameters

| | | |
|---------------------|--------|---|
| pDeviceName | char* | Device name |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

4.3.9 Get Protocol Stack Name

Function

BOOL **VCS_GetProtocolStackName** (HANDLE KeyHandle, char *pProtocolStackName, WORD MaxStrSize, DWORD *pErrorCode)

Description

Function „VCS_GetProtocolStackName” returns the protocol stack name to corresponding handle.

Parameters

| | | |
|------------|--------|-----------------------------------|
| KeyHandle | HANDLE | Handle for port access |
| MaxStrSize | WORD | Reserved memory size for the name |

Return Parameters

| | | |
|---------------------|--------|---|
| pProtocolStackName | char* | Pointer to protocol stack name |
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

4.3.10 Get Interface Name

Function

BOOL **VCS_GetInterfaceName** (HANDLE KeyHandle, char *pInterfaceName, WORD MaxStrSize, DWORD *pErrorCode)

Description

Function „VCS_GetInterfaceName” returns the interface name to corresponding handle.

Parameters

| | | |
|------------|--------|---|
| KeyHandle | HANDLE | Handle for port access |
| MaxStrSize | WORD | Reserved memory size for the interface name |

Return Parameters

| | | |
|---------------------|--------|---|
| pInterfaceName | char* | Name from interface |
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

4.3.11 Get Port Name

Function

BOOL **VCS_GetPortName** (HANDLE KeyHandle, char *pPortName, WORD MaxStrSize, DWORD *pErrorCode)

Description

Function „VCS_GetPortName” returns the port name to corresponding handle.

Parameters

| | | |
|------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| MaxStrSize | WORD | Reserved memory size for the port name |

Return Parameters

| | | |
|---------------------|--------|---|
| pPortName | char* | Port name |
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

5 Configuration Functions

For detailed information about the objects refer to associated document *Firmware Specification*.

5.1 General

5.1.1 Import Parameter

Function

BOOL **VCS_ImportParameter** (HANDLE KeyHandle, WORD NodeId, char *pParameterFileName, BOOL ShowDlg, BOOL ShowMsg, DWORD *pErrorCode)

Description

„VCS_ImportParameter“ writes parameters from a file to the device.

Parameters

| | | |
|--------------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| pParameterFileName | char* | Path of the needed file |
| ShowDlg | BOOL | Dialog is shown |
| ShowMsg | BOOL | Message box are activated |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Additional informations

Function is not available in the Linux library

5.1.2 Export Parameter

Function

BOOL **VCS_ExportParameter** (HANDLE KeyHandle, WORD NodeId, char *pParameterFileName, char *pBinaryFile, char *pUserID, char *pComment, BOOL ShowDlg, BOOL ShowMsg, DWORD *pErrorCode)

Description

„VCS_ExportParameter“ reads all parameters of the device and writes this into the file.

Parameters

| | | |
|--------------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| pParameterFileName | char* | Path of the needed file |
| pBinaryFile | char* | Firmware file of the connected device |
| pUserID | char* | User name |
| pComment | char* | Comment |
| ShowDlg | BOOL | Dialog is shown |
| ShowMsg | BOOL | Message box are activated |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Additional informations

Function is not available in the Linux library

5.1.3 Set Object

Function

BOOL **VCS_SetObject** (HANDLE KeyHandle, WORD NodeId, WORD ObjectIndex, BYTE ObjectSubIndex, void *pData, DWORD NbOfBytesToWrite, DWORD *pNbOfBytesWritten, DWORD *pErrorCode)

Description

The function „VCS_SetObject” writes an object value at the given index and sub-index from object dictionary.

Parameters

| | | |
|------------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| ObjectIndex | WORD | Object index |
| ObjectSubIndex | BYTE | Object sub-index |
| pData | void* | Object data |
| NbOfBytesToWrite | DWORD | Object length to write (number of bytes) |

Return Parameters

| | | |
|---------------------|--------|---|
| pNbOfBytesWritten | DWORD* | Object length written (number of bytes) |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Remarks

All information about object index, object sub-index and object length can be checked in the associated document *Firmware Specification*.

5.1.4 Get Object

Function

BOOL **VCS_GetObject** (HANDLE KeyHandle, WORD NodeId, WORD ObjectIndex, BYTE ObjectSubIndex, void *pData, DWORD NbOfBytesToRead, DWORD *pNbOfBytesRead, DWORD *pErrorCode)

Description

The function „VCS_GetObject” reads an object value at the given index and sub-index from object dictionary.

Parameters

| | | |
|-----------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| ObjectIndex | WORD | Object index |
| ObjectSubIndex | BYTE | Object sub-index |
| NbOfBytesToRead | DWORD | Object length to read (number of bytes) |

Return Parameters

| | | |
|---------------------|--------|---|
| pData | void* | Object data |
| pNbOfBytesRead | DWORD* | Object length read (number of bytes) |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Remarks

All information about object index, object sub-index and object length can be checked in the associated document *Firmware Specification*.

5.1.5 Restore

Function

BOOL **VCS_Restore** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

The function „VCS_Restore” restores all default parameters.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

5.1.6 Store

Function

BOOL **VCS_Store** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

The function „VCS_Store” stores all parameters.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

5.2 Advanced Functions

5.2.1 Motor

5.2.1.1 Set Motor Type

Function

BOOL **VCS_SetMotorType**(HANDLE KeyHandle, WORD NodeId, WORD MotorType, DWORD *pErrorCode)

Description

With function „VCS_SetMotorType” the motor type is written.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| MotorType | WORD | Kind of motor (see Table 3) Object: 0x6402-00 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Kind of motor

| Description | Constant name | Value |
|---------------------------|------------------------------|-------|
| brushed DC motor | MT_DC_MOTOR | 1 |
| EC motor sinus commutated | MT_EC_SINUS_COMMUTATED_MOTOR | 10 |
| EC motor block commutated | MT_EC_BLOCK_COMMUTATED_MOTOR | 11 |

Table 3: Kind of motor

5.2.1.2 Set DC-Motor Parameter**Function**

BOOL **VCS_SetDcMotorParameter** (HANDLE KeyHandle, WORD NodeId, WORD NominalCurrent, WORD MaxOutputCurrent, WORD ThermalTimeConstant, DWORD *pErrorCode)

Description

With function „VCS_SetDcMotorParameter“ it is possible to write all DC motor parameters.

Parameters

| | | | |
|---------------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| NominalCurrent | WORD | Maximal continuous current | Object: 0x6410-01 |
| MaxOutputCurrent | WORD | Maximal peak current | Object: 0x6410-02 |
| ThermalTimeConstant | WORD | Thermal time constant winding | Object: 0x6410-05 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

5.2.1.3 Set EC-Motor Parameter**Function**

BOOL **VCS_SetEcMotorParameter** (HANDLE KeyHandle, WORD NodeId, WORD NominalCurrent, WORD MaxOutputCurrent, WORD ThermalTimeConstant, BYTE NbOfPolePairs, DWORD *pErrorCode)

Description

With function „VCS_SetEcMotorParameter“ it is possible to write all EC motor parameters.

Parameters

| | | | |
|---------------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| NominalCurrent | WORD | Maximal continuous current | Object: 0x6410-01 |
| MaxOutputCurrent | WORD | Maximal peak current | Object: 0x6410-02 |
| ThermalTimeConstant | WORD | Thermal time constant winding | Object: 0x6410-05 |
| NbOfPolePairs | BYTE | Number of pole pairs | Object: 0x6410-03 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

5.2.1.4 Get Motor Type**Function**

BOOL **VCS_GetMotorType** (HANDLE KeyHandle, WORD NodeId, WORD *pMotorType, DWORD *pErrorCode)

Description

With function „VCS_GetMotorType“ it is possible to read the motor type.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|---------------------|--------|---|-------------------|
| MotorType | WORD | Kind of motor (see Table 3) | Object: 0x6402-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

5.2.1.5 Get DC-Motor Parameter

Function

BOOL **VCS_GetDcMotorParameter** (HANDLE KeyHandle, WORD NodeId, WORD* pNominalCurrent, WORD* pMaxOutputCurrent, WORD *pThermalTimeConstant, DWORD *pErrorCode)

Description

With function „VCS_GetDcMotorParameter“ it is possible to read all DC motor parameters.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|----------------------|--------|---|-------------------|
| pNominalCurrent | WORD* | Maximal continuous current | Object: 0x6410-01 |
| pMaxOutputCurrent | WORD* | Maximal peak current | Object: 0x6410-02 |
| pThermalTimeConstant | WORD* | Thermal time constant winding | Object: 0x6410-05 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

5.2.1.6 Get EC-Motor Parameter

Function

BOOL **VCS_GetEcMotorParameter** (HANDLE KeyHandle, WORD NodeId, WORD* pNominalCurrent, WORD* pMaxOutputCurrent, WORD* pThermalTimeConstant, BYTE* pNbOfPolePairs, DWORD *pErrorCode)

Description

With function „VCS_GetEcMotorParameter“ it is possible to read all EC motor parameters.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|----------------------|--------|---|-------------------|
| pNominalCurrent | WORD* | Maximal continuous current | Object: 0x6410-01 |
| pMaxOutputCurrent | WORD* | Maximal peak current | Object: 0x6410-02 |
| pThermalTimeConstant | WORD* | Thermal time constant winding | Object: 0x6410-05 |
| pNbOfPolePairs | BYTE* | Number of pole pairs | Object: 0x6410-03 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

5.2.2 Sensor

5.2.2.1 Set Sensor Type

Function

BOOL **VCS_SetSensorType** (HANDLE KeyHandle, WORD NodeId, WORD Counts, WORD SensorType, DWORD *pErrorCode)

Description

With function „VCS_SetSensorType“ it is possible to write the sensor type.

Parameters

| | | |
|------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| SensorType | WORD | Position Sensor Type (see Table 4) Object: 0x2210-02 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Position Sensor Type

| Description | Constant name | value |
|---|---------------------------|-------|
| Unknown sensor (undefined) | ST_UNKNOWN | 0 |
| Incremental Encoder 1 with index (3-channel) | ST_INC_ENCODER_3CHANNEL | 1 |
| Incremental Encoder 1 without index (2-channel) | ST_INC_ENCODER_2CHANNEL | 2 |
| Hall Sensors | ST_HALL_SENSORS | 3 |
| SSI Encoder binary coded | ST_SSI_ABS_ENCODER_BINARY | 4 |
| SSI Encoder Grey coded | ST_SSI_ABS_ENCODER_GREY | 5 |

Table 4: Position Sensor Type

5.2.2.2 Set Incremental Encoder Parameter

Function

BOOL **VCS_SetIncEncoderParameter** (HANDLE KeyHandle, WORD NodeId, DWORD EncoderResolution, BOOL InvertedPolarity, DWORD *pErrorCode)

Description

With function „VCS_SetIncEncoderParameter“ it is possible to write the incremental encoder parameters.

Parameters

| | | |
|-------------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| EncoderResolution | DWORD | Encoder pulse number [pulse per turn] Object: 0x2210-01 |
| InvertedPolarity | BOOL | Position sensor polarity Object: 0x2210-04 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

5.2.2.3 Set Hall Sensor Parameter

Function

BOOL **VCS_SetHallSensorParameter** (HANDLE KeyHandle, WORD NodeId, BOOL InvertedPolarity, DWORD *pErrorCode)

Description

With function „VCS_SetHallSensorParameter“ it is possible to write the Hall sensor parameter.

Parameters

| | | |
|------------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| InvertedPolarity | BOOL | Position sensor polarity Object: 0x2210-04 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

5.2.2.4 Set SSI Absolute Encoder Parameter

Function

BOOL **VCS_SetSsiAbsEncoderParameter** (HANDLE KeyHandle, WORD NodeId, WORD DataRate, WORD NbOfMultiTurnDataBits, WORD NbOfSingleTurnDataBits, BOOL InvertedPolarity, DWORD *pErrorCode)

Description

With function „VCS_SetSsiAbsEncoderParameter“ it is possible to write all parameters for SSI absolute encoder.

Parameters

| | | |
|------------------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| DataRate | WORD | SSI encoder data rate Object: 0x2211-01 |
| NbOfMultiTurnDataBits | WORD | number of bits multi turn Object: 0x2211-02 |
| NbOfSingleTurnDataBits | WORD | number of bits single turn |
| InvertedPolarity | BOOL | Position sensor polarity Object: 0x2210-04 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

5.2.2.5 Get Sensor Type

Function

BOOL **VCS_GetSensorType** (HANDLE KeyHandle, WORD NodeId, WORD *pSensorType, DWORD *pErrorCode)

Description

With function „VCS_GetSensorType“ it is possible to read the sensor type.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pSensorType | WORD* | Position sensor type (see Table 4) Object: 0x2210-02 |
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

5.2.2.6 Get Incremental Encoder Parameter

Function

BOOL **VCS_GetIncEncoderParameter** (HANDLE KeyHandle, WORD NodeId, DWORD* pEncoderResolution, BOOL* pInvertedPolarity, DWORD *pErrorCode)

Description

With function „VCS_GetIncEncoderParameter” it is possible to read the incremental encoder parameters.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|---------------------|--------|---|-------------------|
| pEncoderResolution | DWORD | Encoder pulse number [pulse per turn] | Object: 0x2210-01 |
| pInvertedPolarity | BOOL | Position sensor polarity | Object: 0x2210-04 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

5.2.2.7 Get Hall Sensor Parameter

Function

BOOL **VCS_GetHallSensorParameter** (HANDLE KeyHandle, WORD NodeId, BOOL* pInvertedPolarity, DWORD *pErrorCode)

Description

With function „VCS_GetHallSensorParameter” it is possible to read the Hall sensor parameters.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|---------------------|--------|---|-------------------|
| pInvertedPolarity | BOOL | Position sensor polarity | Object: 0x2210-04 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

5.2.2.8 Get SSI Absolute Encoder Parameter

Function

BOOL **VCS_GetSsiAbsEncoderParameter** (HANDLE KeyHandle, WORD NodeId, WORD* pDataRate, WORD* pNbOfMultiTurnDataBits, WORD* pNbOfSingleTurnDataBits, BOOL* pInvertedPolarity, DWORD* pErrorCode)

Description

With function „VCS_GetSsiAbsEncoderParameter” it is possible to read all parameters from SSI absolute encoder.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|-------------------------|--------|---|-------------------|
| Return Parameters | | | |
| pDataRate | WORD* | SSI encoder data rate | Object: 0x2211-01 |
| pNbOfMultiTurnDataBits | WORD* | Number of bits multi turn | Object: 0x2211-02 |
| pNbOfSingleTurnDataBits | WORD* | Number of bits single turn | |
| pInvertedPolarity | BOOL* | Position sensor polarity | Object: 0x2210-04 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

5.2.3 Safety**5.2.3.1 Set Maximal Following Error****Function**

BOOL **VCS_SetMaxFollowingError** (HANDLE KeyHandle, WORD NodeId, DWORD MaxFollowingError, DWORD *pErrorCode)

Description

„VCS_SetMaxFollowingError“ writes the maximal allowed following error parameter.

Parameters

| | | | |
|-------------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| MaxFollowingError | DWORD | Maximal allowed difference of position actual value to position demand value. | Object: 0x6065-00 |

Return Parameters

| | | |
|-------------------|--------|---|
| Return Parameters | | |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

5.2.3.2 Get Maximal Following Error**Function**

BOOL **VCS_GetMaxFollowingError** (HANDLE KeyHandle, WORD NodeId, DWORD* pMaxFollowingError, DWORD *pErrorCode)

Description

„VCS_GetMaxFollowingError“ reads the maximal allowed following error parameter.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | | |
|--------------------|--------|---|-------------------|
| pMaxFollowingError | DWORD* | Maximal allowed difference of position actual value to position demand value. | Object: 0x6065-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

5.2.3.3 Set Maximal Profile Velocity

Function

BOOL **VCS_SetMaxProfileVelocity** (HANDLE KeyHandle, WORD NodeId, DWORD MaxProfileVelocity, DWORD *pErrorCode)

Description

„VCS_SetMaxProfileVelocity” writes the maximal allowed velocity.

Parameters

| | | | |
|--------------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| MaxProfileVelocity | DWORD | This value is used as velocity limit in a position (or velocity) move. | Object: 0x607F-00 |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

5.2.3.4 Get Maximal Profile Velocity

Function

BOOL **VCS_GetMaxProfileVelocity** (HANDLE KeyHandle, WORD NodeId, DWORD* pMaxProfileVelocity, DWORD *pErrorCode)

Description

„VCS_GetMaxProfileVelocity” reads the maximal allowed velocity.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | | |
|---------------------|--------|--|-------------------|
| pMaxProfileVelocity | DWORD* | This value is used as velocity limit in a position (or velocity) move. | Object: 0x607F-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

5.2.3.5 Set Maximal Acceleration

Function

BOOL **VCS_SetMaxAcceleration** (HANDLE KeyHandle, WORD NodeId, DWORD MaxAcceleration, DWORD *pErrorCode)

Description

„VCS_SetMaxAcceleration” writes the maximal allowed acceleration/deceleration.

Parameters

| | | | |
|-----------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| MaxAcceleration | DWORD | This value is the limit of the other acceleration/ deceleration objects. | Object: 0x60C5-00 |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

5.2.3.6 Get Maximal Acceleration

Function

BOOL **VCS_GetMaxAcceleration** (HANDLE KeyHandle, WORD NodeId, DWORD* pMaxAcceleration, DWORD *pErrorCode)

Description

„VCS_GetMaxAcceleration“ reads the maximal allowed acceleration/deceleration.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|------------------|--------|---|-------------------|
| pMaxAcceleration | DWORD* | This value is the limit of the other acceleration/deceleration objects. | Object: 0x60C5-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

5.2.4 Position Regulator

5.2.4.1 Set Position Regulator Gain

Function

BOOL **VCS_SetPositionRegulatorGain** (HANDLE KeyHandle, WORD NodeId, WORD P, WORD I, WORD D, DWORD *pErrorCode)

Description

With function „VCS_SetPositionRegulatorGain“ it is possible to write all position regulator gains. Determine the optimal parameters by using the 'Regulation Tuning' of EPOS Studio.

Parameters

| | | | |
|-----------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| P | WORD | Position regulator P-Gain | Object: 0x60FB-01 |
| I | WORD | Position regulator I-Gain | Object: 0x60FB-02 |
| D | WORD | Position regulator D-Gain | Object: 0x60FB-03 |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

5.2.4.2 Set Position Regulator Feed Forward

Function

BOOL **VCS_SetPositionRegulatorFeedForward** (HANDLE KeyHandle, WORD NodeId, WORD VelocityFeedForward, WORD AccelerationFeedForward, DWORD *pErrorCode)

Description

„VCS_SetPositionRegulatorFeedForward“ writes parameters for position regulation with feed forward.

Parameters

| | | | |
|-------------------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| VelocityFeedForward | WORD | Velocity feed forward factor | Object: 0x60FB-04 |
| AccelerationFeedForward | WORD | Acceleration feed forward factor | Object: 0x60FB-05 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

5.2.4.3 Get Position Regulator Gain

Function

BOOL **VCS_GetPositionRegulatorGain** (HANDLE KeyHandle, WORD NodeId, WORD *pP, WORD *pI, WORD *pD, DWORD *pErrorCode)

Description

With function „VCS_GetPositionRegulatorGain“ it is possible to read all position regulator gains.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | | |
|---------------------|--------|---|-------------------|
| pP | WORD* | Position regulator P-Gain | Object: 0x60FB-01 |
| pI | WORD* | Position regulator I-Gain | Object: 0x60FB-02 |
| pD | WORD* | Position regulator D-Gain | Object: 0x60FB-03 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

5.2.4.4 Get Position Regulator Feed Forward

Function

BOOL **VCS_GetPositionRegulatorFeedForward** (HANDLE KeyHandle, WORD NodeId, WORD* pVelocityFeedForward, WORD* pAccelerationFeedForward, DWORD *pErrorCode)

Description

„VCS_GetPositionRegulatorFeedForward“ sets parameter for position regulation feed forward.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | | |
|--------------------------|--------|---|-------------------|
| pVelocityFeedForward | WORD* | Velocity feed forward factor | Object: 0x60FB-04 |
| pAccelerationFeedForward | WORD* | Acceleration feed forward factor | Object: 0x60FB-05 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

5.2.5 Velocity Regulator

5.2.5.1 Set Velocity Regulator Gain

Function

BOOL **VCS_SetVelocityRegulatorGain** (HANDLE KeyHandle, WORD NodeId, WORD P, WORD I, DWORD *pErrorCode)

Description

With function „VCS_SetVelocityRegulatorGain“ it is possible to write all velocity regulator gains. Determine the optimal parameters by using the 'Regulation Tuning' of EPOS Studio.

Parameters

| | | | |
|-----------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| P | WORD | Velocity regulator P-Gain | Object: 0x60F9-01 |
| I | WORD | Velocity regulator I-Gain | Object: 0x60F9-02 |

Return Parameters

| | | | |
|--------------|--------|---|--|
| pErrorCode | DWORD* | Error information about the executed function | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

5.2.5.2 Get Velocity Regulator Gain

Function

BOOL **VCS_GetVelocityRegulatorGain** (HANDLE KeyHandle, WORD NodeId, WORD *pP, WORD *pI, DWORD *pErrorCode)

Description

With function „VCS_GetVelocityRegulatorGain“ it is possible to read all velocity regulator gains.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | | |
|--------------|--------|---|-------------------|
| pP | WORD* | Velocity regulator P-Gain | Object: 0x60F9-01 |
| pI | WORD* | Velocity regulator I-Gain | Object: 0x60F9-02 |
| pErrorCode | DWORD* | Error information about the executed function | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

5.2.6 Current Regulator

5.2.6.1 Set Current Regulator Gain

Function

BOOL **VCS_SetCurrentRegulatorGain** (HANDLE KeyHandle, WORD NodeId, WORD P, WORD I, DWORD *pErrorCode)

Description

With function „VCS_SetCurrentRegulatorGain“ it is possible to write all current regulator gains. Determine the optimal parameters by using the 'Regulation Tuning' of EPOS Studio.

Parameters

| | | | |
|-----------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| P | WORD | Current regulator P-Gain | Object: 0x60F6-01 |
| I | WORD | Current regulator I-Gain | Object: 0x60F6-02 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

5.2.6.2 Get Current Regulator Gain

Function

BOOL **VCS_GetCurrentRegulatorGain** (HANDLE KeyHandle, WORD NodeId, WORD *pP, WORD *pI, DWORD *pErrorCode)

Description

With function „VCS_GetCurrentRegulatorGain” it is possible to read all current regulator gains.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|---------------------|--------|---|-------------------|
| pP | WORD* | Current regulator P-Gain | Object: 0x60F6-01 |
| pI | WORD* | Current regulator I-Gain | Object: 0x60F6-02 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

5.2.7 Inputs/Outputs

5.2.7.1 Digital Input Configuration

Function

BOOL **VCS_DigitalInputConfiguration** (HANDLE KeyHandle, WORD NodeId, WORD DigitalInputNb, WORD Configuration, BOOL Mask, BOOL Polarity, BOOL ExecutionMask, DWORD *pErrorCode)

Description

„VCS_DigitalInputConfiguration” sets the parameter for one digital input.

Parameters

| | | | |
|----------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| DigitalInputNb | WORD | Number of digital input (Sub-index of object) | Object: 0x2070-0x |
| Configuration | WORD | Configures which functionality will be assigned to digital input (bit number) For values see Table 5. | |
| Mask | BOOL | 1: Functionality state will be displayed 0: not displayed | Object: 0x2071-02 |
| Polarity | BOOL | 1: Low active 0: High active | Object: 0x2071-03 |
| ExecutionMask | BOOL | 1: Set the error routine. Only for positive and negative switch. | Object: 0x2071-04 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Digital Input Configuration

| Description | Constant name | value |
|-----------------------|---------------------------|-------|
| General purpose A | DIC_GENERAL_PURPOSE_A | 15 |
| General purpose B | DIC_GENERAL_PURPOSE_B | 14 |
| General purpose C | DIC_GENERAL_PURPOSE_C | 13 |
| General purpose D | DIC_GENERAL_PURPOSE_D | 12 |
| General purpose E | DIC_GENERAL_PURPOSE_E | 11 |
| General purpose F | DIC_GENERAL_PURPOSE_F | 10 |
| General purpose G | DIC_GENERAL_PURPOSE_G | 9 |
| General purpose H | DIC_GENERAL_PURPOSE_H | 8 |
| General purpose I | DIC_GENERAL_PURPOSE_I | 7 |
| General purpose J | DIC_GENERAL_PURPOSE_J | 6 |
| Quick stop | DIC_QUICK_STOP | 5 |
| Device enable | DIC_DRIVE_ENABLE | 4 |
| Position marker | DIC_POSITION_MARKER | 3 |
| Home switch | DIC_HOME_SWITCH | 2 |
| Positive limit switch | DIC_POSITIVE_LIMIT_SWITCH | 1 |
| Negative limit switch | DIC_NEGATIVE_LIMIT_SWITCH | 0 |

Table 5: Digital Input Configuration

5.2.7.2 Digital Output Configuration**Function**

BOOL **VCS_DigitalOutputConfiguration** (HANDLE KeyHandle, WORD NodeId, WORD DigitalOutputNb, WORD Configuration, BOOL State, BOOL Mask, BOOL Polarity, DWORD *pErrorCode)

Description

„VCS_DigitalOutputConfiguration” sets parameter for one digital output.

Parameters

| | | | |
|-----------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| DigitalOutputNb | WORD | Number of digital output (Sub-index of object) | Object: 0x2079-0x |
| Configuration | WORD | Configures which functionality will be assigned to digital output (bit number). For values see Table 6. | |
| State | BOOL | State of digital output | Object: 0x2078-01 |
| Mask | BOOL | 1: Register will be modified | Object: 0x2078-02 |
| Polarity | BOOL | 1: Output will be inverted | Object: 0x2078-03 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Digital Output Configuration

| Description | Constant name | value |
|-------------------|-----------------------|-------|
| General purpose A | DOC_GENERAL_PURPOSE_A | 15 |
| General purpose B | DOC_GENERAL_PURPOSE_B | 14 |
| General purpose C | DOC_GENERAL_PURPOSE_C | 13 |
| General purpose D | DOC_GENERAL_PURPOSE_D | 12 |
| General purpose E | DOC_GENERAL_PURPOSE_E | 11 |
| Position compare | DOC_POSITION_COMPARE | 1 |
| Ready / Fault | DOC_READY_FAULT | 0 |

Table 6: Digital Output Configuration

5.2.7.3 Analog Input Configuration

Function

BOOL **VCS_AnalogInputConfiguration** (HANDLE KeyHandle, WORD NodeId, WORD AnalogInputNb, WORD Configuration, BOOL ExecutionMask, DWORD *pErrorCode)

Description

„VCS_AnalogInputConfiguration” sets parameter for an analog input.

Parameters

| | | | |
|---------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| AnalogInputNb | WORD | Number of analog input (Sub-index of object) | Object: 0x2079 |
| Configuration | WORD | Configures which functionality will be assigned to analog input (bit number) For values see Table 7. | |
| ExecutionMask | BOOL | 1: Register will be modified | Object: 0x2078-02 |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Analog Input Configuration

| Description | Constant name | value |
|---------------------------|------------------------------|-------|
| Analog position set point | AIC_ANALOG_POSITION_SETPOINT | 2 |
| Analog velocity set point | AIC_ANALOG_VELOCITY_SETPOINT | 1 |
| Analog current set point | AIC_ANALOG_CURRENT_SETPOINT | 0 |

Table 7: Analog Input Configuration

5.2.8 Units

5.2.8.1 Set Velocity Units

Function

BOOL **VCS_SetVelocityUnits** (HANDLE KeyHandle, WORD NodeId, BYTE VelDimension, char VelNotation, DWORD *pErrorCode)

Description

„VCS_SetVelocityUnits” writes velocity unit parameters.

Parameters

| | | | |
|--------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| VelDimension | BYTE | Velocity dimension index VD_RPM = 0xA4 | Object: 0x608C-00 |
| VelNotation | char | Velocity notation index VN_STANDARD = 0 VN_DECI = -1 VN_CENTI = -2 VN_MILLI = -3 | Object: 0x608B-00 |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

5.2.8.2 Get Velocity Units

Function

BOOL **VCS_GetVelocityUnits** (HANDLE KeyHandle, WORD NodeId, BYTE* pVelDimension, char* pVelNotation, DWORD *pErrorCode)

Description

„VCS_GetVelocityUnits“ reads velocity unit parameters.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|---------------|--------|---|-------------------|
| pVelDimension | BYTE* | Velocity dimension index VD_RPM = 0xA4 | Object: 0x608C-00 |
| pVelNotation | char* | Velocity notation index VN_STANDARD = 0; VN_DECI = -1; VN_CENTI = -2; VN_MILLI = -3 | Object: 0x608B-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6 Operation Functions

6.1 Operation Mode

6.1.1 Set Operation Mode

Function

BOOL **VCS_SetOperationMode** (HANDLE KeyHandle, WORD NodeId, __int8 Mode, DWORD *pErrorCode)

Description

„VCS_SetOperationMode“ sets the operation mode.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| Mode | __int8 | Operation mode (see Table 8) Object: 0x6060-00 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.1.2 Get Operation Mode

Function

BOOL **VCS_GetOperationMode** (HANDLE KeyHandle, WORD NodeId, __int8 *pMode, DWORD *pErrorCode)

Description

Function „VCS_GetOperationMode“ returns the activated operation mode.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|---------|---|
| pMode | __int8* | Operation mode (see Table 8) Object: 0x6061-00 |
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Operational Modes

| Description | Value | Constant name |
|----------------------------|-------|--------------------------------|
| Position Profile Mode | 1 | OMD_PROFILE_POSITION_MODE |
| Position Velocity Mode | 3 | OMD_PROFILE_VELOCITY_MODE |
| Homing Mode | 6 | OMD_HOMING_MODE |
| Interpolated Position Mode | 7 | OMD_INTERPOLATED_POSITION_MODE |
| Position Mode | -1 | OMD_POSITION_MODE |
| Velocity Mode | -2 | OMD_VELOCITY_MODE |
| Current Mode | -3 | OMD_CURRENT_MODE |
| Master Encoder Mode | -5 | OMD_MASTER_ENCODER_MODE |
| Step Direction Mode | -6 | OMD_STEP_DIRECTION_MODE |

Table 8: Operational modes

6.2 State Machine

For detailed information about the state machine refer to associated document *Firmware Specification*.

6.2.1 Reset Device

Function

BOOL **VCS_ResetDevice** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

The function „VCS_ResetDevice” is used to send the NMT service ‘Reset Node’. It is a command without acknowledge.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.2.2 Set State

Function

BOOL **VCS_SetState** (HANDLE KeyHandle, WORD NodeId, WORD State, DWORD *pErrorCode)

Description

„VCS_SetState” reads the actual state machine state.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| State | WORD | Value of state machine (see Table 9) |

Object: 0x6040-00

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

States

| Description | Value | Constant name |
|-------------------------|--------|---------------|
| Get/Set Disable State | 0x0000 | ST_DISABLED |
| Get/Set Enable State | 0x0001 | ST_ENABLED |
| Get/Set Quickstop State | 0x0002 | ST_QUICKSTOP |
| Get Fault State | 0x0003 | ST_FAULT |

Table 9: State modes

6.2.3 Set Enable State

Function

BOOL **VCS_SetEnableState** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

With the function „VCS_SetEnableState” the device changes to enable state.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.2.4 Set Disable State

Function

BOOL **VCS_SetDisableState** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

With function „VCS_SetDisableState“ changes the device to disable state.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.2.5 Set Quick Stop State

Function

BOOL **VCS_SetQuickStopState** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

With function „VCS_SetQuickStopState“ the device changes to quick stop state.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.2.6 Clear Fault

Function

BOOL **VCS_ClearFault** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

With function „VCS_ClearFault“ the device changes from fault state to disable state.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.2.7 Get State

Function

BOOL **VCS_GetState**(HANDLE KeyHandle, WORD NodeId, WORD* pState, DWORD *pErrorCode)

Description

„VCS_GetState” reads the new state for the state machine.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|--------------|--------|---|-------------------|
| pState | WORD* | Control word value (see Table 9) | Object: 0x6040-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.2.8 Get Enable State

Function

BOOL **VCS_GetEnableState**(HANDLE KeyHandle, WORD NodeId, BOOL *pIsEnabled, DWORD *pErrorCode)

Description

„VCS_GetEnableState” checks if the device is enabled.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|--------------|--------|---|
| pIsEnabled | BOOL* | 1: Device enabled 0: Device not enabled |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.2.9 Get Disable State

Function

BOOL **VCS_GetDisableState**(HANDLE KeyHandle, WORD NodeId, BOOL *pIsDisabled, DWORD *pErrorCode)

Description

„VCS_GetDisableState” checks if the device is disabled.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|--------------|--------|---|
| pIsDisabled | BOOL* | 1: Device disabled 0: Device not disabled |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.2.10 Get Quick Stop State

Function

BOOL **VCS_GetQuickStopState** (HANDLE KeyHandle, WORD NodeId, BOOL *pIsQuickStopped, DWORD *pErrorCode)

Description

The function „VCS_GetQuickStopState” returns the device state quick stop.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|-----------------|--------|--|
| pIsQuickStopped | BOOL* | 1: Device is in quick stop state 0: Device is not in quick stop state |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.2.11 Get Fault State

Function

BOOL **VCS_GetFaultState** (HANDLE KeyHandle, WORD NodeId, BOOL *pIsInFault, DWORD *pErrorCode)

Description

The function „VCS_GetFaultState” returns the device state fault (pIsInFault = TRUE).

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|--------------|--------|--|
| pIsInFault | BOOL* | 1: Device is in fault state 0: Device is not in fault state |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Remarks

Get error information if the device is in fault state see chapter [Error Handling](#).

6.3 Error Handling

6.3.1 Get Number of Device Error

Function

BOOL **VCS_GetNbOfDeviceError** (HANDLE KeyHandle, WORD NodeId, BYTE *pNbDeviceError, DWORD *pErrorCode)

Description

„VCS_GetNbOfDeviceError” returns the number of actual errors that are recorded.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|---------------------|--------|---|-------------------|
| pNbDeviceError | BYTE* | Number of occurred device errors | Object: 0x1003-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

[Programming Example](#)

6.3.2 Get Device Error Code

Function

BOOL **VCS_GetDeviceErrorCode** (HANDLE KeyHandle, WORD NodeId, BYTE ErrorNumber, DWORD *pDeviceErrorCode, DWORD *pErrorCode)

Description

„VCS_GetDeviceErrorCode“ returns the error code of selected error number .

Parameters

| | | | |
|-------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| ErrorNumber | BYTE | Number (Object sub index) of device error (>= 1) | Object: 0x1003-0x |

Return Parameters

| | | | |
|---------------------|--------|---|-------------------|
| pDeviceErrorCode | BYTE* | Actual error code from error history | Object: 0x1003-0x |
| pErrorCode | DWORD* | Error information about the executed function | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.3.3 Programming Example

Description

The example shows how to read the error history from a device. It is written in programming language C++.

```
//Global parameters
HANDLE KeyHandle = 1; //handle from opened interface
WORD NodeId = 1;      //node ID from connected device

//Functional parameters
BYTE nbOfDeviceError = 0; //number of actual errors
DWORD functionErrorCode = 0; //error code from function
DWORD deviceErrorCode = 0; //error code from device

//get number of device errors
if(VCS_GetNbOfDeviceError (KeyHandle, NodeId, &nbOfDeviceError,
                           &functionErrorCode))
{
    //read device error code
    for(BYTE errorNumber = 1; subIndex <= nbOfDeviceError; errorNumber++)
    {
        if(!VCS_GetDeviceErrorCode(KeyHandle, NodeId, errorNumber,
                                    &deviceErrorCode, &functionErrorCode))
        {
            break;
        }
    }
}
```

6.4 Motion Info

This group defines all required functions for motion information:

6.4.1 Get Movement State

Function

BOOL **VCS_GetMovementState** (HANDLE KeyHandle, WORD NodeId, BOOL *pTargetReached, DWORD *pErrorCode)

Description

With „VCS_GetMovementState“ it is possible to check, if drive has reached the target.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|----------------|--------|--|-----------------------------|
| pTargetReached | BOOL* | The drive has reached the target. The function reads actual state of bit 10 from the status word. | Object: 0x6041-00 Bit 10 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.4.2 Get Position Is

Function

BOOL **VCS_GetPositionIs** (HANDLE KeyHandle, WORD NodeId, long *pPositionIs, DWORD *pErrorCode)

Description

„VCS_GetPositionIs“ returns the position actual value.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|--------------|--------|---|-------------------|
| pPositionIs | long* | Position actual value | Object: 0x6064-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.4.3 Get Velocity Is

Function

BOOL **VCS_GetVelocityIs** (HANDLE KeyHandle, WORD NodeId, long *pVelocityIs, DWORD *pErrorCode)

Description

„VCS_GetVelocityIs“ reads the velocity actual value.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|---------------------|--------|---|-------------------|
| pVelocityIs | long* | Velocity actual value | Object: 0x606C-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.4.4 Get Current Is

Function

BOOL **VCS_GetCurrentIs** (HANDLE KeyHandle, WORD NodeId, short *pCurrentIs, DWORD *pErrorCode)

Description

„VCS_GetCurrentIs“ returns the current actual value.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | | |
|---------------------|--------|---|-------------------|
| pCurrentIs | short* | Current actual value | Object: 0x6078-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.4.5 Wait For Target Reached

Function

BOOL **VCS_WaitForTargetReached** (HANDLE KeyHandle, WORD NodeId, DWORD Timeout, DWORD *pErrorCode)

Description

„VCS_WaitForTargetReached“ is waiting until the state is changed to target reached or the time is up.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| Timeout | WORD | Max. wait time until target reached | |

Return Parameters

| | | | |
|---------------------|--------|---|--|
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.5 Profile Position Mode

This group defines all required functions for profile position mode:

6.5.1 Activate Profile Position Mode

Function

BOOL **VCS_ActivateProfilePositionMode** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

With the function „VCS_ActivateProfilePositionMode“ the device changes to profile position mode (PPM).

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.5.2 Set Position Profile**Function**

BOOL **VCS_SetPositionProfile** (HANDLE KeyHandle, WORD NodeId, DWORD ProfileVelocity, DWORD ProfileAcceleration, DWORD ProfileDeceleration, DWORD *pErrorCode)

Description

„VCS_SetPositionProfile“ sets the position profile parameters.

Parameters

| | | | |
|---------------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| ProfileVelocity | DWORD | Position profile velocity | Object: 0x6081-00 |
| ProfileAcceleration | DWORD | Position profile acceleration | Object: 0x6083-00 |
| ProfileDeceleration | DWORD | Position profile deceleration | Object: 0x6084-00 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.5.3 Get Position Profile**Function**

BOOL **VCS_GetPositionProfile** (HANDLE KeyHandle, WORD NodeId, DWORD *pProfileVelocity, DWORD *pProfileAcceleration, DWORD *pProfileDeceleration, DWORD *pErrorCode)

Description

„VCS_GetPositionProfile“ returns the position profile parameters.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | | |
|----------------------|--------|---|-------------------|
| pProfileVelocity | DWORD* | Position profile velocity | Object: 0x6081-00 |
| pProfileAcceleration | DWORD* | Position profile acceleration | Object: 0x6083-00 |
| pProfileDeceleration | DWORD* | Position profile deceleration | Object: 0x6084-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.5.4 Move To Position

Function

BOOL **VCS_MoveToPosition** (HANDLE KeyHandle, WORD NodeId, long TargetPosition, BOOL Absolute, BOOL Immediately, DWORD *pErrorCode)

Description

With function „VCS_MoveToPosition“ device movement starts with position profile to target position.

Parameters

| | | | |
|----------------|--------|--|----------------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| TargetPosition | long | Target position | Object: 0x607A-00 |
| Absolute | BOOL | TRUE starts an absolute, FALSE a relative movement | Object: 0x6040-00 Bit 6 |
| Immediately | BOOL | TRUE starts immediately, FALSE waits to end of last positioning | Object: 0x6040-00 Bit 5 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.5.5 Get Target Position

Function

BOOL **VCS_GetTargetPosition** (HANDLE KeyHandle, WORD NodeId, long *pTargetPosition, DWORD *pErrorCode)

Description

The function „VCS_GetTargetPosition“ returns the profile position mode target value.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | | |
|---------------------|--------|---|-------------------|
| pTargetPosition | long* | Target position | Object: 0x607A-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.5.6 Halt Position Movement

Function

BOOL **VCS_HaltPositionMovement** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

With function „VCS_HaltPositionMovement“ movement stops with profile deceleration.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | | |
|---------------------|--------|---|--|
| pErrorCode | DWORD* | Error information about the executed function | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.5.7 Advanced Functions

6.5.7.1 Enable Position Window

Function

BOOL **VCS_EnablePositionWindow** (HANDLE KeyHandle, WORD NodeId, DWORD PositionWindow, WORD PositionWindowTime, DWORD *pErrorCode)

Description

With function „VCS_EnablePositionWindow“ the position window is activated.

Parameters

| | | | |
|--------------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| PositionWindow | DWORD | Position window value | Object: 0x6067-00 |
| PositionWindowTime | WORD | Position window time value | Object: 0x6068-00 |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.5.7.2 Disable Position Window

Function

BOOL **VCS_DisablePositionWindow** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

With function „VCS_DisablePositionWindow“ the position window is deactivated.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.6 Profile Velocity Mode

This group defines all required functions for profile velocity mode:

6.6.1 Activate Profile Velocity Mode

Function

BOOL **VCS_ActivateProfileVelocityMode** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

With the function „VCS_ActivateProfileVelocityMode“ the device changes to profile velocity mode (PVM).

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.6.2 Set Velocity Profile

Function

BOOL **VCS_SetVelocityProfile** (HANDLE KeyHandle, WORD NodeId, DWORD ProfileAcceleration, DWORD ProfileDeceleration, DWORD *pErrorCode)

Description

„VCS_SetVelocityProfile“ sets the velocity profile parameters.

Parameters

| | | | |
|---------------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| ProfileAcceleration | DWORD | Velocity profile acceleration | Object: 0x6083-00 |
| ProfileDeceleration | DWORD | Velocity profile deceleration | Object: 0x6084-00 |

Return Parameters

| | | |
|-------------------|--------|---|
| Return Parameters | | |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.6.3 Get Velocity Profile

Function

BOOL **VCS_GetVelocityProfile** (HANDLE KeyHandle, WORD NodeId, DWORD *pProfileAcceleration, DWORD *pProfileDeceleration, DWORD *pErrorCode)

Description

„VCS_GetVelocityProfile“ returns the velocity profile parameters.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | | |
|----------------------|--------|---|-------------------|
| pProfileAcceleration | DWORD* | Velocity profile acceleration | Object: 0x6083-00 |
| pProfileDeceleration | DWORD* | Velocity profile deceleration | Object: 0x6084-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.6.4 Move With Velocity

Function

BOOL **VCS_MoveWithVelocity** (HANDLE KeyHandle, WORD NodeId, long TargetVelocity, DWORD *pErrorCode)

Description

With function „VCS_MoveWithVelocity“ device movement starts with velocity profile to target velocity.

Parameters

| | | | |
|----------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| TargetVelocity | long | Target velocity | Object: 0x60FF-00 |

Return Parameters

| | | |
|-------------------|--------|---|
| Return Parameters | | |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.6.5 Get Target Velocity

Function

BOOL **VCS_GetTargetVelocity** (HANDLE KeyHandle, WORD NodeId, long *pTargetVelocity, DWORD *pErrorCode)

Description

The function „VCS_GetTargetVelocity” returns the profile velocity mode target value.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|-------------------|--------|---|-------------------|
| Return Parameters | | | |
| pTargetVelocity | long* | Target velocity | Object: 0x60FF-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.6.6 Halt Velocity Movement

Function

BOOL **VCS_HaltVelocityMovement** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

With function „VCS_HaltVelocityMovement” movement stops with profile deceleration.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.6.7 Advanced Functions

6.6.7.1 Enable Velocity Window

Function

BOOL **VCS_EnableVelocityWindow** (HANDLE KeyHandle, WORD NodeId, DWORD VelocityWindow, WORD VelocityWindowTime, DWORD *pErrorCode)

Description

With function „VCS_EnableVelocityWindow” the velocity window is activated.

Parameters

| | | | |
|--------------------|--------|--|-------------------|
| Parameters | | | |
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| VelocityWindow | DWORD | Velocity window value | Object: 0x606D-00 |
| VelocityWindowTime | WORD | Velocity window time value | Object: 0x606E-00 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.6.7.2 Disable Velocity Window

Function

BOOL **VCS_DisableVelocityWindow** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

With function „VCS_DisableVelocityWindow“ the velocity window is deactivated.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.7 Homing Mode

This group defines all required functions for homing mode:

6.7.1 Activate Homing Mode

Function

BOOL **VCS_ActivateHomingMode** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

With the function „VCS_ActivateHomingMode“ the device changes to homing mode (HM).

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.7.2 Set Homing Parameter

Function

BOOL **VCS_SetHomingParameter** (HANDLE KeyHandle, WORD NodeId, DWORD HomingAcceleration, DWORD SpeedSwitch, DWORD SpeedIndex, long HomeOffset, WORD CurrentThreshold, long HomePosition, DWORD *pErrorCode)

Description

With function „VCS_SetHomingParameter“ it is possible to write all homing parameters.

Parameters

| | | | |
|--------------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| HomingAcceleration | DWORD | Acceleration for homing profile | Object: 0x609A-00 |
| SpeedSwitch | DWORD | Speed during search for switch | Object: 0x6099-01 |
| SpeedIndex | DWORD | Speed during search for index signal | Object: 0x6099-02 |
| HomeOffset | long | Home offset after homing | Object: 0x607C-00 |
| CurrentThreshold | WORD | Current threshold for | Object: 0x2080-00 |

| maxon motor | |
|-----------------------------|----------------------|
| EPOS Positioning Controller | EPOS Command Library |

| | | | |
|--------------|------|--|-------------------|
| | | homing method -1, -2, -3 and -4 | |
| HomePosition | long | Assign the current Homing position with this value | Object: 0x2081-00 |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Remarks

Parameter units depend on (position, velocity, acceleration) notation index.

6.7.3 Get Homing Parameter

Function

BOOL **VCS_GetHomingParameter** (HANDLE KeyHandle, WORD NodeId, DWORD *pHomingAcceleration, DWORD *pSpeedSwitch, DWORD *pSpeedIndex, long *pHomeOffset, WORD *pCurrentThreshold, long *pHomePosition, DWORD *pErrorCode)

Description

With function „VCS_GetHomingParameter“ it is possible to read all homing parameters.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|---------------------|--------|---|-------------------|
| pHomingAcceleration | DWORD* | Acceleration for homing profile | Object: 0x609A-00 |
| pSpeedSwitch | DWORD* | Speed during search for switch | Object: 0x6099-01 |
| pSpeedIndex | DWORD* | Speed during search for index signal | Object: 0x6099-02 |
| pHomeOffset | long* | Home offset after homing | Object: 0x607C-00 |
| pCurrentThreshold | WORD* | Current threshold for homing method -1, -2, -3 and -4 | Object: 0x2080-00 |
| pHomePosition | long* | Home position value | Object: 0x2081-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

Remarks

Parameter units depend on (position, velocity, acceleration) notation index.

6.7.4 Find Home

Function

BOOL **VCS_FindHome** (HANDLE KeyHandle, WORD NodeId, __int8 HomingMethod, DWORD *pErrorCode)

Description

With function „VCS_FindHome“ and the parameter „HomingMethod“ it is possible to find the system home. For example a home switch.

Parameters

| | | |
|--------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| HomingMethod | __int8 | Homing method Object: 0x6098-00 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Homing method

| Method Number | Constant value | Description |
|---------------|---|--|
| 35 | HM_ACTUAL_POSITION | Actual Position |
| 34 | HM_INDEX_POSITIVE_SPEED | Index Positive Speed |
| 33 | HM_INDEX_NEGATIVE_SPEED | Index Negative Speed |
| 27 | HM_HOME_SWITCH_NEGATIVE_SPEED | Home Switch Negative Speed |
| 23 | HM_HOME_SWITCH_POSITIVE_SPEED | Home Switch Positive Speed |
| 18 | HM_POSITIVE_LIMIT_SWITCH | Positive Limit Switch |
| 17 | HM_NEGATIVE_LIMIT_SWITCH | Negative Limit Switch |
| 11 | HM_HOME_SWITCH_NEGATIVE_SPEED_AND_INDEX | Home Switch Negative Speed & Index |
| 7 | HM_HOME_SWITCH_POSITIVE_SPEED_AND_INDEX | Home Switch Positive Speed & Index |
| 2 | HM_POSITIVE_LIMIT_SWITCH_AND_INDEX | Positive Limit Switch & Index |
| 1 | HM_NEGATIVE_LIMIT_SWITCH_AND_INDEX | Negative Limit Switch & Index |
| 0 | | No homing operation required |
| -1 | HM_CURRENT_THRESHOLD_POSITIVE_SPEED_AND_INDEX | Current Threshold Positive Speed & Index |
| -2 | HM_CURRENT_THRESHOLD_NEGATIVE_SPEED_AND_INDEX | Current Threshold Negative Speed & Index |
| -3 | HM_CURRENT_THRESHOLD_POSITIVE_SPEED | Current Threshold Positive Speed |
| -4 | HM_CURRENT_THRESHOLD_NEGATIVE_SPEED | Current Threshold Negative Speed |

Table 10: Homing methods

6.7.5 Stop Homing**Function**

BOOL **VCS_StopHoming** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

The function „VCS_StopHoming” interrupts homing.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.7.6 Define Position

Function

BOOL **VCS_DefinePosition** (HANDLE KeyHandle, WORD NodeId, long HomePosition, DWORD *pErrorCode)

Description

The function „VCS_DefinePosition“ is using homing method 35 (Actual Position) to set a new home position.

Parameters

| | | | |
|--------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| HomePosition | long | Assign the homing position with this value | Object: 0x2081-00 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.8 Interpolated Position Mode (IPM)

6.8.1 Activate Interpolated Position Mode

Function

BOOL **VCS_ActivateInterpolatedPositionMode** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

With the function „VCS_ActivateInterpolatedPositionMode“ the device changes to interpolated position mode (IPM).

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.8.2 Set IPM Buffer Parameter

Function

BOOL **VCS_SetIpmBufferParameter** (HANDLE KeyHandle, WORD NodeId, WORD UnderflowWarningLimit, WORD OverflowWarningLimit, DWORD *pErrorCode)

Description

The function „VCS_SetIpmBufferParameter“ set warning borders of the data input.

Parameters

| | | | |
|-----------------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| UnderflowWarningLimit | WORD | This object gives lower signalization level of the data input FIFO. | Object: 0x20C4-02 |
| OverflowWarningLimit | WORD | This object gives the higher signalization level of the data input FIFO. | Object: 0x20C4-03 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.8.3 Get IPM Buffer Parameter**Function**

BOOL **VCS_GetIpmBufferParameter** (HANDLE KeyHandle, WORD NodeId, WORD* pUnderflowWarningLimit, WORD* pOverflowWarningLimit, DWORD* pMaxBufferSize, DWORD *pErrorCode)

Description

The function „VCS_GetIpmBufferParameter“ read warning borders and the max. buffer size of the data input.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|------------------------|--------|--|-------------------|
| pUnderflowWarningLimit | WORD* | This object gives lower signalization level of the data input FIFO. | Object: 0x20C4-02 |
| pOverflowWarningLimit | WORD* | This object gives the higher signalization level of the data input FIFO. | Object: 0x20C4-03 |
| pMaxBufferSize | DWORD* | This object provides the maximal buffer size | Object: 0x60C4-01 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.8.4 Clear IPM Buffer**Function**

BOOL **VCS_ClearIpmBuffer** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

The function „VCS_ClearIpmBuffer“ clears input buffer and enables the access to the input buffer for the drive functions.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.8.5 Get Free IPM Buffer Size**Function**

BOOL **VCS_GetFreeIpmBufferSize** (HANDLE KeyHandle, WORD NodeId, DWORD *pBufferSize, DWORD *pErrorCode)

Description

The function „VCS_GetFreeIpmBufferSize“ read the actual free buffer size.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services. |

Return Parameters

| | | | |
|---------------------|--------|---|-------------------|
| pBufferSize | DWORD | Actual free buffer size | Object: 0x60C4-02 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.8.6 Add PVT Value To IPM Buffer

Function

BOOL **VCS_AddPvtValueToIpMBuffer** (HANDLE KeyHandle, WORD NodeId, long Position, long Velocity, BYTE Time, DWORD *pErrorCode)

Description

The function „VCS_AddPvtValueToIpMBuffer“ adds a new PVT reference point to the device.

Parameters

| | | | |
|-----------|--------|--|----------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| Position | long | Position of the reference point | Object: 0x20C1-00 |
| Velocity | long | Velocity of the reference point | |
| Time | BYTE | Time of the reference point | |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.8.7 Start IPM Trajectory

Function

BOOL **VCS_StartIpMTrajectory** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

The function „VCS_StartIpMTrajectory“ starts the IPM trajectory.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.8.8 Stop IPM Trajectory

Function

BOOL **VCS_StopIpMTrajectory** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

The function „VCS_StopIpMTrajectory“ stops the IPM trajectory.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.8.9 Get IPM Status

Function

BOOL **VCS_GetIpmStatus** (HANDLE KeyHandle, WORD NodeId, BOOL* pTrajectoryRunning, BOOL* plsUnderflowWarning, BOOL* plsOverflowWarning, BOOL* plsVelocityWarning, BOOL* plsAccelerationWarning, BOOL* plsUnderflowError, BOOL* plsOverflowError, BOOL* plsVelocityError, BOOL* plsAccelerationError, DWORD *pErrorCode)

Description

The function „VCS_GetIpmStatus” returns different warning and error states.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|------------------------|--------|--|----------------------|
| pTrajectoryRunning | BOOL* | State if IPM active | Object: 0x20C4-01 |
| plsUnderflowWarning | BOOL* | State if buffer underflow level is reached | |
| plsOverflowWarning | BOOL* | State if buffer overflow level is reached | |
| plsVelocityWarning | BOOL* | State if IPM velocity greater than profile velocity | |
| plsAccelerationWarning | BOOL* | State if IPM acceleration greater than profile acceleration | |
| plsUnderflowError | BOOL* | State of underflow error | |
| plsOverflowError | BOOL* | State of overflow error | |
| plsVelocityError | BOOL* | State if IPM velocity greater than max. profile velocity | |
| plsAccelerationError | BOOL* | State if IPM acceleration greater than max. profile acceleration | |
| pErrorCode | DWORD* | Error information about the executed function | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.9 Position Mode

This group defines all required functions for position mode:

6.9.1 Activate Position Mode

Function

BOOL **VCS_ActivatePositionMode** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

With the function „VCS_ActivatePositionMode” the device changes to position mode (PM).

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.9.2 Set Position Must

Function

BOOL **VCS_SetPositionMust** (HANDLE KeyHandle, WORD NodeId, long PositionMust, DWORD *pErrorCode)

Description

„VCS_SetPositionMust“ sets the position demand value.

Parameters

| | | | |
|--------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| PositionMust | long | Position demand value | Object: 0x2062-00 |

Return Parameters

| | | | |
|---------------------|--------|---|--|
| pErrorCode | DWORD* | Error information about the executed function | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.9.3 Get Position Must

Function

BOOL **VCS_GetPositionMust** (HANDLE KeyHandle, WORD NodeId, long *pPositionMust, DWORD *pErrorCode)

Description

„VCS_GetPositionMust“ returns the position demand value.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | | |
|---------------------|--------|---|-------------------|
| pPositionMust | long* | Position demand value | Object: 0x2062-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.9.4 Advanced Functions

6.9.4.1 Activate Analog Position Setpoint

Function

BOOL **VCS_ActivateAnalogPositionSetpoint** (HANDLE KeyHandle, WORD NodeId, WORD AnalogInputNumber, float Scaling, long Offset, DWORD *pErrorCode)

Description

„VCS_ActivateAnalogPositionSetpoint“ configures the selected analog input for analog position setpoint.

Parameters

| | | | |
|-------------------|--------|--|--------------------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| AnalogInputNumber | WORD | Number of the used analog input | Object: 0x207B-01 or 0x207B-02 |
| Scaling | float | The scaling factor for analog position setpoint functionality | Object: 0x2303-01 |
| Offset | long | Offset for analog position setpoint functionality | Object: 0x2303-02 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.9.4.2 Deactivate Analog Position Setpoint

Function

BOOL **VCS_DeactivateAnalogPositionSetpoint** (HANDLE KeyHandle, WORD NodeId, WORD AnalogInputNumber, DWORD *pErrorCode)

Description

„VCS_DeactivateAnalogPositionSetpoint“ disable the selected analog input for analog position setpoint.

Parameters

| | | |
|-------------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| AnalogInputNumber | WORD | Number of the used analog input |
| | | Object: 0x207B-01 or 0x207B-02 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.9.4.3 Enable Analog Position Setpoint

Function

BOOL **VCS_EnableAnalogPositionSetpoint** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

„VCS_EnableAnalogPositionSetpoint“ enable the execution mask for analog position setpoint.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.9.4.4 Disable Analog Position Setpoint

Function

BOOL **VCS_DisableAnalogPositionSetpoint** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

„VCS_DisableAnalogPositionSetpoint“ disable the execution mask for analog position setpoint.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.10 Velocity Mode

This group defines all required functions for velocity mode:

6.10.1 Activate Velocity Mode

Function

BOOL **VCS_ActivateVelocityMode** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

With the function „VCS_ActivateVelocityMode“ the device changes to velocity mode (VM).

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.10.2 Set Velocity Must

Function

BOOL **VCS_SetVelocityMust** (HANDLE KeyHandle, WORD NodeId, long VelocityMust, DWORD *pErrorCode)

Description

The function „VCS_SetVelocityMust“ sets the velocity demand value.

Parameters

| | | | |
|--------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| VelocityMust | long | Velocity demand value | Object: 0x206B-00 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.10.3 Get Velocity Must

Function

BOOL **VCS_GetVelocityMust**(HANDLE KeyHandle, WORD NodeId, long *pVelocityMust, DWORD *pErrorCode)

Description

The function „VCS_GetVelocityMust“ returns the velocity demand value.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|---------------|--------|---|-------------------|
| pVelocityMust | long* | Velocity demand value | Object: 0x206B-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.10.4 Advanced Functions

6.10.4.1 Activate Analog Velocity Setpoint

Function

BOOL **VCS_ActivateAnalogVelocitySetpoint**(HANDLE KeyHandle, WORD NodeId, WORD AnalogInputNumber, float Scaling, long Offset, DWORD *pErrorCode)

Description

„VCS_ActivateAnalogVelocitySetpoint“ configures the selected analog input for analog velocity setpoint.

Parameters

| | | | |
|-------------------|--------|--|--------------------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| AnalogInputNumber | WORD | Number of the used analog input | Object: 0x207B-01 or 0x207B-02 |
| Scaling | float | The scaling factor for analog velocity setpoint functionality | Object: 0x2302-01 |
| Offset | long | Offset for analog velocity setpoint functionality | Object: 0x2302-02 |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.10.4.2 Deactivate Analog Velocity Setpoint

Function

BOOL **VCS_DeactivateAnalogVelocitySetpoint** (HANDLE KeyHandle, WORD NodeId, WORD AnalogInputNumber, DWORD *pErrorCode)

Description

„VCS_DeactivateAnalogVelocitySetpoint“ disable the selected analog input for analog velocity setpoint.

Parameters

| | | | |
|-------------------|--------|--|--------------------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| AnalogInputNumber | WORD | Number of the used analog input | Object: 0x207B-01 or 0x207B-02 |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.10.4.3 Enable Analog Velocity Setpoint

Function

BOOL **VCS_EnableAnalogVelocitySetpoint** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

„VCS_EnableAnalogVelocitySetpoint“ enable the execution mask for analog velocity setpoint.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.10.4.4 Disable Analog Velocity Setpoint

Function

BOOL **VCS_DisableAnalogVelocitySetpoint** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

„VCS_DisableAnalogVelocitySetpoint“ disable the execution mask for analog velocity setpoint.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.11 Current Mode

This group defines all required functions for current mode:

6.11.1 Activate Current Mode

Function

BOOL **VCS_ActivateCurrentMode** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

Function „VCS_ActivateCurrentMode“ changes operational mode to current mode.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.11.2 Get Current Must

Function

BOOL **VCS_GetCurrentMust** (HANDLE KeyHandle, WORD NodeId, short *pCurrentMust, DWORD *pErrorCode)

Description

With function „VCS_GetCurrentMust“ it is possible to read the current mode demand value.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|---------------------|--------|---|-------------------|
| pCurrentMust | short* | Current mode demand value | Object: 0x2030-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.11.3 Set Current Must

Function

BOOL **VCS_SetCurrentMust** (HANDLE KeyHandle, WORD NodeId, short CurrentMust, DWORD *pErrorCode)

Description

With function „VCS_SetCurrentMust“ it is possible to write current mode demand value.

Parameters

| | | | |
|-------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| CurrentMust | short | Current mode demand value | Object: 0x2030-00 |

Return Parameters

| | | | |
|---------------------|--------|---|--|
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.11.4 Advanced Functions

6.11.4.1 Activate Analog Current Setpoint

Function

BOOL **VCS_ActivateAnalogCurrentSetpoint** (HANDLE KeyHandle, WORD NodeId, WORD AnalogInputNumber, float Scaling, short Offset, DWORD *pErrorCode)

Description

„VCS_ActivateAnalogCurrentSetpoint“ configures the selected analog input for analog current setpoint.

Parameters

| | | | |
|-------------------|--------|--|--------------------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| AnalogInputNumber | WORD | Number of the used analog input | Object: 0x207B-01 or 0x207B-02 |
| Scaling | float | The scaling factor for analog current setpoint functionality | Object: 0x2301-01 |
| Offset | short | Offset for analog current setpoint functionality | Object: 0x2301-02 |

Return Parameters

| | | | |
|---------------------|--------|---|--|
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.11.4.2 Deactivate Analog Current Setpoint

Function

BOOL **VCS_DeactivateAnalogCurrentSetpoint** (HANDLE KeyHandle, WORD NodeId, WORD AnalogInputNumber, DWORD *pErrorCode)

Description

„VCS_DeactivateAnalogCurrentSetpoint“ disable the selected analog input for analog current setpoint.

Parameters

| | | |
|-------------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| AnalogInputNumber | WORD | Number of the used analog input Object: 0x207B-01 or 0x207B-02 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.11.4.3 Enable Analog Current Setpoint

Function

BOOL **VCS_EnableAnalogCurrentSetpoint** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

„VCS_EnableAnalogCurrentSetpoint“ enable the execution mask for analog current setpoint.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.11.4.4 Disable Analog Current Setpoint

Function

BOOL **VCS_DisableAnalogCurrentSetpoint** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

„VCS_DisableAnalogCurrentSetpoint“ disable the execution mask for analog current setpoint.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.12 Master Encoder Mode

6.12.1 Activate Master Encoder Mode

Function

BOOL **VCS_ActivateMasterEncoderMode** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

With the function „VCS_ActivateMasterEncoderMode“ the device changes to master encoder mode (MEM).

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.12.2 Set Master Encoder Parameter**Function**

BOOL **VCS_SetMasterEncoderParameter** (HANDLE KeyHandle, WORD NodeId, WORD ScalingNumerator, WORD ScalingDenominator, BYTE Polarity, DWORD MaxVelocity, DWORD MaxAcceleration, DWORD *pErrorCode)

Description

With function „VCS_SetMasterEncoderParameter“ it is possible to write all parameters for master encoder mode.

Parameters

| | | | |
|--------------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| ScalingNumerator | WORD | Scaling numerator for position calculation | Object: 0x2300-02 |
| ScalingDenominator | WORD | Scaling denominator for position calculation | Object: 0x2300-03 |
| Polarity | BYTE | Polarity of the direction input. 0: Positive 1: Negative | Object: 0x2300-04 |
| MaxVelocity | DWORD | This parameter is the maximal allowed speed during a profiled move. | Object: 0x607F-01 |
| MaxAcceleration | DWORD | Defines the maximal allowed acceleration. | Object: 0x60C5-01 |

6.12.3 Get Master Encoder Parameter**Function**

BOOL **VCS_GetMasterEncoderParameter** (HANDLE KeyHandle, WORD NodeId, WORD* pScalingNumerator, WORD* pScalingDenominator, BYTE* pPolarity, DWORD* pMaxVelocity, DWORD* pMaxAcceleration, DWORD *pErrorCode)

Description

With function „VCS_GetMasterEncoderParameter“ it is possible to read all parameters for master encoder mode.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|---------------------|-------|--|-------------------|
| pScalingNumerator | WORD* | Scaling numerator for position calculation | Object: 0x2300-02 |
| pScalingDenominator | WORD* | Scaling denominator for position calculation | Object: 0x2300-03 |
| pPolarity | BYTE* | Polarity of the direction input. 0: Positive 1: Negative | Object: 0x2300-04 |

| | |
|-----------------------------|----------------------|
| maxon motor | |
| EPOS Positioning Controller | EPOS Command Library |

| | | | |
|------------------|--------|---|-------------------|
| pMaxVelocity | DWORD* | This parameter is the maximal allowed speed during a profiled move. | Object: 0x607F-01 |
| pMaxAcceleration | DWORD* | Defines the maximal allowed acceleration. | Object: 0x60C5-01 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.13 Step Direction Mode

6.13.1 Activate Step Direction Mode

Function

BOOL **VCS_ActivateStepDirectionMode** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

With the function „VCS_ActivateStepDirectionMode“ the device changes to step direction mode (SDM).

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | |
|-------------------|--------|---|
| Return Parameters | | |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.13.2 Set Step Direction Parameter

Function

BOOL **VCS_SetStepDirectionParameter** (HANDLE KeyHandle, WORD NodeId, WORD ScalingNumerator, WORD ScalingDenominator, BYTE Polarity, DWORD MaxVelocity, DWORD MaxAcceleration, DWORD *pErrorCode)

Description

With function „VCS_SetStepDirectionParameter“ it is possible to write all parameters for step direction mode.

Parameters

| | | | |
|--------------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| ScalingNumerator | WORD | Scaling numerator for position calculation | Object: 0x2300-02 |
| ScalingDenominator | WORD | Scaling denominator for position calculation | Object: 0x2300-03 |
| Polarity | BYTE | Polarity of the direction input. 0: Positive 1: Negative | Object: 0x2300-04 |
| MaxVelocity | DWORD | This parameter is the maximal allowed speed during a profiled move. | Object: 0x607F-01 |
| MaxAcceleration | DWORD | Defines the maximal allowed acceleration. | Object: 0x60C5-01 |

6.13.3 Get Step Direction Parameter

Function

BOOL **VCS_GetStepDirectionParameter** (HANDLE KeyHandle, WORD NodeId, WORD* pScalingNumerator, WORD* pScalingDenominator, BYTE* pPolarity, DWORD* pMaxVelocity, DWORD* pMaxAcceleration, DWORD* pErrorCode)

Description

With function „VCS_GetStepDirectionParameter“ it is possible to read all parameters for step direction mode.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|---------------------|--------|---|-------------------|
| pScalingNumerator | WORD* | Scaling numerator for position calculation | Object: 0x2300-02 |
| pScalingDenominator | WORD* | Scaling denominator for position calculation | Object: 0x2300-03 |
| pPolarity | BYTE* | Polarity of the direction input. 0: Positive 1: Negative | Object: 0x2300-04 |
| pMaxVelocity | DWORD* | This parameter is the maximal allowed speed during a profiled move. | Object: 0x607F-01 |
| pMaxAcceleration | DWORD* | Defines the maximal allowed acceleration. | Object: 0x60C5-01 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.14 Inputs Outputs

This group defines all required functions for inputs and outputs information:

Remark

More information about the inputs from the other devices are available in the “Firmware Specification” documents!

6.14.1 Get All Digital Inputs

Function

BOOL **VCS_GetAllDigitalInputs** (HANDLE KeyHandle, WORD NodeId, WORD* pInputs, DWORD* pErrorCode)

Description

„VCS_GetAllDigitalInputs“ returns state of all digital inputs.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|---------------------|--------|--|-------------------|
| pInputs | WORD* | Display the state of the digital input functionalities. If a bit is read as “1”, the functionality is activated. | Object: 0x2071-01 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.14.2 Get All Digital Outputs

Function

BOOL **VCS_GetAllDigitalOutputs** (HANDLE KeyHandle, WORD NodeId, WORD *pOutputs, DWORD *pErrorCode)

Description

„VCS_GetAllDigitalOutputs” returns state of all digital outputs.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|--------------|--------|---|-------------------|
| pOutputs | WORD* | State of all digital outputs. If a bit is read as “1”, the state activated. | Object: 0x2078-01 |
| pErrorCode | DWORD* | Error information about the executed function | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.14.3 Set All Digital Outputs

Function

BOOL **VCS_SetAllDigitalOutputs** (HANDLE KeyHandle, WORD NodeId, WORD Outputs, DWORD *pErrorCode)

Description

„VCS_SetAllDigitalOutputs” set state of all digital outputs.

Parameters

| Parameters | | | |
|------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| Outputs | WORD | State of all digital outputs. If a bit is written as “1”, the state is activated. | Object: 0x2078-01 |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.14.4 Get Analog Input

Function

BOOL **VCS_GetAnalogInput** (HANDLE KeyHandle, WORD NodeId, WORD InputNumber, WORD *pAnalogValue, DWORD *pErrorCode)

Description

„VCS_GetAnalogInput” returns the value from an analog input.

Parameters

| | | |
|-------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| InputNumber | WORD | Analog input number |

Return Parameters

| | | | |
|--------------|--------|---|-------------------|
| pAnalogValue | WORD* | Analog value from input | Object: 0x207C-0? |
| pErrorCode | DWORD* | Error information about the executed function | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.14.5 Set Analog Output

Function

BOOL **VCS_SetAnalogOutput** (HANDLE KeyHandle, WORD NodeId, WORD OutputNumber, WORD AnalogValue, DWORD *pErrorCode)

Description

„VCS_SetAnalogOutput“ set the voltage level of an analog output.

Parameters

| | | |
|--------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| OutputNumber | WORD | Analog output number |
| pAnalogValue | WORD* | Analog value for output |
| | | Object: 0x207E-00 |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.14.6 Position Compare

6.14.6.1 Set Position Compare Parameter

Function

BOOL **VCS_SetPositionCompareParameter** (HANDLE KeyHandle, WORD NodeId, BYTE OperationalMode, BYTE IntervalMode, BYTE DirectionDependency, WORD IntervalWidth, WORD IntervalRepetitions, WORD PulseWidth, DWORD* pErrorCode)

Description

„VCS_SetPositionCompareParameter“ write all parameters for position compare.

Parameters

| Parameters | | | |
|---------------------|--------|--|----------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| OperationalMode | BYTE | Used operational mode in position sequence mode: (see Table 11) | Object: 0x207A-01 |
| IntervalMode | BYTE | Used interval mode in position sequence mode: (see Table 12) | |
| DirectionDependency | BYTE | Used direction dependency in position sequence mode: (see Table 13) | |
| IntervalWidth | WORD | This object holds the width of the position intervals | Object: 0x207A-03 |
| IntervalRepetitions | WORD | This object allows to configure the number of position intervals to be considered by position compare | Object: 0x207A-04 |
| PulseWidth | WORD | This object configures the pulse width of the trigger output | Object: 0x207A-05 |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

OperationalMode

| Description | Value | Constant name |
|------------------------|-------|----------------------------|
| Single position mode | 0 | PCO_SINGLE_POSITION_MODE |
| Position sequence mode | 1 | PCO_POSITION_SEQUENCE_MODE |

Table 11: Position Compare - Operational mode

IntervalMode

| Description | Value | Constant name |
|---|-------|----------------------------|
| Interval positions are set in negative direction relative to the position compare reference position | 0 | PCI_NEGATIVE_DIR_TO_REFPOS |
| Interval positions are set in positive direction relative to the position compare reference position | 1 | PCI_POSITIVE_DIR_TO_REFPOS |
| Interval positions are set in positive and negative direction relative to the position compare reference position | 2 | PCI_BOTH_DIR_TO_REFPOS |

Table 12: Position Compare - Interval mode

DirectionDependency

| Description | Value | Constant name |
|---|-------|------------------------------|
| Positions are compared only if actual motor direction is negative | 0 | PCD_MOTOR_DIRECTION_NEGATIVE |
| Positions are compared only if actual motor direction is positive | 1 | PCD_MOTOR_DIRECTION_POSITIVE |
| Positions are compared regardless of the actual motor direction | 2 | PCD_MOTOR_DIRECTION_BOTH |

Table 13: Position Compare - Direction Dependency

6.14.6.2 Get Position Compare Parameter**Function**

BOOL **VCS_GetPositionCompareParameter** (HANDLE KeyHandle, WORD NodeId, BYTE* pOperationalMode, BYTE* pIntervalMode, BYTE* pDirectionDependency, WORD* pIntervalWidth, WORD* pIntervalRepetitions, WORD* pPulseWidth, DWORD* pErrorCode)

Description

„VCS_GetPositionCompareParameter“ read all parameters for position compare.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|----------------------|--------|---|----------------------|
| pOperationalMode | BYTE* | Used operational mode in position sequence mode: (see Table 11) | Object: 0x207A-01 |
| pIntervalMode | BYTE* | Used interval mode in position sequence mode: (see Table 12) | |
| pDirectionDependency | BYTE* | Used direction dependency in position sequence mode: (see Table 13) | |
| pIntervalWidth | WORD* | This object holds the width of the position intervals | Object: 0x207A-03 |
| pIntervalRepetitions | WORD* | This object allows to configure the number of position intervals to be considered by position compare | Object: 0x207A-04 |
| pPulseWidth | WORD* | This object configures the pulse width of the trigger output | Object: 0x207A-05 |
| pErrorCode | DWORD* | Error information about the executed function | |
| Return Value | | | |
| | BOOL | Nonzero if successful; otherwise 0 | |

6.14.6.3 Activate Position Compare**Function**

BOOL **VCS_ActivatePositionCompare** (HANDLE KeyHandle, WORD NodeId, WORD DigitalOutputNumber, BOOL Polarity, DWORD* pErrorCode)

Description

Function „VCS_ActivatePositionCompare“ enables the output to position compare method.

Parameters

| | | | |
|---------------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| DigitalOutputNumber | WORD | Selected digital output for position compare | Object: 0x2079 |
| Polarity | BOOL | Polarity of the selected output | Object: 0x2078-03 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.14.6.4 Deactivate Position Compare**Function**

BOOL **VCS_DeactivatePositionCompare** (HANDLE KeyHandle, WORD NodeId, WORD DigitalOutputNumber, DWORD* pErrorCode)

Description

Function „VCS_DeactivatePositionCompare“ disables the output to position compare method.

Parameters

| | | | |
|---------------------|--------|--|----------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| DigitalOutputNumber | WORD | Selected digital output for position compare | Object: 0x2079 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.14.6.5 Enable Position Compare**Function**

BOOL **VCS_EnablePositionCompare** (HANDLE KeyHandle, WORD NodeId, DWORD* pErrorCode)

Description

Function „VCS_EnablePositionCompare“ enables the output mask for position compare method.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.14.6.6 Disable Position Compare

Function

BOOL **VCS_DisablePositionCompare** (HANDLE KeyHandle, WORD NodeId, DWORD* pErrorCode)

Description

Function „VCS_DisablePositionCompare“ disables the output mask from position compare method.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.14.6.7 Set Position Compare Reference Position

Function

BOOL **VCS_SetPositionCompareReferencePosition** (HANDLE KeyHandle, WORD NodeId, long ReferencePosition, DWORD* pErrorCode)

Description

„VCS_SetPositionCompareReferencePosition“ writes the reference position for position compare method.

Parameters

| | | |
|-------------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| ReferencePosition | long | This object holds the position that is compared with the position actual value |
| | | Object: 0x207A-02 |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.14.7 Position Marker

6.14.7.1 Set Position Marker Parameter

Function

BOOL **VCS_SetPositionMarkerParameter** (HANDLE KeyHandle, WORD NodeId, BYTE PositionMarkerEdgeType, BYTE PositionMarkerMode, DWORD* pErrorCode)

Description

„VCS_SetPositionMarkerParameter“ write all parameters for position marker method.

Parameters

| | | |
|------------------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| PositionMarkerEdgeType | BYTE | The value of this object defines on what kind of edge the position should be captured: (see Table 14) |
| | | Object: 0x2074-02 |
| PositionMarkerMode | BYTE | This object defines the position marker-capturing mode: |
| | | Object: 0x2074-03 |

| | | |
|--------------------------|------------------------------------|---|
| | | (see Table 15) |
| Return Parameters | | |
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | | |
| BOOL | Nonzero if successful; otherwise 0 | |

PositionMarkerEdgeType

| Description | Value | Constant name |
|--------------|-------|------------------|
| Both edges | 0 | PET_BOTH_EDGES |
| Rising edge | 1 | PET_RISING_EDGE |
| Falling edge | 2 | PET_FALLING_EDGE |

Table 14: Position marker edge types

PositionMarkerMode

| Description | Value | Constant name |
|-------------|-------|---------------|
| Continuous | 0 | PM_CONTINUOUS |
| Single | 1 | PM_SINGLE |
| Multiple | 2 | PM_MULTIPLE |

Table 15: Position marker modes

6.14.7.2 Get Position Marker Parameter

Function

BOOL **VCS_GetPositionMarkerParameter** (HANDLE KeyHandle, WORD NodeId, BYTE* pPositionMarkerEdgeType, BYTE* pPositionMarkerMode, DWORD* pErrorCode)

Description

„VCS_GetPositionMarkerParameter“ read all parameters for position marker method.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|-------------------------|------------------------------------|--|----------------------|
| pPositionMarkerEdgeType | BYTE* | The value of this object defines on what kind of edge the position should be captured: (see Table 14) | Object: 0x2074-02 |
| pPositionMarkerMode | BYTE* | This object defines the position marker capturing mode: (see Table 15) | Object: 0x2074-03 |
| pErrorCode | DWORD* | Error information about the executed function | |
| Return Value | | | |
| BOOL | Nonzero if successful; otherwise 0 | | |

6.14.7.3 Activate Position Marker

Function

BOOL **VCS_ActivatePositionMarker** (HANDLE KeyHandle, WORD NodeId, WORD DigitalInputNumber, BOOL Polarity, DWORD* pErrorCode)

Description

Function „VCS_ActivatePositionMarker“ enables the digital input to position marker method.

| | |
|-----------------------------|----------------------|
| maxon motor | |
| EPOS Positioning Controller | EPOS Command Library |

Parameters

| | | | |
|--------------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| DigitalInputNumber | WORD | Selected digital input for position marker | Object: 0x2070 |
| Polarity | BOOL | Polarity of the selected input | Object: 0x2071-03 |

Return Parameters

| | | |
|-------------------|--------|---|
| Return Parameters | | |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.14.7.4 Deactivate Position Marker

Function

BOOL **VCS_DeactivatePositionMarker** (HANDLE KeyHandle, WORD NodeId, WORD DigitalInputNumber, DWORD* pErrorCode)

Description

Function „VCS_DeactivatePositionMarker“ disables the digital input to position marker method.

Parameters

| | | | |
|--------------------|--------|--|----------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| DigitalInputNumber | WORD | Selected digital input for position marker | Object: 0x2070 |

Return Parameters

| | | |
|-------------------|--------|---|
| Return Parameters | | |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

6.14.7.5 Read Position Marker Counter

Function

BOOL **VCS_ReadPositionMarkerCounter** (HANDLE KeyHandle, WORD NodeId, WORD *pCount, DWORD *pErrorCode)

Description

„VCS_ReadPositionMarkerCounter“ returns the number of the detected edges.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | | |
|--------------|--------|--|-------------------|
| pCount | WORD* | This object counts the number of the detected edges. | Object: 0x2074-04 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.14.7.6 Read Position Marker Captured Position

Function

BOOL **VCS_ReadPositionMarkerCapturedPosition** (HANDLE KeyHandle, WORD NodeId, WORD CounterIndex, long* pCapturedPosition, DWORD *pErrorCode)

Description

„VCS_ReadPositionMarkerCapturedPosition“ returns the last captured position or the position from the position marker history.

Parameters

| | | | |
|--------------|--------|--|-------------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| CounterIndex | WORD | 0: Read position marker captured position | Object: 0x2074-01 |
| | | 1 or 2: Read position marker history | Object: 0x2074-05 or 06 |

Return Parameters

| | | | |
|-------------------|--------|---|-----------------------------------|
| pCapturedPosition | long* | This object contains the captured position or the position marker history | Object: 0x2074-01 or 0x2074-05/06 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

6.14.7.7 Reset Position Marker Counter

Function

BOOL **VCS_ResetPositionMarkerCounter** (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode)

Description

„VCS_ResetPositionMarkerCounter“ clears the counter and the captured positions by writing zero to object position marker counter (0x2074-04).

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

7 Data Recording Functions

7.1 Data Recorder Setup

7.1.1 Set Recorder Parameter

Function

BOOL **VCS_SetRecorderParameter** (HANDLE KeyHandle, WORD NodeId, WORD SamplingPeriod, WORD NbOfPrecedingSamples, WORD PulseWidth, DWORD* pErrorCode)

Description

„VCS_SetRecorderParameter“ writes parameters for data recorder .

Parameters

| | | | |
|----------------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| SamplingPeriod | WORD | Sampling Period as a multiple of the current regulator cycle (n-times 0.1ms) | Object: 0x2012-00 |
| NbOfPrecedingSamples | WORD | Number of preceding samples (data history). | Object: 0x2013-00 |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

7.1.2 Get Recorder Parameter

Function

BOOL **VCS_GetRecorderParameter** (HANDLE KeyHandle, WORD NodeId, WORD* pSamplingPeriod, WORD* pNbOfPrecedingSamples, WORD PulseWidth, DWORD* pErrorCode)

Description

„VCS_GetRecorderParameter“ reads parameters for data recorder .

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | | |
|-----------------------|--------|--|-------------------|
| pSamplingPeriod | WORD* | Sampling Period as a multiple of the current regulator cycle (n-times 0.1ms) | Object: 0x2012-00 |
| pNbOfPrecedingSamples | WORD* | Number of preceding samples (data history). | Object: 0x2013-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

7.1.3 Enable Trigger

Function

BOOL **VCS_EnableTrigger** (HANDLE KeyHandle, WORD NodeId, BYTE TriggerType, DWORD* pErrorCode)

Description

„VCS_EnableTrigger“ connects trigger(-s) for data recording.

Parameters

| | | | |
|-------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| TriggerType | BYTE | Configuration of Auto Trigger functions. If a bit is write as one the trigger is activated: (see Table 16) It is possible to activate more than one trigger at the same time. | Object: 0x2011-00 |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Trigger Types

| Description | Value | Constant name |
|------------------------|-------|---------------------------|
| Trigger movement start | 1 | DR_MOVEMENT_START_TRIGGER |
| Error trigger | 2 | DR_ERROR_TRIGGER |
| Digital input trigger | 4 | DR_DIGITAL_INPUT_TRIGGER |
| Trigger movement end | 8 | DR_MOVEMENT_END_TRIGGER |

Table 16: Data recorder trigger types

7.1.4 Disable all Triggers

Function

BOOL **VCS_DisableAllTrigger** (HANDLE KeyHandle, WORD NodeId, DWORD* pErrorCode)

Description

„VCS_DisableAllTrigger“ sets data recorder configuration (0x2011-00) for triggers to zero.

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

7.1.5 Activate Channel

Function

BOOL **VCS_ActivateChannel** (HANDLE KeyHandle, WORD NodeId, BYTE ChannelNumber, WORD ObjectIndex, BYTE ObjectSubIndex, BYTE ObjectSize, DWORD* pErrorCode)

Description

„VCS_ActivateChannel“ connects object for data recording.

Start with channel number one! For every activated channel the number of sampling variables (Object 0x2014-00) will be incremented

Parameters

| | | | |
|----------------|--------|--|------------------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| ChannelNumber | BYTE | Channel number [1 ... 4] | |
| ObjectIndex | WORD | Object index for data recording | Object: 0x2015-ChannelNumber |
| ObjectSubIndex | BYTE | Object sub index for data recording | Object: 0x2016-ChannelNumber |
| ObjectSize | BYTE | Object size in bytes for data recording | |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

7.1.6 Deactivate all Channels

Function

BOOL **VCS_DeactivateAllChannel** (HANDLE KeyHandle, WORD NodeId, DWORD* pErrorCode)

Description

„VCS_DeactivateAllChannel“ sets all data recording objects to zero (0x2014, 0x2015 and 0x2016).

Parameters

| | | | |
|-----------|--------|--|--|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |

Return Parameters

| | | |
|--------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

7.2 Data Recorder Status

Functions are not available in the Linux library!

7.2.1 Start Recorder

Function

BOOL **VCS_StartRecorder** (HANDLE KeyHandle, WORD NodeId, DWORD* pErrorCode)

Description

„VCS_StartRecorder“ starts the data recording.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Additional informations

Function is not available in the Linux library

7.2.2 Stop Recorder

Function

BOOL **VCS_StopRecorder** (HANDLE KeyHandle, WORD NodeId, DWORD* pErrorCode)

Description

„VCS_StopRecorder“ stops the data recording.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Additional informations

Function is not available in the Linux library

7.2.3 Force Trigger

Function

BOOL **VCS_ForceTrigger** (HANDLE KeyHandle, WORD NodeId, DWORD* pErrorCode)

Description

„VCS_ForceTrigger“ forces the data recording triggers.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Additional informations

Function is not available in the Linux library

7.2.4 Is Recorder Running

Function

BOOL **VCS_IsRecorderRunning** (HANDLE KeyHandle, WORD NodeId, BOOL* pRunning, DWORD* pErrorCode)

Description

„VCS_IsRecorderRunning“ returns data recorder status running.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|--------------|--------|--|-------------------------------|
| pRunning | BOOL | 1: Data recorder running 0: Data recorder stopped | Object: 0x2017-00, (bit 0) |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

Additional informations

Function is not available in the Linux library

7.2.5 Is Recorder Triggered

Function

BOOL **VCS_IsRecorderTriggered** (HANDLE KeyHandle, WORD NodeId, BOOL* pTriggered, DWORD* pErrorCode)

Description

„VCS_IsRecorderTriggered“ returns data recorder status triggered.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|--------------|--------|--|------------------------------|
| pTriggered | BOOL | 1: Data recorder triggered 0: Data recorder not triggered | Object: 0x2017-00 (bit 1) |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

Additional informations

Function is not available in the Linux library

7.3 Data Recorder Data

7.3.1 Read Channel Vector Size

Function

BOOL **VCS_ReadChannelVectorSize**(HANDLE KeyHandle, WORD NodeId, DWORD* pVectorSize, DWORD* pErrorCode)

Description

„VCS_ReadChannelVectorSize” returns the maximal number of samples per variable. This parameter is dynamically calculated by the data recorder.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | | |
|--------------|--------|---|-------------------|
| pVectorSize | DWORD | Maximal number of samples per variable. | Object: 0x2018-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

Additional informations

Function is not available in the Linux library

7.3.2 Read Channel Data Vector

Function

BOOL **VCS_ReadChannelDataVector**(HANDLE KeyHandle, WORD NodeId, BYTE ChannelNumber, BYTE* pDataVector, DWORD VectorSize, DWORD* pErrorCode)

Description

„VCS_ReadChannelDataVector” returns the data points of a selected channel.

Parameters

| | | | |
|---------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| ChannelNumber | BYTE | Selected channel | |
| VectorSize | DWORD | Size of data points | Object: 0x2018-00 |

Return Parameters

| | | | |
|--------------|--------|---|-------------------|
| pDataVector | BYTE | Data points of selected channel | Object: 0x201B-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

Additional informations

Function is not available in the Linux library

7.3.3 Show Channel Data Dialog

Function

BOOL **VCS_ShowChannelDataDlg**(HANDLE KeyHandle, WORD NodeId, DWORD* pErrorCode)

Description

„VCS_ShowChannelDataDlg” opens the dialog to show the data channel(-s).

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Additional informations

Function is not available in the Linux library

7.3.4 Export Channel Data to File

Function

BOOL **VCS_ExportChannelDataToFile** (HANDLE KeyHandle, WORD NodeId, char* FileName, DWORD* pErrorCode)

Description

„VCS_ExportChannelDataToFile” saves data point in a file.

Parameters

| | | |
|-----------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| FileName | char* | Path and file name for save data points. File endings: *.csv, *.txt or *.rda. |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Additional informations

Function is not available in the Linux library

7.4 Advanced Functions

7.4.1 Read Data Buffer

Function

BOOL **VCS_ReadDataBuffer**(HANDLE KeyHandle, WORD NodeId, BYTE* pDataBuffer, DWORD BufferSizeToRead, DWORD* pBufferSizeRead, WORD* pVectorStartOffset, WORD* pMaxNbOfSamples, WORD* pNbOfRecordedSamples, DWORD* pErrorCode)

Description

„VCS_ReadDataBuffer“ returns the buffer data points.

Parameters

| | | |
|------------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| BufferSizeToRead | DWORD | Buffer size |

Return Parameters

| | | | |
|----------------------|--------|---|-------------------|
| pDataBuffer | BYTE* | Data points | Object: 0x201B-00 |
| pBufferSizeRead | DWORD* | Size of read data buffer | |
| pVectorStartOffset | WORD* | Offset to the start of the recorded data vector within the ring buffer. | Object: 0x201A-00 |
| pMaxNbOfSamples | WORD* | Maximal number of samples per variable. | Object: 0x2018-00 |
| pNbOfRecordedSamples | WORD* | Number of recorded samples. | Object: 0x2019-00 |
| pErrorCode | DWORD* | Error information about the executed function | |
| | | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 | |

7.4.2 Extract Channel Data Vector

Function

BOOL **VCS_ExtractChannelDataVector**(HANDLE KeyHandle, WORD NodeId, BYTE ChannelNumber, BYTE* pDataBuffer, DWORD BufferSize, BYTE* pDataVector, DWORD VectorSize, WORD VectorStartOffset, WORD MaxNbOfSamples, WORD NbOfRecordedSamples, DWORD* pErrorCode)

Description

„VCS_ExtractChannelDataVector“ returns the vector of one data channel.

Parameters

| Parameters | | | |
|---------------------|--------|--|-------------------|
| KeyHandle | HANDLE | Handle for port access | |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). | |
| ChannelNumber | BYTE | Selected channel | |
| pDataBuffer | BYTE | Data points | Object: 0x201B-00 |
| BufferSize | DWORD | Buffer size | |
| VectorSize | DWORD | Vector size | |
| VectorStartOffset | WORD | Offset to the start of the recorded data vector within the ring buffer. | Object: 0x201A-00 |
| MaxNbOfSamples | WORD | Maximal number of samples per variable. | Object: 0x2018-00 |
| NbOfRecordedSamples | WORD | Number of recorded samples. | Object: 0x2019-00 |

Return Parameters

| | | |
|--------------|--------|---|
| pDataVector | BYTE* | Data points of the channel |
| pErrorCode | DWORD* | Error information about the executed function |
| | | |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

8 Low Layer Functions

8.1 Send CAN Frame

Function

BOOL **VCS_SendCANFrame** (HANDLE KeyHandle, WORD CobID, WORD Length, void *pData, DWORD *pErrorCode)

Description

„VCS_SendCANFrame“ sends a general CAN frame to the CAN bus.

Parameters

| | | |
|-----------|--------|-----------------------------|
| KeyHandle | HANDLE | Handle for port access |
| CobID | WORD | CAN frame 11-bit identifier |
| Length | WORD | CAN frame data length |
| pData | void* | CAN frame data |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

8.2 Read CAN Frame

Function

BOOL **VCS_ReadCANFrame** (HANDLE KeyHandle, WORD CobID, WORD Length, void *pData, DWORD Timeout, DWORD *p ErrorCode)

Description

„VCS_ReadCANFrame“ reads a general CAN frame from the CAN bus.

Parameters

| | | |
|-----------|--------|-----------------------------|
| KeyHandle | HANDLE | Handle for port access |
| CobID | WORD | CAN frame 11-bit identifier |
| Length | WORD | CAN frame data length |
| Timeout | WORD | Maximum waiting period |

Return Parameters

| | | |
|---------------------|--------|---|
| pData | void* | CAN frame data |
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

8.3 Request CAN Frame

Function

BOOL **VCS_RequestCANFrame** (HANDLE KeyHandle, WORD CobID, WORD Length, void *pData, DWORD *pErrorCode)

Description

„VCS_RequestCANFrame“ requests a general CAN frame from the CAN bus using Remote Transmit Request (RTR).

Parameters

| | | |
|-----------|--------|-----------------------------|
| KeyHandle | HANDLE | Handle for port access |
| CobID | WORD | CAN frame 11-bit identifier |
| Length | WORD | CAN frame data length |

Return Parameters

| | | |
|---------------------|--------|---|
| pData | void* | CAN frame data |
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

8.4 Send NMT Service

Function

BOOL **VCS_SendNMTService** (HANDLE KeyHandle, WORD NodeId, WORD CommandSpecifier, DWORD *pErrorCode)

Description

The function „VCS_SendNMTService” is used to send a NMT protocol from a master to a slave. It is a command without acknowledge.

Parameters

| | | |
|------------------|--------|--|
| KeyHandle | HANDLE | Handle for port access |
| NodeId | WORD | Node ID of the addressed device. ID is given from hardware switches or the layer setting services (LSS). |
| CommandSpecifier | WORD | NMT service (see Table 17) |

Return Parameters

| | | |
|---------------------|--------|---|
| pErrorCode | DWORD* | Error information about the executed function |
| Return Value | BOOL | Nonzero if successful; otherwise 0 |

Command Specifier

| Description | Value | Constant name |
|-----------------------|-------|---------------------------|
| Start remote node | 1 | NCS_START_REMOTE_NODE |
| Stop remote node | 2 | NCS_STOP_REMOTE_NODE |
| Enter pre-operational | 128 | NCS_ENTER_PRE_OPERATIONAL |
| Reset node | 129 | NCS_RESET_NODE |
| Reset communication | 130 | NCS_RESET_COMMUNICATION |

Table 17: Command specifier

9 Error Overview

9.1 Overview Communication Errors

| Abort Code | Name | Error cause |
|-------------|--|---|
| 0x0000 0000 | No Communication Error | The communication was successful |
| 0x0503 0000 | Toggle Error | Toggle bit not alternated |
| 0x0504 0000 | SDO Time Out | SDO protocol timed out |
| 0x0504 0001 | Client/server specifier Error | Client/server command specifier not valid or unknown |
| 0x0504 0002 | Invalid block size | Invalid block size (block mode only) |
| 0x0504 0003 | Invalid sequence | Invalid sequence number (block mode only) |
| 0x0504 0004 | CrcError | CRC error (block mode only) |
| 0x0504 0005 | Out of Memory Error | Out of Memory |
| 0x0601 0000 | Access Error | Unsupported access to an object (e.g. write command to a read-only object) |
| 0x0601 0001 | Write Only | Read command to a write only object |
| 0x0601 0002 | Read Only | Write command to a read only object |
| 0x0602 0000 | Object does not exist Error | The last read or write command had a wrong object index or sub-index |
| 0x0604 0041 | PDO mapping Error | The object cannot be mapped to the PDO |
| 0x0604 0042 | PDO length Error | The number and length of the objects to be mapped would exceed PDO length |
| 0x0604 0043 | General parameter Error | General parameter incompatibility |
| 0x0604 0047 | General Intern Incompatibility Error | General internal incompatibility in device |
| 0x0606 0000 | Hardware Error | Access failed due to an hardware error |
| 0x0607 0010 | Service Parameter Error | Data type does not match, length or service parameter does not match |
| 0x0607 0012 | Service Parameter Error too High Error | Data type does not match, length or service parameter too high |
| 0x0607 0013 | Service Parameter Error too Low Error | Data type does not match, length or service parameter too low |
| 0x0609 0011 | Object Sub-index Error | The last read or write command had a wrong Object sub-index |
| 0x0609 0030 | Value Range Error | Value range of parameter exceeded |
| 0x0609 0031 | Value too High Error | Value of parameter written too high |
| 0x0609 0032 | Value too Low Error | Value of parameter written too low |
| 0x0609 0036 | Maximum less Minimum Error | Maximum value is less than minimum value |
| 0x0800 0000 | General Error | General error |
| 0x0800 0020 | Transfer or store Error | Data cannot be transferred or stored |
| 0x0800 0021 | Local control Error | Data cannot be transferred or stored to application because of local control |
| 0x0800 0022 | Wrong Device State | Data cannot be transferred or stored to application because of the present device state |
| 0x0F00 FFB9 | Error CAN id | Wrong CAN id |
| 0x0F00 FFBC | Error Service Mode | The device is not in service mode |
| 0x0F00 FFBE | Password Error | The password is wrong |
| 0x0F00 FFBF | Illegal Command Error | The RS232 command is illegal (does not exist) |
| 0x0F00 FFC0 | Wrong NMT State Error | The device is in wrong NMT state |

Table 18: Communication errors

9.2 Overview „EPOS Command Library” specified Errors

9.2.1 General Errors

| Code | Name | Error cause |
|-------------|-------------------------|--|
| 0x0000 0000 | No Error | The function was successful |
| 0x1000 0001 | Internal Error | Internal Error |
| 0x1000 0002 | Null Pointer | Null Pointer passed to function |
| 0x1000 0003 | Handle not Valid | Handle passed to function is not valid |
| 0x1000 0004 | Bad Virtual Device Name | Virtual Device name is not valid |
| 0x1000 0005 | Bad Device Name | Device name is not valid |
| 0x1000 0006 | Bad ProtocolStack Name | ProtocolStack name is not valid |
| 0x1000 0007 | Bad Interface Name | Interface name is not valid |
| 0x1000 0008 | Bad Port Name | Port is not valid |
| 0x1000 0009 | Library not Loaded | Could not load external library |
| 0x1000 000A | Executing Command | Command failed |
| 0x1000 000B | Timeout | Timeout occurred during execution |
| 0x1000 000C | Bad Parameter | Bad Parameter passed to function |
| 0x1000 000D | Command Aborted By User | Command aborted by user |

Table 19: „Command DLL” specified general errors

9.2.2 Interface Layer Errors

| Code | Name | Error cause |
|-------------|--------------------|---------------------------------|
| 0x2000 0001 | Opening Interface | Error opening interface |
| 0x2000 0002 | Closing Interface | Error closing interface |
| 0x2000 0003 | Interface not Open | Interface is not open |
| 0x2000 0004 | Opening Port | Error opening port |
| 0x2000 0005 | Closing Port | Error closing port |
| 0x2000 0006 | Port not Open | Port is not open |
| 0x2000 0007 | Reset Port | Error resetting port |
| 0x2000 0008 | Set Port Settings | Error configuring port settings |
| 0x2000 0009 | Set Port Mode | Error configuring port mode |

Table 20: „Command DLL” specified interface layer errors

9.2.3 Interface Layer 'RS232' Errors

| Code | Name | Error cause |
|-------------|------------|--------------------|
| 0x2100 0001 | Write Data | Error writing data |
| 0x2100 0002 | Read Data | Error reading data |

Table 21: „Command DLL” specified interface layer 'RS232' errors

9.2.4 Interface Layer 'CAN' Errors

| Code | Name | Error cause |
|-------------|--------------------|------------------------------|
| 0x2200 0001 | Receive CAN Frame | Error receiving CAN frame |
| 0x2200 0002 | Transmit CAN Frame | Error transmitting CAN frame |

Table 22: „Command DLL” specified interface layer 'CAN' errors

9.2.5 Interface Layer 'USB' Errors

| Code | Name | Error cause |
|-------------|------------|--------------------|
| 0x2300 0001 | Write Data | Error writing data |
| 0x2300 0002 | Read Data | Error reading data |

Table 23: „Command DLL” specified interface layer 'USB' errors

9.2.6 Protocol Layer 'MaxonRS232' Errors

| Code | Name | Error cause |
|-------------|---------------------|-------------------------------|
| 0x3100 0001 | NegAckReceived | Negative acknowledge received |
| 0x3100 0002 | BadCrcReceived | Bad checksum received |
| 0x3100 0003 | BadDataSizeReceived | Bad data size received |

Table 24: „Command DLL” specified protocol ‘MaxonRS232’ errors

9.2.7 Protocol Layer 'CANopen' Errors

| Code | Name | Error cause |
|-------------|------------------------------|--|
| 0x3200 0001 | SdoReceiveFrameNotReceived | CAN frame of SDO protocol not received |
| 0x3200 0002 | RequestedCanFrameNotReceived | Requested CAN frame not received |
| 0x3200 0003 | CanFrameNotReceived | Can frame not received |

Table 25: „Command DLL” specified protocol ‘CANopen’ errors

9.2.8 Protocol Layer 'USB' Errors

| Code | Name | Error cause |
|-------------|---------------------|------------------------|
| 0x3300 0001 | Stuffing | Failed Stuffing Data |
| 0x3300 0002 | Destuffing | Failed Destuffing Data |
| 0x3300 0003 | BadCrcReceived | Bad CRC received |
| 0x3300 0004 | BadDataSizeReceived | Bad Data received |

Table 26: „Command DLL” specified protocol ‘USB’ errors

10 Version History

| Date | DLL Version | Documentation | Description |
|------------|-------------|------------------------|---|
| 11.11.2003 | 1.00 | Edition November 2003 | <ul style="list-style-type: none"> First library version |
| 01.12.2003 | 1.01 | Edition December 2003 | <ul style="list-style-type: none"> All selection functions have been changed: VCS_GetBaudrateSelection(..), VCS_GetDeviceName(..), VCS_GetDeviceNameSelection(..), VCS_GetDriverInfo(..), VCS_GetInterfaceName(..), VCS_GetInterfaceNameSelection(..), VCS_GetPortName(..), VCS_GetPortNameSelection(..), VCS_GetProtocolStackModeSelection(..), VCS_GetProtocolStackName(..), VCS_GetProtocolStackNameSelection(..) |
| 05.01.2004 | 1.02 | Edition January 2004 | <ul style="list-style-type: none"> Insert IXXAT details |
| 06.04.2004 | 2.0.0.0 | Edition April 2004 | <ul style="list-style-type: none"> New functions documented: VCS_CloseAllDevices(..), VCS_DigitalInputConfiguration(..), VCS_DigitalOutputConfiguration(..), VCS_GetAllDigitalInputs(..), VCS_GetAllDigitalOutputs(..), VCS_GetAnalogInput(..), VCS_SetAllDigitalOutputs(..), VCS_SendNMTService(..), VCS_OpenDeviceDlg(..) All this functions have been changed: VCS_GetBaudrateSelection(..), VCS_FindHome(..), VCS_GetHomingParameter(..), VCS_SetHomingParameter(..), VCS_MoveToPosition(..), VCS_GetOperationMode(..), VCS_SetOperationMode(..), VCS_GetObject(..), VCS_SetObject(..) All this functions have been deleted: VCS_GetProtocolStackMode(..), VCS_GetProtocolStackModeSelection(..) |
| 16.07.2004 | 2.0.3.0 | Edition July 2004 | <ul style="list-style-type: none"> Error correction documentation Additional information about error codes |
| 01.03.2005 | 3.0.0.0 | Edition March 2005 | <ul style="list-style-type: none"> Insert from Vector CAN cards details |
| 01.10.2005 | 4.0.0.0 | Edition October 2005 | <ul style="list-style-type: none"> Error correction documentation |
| 03.02.2006 | 4.0.0.0 | Edition February 2006 | <ul style="list-style-type: none"> Additional information about error codes |
| 12.04.2006 | 4.1.0.0 | Edition April 2006 | <ul style="list-style-type: none"> New error codes |
| 12.04.2006 | 4.1.1.0 | Edition April 2006 | <ul style="list-style-type: none"> VCS_SendCANFrame bug fixed |
| 11.10.2006 | 4.2.0.0 | Edition October 2006 | <ul style="list-style-type: none"> New function: VCS_GetErrorInfo(..) |
| 16.10.2006 | 4.2.1.0 | Edition October 2006 | <ul style="list-style-type: none"> VCS_GetDriverInfo, VCS_SetHomingParameter bug fixed |
| 01.02.2007 | 4.3.0.0 | Edition January 2007 | <ul style="list-style-type: none"> Support for National Instruments Interfaces |
| 10.08.2007 | 4.4.0.0 | Edition August 2007 | <ul style="list-style-type: none"> Support for IXXAT VCI V3 |
| 01.05.2008 | 4.5.0.0 | Edition April 2008 | <ul style="list-style-type: none"> New functions for read device errors (Get Device Error) Adaption for EPOS2 |
| 04.09.2009 | 4.6.0.0 | Edition September 2009 | <ul style="list-style-type: none"> Support for EPOS2 functionality Support for data recorder Support for parameter export and import VCS_ReadCANFrame |
| 22.10.2009 | 4.6.1.3 | Edition October 2009 | <ul style="list-style-type: none"> Multithreading bug fixed |
| 30.08.2009 | 4.7.1.0 | Edition August 2010 | <ul style="list-style-type: none"> New Parameter "DialogMode" for Findxxx Functions New ProtocolStack Name "MAXON SERIAL V2" (Library is still compatible with old name "EPOS2_USB") VCS_WaitForTargetReached returns false, if timeout elapses |
| 11.10.2010 | 4.7.2.0 | Edition | <ul style="list-style-type: none"> Deadlock when closing Application fixed |

| maxon motor | | | |
|-----------------------------|---------|--------------------------|---|
| EPOS Positioning Controller | | EPOS Command Library | |
| | | October 2010 | <ul style="list-style-type: none"> • Communication for IXXAT VCI V3.3 fixed |
| 28.10.2010 | 4.7.3.0 | Edition November 2010 | <ul style="list-style-type: none"> • Bugfix "VCS_CloseDevice", "VCS_CloseAllDevices" |
| 28.01.2011 | 4.8.1.0 | Edition January 2011 | <ul style="list-style-type: none"> • Expand to 64-Bit Windows and 32-Bit Linux • Bugfix Segmented Write |
| 02.02.2011 | 4.8.2.0 | Edition February 2011 | <ul style="list-style-type: none"> • Bugfix NI-LIN device |

LIST OF FIGURES

| | | |
|-----------|---|----|
| Figure 1: | EPOS documentation hierarchy | 8 |
| Figure 2: | Example Windows communication structure | 9 |
| Figure 3: | Example Linux communication structure | 10 |

LIST OF TABLES

| | | |
|-----------|--|----|
| Table 1: | Supported platforms | 5 |
| Table 2: | Data type definitions | 10 |
| Table 3: | Kind of motor | 22 |
| Table 4: | Position Sensor Type | 24 |
| Table 5: | Digital Input Configuration | 33 |
| Table 6: | Digital Output Configuration | 33 |
| Table 7: | Analog Input Configuration | 34 |
| Table 8: | Operational modes | 36 |
| Table 9: | State modes | 37 |
| Table 10: | Homing methods | 51 |
| Table 11: | Position Compare - Operational mode | 68 |
| Table 12: | Position Compare - Interval mode | 68 |
| Table 13: | Position Compare - Direction Dependency | 68 |
| Table 14: | Position marker edge types | 71 |
| Table 15: | Position marker modes | 71 |
| Table 16: | Data recorder trigger types | 75 |
| Table 17: | Command specifier | 83 |
| Table 18: | Communication errors | 84 |
| Table 19: | „Command DLL” specified general errors | 85 |
| Table 20: | „Command DLL” specified interface layer errors | 85 |
| Table 21: | „Command DLL” specified interface layer ‘RS232’ errors | 85 |
| Table 22: | „Command DLL” specified interface layer ‘CAN’ errors | 85 |
| Table 23: | „Command DLL” specified interface layer ‘USB’ errors | 85 |
| Table 24: | „Command DLL” specified protocol ‘MaxonRS232’ errors | 86 |
| Table 25: | „Command DLL” specified protocol ‘CANopen’ errors | 86 |
| Table 26: | „Command DLL” specified protocol ‘USB’ errors | 86 |