

5270842/5273821**Digital Kitchen Scale with Removable Stainless Steel Tray**

Thank you for purchasing a Taylor® digital kitchen scale. Your Taylor® scale is an example of superior design and craftsmanship. Please read this instruction manual carefully before use. Keep these instructions handy for future reference.

BATTERY INFORMATION

This scale operates on 3 "AAA" batteries (included). Always replace all batteries at the same time; do not combine old and new batteries. Do not mix alkaline standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. Replace batteries if "Lo" appears on the display, or the readings grow dim or irregular. To replace the batteries:

1. Open the battery compartment on the bottom of the scale
2. Remove the old batteries from the compartment.
3. Place the batteries into the battery compartment as indicated by the polarity symbols marked in the compartment.
4. Replace the battery compartment cover.

NOTE: Please recycle or dispose of batteries per local regulations.

WARNING: Batteries may pose a choking hazard. As with all small items, do not let children handle batteries. If swallowed, seek medical attention immediately.

PRECAUTION: Do not dispose of batteries in fire. Batteries may explode or leak. Remove the batteries if the scale will not be used for a long period of time.

GENERAL WEIGHING OPERATION

1. Place the scale on a hard, level surface. The scale can be used with or without the stainless steel weighing tray. If the tray is placed on the scale after the power is turned on it will need to be reset to zero. See TARE OPERATION below.
2. Press the "⏻/TARE" button to turn the scale on. The display will turn on and show zero when it is ready for use. If the display does not show zero, press the "⏻/TARE" button. The scale will reset (tare) to zero.
3. The scale is set to weigh in pounds/ounces. To switch between pounds/ounces (lb. oz.), grams (g), fluid ounces (fl oz.) and milliliters (mL) press the "UNIT" button.
4. Place the item to be weighed on the center of the platform. The weight will display. As you add weight, the weight displayed increases.
5. The scale will turn off automatically after approximately 1 minute of non-use or if there is no change in weight in approximately 3 minutes. To turn the scale off manually, press and hold the "⏻/TARE" button until the scale turns off.

TARE OPERATION

You may wish to weigh ingredients in a bowl or other container (not included). In this case, you will need to tare, or offset, the weight of the bowl so that only the weight of the ingredients is displayed.

1. Choose a container that will safely balance on the platform without tipping or falling. Do not use a heavy container, as this might reduce the maximum capacity of the scale.
2. While the scale is off, place the empty container on the scale platform. Turn the scale on. The display will turn on and then show zero. The weight of the container has been zeroed out.
3. Add the ingredient to be weighed. The weight of the ingredient alone will display.
4. The weight of additional ingredients may be tared out as well. For example, if a recipe calls for 8oz of rice and 8oz of beans, place the rice into the bowl. Once the correct amount of rice is weighed, press the "TARE" button to reset the display to zero. Add the 8oz of beans. Both ingredients have been accurately weighed in the same bowl.

5. When weights have been tared out, the display will show a negative number when the items are removed from the scale. Press the "TARE" button to reset the scale back to zero for a new measurement.

HOLD FUNCTION

When the "HOLD" function is turned on, the LCD screen will continue to display the weight after the item is removed from the platform. To turn on the "HOLD" function:

1. While the scale is on, place the item to be weighed on the platform.
2. Press the "HOLD" button and the "HOLD" icon appears. The weight is locked in and the items on the platform can be removed.
3. To release the "HOLD" function, press the "HOLD" button again. "HOLD" will disappear from the screen. The "HOLD" function is automatically disabled when the scale turns off.

Notes:

- Other functions will not operate when the scale is in the "HOLD" mode.
- The "HOLD" function can only operate if the weight is stable on the platform. If the weight is unstable, check to see that the scale platform rests properly on the scale. If necessary, move the item slightly on the platform until the weight locks in.

PRECAUTIONS

1. Clean exposed parts with a soft, slightly damp cloth. To remove stains, use a mild soap. Never use detergents, excess water, treated cloths, harsh cleaning agents, or sprays. **DO NOT** immerse the electronic scale in water or wash in a dishwasher. **NOTE: The stainless steel tray can be put in the dishwasher for cleaning. Dry thoroughly after washing to prevent water spots.**
2. Do not tamper with the scale's internal components. Doing so will invalidate the warranty on this unit and may cause damage. The scale contains no user-serviceable parts.
3. Although your scale is designed to be maintenance-free, it contains sensitive electronic parts. Avoid rough treatment. Treat it with care to ensure the best performance.
4. This scale is intended for home/consumer use only. It is not intended for commercial or medical use.
5. This scale is designed to read weights up to 11 lb. x 0.01 oz./5000 g x 1 g/176 fl. oz x 0.01 fl. oz/
6. 5000mL x 1mL. To prevent damage, do not place more than 11 lb / 5000 g / 176 fl.oz / 5000mL on it.
7. Do not store scale where you store cleaning chemicals. The vapors from some household products may affect the electronic components of your scale. Do not store scale on its side.
8. This scale is an extremely sensitive weighing device. In order to prevent run down of the battery, do not store anything on the scale.
9. Do not dispose of batteries in fire. Batteries may explode or leak. Remove the battery if the scale will not be used for a long period of time.
10. "UnSt" = Unstable Warning. Should "UnSt" appear on the display, this indicates the scale is unstable. Place the scale on a hard, level surface during use.
11. "O-Ld" = Overload Warning: Should "O-Ld" (overload) appear on the display during a weighing, this indicates that the maximum weighing capacity has been exceeded. Remove the weight immediately; otherwise, permanent damage could occur.

**Party issuing Supplier's Declaration of Conformity &
Responsible party – U.S. Contact information:**

Taylor Precision Products
2311 W. 22nd Street, Suite 200
Oak Brook, IL 60523

Equipment:

Product Name: Digital Kitchen Scale

Model No.: 5270842/5273821

Trade Name: Taylor

We declare under our sole responsibility that the above referenced product has been tested according to FCC requirements and this device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ONE (1) YEAR LIMITED WARRANTY

Taylor® warrants this product to be free from defects in material or workmanship (excluding batteries) for one (1) year for the original purchaser from date of retail purchase. It does not cover damages or wear resulting from accident, misuse, abuse, commercial use, or unauthorized adjustment and/or repair. If service is required, do not return to retailer. Should this product require service (or replacement at our option), please pack the item carefully and return it prepaid, along with store receipt showing the date of purchase and a note explaining reason for return to:

Taylor Precision Products
2220 Entrada Del Sol, Suite A
Las Cruces, New Mexico 88001 USA
www.taylorusa.com
Email: Taylorusa@lifetimebrands.com

There are no expressed warranties except as listed above. This warranty gives you specific legal rights, and you may have other rights which vary from state to state. For additional product information, or warranty information outside the USA, please contact us through www.taylorusa.com.

©2020 Taylor Precision Products, a division of Lifetime Brands Inc. All rights reserved
Made to our exact specifications in China. Not legal for trade.

5270842_5273821 5.20 CS