

# BLDC Control Demo User's Guide

## 1. Introduction

This document provides instructions for running and controlling the Brushless DC (BLDC) sensorless application with the Freedom and Tower System development boards shown in [Table 1](#).

The required software, hardware setup, jumper settings, project arrangement, and user interface is described in the following sections. For more information, see [Section 9, “References”](#) or visit [www.nxp.com/motorcontrol\\_bldc](http://www.nxp.com/motorcontrol_bldc).

## Contents

1.	Introduction .....	1
2.	Supported Development Boards .....	2
3.	Motor Control versus MCUXpresso SDK Peripheral Drivers .....	2
4.	Hardware Setup .....	2
4.1.	Linux 45ZWN24-40 motor.....	3
4.2.	Tower System.....	3
4.3.	Tower System assembly .....	10
4.4.	Freedom development platform.....	11
5.	Project File Structure .....	15
6.	Tools.....	16
7.	Application Building and Debugging .....	17
7.1.	IAR Embedded Workbench IDE .....	17
7.2.	Kinetis Design Studio (KDS) .....	21
7.3.	ARM-MDK Keil $\mu$ Vision.....	23
8.	User Interface .....	25
8.1.	Control button.....	25
9.	Acronyms and Abbreviations .....	26
10.	References .....	26
11.	Revision History .....	26

## 2. Supported Development Boards

There are three supported development boards with two Kinetis KV series motor-control MCUs for motor-control applications. The development boards and the supported MCUs are shown in the following table. The Tower System modular development platform and the Freedom development platform are targeted for low-voltage and low-power applications with BLDC control type.

**Table 1. Supported development boards**

—		Platform	
		Freedom	Tower System
Power stage		FRDM-MC-LVBLDC	TWR-LV3PH
MCU	KV10Z	FRDM-KV10Z	TWR-KV10Z32
	KV11Z	—	TWR-KV11Z75M
	KV31F	FRDM-KV31F	TWR-KV31F120
	KV46F	—	TWR-KV46F150M
	KV58F	—	TWR-KV58F220M
	KE15Z	FRDM-KE15Z	—
	KE18F	—	TWR-KE18F

## 3. Motor Control versus MCUXpresso SDK Peripheral Drivers

Motor Control examples use MCUXpresso SDK peripheral drivers to configure general peripherals as clocks, SPI, SIM, ports. However, motor control requires critical application timing as most of control algorithm runs in 100us loop. To optimize CPU load, the maximum of peripheral hardware features are implemented for PWM signal generation, analogue signal sampling and synchronization between PWM and ADC units.

Standard MCUXpresso SDK peripheral drivers do not support configuration and handling all required features. Motor control drivers are designed to configure critical MC peripherals (eflexPWM, FTM, ADC, PDB).

It is highly recommended not to modify default configuration of allocated MC peripherals due to possible application timing conflict. The particular `mcdrv_<board&MCU>.c` source file contains configuration functions of allocated peripherals.

## 4. Hardware Setup

The BLDC sensorless application runs on Tower System and Freedom development platforms with a default 24 V Linux motor.

## 4.1. Linux 45ZWN24-40 motor

The BLDC sensorless application uses the Linux 45ZWN24-40 motor described in the following table. The motor can be used with the Tower System or Freedom development platforms.

**Table 2. Linux 45ZWN24-40 motor parameters**

Characteristic	Symbol	Value	Units
Rated Voltage	$V_t$	24	V
Rated Speed @ $V_t$	—	4000	RPM
Rated Torque	T	0.0924	Nm
Rated Power	P	40	W
Continuous Current	$I_{cs}$	2.34	A
Number of Pole Pairs	pp	2	—



**Figure 1. Linux motor 45ZWN24-40**

The motor has two types of cable connectors. One cable has three wires and it is designated to power the motor. The second cable has five wires and it is designated for the Hall sensors signal sensing. Only the power input wires are needed for the BLDC sensorless application.

## 4.2. Tower System

To run the BLDC application using the Tower System, these Tower boards are required:

- Tower board with a Kinetis V series MCU ([TWR-KV10Z32](#), [TWR-KV11Z75M](#), [TWR-KV31F120M](#), [TWR-KV46F150M](#), or [TWR-KV58F220M](#)).
- Tower board with Kinetis E series MCU (TWR-KE18F).
- 3-Phase Low-Voltage Motor Control module (see [TWR-MC-LV3PH](#)) including the Linux motor.
- Tower System elevator modules (see [TWR-ELEV](#)).


### 4.2.1. TWR-MC-LV3PH module

The 3-Phase Low-Voltage Motor Control module (TWR-MC-LV3PH) is a peripheral Tower System module, interchangeable across the Tower System. The phase voltage and current feedback signals are provided. These signals enable a variety of algorithms to control the 3-phase PMSM and BLDC motors.

A high level of board protection (over-current, under-voltage, over-temperature) is provided by the MC33937 pre-driver. Before you insert the TWR-MC-LV3PH module into the Tower System, ensure that the jumpers on your TWR-MC-LV3PH module are configured as follows:

**Table 3. TWR-MC-LV3PH jumper settings**

Jumper	Setting	Function
J2	1-2	Selects the internal analog power supply.
J3	1-2	Selects the internal analog power reference (GND).
J10	2-3	Selects BEMF_SENSE_C.
J11	2-3	Selects BEMF_SENSE_B.
J12	2-3	Selects BEMF_SENSE_A.
J13	2-3	Selects I_SENSE_DCB.
J14	2-3	Selects V_SENSE_DCB_HALF.



**Figure 2. TWR-LV-MC3PH jumper settings**

#### 4.2.2. TWR-KV10Z32 MCU module

Configure the jumpers on the TWR-KV10Z32 MCU and TWR-MC-LV3PH modules properly. This table lists the relevant jumpers and their settings for the TWR-KV10Z32 MCU module:

**Table 4. TWR-KV10Z32 jumper settings**

Jumper	Setting	Jumper	Setting	Jumper	Setting
J1	2-3	J10	2-3	J21	3-4
J2	1-2	J11	open	J22	3-4
J3	2-3	J12	open	J25	open
J4	1-2	J13	open	J26	1-2
J5	1-2	J14	open	J27	1-2
J7	1-2	J18	2-3	J28	1-2
J8	2-3	J19	2-3	J29	1-2
J9	1-2	J20	2-3	—	—




Figure 3. TWR-KV10Z32 MCU module




### 4.2.3. TWR-KV11Z75M MCU module

Configure the jumpers on the TWR-KV11Z75M MCU and TWR-MC-LV3PH modules properly. This table lists the relevant jumpers and their settings for the TWR-KV11Z75M MCU module:

**Table 5. TWR-KV11Z jumper settings**

Jumper	Setting	Jumper	Setting	Jumper	Setting
J1	1-2	J9	open	J512	1-2
J2	2-3	J10	1-2	J517, J518	J518-J517(2)
J4	2-3	J11	2-3	J519	1-2
J5	5-6, 7-8, 9-10	J12	1-2	J523	1-2
J6	open	J13	2-3	J524	open
J7	open	J14	1-2	J526	1-2
J8	open	J17	2-3	—	—
J505	2-3	J506	2-3	—	—




**Figure 4. TWR-KV11Z75M MCU module**

#### 4.2.4. TWR-KV31F MCU module

Configure the jumpers on the TWR-KV31F120 MCU and TWR-MC-LV3PH modules properly. This table lists the relevant jumpers and their settings for the TWR-KV31F120 MCU module:

**Table 6. TWR-KV31F jumper settings**

Jumper	Setting	Jumper	Setting	Jumper	Setting
J1	1-2	J10	open	J17	1-2, 3-4, 5-6, 7-8
J3	1-2	J11	open	J20	open
J4	open	J12	open	J22	2-3
J5	1-3	J13	1-2	J23	2-3
J8	open	J14	1-2	J25	1-2
J9	open	J15	1-2	J26	2-3




**Figure 5. TWR-KV31F120M MCU module**

### 4.2.5. TWR-KV46F150M MCU module

Configure the jumpers on the TWR-KV46F150 and TWR-MC-LV3PH modules properly. This table lists the relevant jumpers and their settings for the TWR-KV46F150 MCU module:

**Table 7. TWR-KV46F jumper settings**

Jumper	Setting	Jumper	Setting	Jumper	Setting
J1	open	J16	open	J505	3-4
J2	open	J19	open	J506	3-4
J4	2-3	J20	1-2	J512	1-2
J5	1-2	J21	open	J514	2-3
J13	1-2, 3-4	J23	open	J517	2-3
J15	1-2	—	—	J519	3-4



**Figure 6. TWR-KV46F150M MCU module**




### 4.2.6. TWR-KV58F Tower System module

The TWR-KV58F220M is a development module for the Kinetis KV5x family of MCUs built around the ARM® Cortex®-M7 core. This MCU has enough power for use in multi-motor control applications (such as the PMSM or BLDC motors with simple or advanced control techniques). The MCU has a wide range of motor-control peripherals, lots of memory (depending on the model used), and a powerful core.

To begin, configure the jumpers on the TWR-KV58F220M and TWR-MC-LV3PH Tower System modules properly. This table lists the specific jumpers and their settings for the TWR-KV58F220M Tower System module:

**Table 8. TWR-KV58F jumper settings**

Jumper	Setting	Jumper	Setting	Jumper	Setting
J1	1-2	J11	1-2	J23	2-3
J2	open	J12	1-2	J24	2-3
J3	1-2	J14	open	J25	2-3
J4	1-2	J17	open	J26	2-3
J7	1-2	J18	open	J28	1-2
J8	1-2	J19	open	J29	open
J9	open	J20	open	J30	1-2, 3-4, 5-6, 7-8
J10	1-2	J21	1-2	—	—



**Figure 7. TWR-KV58F Tower System module**


### 4.2.7. TWR-KE18F Tower System module

The TWR-KE18F is a development tool for the NXP Kinetis KE1x family of MCUs built around the ARM Cortex-M4 core. This MCU has enough power for use in motor-control applications (such as PMSM or BLDC motors with simple or advanced control techniques). The MCU has a wide range of peripherals, lots of memory (depending on the model used), and a powerful core.

To begin, configure the jumpers on the TWR-KE18F and TWR-MC-LV3PH Tower System modules properly. The following table lists the specific jumpers and their settings for the TWR-KE18F Tower System module.

**Table 9. TWR-KE18F jumper settings**

Jumper	Setting	Jumper	Setting	Jumper	Setting
J3	2-3	J9	1-2	J18	1-2
J4	1-2	J11	1-2	J19	1-2
J5	2-3	J12	1-2	J21	open
J6	1-2	J13	1-2	J22	1-2
J7	1-2	J16	1-2	J23	Open
J8	open	J17	1-2	J24	1-2



**Figure 8. TWR-KE18F Tower System module**

## 4.3. Tower System assembly

1. Insert the TWR-KVxxXxx MCU module and the TWR-MC-LV3PH module into the TWR-ELEV card slots. Ensure that the primary sides of the modules (marked by white stripes) are inserted into the primary elevator card (marked by white connectors).

2. After assembling the Tower System, connect the required cables as follows:
  - Connect the power input cable (3-wire connector) of the Linux motor to its corresponding connector (J5) on the TWR-MC-LV3PH motor control driver board.
  - Plug in the power supply cable that is attached to the TWR-MC-LV3PH system kit to the motor control peripheral board TWR-MC-LV3PH.
  - Connect the TWR MCU module to the host PC via a USB cable connected to J23 of the TWR-KV10Z32 MCU module or J21 of the TWR-KV31F120 MCU module and any USB port on the host PC.




Figure 9. Assembled Tower System

## 4.4. Freedom development platform

To run the BLDC application using Freedom, you need these Freedom boards:

- Kinetis KV10Z Freedom board (see [FRDM-KV10Z](#)), Kinetis KV31F Freedom board (see [FRDM-KV31F](#)) or Kinetis KE15Z Freedom board.
- 3-Phase Low-Voltage Power Freedom shield (see [FRDM-MC-LV3PH](#)) including the Linux motor.



#### 4.4.1. FRDM-MC-LVBLDC low-voltage evaluation board

The FRDM-MC-LVBLDC low-voltage evaluation board (in a shield form factor) effectively turns the Freedom development platform into a complete motor-control reference design compatible with the existing Freedom development platforms (FRDM-KV31F and FRDM-KV10Z).

The FRDM-MC-LVBLDC board does not require any hardware configuration or jumper settings. It contains no jumpers.




Figure 10. FRDM-MC-LVBLDC

#### 4.4.2. FRDM-KV10Z board

The FRDM-KV10Z board is a low-cost development tool for the Kinetis V series KV1x MCU family built on the ARM Cortex-M0+ processor. The FRDM-KV10Z board's hardware is form-factor compatible with the Arduino™ R3 pin layout, providing a broad range of expansion board options. The FRDM-KV10Z platform features OpenSDA, the Freescale open source hardware embedded serial and debug adapter running an open source bootloader.

The FRDM-KV10Z board does not require any hardware configuration or jumper settings. It contains no jumpers.






Figure 11. FRDM-KV10Z Freedom development board

### 4.4.3. FRDM-KV31F board

The FRDM-KV31F board is a low-cost development tool for the Kinetis V series KV3x MCU family built upon the ARM Cortex-M4 processor. The FRDM-KV31F board hardware is form-factor compatible with the Arduino™ R3 pin layout, providing a broad range of expansion board options, including FRDM-MC-LVPMSC and FRDM-MC-LVBLDC for PMSM and BLDC motor control.

The FRDM-KV31F platform features OpenSDA, the open-source hardware embedded serial and debug adapter running an open-source bootloader. This circuit offers several options for serial communication, flash programming, and run-control debugging.

The FRDM-KV31F board does not require any hardware configuration or jumper settings. It contains no jumpers.




Figure 12. FRDM-KV31F Freedom development board


#### 4.4.4. FRDM-KE15Z board

The FRDM-KE15Z is a low-cost development tool for Kinetis KE1x family of MCUs built around the ARM Cortex-M0+ core. The FRDM-KE15Z hardware is form-factor compatible with the Arduino™ R3 pin layout, providing a broad range of expansion board options. The FRDM-KE15Z platform features OpenSDA, the NXP open-source hardware embedded serial and debug adapter running an open-source bootloader.

To begin, configure the jumpers on the FRDM-KE15Z Freedom System module properly. The following table lists the specific jumpers and their settings for the FRDM-KE15Z Freedom System module.

**Table 10. FRDM-KE15Z jumper settings**

Jumper	Setting	Jumper	Setting	Jumper	Setting
J7	1-2	J10	1-2	J15	2-3
J8	1-2	J14	1-2		



**Figure 13. FRDM-KE15Z Freedom development board**

#### 4.4.5. Freedom development platform assembly

1. Connect the FRDM-MC-LVBLDC shield on top of the FRDM-KVxxx board.
2. Connect the BLDC motor 3-phase wires into the screw terminals on the board.
3. Plug in the USB cable from the USB host to the OpenSDA micro USB connector.
4. Plug in a 12 V DC power supply to the DC power jack.



Figure 14. Assembled Freedom system

## 5. Project File Structure

The demo project folder (for example *boards\frdmkv10z\demo\_apps\mc\_bldc*) contains these folders and files:

- *IAR* folder—contains the configuration files for IAR Embedded Workbench® IDE. If IAR Embedded Workbench for ARM is installed on your computer, open the project using IAR IDE.
- *KDS* folder—contains the configuration files for KDS IDE and the launch configuration for debuggers. If KDS is installed on your computer, open the project using KDS IDE.
- *MDK* folder—contains the configuration files for µVision® Keil® IDE. If Keil IDE is installed on your computer, open the project using Keil IDE.
- *Project files*—contains the device-specific files. They specify the peripheral initialization routines, motor definitions, and state machines. The source code contains a lot of comments. The functions of the particular files are explained in this list:
  - *ml\_bldc\_appconfig.h* — contains definitions of constants for the application control processes (parameters of the motor and regulators, and the constants for BLDC sensorless control-related algorithms).
  - *main.c* — contains basic application initialization (enabling interrupts), subroutines for accessing the MCU peripherals, and interrupt service routines.
  - *mcdrv.h* — includes specific *mcdrv\_< board&MCU >.h* file to the project
  - *mcdrv\_< board&MCU >.c* — contains motor-control driver peripherals initialization functions, specific for the board and MCU used.

- *mcdrv\_<board&MCU>.h* — header file for *mcdrv\_<board&MCU>.c*. This file contains macros for changing the PWM period and ADC channels assigned to the back-emf voltages and board voltage and current.
- *pin\_mux.c* — contains board initialization function for configuring pin routing. This file is generated with the Pins tool.
- *pin\_mux.h* — header file for *pin\_mux.c*.
- *board.c* — common MCUXpresso SDK file containing initialization of a debug console
- *board.h* — common MCUXpresso SDK file containing macros for specific board pinout
- *clock\_config.c* — contains MCU clock configuration functions
- *clock\_config.h* — header file for *clock\_config.c*
- *readme.txt* — basic information about requirements, settings and demo.

The motor-control folder `<MCUXpresso SDK_install_folder>\middleware\motor_control\bldc` contains these common source and header files used in all motor-control projects. The folder contains the subfolders common to the entire project in this package:

- *mc\_algorithms*—contains the control algorithms used to control the BLDC motor.
- *mc\_drivers*—contains the source and header files used to initialize and run motor-control applications.
- *mc\_state\_machine*—contains the software routines that are executed when the application is in a particular state or state transition.
- *state\_machine*—contains the state machine functions for the Fault, Initialization, Stop, and Run states.

Each motor-control project is based on RTCESL (Real-Time Control Embedded Software Library) placed in the `<MCUXpresso SDK_install_folder>\middleware` folder. The library contains the mathematical functions used in the project. It contains the library subfolders for specific cores (“*cm0*”, “*cm4*”, and “*cm7*”). This subfolder includes the required header files and library files used in the project. The *RTCESL* folder is taken from the RTCESL release 4.3, and it is fully compatible with the official release. The library names are changed for easier use with the available IDEs. See [nxp.com/rtcesl](http://nxp.com/rtcesl) for more information about RTCESL.

## 6. Tools

The following list shows the required software to be installed on your PC to run and control the BLDC sensorless application properly.

- [IAR Embedded Workbench IDE v7.60 or higher](#)
- [Kinetic Design Studio IDE v3.2 or higher](#)
- [ARM-MDK Keil  \$\mu\$ Vision version 5.20](#)



## 7. Application Building and Debugging

The package contains projects for Kinetis Design Studio, IAR Embedded Workbench, and  $\mu$ Vision Keil IDEs. Both of them are targeted for motor-control applications. The release configuration is the default one, and there are no special requirements needed to run and debug the demonstration applications.

### 7.1. IAR Embedded Workbench IDE

Use IAR Embedded Workbench IDE to compile and run the demonstration projects. The first step is to choose the demonstration, development board, and MCU. For example, to run a demonstration project for the Freedom development platform and Kinetis KV10 MCU, the project is located in the `<MCUXpresso SDK_install_folder>\boards\frdmkv10z\demo_apps\mc_bldc\iar\` folder, which contains all necessary files. Double-click “mc\_bldc.eww” to run this project. This figure shows the IAR workspace:




Figure 15. IAR Embedded Workbench IDE

The project opened in IAR Embedded Workbench is fully configured and includes all source and header files required by the application (such as the startup code, clock configuration, and peripherals' configuration). You can choose from two compiling conditions (“debug” or “release”) shown in [Figure 15](#) point 2. Each of the two conditions has its own setting:

- “debug”—used for debugging, optimization has the “None – turned off” flag.
- “release”—used for releasing, optimization has the “High – highest optimization for speed” flag.

### NOTE


The “debug” condition has the optimization turned off, and the output file may not fit into MCUs with a smaller flash (for example KV10Z32).

The source code shown in [Figure 15](#) includes these source files and folders:

- Point 3—the RTCESL library source folder contains header files for the mathematical and control functions used in this project. The theory about using and applying these functions is described in the user’s guides specific for each library. Find the user’s guides at [nxp.com/fslesl](http://nxp.com/fslesl).

- Point 4—the board independent source files contain the application source code. These files are placed in the `<MCUXpresso SDK_install_folder>\middleware\motor_control\bldc` folder.
- Point 5—the device-specific files contain the application source code. These files are placed in the `<MCUXpresso SDK_install_folder>\boards<board&MCU>\demo_apps\mc_blcdc` folder.
- Point 6—shows the output file generated by the compiler, and is ready to use with the default debugger (P&E Micro OpenSDA). This debugger is set as default for the Tower System boards, and can be changed in the project options by right-clicking Point 1, selecting “Options”, and clicking “Debugger”. Start the project debugging by clicking Point 7 ([Figure 15](#)).

The installation package contains only the required project files. All cached files are deleted by default. From IAR IDE version 7.60 onwards, the updated P&E Micro OpenSDA driver requires selecting a valid device (see the following figure) during the first code build and loading to the MCU.



**Figure 16. IAR IDE select device alert**

After you click the “OK” button, the “P&E Connection Manager” opens. Click the “Select New Device” button and select the particular MCU according to [Table 11](#).




Figure 17. P&amp;E Connection Manager

Table 11. Supported development platforms

—		Platform	
		Tower	Freedom
MCU	KV10Z	KV10Z32M7	KV10Z32M7
	KV31F	KV31F512M12	KV31F512M12
	KV11Z	KV11Z128M7	—
	KV46F	KV46F256M16	—
	KV58F	KV58F512M22	—
	KE15Z	—	KE15Z256
	KE18F	KE18F160M	—



## 7.2. Kinetis Design Studio (KDS)

Kinetis Design Studio (KDS) is an IDE tool that you can use to develop and test software for NXP MCUs. It supports a wide range of Kinetis devices, such as the powerful K series, low-power KL series, and KV series targeted for motor control. KDS includes tools for compiling, linking, and debugging of source code. KDS supports a wide range of debuggers, such as P&E Micro or J-Link™ (and others). Download the latest release of KDS from the official NXP website ([nxp.com/kds](http://nxp.com/kds)). For installation and configuration, see *Kinetis Design Studio V3.2.0 User's Guide* (document [KDSUG](#)).

To open a demonstration, choose the development board and MCU. For example, if you want to open a demonstration project for the Freedom development platform and Kinetis KV10 MCU, locate the project in `<MCUXpresso SDK_install_folder>\boards\frdmkv10z\demo_apps\mc_blcd\kds`, run KDS IDE from the default installation path or from the installed programs, and perform these steps:

- Click the “File” menu in the top-left corner of the IDE, and select “Import...”.
- A window opens. Highlight “Existing Projects into Workspace” in the “General” folder, and click the “Next” button:




Figure 18. KDS—importing project

- The “Import” window opens. Click the “Browse” button, and then locate the project in the `<MCUXpresso SDK_install_folder>\boards\frdmkv10z\demo_apps\mc_blcd\kds` folder. Click the “OK” button.




Figure 19. KDS import project 3

- Confirm the project by clicking the “Finish” button.

The project is now imported to Kinetis Design Studio (Figure 20). Point 1 shows the imported project in “Project Explorer”, and Point 2 shows the source code of this project. Build the project by clicking the “build” icon (Point 3) where the “release” configuration is set as default. You can change the configuration to “debug”. Each of these two conditions has its own setting:

- “debug”—used for debugging, optimization has the “None – turned off” flag.
- “release”—used for releasing, optimization has the “High – Highest optimization for speed” flag.

#### NOTE

The “debug” condition has the optimization turned off, and the output file may not fit into MCUs with a smaller flash (for example KV10Z32).




Figure 20. KDS BLDC project


After the project is compiled, either the *debug* or *release* folder is created, depending on the build condition selected. An \*.elf binary file is created in one or both of those folders. Now use the debugger (Point 4 in Figure 20). You can use the predefined debugger (P&E Micro OpenSDA), or choose a different debugger from the menu. In the top list menu, select “Run-> Debug Configuration” to define a different type of debugger, or change the conditions of debugging (such as the optimization level).

### 7.3. ARM-MDK Keil $\mu$ Vision

The ARM-MDK Keil  $\mu$ Vision IDE (Keil) is a software development and testing tool for various MCUs. It supports a wide range of Kinetis devices, such as the powerful K series, low-power KL series, and KV series targeted for motor control. Keil includes tools for compiling, linking, and debugging of source code. Keil supports a wide range of debuggers, such as P&E Micro or J-Link (and others). Download the latest release of Keil from the official Keil website [www2.keil.com/mdk5/uvision](http://www2.keil.com/mdk5/uvision).

To open the demonstration, choose the development board and MCU. For example, to open a reference project for the Freedom development platform and Kinetis KV10 MCU, locate the project in the `<MCUXpresso SDK_install_folder>\boards\frdmkv10z\demo_apps\mc_bldc\mdk` folder:

- Double click the `mc_bldc.uvprojx` project file.
- After the project is opened, click the “Build” button (Point 1) to compile the project. Click the “Download” button (Point 2) to download the code to the target. Then click the “Debug” button to enter the debug session (Point 3):



**Figure 21. Keil BLDC project**

- Before downloading the code to the target, select the proper target device (if using the P&E Micro OpenSDA debugger).






Figure 22. P&E Micro debugger—target selection

- There are two project configurations:
  - “debug”—used for debugging, the optimization has the “None – turned off” flag.
  - “release”—used for releasing, the optimization has the “High – Highest optimization for speed” flag.
- Use the predefined debugger (such as P&E Micro OpenSDA), or choose a different debugger from the menu. In the top list menu, select “Run-> Debug Configuration” to define a different type of debugger or change the conditions of debugging (such as the optimization level).

## 8. User Interface

The application contains the demo application mode to demonstrate the motor rotation. Operate it using the user button. The Tower System and Freedom boards include a user button associated with the port interrupt (generated whenever one of the buttons is pressed). At the beginning of the ISR, a simple logic executes, and the interrupt flag clears. When you press the SW2 button, the demo mode starts; when you press the same button again, the application stops and transitions back to the STOP state. There is also an LED indication of the current application state. The green continuous LED indicates that the application is in the RUN state, the flashing LED indicates the FAULT state, and the LED off (or red LED) indicates the STOP state.

Control the application using the buttons on the NXP Kinetis V Tower System and Freedom development boards.

### 8.1. Control button

When you press the SW2 button, the demonstration mode switches on (or off, if it is already switched on).

## 9. Acronyms and Abbreviations

Table 12. Acronyms and abbreviations

Term	Meaning
AN	Application Note
BLDC	Brushless DC motor
DRM	Design Reference Manual
MCU	Microcontroller
MSD	Mass Storage Device

## 10. References

See these documents at [nxp.com](http://nxp.com):

1. *Kinetis Design Studio v3.2.0 User's Guide* (document [KDSUG](#))
2. [Embedded Software Libraries User's Guides](#)
3. *3-Phase BLDC Sensorless Motor Control Application* (document [DRM144](#))
4. *Sensorless BLDC Control on Kinetis KV* (document [AN5263](#))

## 11. Revision History

Table 13. Revision history

Revision number	Date	Substantive changes
1	06/2016	Initial release.



---

**How to Reach Us:**

**Home Page:**

[nxp.com](http://nxp.com)

**Web Support:**

[nxp.com/support](http://nxp.com/support)

Information in this document is provided solely to enable system and software implementers to use NXP products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document. NXP reserves the right to make changes without further notice to any products herein.

NXP makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does NXP assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in NXP data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. NXP does not convey any license under its patent rights nor the rights of others. NXP sells products pursuant to standard terms and conditions of sale, which can be found at the following address:

[nxp.com/SalesTermsandConditions](http://nxp.com/SalesTermsandConditions).

NXP, the NXP logo, NXP SECURE CONNECTIONS FOR A SMARTER WORLD, Freescale, the Freescale logo, and Kinetis are trademarks of NXP B.V. ARM, the ARM Powered logo, Cortex, Keil, and  $\mu$ Vision are registered trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. IAR Embedded Workbench is a registered trademark owned by IAR Systems AB. J-Link is a trademark licensed to IAR Systems AB. All other product or service names are the property of their respective owners.

© 2016 NXP B.V.

Document Number: BLDCDEMOUG  
Rev. 1  
06/2016

