


از چهارم

گام 2:



```
COM1 - PuTTY
firm]
[OK]
Erase of nvram: complete
Switch#
*Mar 1 00:34:35.031: %SYS-7-NV_BLOCK_INIT: Initialized the geometry of nvram
Switch#complete
Translating "complete"...domain server (255.255.255.255)
% Unknown command or computer name, or unable to find computer address
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#dir
^
% Invalid input detected at '^' marker.

Switch(config)#exit
Switch#dir
Directory of flash:/

   2  -rwx       736   Mar 1 1993 00:00:52 +00:00  vlan.dat
   4  drwx       192   Mar 1 1993 00:07:01 +00:00  c2960-lanbase-mz.122-50.SE
5
 559  -rwx       105   Mar 1 1993 00:07:01 +00:00  info
 560  -rwx        57   Mar 1 1993 03:47:37 +00:00  express_setup.debug

32514048 bytes total (21554688 bytes free)
Switch#
*Mar 1 00:39:54.058: %SYS-5-CONFIG_I: Configured from console by consoled;
Delete filename [;]?
Delete flash:;? [confirm]
%Error deleting flash:; (No such file or directory)
Switch#delete flash:/vlan.dat
Delete filename [vlan.dat]?
Delete flash:/vlan.dat? [confirm]
Switch#dir
Directory of flash:/

   4  drwx       192   Mar 1 1993 00:07:01 +00:00  c2960-lanbase-mz.122-50.SE
5
 559  -rwx       105   Mar 1 1993 00:07:01 +00:00  info
 560  -rwx        57   Mar 1 1993 03:47:37 +00:00  express_setup.debug

32514048 bytes total (21555712 bytes free)
Switch#
```

```

560 -rw-r--r-- 1 root 10240 Mar 1 1993 03:47:37 400:00 express_setup.debug
32514048 bytes total (21555712 bytes free)
Switch#reload

System configuration has been modified. Save? [yes/no]: no
Proceed with reload? [confirm]

*Mar  1 00:42:40.169: %SYS-5-RELOAD: Reload requested by console. Reload reason:
Reload command
Boot Sector Filesystem (bs) installed, fsid: 2
Base ethernet MAC Address: ec:e1:a9:57:de:00
Xmodem file system is available.

```

گام 3:

```

Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#hostname Als2
Als2(config)#show interface status
^
% Invalid input detected at '^' marker.

Als2(config)#show interfaces status
^
% Invalid input detected at '^' marker.

Als2(config)#do show interfaces status

```

Port	Name	Status	Vlan	Duplex	Speed	Type
Fa0/1		notconnect	1	auto	auto	10/100BaseTX
Fa0/2		notconnect	1	auto	auto	10/100BaseTX
Fa0/3		notconnect	1	auto	auto	10/100BaseTX
Fa0/4		notconnect	1	auto	auto	10/100BaseTX
Fa0/5		notconnect	1	auto	auto	10/100BaseTX
Fa0/6		connected	1	a-full	a-100	10/100BaseTX
Fa0/7		notconnect	1	auto	auto	10/100BaseTX
Fa0/8		notconnect	1	auto	auto	10/100BaseTX
Fa0/9		connected	1	a-full	a-100	10/100BaseTX
Fa0/10		connected	1	a-full	a-100	10/100BaseTX
Fa0/11		notconnect	1	auto	auto	10/100BaseTX
Fa0/12		notconnect	1	auto	auto	10/100BaseTX

```

Fa0/10          connected    1          a-full  a-100  10/100BaseTX
Fa0/11          notconnect   1          auto    auto   10/100BaseTX
Fa0/12          notconnect   1          auto    auto   10/100BaseTX
Fa0/13          notconnect   1          auto    auto   10/100BaseTX
Fa0/14          notconnect   1          auto    auto   10/100BaseTX
Fa0/15          notconnect   1          auto    auto   10/100BaseTX
Fa0/16          notconnect   1          auto    auto   10/100BaseTX
Fa0/17          notconnect   1          auto    auto   10/100BaseTX
Fa0/18          notconnect   1          auto    auto   10/100BaseTX
Fa0/19          notconnect   1          auto    auto   10/100BaseTX
Fa0/20          notconnect   1          auto    auto   10/100BaseTX
Fa0/21          notconnect   1          auto    auto   10/100BaseTX
Fa0/22          notconnect   1          auto    auto   10/100BaseTX
Fa0/23          notconnect   1          auto    auto   10/100BaseTX
Fa0/24          notconnect   1          auto    auto   10/100BaseTX
Gi0/1          notconnect   1          auto    auto   10/100/1000Ba
seTX
Gi0/2          notconnect   1          auto    auto   10/100/1000Ba
seTX
Als2(config)#interface range fast
Als2(config)#interface range fastEthernet 0/1-24, giga
Als2(config)#interface range fastEthernet 0/1-24, gigabitEthernet 0/1-2
Als2(config-if-range)#shu
Als2(config-if-range)#shutdown
Als2(config-if-range)#
*Mar  1 00:10:25.253: %LINEPROTO-5-UPDOWN: Line protocol on Interface Vlan1, cha
nged state to down
*Mar  1 00:10:27.073: %LINK-5-CHANGED: Interface FastEthernet0/1, changed state
to administratively down
*Mar  1 00:10:27.090: %LINK-5-CHANGED: Interface FastEthernet0/2, changed state
to administratively down
*Mar  1 00:10:27.098: %LINK-5-CHANGED: Interface FastEthernet0/3, changed state
to administratively down
*Mar  1 00:10:27.107: %LINK-5-CHANGED: Interface FastEthernet0/4, changed state

```

```
to administratively down
*Mar 1 00:10:27.191: %LINK-5-CHANGED: Interface FastEthernet0/14, changed state
to administratively down
*Mar 1 00:10:27.199: %LINK-5-CHANGED: Interface FastEthernet0/15, changed state
to administratively down
*Mar 1 00:10:27.207: %LINK-5-CHANGED: Interface FastEthernet0/16, changed state
to administratively down
*Mar 1 00:10:27.216: %LINK-5-CHANGED: Interface FastEthernet0/17, changed state
to administratively down
*Mar 1 00:10:27.224: %LINK-5-CHANGED: Interface FastEthernet0/18, changed state
to administratively down
*Mar 1 00:10:27.232: %LINK-5-CHANGED: Interface FastEthernet0/19, changed state
to administratively down
*Mar 1 00:10:27.241: %LINK-5-CHANGED: Interface FastEthernet0/20, changed state
to administratively down
*Mar 1 00:10:27.249: %LINK-5-CHANGED: Interface FastEthernet0/21, changed state
to administratively down
*Mar 1 00:10:27.274: %LINK-5-CHANGED: Interface FastEthernet0/22, changed state
to administratively down
*Mar 1 00:10:27.283: %LINK-5-CHANGED: Interface FastEthernet0/23, changed state
to administratively down
*Mar 1 00:10:27.291: %LINK-5-CHANGED: Interface FastEthernet0/24, changed state
to administratively down
*Mar 1 00:10:27.291: %LINK-5-CHANGED: Interface GigabitEthernet0/1, changed sta
te to administratively down
*Mar 1 00:10:27.300: %LINK-5-CHANGED: Interface GigabitEthernet0/2, changed sta
te to administratively down
*Mar 1 00:10:28.122: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthern
et0/6, changed state to down
*Mar 1 00:10:28.155: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthern
et0/9, changed state to down
*Mar 1 00:10:28.164: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthern
et0/10, changed state to down
Als2(config-if-range)#
```

```
to administratively down
*Mar 1 00:10:27.291: %LINK-5-CHANGED: Interface FastEthernet0/24, changed state
to administratively down
*Mar 1 00:10:27.291: %LINK-5-CHANGED: Interface GigabitEthernet0/1, changed sta
te to administratively down
*Mar 1 00:10:27.300: %LINK-5-CHANGED: Interface GigabitEthernet0/2, changed sta
te to administratively down
*Mar 1 00:10:28.122: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthern
et0/6, changed state to down
*Mar 1 00:10:28.155: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthern
et0/9, changed state to down
*Mar 1 00:10:28.164: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthern
et0/10, changed state to down
Als2(config-if-range)#vtp mode tran
Als2(config-if-range)#vtp mode transparent
Setting device to VTP TRANSPARENT mode.
% Command exited out of interface range and its sub-modes.
Not executing the command for second and later interfaces
Als2(config)#no ip domain lookup
Als2(config)#
```

## گام 4:

```

Als2(config)#interface range fastEthernet 0/9-10
Als2(config-if-range)#cha
Als2(config-if-range)#channel-gr
Als2(config-if-range)#channel-group 3 mode de
Als2(config-if-range)#channel-group 3 mode desirable
Creating a port-channel interface Port-channel 3

Als2(config-if-range)#inter
Als2(config-if-range)#interface port-ch
Als2(config-if-range)#interface port-channel 3
% Command exited out of interface range and its sub-modes.
  Not executing the command for second and later interfaces
Als2(config-if)#interface range fastEthernet 0/9-10
Als2(config-if-range)#channel-pr
Als2(config-if-range)#channel-protocol pagp
Als2(config-if-range)#channel-group 3 mode desirable
Als2(config-if-range)#inter
Als2(config-if-range)#interface port-channel 3
% Command exited out of interface range and its sub-modes.
  Not executing the command for second and later interfaces
Als2(config-if)#

```

```

Als2#show etherchannel summary
Flags:  D - down          P - bundled in port-channel
        I - stand-alone  s - suspended
        H - Hot-standby (LACP only)
        R - Layer3       S - Layer2
        U - in use       f - failed to allocate aggregator

        M - not in use, minimum links not met
        u - unsuitable for bundling
        w - waiting to be aggregated
        d - default port

Number of channel-groups in use: 1
Number of aggregators:          1

Group  Port-channel  Protocol    Ports
-----+-----+-----+-----
3      Po3 (SD)        PAgP        Fa0/9 (D)   Fa0/10 (D)

Als2#

```

## گام 5:

```

Als2(config)#vlan 99
Als2(config-vlan)#name Management
Als2(config-vlan)#vlan 200
Als2(config-vlan)#name Engineering

```

```

Als2(config)#vlan 99
Als2(config-vlan)#name Management
Als2(config-vlan)#do show vlan

```

VLAN	Name	Status	Ports
1	default	active	Fa0/1, Fa0/2, Fa0/3, Fa0/4 Fa0/5, Fa0/6, Fa0/7, Fa0/8 Fa0/9, Fa0/10, Fa0/11, Fa0/12 Fa0/13, Fa0/14, Fa0/15, Fa0/16 Fa0/17, Fa0/18, Fa0/19, Fa0/20 Fa0/21, Fa0/22, Fa0/23, Fa0/24 Gi0/1, Gi0/2
99	Management	active	
200	Engineering	active	
1002	fddi-default	act/unsup	
1003	token-ring-default	act/unsup	
1004	fddinet-default	act/unsup	
1005	trnet-default	act/unsup	

VLAN	Type	SAID	MTU	Parent	RingNo	BridgeNo	Stp	BrdgMode	Trans1	Trans2
1	enet	100001	1500	-	-	-	-	-	0	0
99	enet	100099	1500	-	-	-	-	-	0	0
200	enet	100200	1500	-	-	-	-	-	0	0
1002	fddi	101002	1500	-	-	-	-	-	0	0
1003	tr	101003	1500	-	-	-	-	-	0	0
1004	fdnet	101004	1500	-	-	-	ieee	-	0	0
1005	trnet	101005	1500	-	-	-	ibm	-	0	0

Remote SPAN VLANs

Primary	Secondary	Type	Ports
---------	-----------	------	-------

```

Als2(config-vlan)#
Als2(config-vlan)#

```

```

Als2(config)#
Als2(config)#in
Als2(config)#interface fas
Als2(config)#interface fastEthernet 0/9
Als2(config-if)#sw
Als2(config-if)#switchport mode trunk
Als2(config-if)#exit
Als2(config)#interface fastEthernet 0/10
Als2(config-if)#switchport mode trunk
Als2(config-if)#exit

```

```

Als2(config)#interface fastEthernet 0/9
Als2(config-if)#no sh
Als2(config-if)#no shutdown

```

```

Als2(config-if)#interface fastEthernet 0/10
Als2(config-if)#no sh
Als2(config-if)#no shutdown

```

```

Als2(config-if)#interface fastEthernet 0/6
Als2(config-if)#no sh
Als2(config-if)#no shutdown
Als2(config-if)#do show interface status

Port      Name      Status      Vlan      Duplex  Speed Type
Fa0/1      disabled  1           auto      auto    10/100BaseTX
Fa0/2      disabled  1           auto      auto    10/100BaseTX
Fa0/3      disabled  1           auto      auto    10/100BaseTX
Fa0/4      disabled  1           auto      auto    10/100BaseTX
Fa0/5      disabled  1           auto      auto    10/100BaseTX
Fa0/6      connected 200        a-full    a-100   10/100BaseTX
Fa0/7      disabled  1           auto      auto    10/100BaseTX
Fa0/8      disabled  1           auto      auto    10/100BaseTX
Fa0/9      connected trunk      a-full    a-100   10/100BaseTX
Fa0/10     connected trunk      a-full    a-100   10/100BaseTX
Fa0/11     disabled  1           auto      auto    10/100BaseTX
Fa0/12     disabled  1           au
*Mar 1 01:27:35.127: %LINK-3-UPDOWN: Interface FastEthernet0/6, changed state to up
*Mar 1 01:27:36.150: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/6, changed state to upto   auto 10/100BaseTX
Fa0/13     disabled  1           auto      auto    10/100BaseTX
Fa0/14     disabled  1           auto      auto    10/100BaseTX
Fa0/15     disabled  1           auto      auto    10/100BaseTX
Fa0/16     disabled  1           auto      auto    10/100BaseTX
Fa0/17     disabled  1           auto      auto    10/100BaseTX
Fa0/18     disabled  1           auto      auto    10/100BaseTX
Fa0/19     disabled  1           auto      auto    10/100BaseTX
Fa0/20     disabled  1           auto      auto    10/100BaseTX
Fa0/21     disabled  1           auto      auto    10/100BaseTX
Fa0/22     disabled  1           auto      auto    10/100BaseTX
Fa0/23     disabled  1           auto      auto    10/100BaseTX
Fa0/24     disabled  1           auto      auto    10/100BaseTX
Gi0/1      disabled  1           auto      auto    10/100/1000BaseTX
Gi0/2      disabled  1           auto      auto    10/100/1000BaseTX
Po3        connected trunk      a-full    a-100
Als2(config-if)#
Als2(config-if)#

```

```

Als2(config-if)#
Als2(config-if)#interface fastEthernet 0/10
Als2(config-if)#des
Als2(config-if)#description "connected to server"
Als2(config-if)#exit
Als2(config)#interface fastEthernet 0/9
Als2(config-if)#description "connected to server"
Als2(config-if)#exit
Als2(config)#interface fastEthernet 0/6
Als2(config-if)#description "connected to client"
Als2(config-if)#exit
Als2(config)#do show interface status

Port      Name      Status      Vlan      Duplex  Speed Type
Fa0/1      disabled  1           auto      auto    10/100BaseTX
Fa0/2      disabled  1           auto      auto    10/100BaseTX
Fa0/3      disabled  1           auto      auto    10/100BaseTX
Fa0/4      disabled  1           auto      auto    10/100BaseTX
Fa0/5      disabled  1           auto      auto    10/100BaseTX
Fa0/6      "connected to clie connected 200        a-full    a-100   10/100BaseTX
Fa0/7      disabled  1           auto      auto    10/100BaseTX
Fa0/8      disabled  1           auto      auto    10/100BaseTX
Fa0/9      "connected to serv connected trunk      a-full    a-100   10/100BaseTX
Fa0/10     "connected to serv connected trunk      a-full    a-100   10/100BaseTX
Fa0/11     disabled  1           auto      auto    10/100BaseTX
Fa0/12     disabled  1           auto      auto    10/100BaseTX
Fa0/13     disabled  1           auto      auto    10/100BaseTX
Fa0/14     disabled  1           auto      auto    10/100BaseTX
Fa0/15     disabled  1           auto      auto    10/100BaseTX
Fa0/16     disabled  1           auto      auto    10/100BaseTX
Fa0/17     disabled  1           auto      auto    10/100BaseTX
Fa0/18     disabled  1           auto      auto    10/100BaseTX
Fa0/19     disabled  1           auto      auto    10/100BaseTX
Fa0/20     disabled  1           auto      auto    10/100BaseTX
Fa0/21     disabled  1           auto      auto    10/100BaseTX
Fa0/22     disabled  1           auto      auto    10/100BaseTX
Fa0/23     disabled  1           auto      auto    10/100BaseTX
Fa0/24     disabled  1           auto      auto    10/100BaseTX
Gi0/1      disabled  1           auto      auto    10/100/1000BaseTX
Gi0/2      disabled  1           auto      auto    10/100/1000BaseTX
Po3        connected trunk      a-full    a-100
Als2(config)#

```



گام 6:

```
Als2(config)#interface vlan 99
Als2(config-if)#ip address 172.16.99.102 255.255.255.0
Als2(config-if)#no
Als2(config-if)#no sh
Als2(config-if)#no shutdown
Als2(config-if)#interface vlan 200
Als2(config-if)#ip address 172.16.200.101 255.255.255.0
Als2(config-if)#no shutdown
Als2(config-if)#
```

پینگ هایی که گرفته شد موفقیت امیز نبود بخاطر این که هنوز DLS ، ip routing نشده بود.

گام 7:

DLS:


```
DLS_1(config)#ip routing
DLS_1(config)#interface vlan99
DLS_1(config-if)#ip default-gateway 172.16.99.1
DLS_1(config)#
```

ALS:

```
Als2(config)#exit
Als2#enable
*Mar 1 02:59:34.009: %SYS-5-CONFIG_I: Configured from console by console
Als2#ping 172.16.99.1

Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 172.16.99.1, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/203/1007 ms
Als2#
```





```
C:\Users\netlab12>ping 172.16.100.101

Pinging 172.16.100.101 with 32 bytes of data:
Reply from 169.254.169.49: Destination host unreachable.
Reply from 169.254.169.49: Destination host unreachable.
Reply from 169.254.169.49: Destination host unreachable.
Reply from 169.254.169.49: Destination host unreachable.

Ping statistics for 172.16.100.101:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),

C:\Users\netlab12>
```

پینگ هایی که گرفته شد موفقیت امیز بوده بخاطر اینکه در گام پیش سوییچ لایه سوم ip routing شده است

گام 9:

:DLS

```
DLS_1(config)#ip dhcp excluded-address 10.1.10.1 10.1.10.20
DLS_1(config)#ip dhcp pool dls-pool
DLS_1(dhcp-config)#ip dhcp excluded-address 172.16.100.1 172.16.200.1
DLS_1(config)#network 172.16.100.1 255.255.255.0
      ^
% Invalid input detected at '^' marker.

DLS_1(config)#network 172.16.200.1 255.255.255.0
      ^
% Invalid input detected at '^' marker.

DLS_1(config)#network 172.16.99.1 255.255.255.0
      ^
% Invalid input detected at '^' marker.

DLS_1(config)#network 172.16.100.0 255.255.255.0
      ^
% Invalid input detected at '^' marker.

DLS_1(config)#ip dhcp excluded-address 172.16.100.1 172.16.200.1
DLS_1(config)#ip dhcp pool dls-pool
DLS_1(dhcp-config)#network 172.16.100.0 255.255.255.0
DLS_1(dhcp-config)#default-router 172.16.100.1
DLS_1(dhcp-config)#network 172.16.200.0 255.255.255.0
DLS_1(dhcp-config)#default-router 172.16.200.1
DLS_1(dhcp-config)#
```

:ALS

```
C:\Users\netlab12>ipconfig

Windows IP Configuration

Ethernet adapter Ethernet 2:

    Connection-specific DNS Suffix  . : 
    Link-local IPv6 Address . . . . . : fe80::c9d2:eca3:c1aa:23ca%7
    IPv4 Address. . . . . : 192.168.56.1
    Subnet Mask . . . . . : 255.255.255.0
    Default Gateway . . . . . : 

Ethernet adapter Ethernet:

    Connection-specific DNS Suffix  . : 
    Link-local IPv6 Address . . . . . : fe80::a940:e449:5fbe:a931%5
    Autoconfiguration IPv4 Address. . : 169.254.169.49
    Subnet Mask . . . . . : 255.255.0.0
    Default Gateway . . . . . : 172.16.200.1

C:\Users\netlab12>
```

```
C:\Users\netlab12>ipconfig
```

# Windows IP Configuration

## Ethernet adapter Ethernet 2:

```
Connection-specific DNS Suffix . :  
Link-local IPv6 Address . . . . . : fe80::c9d2:eca3:c1aa:23ca%7  
IPv4 Address. . . . . : 192.168.56.1  
Subnet Mask . . . . . : 255.255.255.0  
Default Gateway . . . . . :
```

## Ethernet adapter Ethernet:

```
Connection-specific DNS Suffix . :  
Link-local IPv6 Address . . . . . : fe80::a940:e449:5fbe:a931%5  
IPv4 Address. . . . . : 172.16.200.101  
Subnet Mask . . . . . : 255.255.255.0  
Default Gateway . . . . . : 172.16.200.1
```