

1. CAG Relay Model (12, 13, 14 , 17, 19, 32, 33, 34, 37, 39)

The relay type model contains all elements of the actual relay. However, in the application of the relay, please consider the following:

1. For the CAG 3x relays should be selected dependent on the CT connection ("2phase + Earth" or "3phase") the corresponding relay type.
2. The current settings are in the model in p.u. instead of percent (%)