



POWERFACTORY

PowerFactory 2021

Technical Reference

DigSILENT F59 Overvoltage Generic Relay

PF2021

POWER SYSTEM SOLUTIONS
MADE IN GERMANY

Publisher:

DlgSILENT GmbH
Heinrich-Hertz-Straße 9
72810 Gomaringen / Germany
Tel.: +49 (0) 7072-9168-0
Fax: +49 (0) 7072-9168-88
info@digsilent.de

Please visit our homepage at:
<https://www.digsilent.de>

Copyright © 2021 DlgSILENT GmbH

All rights reserved. No part of this
publication may be reproduced or
distributed in any form without written
permission of DlgSILENT GmbH.

November 15, 2019
PowerFactory 2021
Revision 924

Contents

1	F59 Overvoltage	1
1.1	Intent	1
1.2	Functionality	1
1.3	Inputs	1
1.4	Available Units	1
1.5	Outputs	2

1 F59 Overvoltage

1.1 Intent

To simulate a set of phase over voltage protective element.

1.2 Functionality

The *F59 overvoltage* generic relay model simulates a set of phase-phase and phase-ground over voltage elements. In each group of elements (i.e. the phase-phase elements) one inverse/definite time and 3 definite time elements are available.

1.3 Inputs

- One 3 phase VT ("Phase Vt" block, *StaVt* class).

1.4 Available Units

Measurement

- One 3phase measurement element ("Measurement" block, *RMS Calculation* enabled, *Filter* disabled [*RelMeasure* class]).
- One 3phase delta measurement element ("Measurement delta" block, *RMS Calculation* enabled, *Filter* disabled [*RelMeasure* class]).

Protective elements

- One inverse/definite time phase-phase overvoltage element ("Upp>" block [*RelChar* class]).
- Three definite time phase-phase overvoltage elements ("Upp>>", "Upp>>>" and "Upp>>>>" block [*RelUlim* class]).
- One inverse/definite time phase-ground overvoltage element ("Upn>" block [*RelChar* class]).
- Three definite time phase-ground overvoltage elements ("Upn>>", "Upn>>>" and "Upn>>>>" block [*RelUlim* class]).

Output logic

- One relay trip element ("Output logic" block, *RelLogdip* class).

1.5 Outputs

- *yout* associated by default to any protective element trip.
- *yout1* associated by default to any phase-phase overvoltage protective element trip.
- *yout2* associated by default to any phase-ground overvoltage protective element trip.

The output logic can be configured in the "Logic" tab page of the "Output Logic" block.