

The logo for Silent DIG, featuring the word "SILENT" in white capital letters above the word "DIG" in red capital letters, all contained within a white square with a red diagonal stripe.The background of the slide features a complex electrical grid diagram with various components like buses, lines, and transformers, overlaid on a blue wireframe sphere. The bottom half of the slide is a solid red color.

POWERFACTORY

PowerFactory 2021

Technical Reference

Alstom EPAC starting unit

RelFdeta1st, TypFdeta1st

POWER SYSTEM SOLUTIONS
MADE IN GERMANY

PF2021

Publisher:

DlgSILENT GmbH
Heinrich-Hertz-Straße 9
72810 Gomaringen / Germany
Tel.: +49 (0) 7072-9168-0
Fax: +49 (0) 7072-9168-88
info@digsilent.de

Please visit our homepage at:
<https://www.digsilent.de>

Copyright © 2020 DlgSILENT GmbH

All rights reserved. No part of this
publication may be reproduced or
distributed in any form without written
permission of DlgSILENT GmbH.

December 1, 2020
PowerFactory 2021
Revision 1

Contents

1 General Description	1
1.1 Available settings	1
Alstom EPAC	1
Alstom PXLN	1
2 Features & User interface	2
2.1 Alstom EPAC Starting Logic (RelFdeta1st)	2
2.1.1 Basic data	2
2.1.2 Overcurrent	3
2.1.3 Underimpedance	5
2.1.4 Ground Detection	7
2.1.5 Phase preference Logic	9
Phase preferences for Ph-Ph-E Faults	9
2.1.6 Description	9
2.2 Alstom EPAC Starting Type(TypFdeta1st)	10
2.2.1 Basic Data	10
2.2.2 Ground Detection	10
2.2.3 Overcurrent	10
2.2.4 Underimpedance	10
2.2.5 Common	11
3 Integration in the relay scheme	11
A Parameter Definitions	12
A.1 Alstom EPAC Starting block Type (TypFdeta1st)	12
A.2 Alstom EPAC Starting Element (RelFdeta1st)	13
B Signal Definitions	14
List of Figures	15
List of Tables	16

1 General Description

The Alstom EPAC Starting block implements the fault detection logic available in the following relay models

- Alstom EPAC 3000
- Alstom EPAC 3100
- Alstom EPAC 3500

The following logic of fault detection are available and can be set as always enabled, user configurable or disabled:

- *Overcurrent* $I >$
- *Impedance* Z

A specific earth fault detection logic is always active.

1.1 Available settings

Alstom EPAC :

The *Alstom EPAC* starting block defines:

- An overcurrent starting with double current threshold.
- An underimpedance starting logic
- An earth detection logic with zero sequence current threshold and zero sequence voltage threshold .
- Loop preferences for 2 phase-ground fault.

Alstom PXLN :

The *Alstom PXLN* starting block defines:

- an overcurrent starting logic with double current threshold
- An earth detection logic with zero sequence current threshold and zero sequence voltage threshold .
- Loop preferences for 2 phase-ground fault.

The *Alstom PXLN* overcurrent starting logic is identical to the Alstom EPAC overcurrent starting logic. For this reason the “Alstom EPAC Starting” element can be used simply disabling the *Impedance Z* logic.

2 Features & User interface

2.1 Alstom EPAC Starting Logic (RelFdetaIst)

The user can change the block settings using the “Alstom EPAC Starting” dialogue (“RelFdetaIst” class). The dialogue consists of six tab pages: *Basic Data*, *Ground Detection*, *Overcurrent*, *Underimpedance*, *Phase Preference Logic*, and *Description*.

2.1.1 Basic data

The “Basic Data” tab page contains the block name, a link to the relevant starting type object, two check buttons which allow to select the active starting logic between the logic available for the given model, one combo box which allows to define the power system grounding (*Solidly earthed*, *Compensated* or *Isolated*) and three edit boxes which define the line length and positive sequence impedance values. Multiple starting logic can be active at the same time. In Figure 2.1 the whole starting logic is showed.





Figure 2.1: DlgSILENT Alstom EPAC starting logic



2.1.2 Overcurrent

When the overcurrent starting is available and the *Overcurrent I* > checkbox is set the phase currents are compared with the *S1* (“S1” parameter) and the *S2* (“S2” parameter) phase current threshold. The phase currents are evaluated and the following quantities are calculated

- *Greatest phase current.*
- *Smallest phase current.*
- *Middle phase current* (the phase current which is not the Greater nor the Smallest phase current).

The following rules are applied to detect the fault type and the loop which must be declared as started:

- if the *Greatest phase current* is greater than “S2” and the *Smallest phase current* is greater than “S1” then a *Three Phase* fault is declared.
- if the *Greatest phase current* is greater than “S2” and the *Middle phase current* is greater than “S1” and an earth fault has been detected by the *Ground Detection* logic then a *Phase-Phase-Ground* fault is declared.
- if the *Greatest phase current* is greater than “S2” and the *Middle phase current* is greater than “S1” and no earth fault has been detected by the *Ground Detection* logic then a *Phase-Phase* fault is declared.
- if the *Greatest phase current* is greater than “S2” and the *Middle phase current* is smaller than “S1” then a *Single Phase Ground* fault is declared.

For any kind of detected fault (except for the *Three Phase* fault), the phase which is the Greatest phase current and the phase which is the *Middle phase current* are used to calculate the started loops.





Figure 2.2: Alstom EPAC Greatest, Smallest and Middle Phase Current selection logic







Figure 2.3: *DigSILENT* Alstom EPAC Overcurrent starting logic



2.1.3 Underimpedance

When the underimpedance starting is available and the *Impedance Z* checkbox has been set, if the *Overcurrent* starting logic didn't detect any fault, the phase impedances and the phase-phase impedances are evaluated using the distance starting zone shapes shown in Figure 2.5, Figure 2.6, and Figure 2.7.

Different distance starting zone shapes are active for the phase faults (see Figure 2.5), for the earth faults for the first distance protection zone (see Figure 2.6) and for the earth faults for the other distance protection zones (see Figure 2.7).

The distance starting zone shapes are defined using the “Z reach” (“Zmax” parameter) setting and the “+R reach” (“Rmax” parameter) setting of the polygonal element pointed in the *Under-impedance* tab page of the “Alstom EPAC Starting Type” by “Z01 Reference block” (“pz01referenceblock”) and “Z02 Reference block” (“pz02referenceblock”).





Figure 2.4: DlgSILENT Alstom EPAC Underimpedance starting logic






Figure 2.5: *DlgSILENT* The Underimpedance phase starting detection zone




Figure 2.6: *DlgSILENT* The Underimpedance ground starting detection zone 1




Figure 2.7: DigSILENT The Underimpedance ground starting detection zone > 1

The unique difference between the

2.1.4 Ground Detection

The ground detection logic use one zero sequence current threshold and one zero sequence voltage threshold to detect the ground fault condition.

A ground fault is declared if the zero sequence current is greater than "Residual current threshold" ("slr" parameter) edit box value or the zero sequence voltage is greater than "Residual voltage threshold" ("sUr parameter") edit box value.

Just below the two mentioned edit boxes the "Tripping on maximum residual voltage" ("iutripen") check box allows to enable/disable the operation of the "yout" output signal when the the zero sequence voltage is greater than "Residual voltage threshold" ("sUr") for a time greater than "Tripping time delay" ("Temp").

The earth detection logic is showed in Figure 2.8





Figure 2.8: *DlgSILENT Alstom EPAC Earth detection starting logic*



2.1.5 Phase preference Logic

The *Fault Loop* logic defines additional loop selection preferences in case of Phase-Phase-Ground.

The “Enable” (“ienabled” parameter) check box allows to enable or disable the *Phase preference Logic*.

Phase preferences for Ph-Ph-E Faults (“PhasePref” parameter) It’s the logic applied when a Phase-Phase-Ground fault has been detected. One between the following options can be selected:

- *A(C) acyclic*
- *C(A) acyclic*
- *A(B) acyclic*
- *B(A) acyclic*
- *B(C) acyclic*
- *C(B) acyclic*
- *A(C) cyclic*
- *C(A) cyclic*

Table 2.1: Started loop applying the Phase Preferences logic to a Ph-Ph-Grnd fault

FaultType	A(C) acyclic	C(A) acyclic	A(B) acyclic	B(A) acyclic	B(C) acyclic	C(B) acyclic	A(C) cyclic	C(A) cyclic
A-B-Grnd	A	A	A	B	B	B	B	A
A-C-Grnd	A	C	A	A	C	C	A	C
B-C-Grnd	C	C	B	B	B	C	C	B

2.1.6 Description

The *Description* tab page can be used to insert some information to identify the Alstom EPAC Starting protective element (both with a generic string and with an unique textual string similar to the *Foreign Key* approach used in the relational databases) and to identify the source of the data used to create it.

2.2 Alstom EPAC Starting Type(TypFdetaIst)

The *Alstom EPAC Starting* block main characteristics must be configured in the “Alstom EPAC Starting Type” dialogue (*TypFdetaIst* class). The dialogue contains five tab pages: *Basic Data*, *Ground Detection*, *Overcurrent*, *Underimpedance*, and *Common*.

2.2.1 Basic Data

The *Basic data* tab page contains the “Model” combobox (“prodname” parameter) which allows to select the active “Alstom EPAC Starting” type. The following types are available:

- EPAC 3000
- EPAC 3100
- EPAC 3500

The “Model” combobox is used only for documentation purpose, the implemented starting logic is unique and is not affected by the selected model.

The two combo boxes *Overcurrent I > Configuration* (“iovercconf” parameter) and *Underimpedance* (“iimpedconf” parameter) allow to define which starting types are shown in the “Alstom EPAC Starting” dialogue (“RelFdetaIst” class). Each combobox contains the following options

- *Disabled*
- *Enabled*
- *User Configurable*

When the *Disabled* option is selected the relevant check box is hidden in the “Basic Data” tab page of the “Alstom EPAC Starting” dialogue. When the *Enabled* option is selected the relevant check box is showed as checked and cannot be modified. When the *User Configurable* option is selected the relevant check box is showed and can be checked or unchecked.

2.2.2 Ground Detection

The *Ground Detection* tab page contains the range definition for the element parameters available in the “Ground Detection” tab page of the “Alstom EPAC Starting” dialogue.

2.2.3 Overcurrent

The *Overcurrent* tab page contains the range definition for the element parameters available in the “Overcurrent” tab page of the “Alstom EPAC Starting” dialogue.

2.2.4 Underimpedance

The *Underimpedance* tab page contains the range definition for the element parameters available in the “Underimpedance” tab page of the “Alstom EPAC Starting” dialogue.

A Parameter Definitions

A.1 Alstom EPAC Starting block Type (TypFdeta1st)

Table A.1: Input parameters of Alstom EPAC Starting type (TypFdeta1st)

Parameter	Description	Unit
loc.name	Name assigned by the user to the block type	Text
prodname	The starting block type (supported types: <i>EPAC 3000</i> , <i>EPAC 3100</i> , <i>EPAC 3500</i>)	Text
rlinelen	Range of the <i>Line Length</i> variable	Text
rR1	Range of the Line positive sequence reactance	Text
rX1	Range of the Line positive sequence resistance	Text
ioverccconf	Flag defining if the overcurrent starting is always <i>Enabled</i> , <i>Disabled</i> or is <i>User Configurable</i>	Integer
iimpedconf	Flag defining how the impedance starting is always <i>Enabled</i> , <i>Disabled</i> or is <i>User Configurable</i>	Integer
rSIr	Range of the <i>Residual Current Threshold</i> used for the earth fault detection	Text
rSUr	Range of the <i>Residual Voltage Threshold</i> used for the earth fault detection	Text
rTemp	Range of the <i>Tripping Time Delay</i> used for the earth fault detection	Text
rS1	Range of the first phase overcurrent starting threshold	Text
rS2	Range of the second phase overcurrent starting threshold	Text
pz01refblock	Pointer to an EPAC type polygonal element which defines the forward direction Z reach and the R reach of the impedance starting	PF object pointer
pz02refblock	Pointer to an EPAC type polygonal element which defines the reverse direction Z reach	PF object pointer
rX01	Range of the Reactance which define the angle of the starting earth impedance shape (zone 1)	Text
rX02	Range of the Reactance which define the angle of the starting earth impedance shape (zone > 1)	Text
rR01	Range of the Resistance which define the angle of the starting earth impedance shape (zone 1)	Text
rR02	Range of the Resistance which define the angle of the starting earth impedance shape (zone > 1)	Text
Ts	Pick up time, its the time spent measuring the currents in the load flow and short circuit calculation and in the RMS simulation	Seconds
Tr	Reset time, its the delay with which the block reset the trip outputs after that the start condition is not anymore verified	Seconds
KrRX	Underimpedance reset ratio	Real number
KrI	Current Starting reset ratio	Real number

A.2 Alstom EPAC Starting Element (RelFdeta1st)

Table A.2: Input parameters of Alstom EPAC Starting element (*RelFdeta1st*)

Parameter	Description	Unit
loc_name	Name assigned by the user to the block	Text
ioverc	Flag to enable the current starting logic	Integer
iimped	Flag to enable the underimpedance starting logic	Integer
ineutearth	Earthing system (<i>Solidly Earthed, Compensated, Insulated</i>) (documentation purpose only)	Integer
linelen	The <i>Line Length</i> variable (documentation purpose only)	Text
R1	The Line positive sequence reactance (used for the forward and reverse reach of the impedance zone starting)	Text
X1	The Line positive sequence resistance	Text
SIr	The <i>Residual Current Threshold</i> used for the earth fault detection	Text
SUr	The <i>Residual Voltage Threshold</i> used for the earth fault detection	Text
Temp	The <i>Tripping Time Delay</i> used for the earth fault detection	Text
S1	The first phase overcurrent starting threshold	Text
S2	The second phase overcurrent starting threshold	Text
X01	The Reactance which define the angle of the starting earth impedance shape (zone 1)	Text
X02	The Reactance which define the angle of the starting earth impedance shape (zone > 1)	Text
R01	The Resistance which define the angle of the starting earth impedance shape (zone 1)	Text
R02	The Resistance which define the angle of the starting earth impedance shape (zone > 1)	Text
ienabled	Flag to enable/disable the Ph-Ph-grnd fault phase preferences	Integer
PhasePref	Phase preferences logic for a Ph-Ph-grnd fault	Text

B Signal Definitions

Table B.1: Input/output signals of the Alstom EPAC Starting element (*CalFdeta1st*)

Name	Description	Unit	Type	Model
R.A	Phase A loop resistance	Secondary Ohms	IN	Any
X.A	Phase A loop inductance	Secondary Ohms	IN	Any
R.B	Phase B loop resistance	Secondary Ohms	IN	Any
X.B	Phase B loop inductance	Secondary Ohms	IN	Any
R.C	Phase C loop resistance	Secondary Ohms	IN	Any
X.C	Phase C loop inductance	Secondary Ohms	IN	Any
RI.A	Phase A - Phase B loop resistance	Secondary Ohms	IN	Any
XI.A	Phase A Phase B loop inductance	Secondary Ohms	IN	Any
RI.B	Phase B - Phase C loop resistance	Secondary Ohms	IN	Any
XI.B	Phase B Phase C loop inductance	Secondary Ohms	IN	Any
RI.C	Phase C - Phase A loop resistance	Secondary Ohms	IN	Any
XI.C	Phase C Phase A loop inductance	Secondary Ohms	IN	Any
I.A	Phase A current	Secondary Amperes	IN	Any
I.B	Phase B current	Secondary Amperes	IN	Any
I.C	Phase C current	Secondary Amperes	IN	Any
II.A	Phase A - Phase B current	Secondary Amperes	IN	Any
II.B	Phase B - Phase C current	Secondary Amperes	IN	Any
II.C	Phase C - Phase A current	Secondary Amperes	IN	Any
I0x3	Zero sequence current	Secondary Amperes	IN	Any
I2x3	Negative sequence current	Secondary Amperes	IN	Any
wlr.A	Phase A current real part	Secondary Amperes	IN	Any
wli.A	Phase A current imaginary part	Secondary Amperes	IN	Any
wlr.B	Phase B current real part	Secondary Amperes	IN	Any
wli.B	Phase B current imaginary part	Secondary Amperes	IN	Any
wlr.C	Phase C current real part	Secondary Amperes	IN	Any
wli.C	Phase C current imaginary part	Secondary Amperes	IN	Any
wl0x3r	Zero sequence current real part	Secondary Amperes	IN	Any
wl0x3i	Zero sequence current imaginary part	Secondary Amperes	IN	Any
U.A	Phase A voltage	Secondary Volts	IN	Any
U.B	Phase B voltage	Secondary Volts	IN	Any
U.C	Phase C voltage	Secondary Volts	IN	Any
U0x3	Zero sequence voltage	Secondary Volts	IN	Any
wUr.A	Phase A voltage real part	Secondary Volts	IN	Any
wUi.A	Phase A voltage imaginary part	Secondary Volts	IN	Any
wUr.B	Phase B voltage real part	Secondary Volts	IN	Any
wUi.B	Phase B voltage imaginary part	Secondary Volts	IN	Any
wUr.C	Phase C voltage real part	Secondary Volts	IN	Any
wUi.C	Phase C voltage imaginary part	Secondary Volts	IN	Any
yloop	ID of the loop from which the fault must be removed		OUT	Any
ystart	Starting signal/ starting time	Seconds (or 1/0 RMS/EMT simulation)	OUT	Any
ysall	Starting signal/ starting time for all loops (3ph fault)	Seconds (or 1/0 RMS/EMT simulation)	OUT	Any
yout	Trip signal (Zero sequence voltage greater than "sUR") for a time greater than "Temp"	Seconds (or 1/0 RMS/EMT simulation)	OUT	Any
yloop1E	ID of the loop of the first earth zone from which the fault must be removed		OUT	Any
ystart1E	Starting signal/ starting time of the first earth zone	Seconds (or 1/0 RMS/EMT simulation)	OUT	Any
ysall1E	Starting signal/ starting time for all loops (3ph fault) of the first earth zone	Seconds (or 1/0 RMS/EMT simulation)	OUT	Any

List of Figures

2.1	<i>DlgSILENT</i> Alstom EPAC <i>starting logic</i>	2
2.2	Alstom EPAC <i>Greatest, Smallest and Middle Phase Current selection logic</i> . . .	3
2.3	<i>DlgSILENT</i> Alstom EPAC Overcurrent starting logic	4
2.4	<i>DlgSILENT</i> Alstom EPAC <i>Underimpedance starting logic</i>	5
2.5	<i>DlgSILENT</i> The <i>Underimpedance phase starting detection zone</i>	6
2.6	<i>DlgSILENT</i> The <i>Underimpedance ground starting detection zone 1</i>	6
2.7	<i>DlgSILENT</i> The <i>Underimpedance ground starting detection zone > 1</i>	7
2.8	<i>DlgSILENT</i> Alstom EPAC <i>Earth detection starting logic</i>	8
3.1	<i>DlgSILENT</i> Connection scheme of a <i>Alstom EPAC Starting “RelFdetalst”</i> block. .	11

List of Tables

2.1	Started loop applying the Phase Preferences logic to a Ph-Ph-Grnd fault	9
A.1	Input parameters of Alstom EPAC Starting type (<i>TypFdetaIst</i>)	12
A.2	Input parameters of Alstom EPAC Starting element (<i>RelFdetaIst</i>)	13
B.1	Input/output signals of the Alstom EPAC Starting element (<i>CalFdetaIst</i>)	14