



POWERFACTORY

PowerFactory 2021

Technical Reference

DigSILENT F21 Distance Mho Generic Relay

PF2021

POWER SYSTEM SOLUTIONS
MADE IN GERMANY

Publisher:

DlgSILENT GmbH
Heinrich-Hertz-Straße 9
72810 Gomaringen / Germany
Tel.: +49 (0) 7072-9168-0
Fax: +49 (0) 7072-9168-88
info@digsilent.de

Please visit our homepage at:
<https://www.digsilent.de>

Copyright © 2021 DlgSILENT GmbH

All rights reserved. No part of this
publication may be reproduced or
distributed in any form without written
permission of DlgSILENT GmbH.

May 6, 2019
PowerFactory 2021
Revision 892

Contents

1	F21 Distance Mho	1
1.1	Intent	1
1.2	Functionality	1
1.3	Inputs	1
1.4	Available Units	1
1.5	Outputs	2

1 F21 Distance Mho

1.1 Intent

To simulate a set of distance phase and ground mho elements with overcurrent/voltage restraint overcurrent starting.

1.2 Functionality

The *F21 Distance Mho* generic relay models 5 phase mho and 5 ground mho, a polarizing element, an overcurrent starting element, one distance directional element and one load encroachment element. The starting element can trigger a delayed back up trip.

The polarizing method is user configurable; one of the following methods can be used:

- Self.
- Cross Quadrature.
- Cross (Quad L-L).
- Positive sequence.
- Self, Ground compensated.

The distance elements can operate a single phase (for phase-ground faults), a double phase (for phase-phase faults) or a 3 phase trip.

The POTT (Permissive Overreach Transfer Trip) and the PUTT (Permissive Underreach Transfer Trip) distance protection schemes are supported. The scheme can be activated setting uequal to *TRIP* the *PUTT* and the *POTT* variable in the "Logic" tab page of the "Output Logic" block.

The *F21 Distance Mho* generic relay can be associated to the following generic relays:

- F50BF Breaker failure.
- F68 OOS/Power Swing.
- F79 Recloser.

1.3 Inputs

- One 3 phase CT ("Phase Ct" block, [*StaCt* class]).
- One 3 phase VT ("Phase Vt" block, [*StaVt* class]).

1.4 Available Units

Measurement

- One 3phase measurement element ("Measurement" block, *RMS Calculation* enabled, *Filter* enabled [*RelMeasure* class]).

Protective elements

- One polarizing element ("Polarizing" block, [*RelZpol* class]).
- One starting element ("Starting" block, [*RelFdetect* class]).
- One directional element ("Directional" block, [*RelDisdir* class]).
- One load encroachment element ("Load encroachment", [*RelDisloadenc* class]).
- Five 3 phase-phase loop mho elements ("Ph-Ph Mho 1", "Ph-Ph Mho 2", "Ph-Ph Mho 3", "Ph-Ph Mho 4" and "Ph-Ph Mho 5" block, [*RelDismho* class]).
- Five 3 phase-ground loop mho elements ("Ph-Grnd Mho 1", "Ph-Grnd Mho 2", "Ph-Grnd Mho 3", "Ph-Grnd Mho 4" and "Ph-Grnd Mho 5" block, [*RelDismho* class]).
- Five timers ("Mho 1 Delay", "Mho 2 Delay", "Mho 3 Delay", "Mho 4 Delay", and "Mho 5 Delay" block, [*RelTimer* class]).
- One delayed trip timer triggered by the starting signal ("Starting Backup trip delay" block, [*RelTimer* class]).

Output logic

- One output block ("Output logic", *RelLogdip* class).

The output logic can be configured in the "Logic" tab page of the "Output Logic" block.

1.5 Outputs

- *yout* associated by default to any protective element trip trigs a 3 phase trip.
- *yout_A* associated by default to any protective element trip trigs a phase A trip (*single phase* and *two phase trip* only).
- *yout_B* associated by default to any protective element trip trigs a phase B trip (*single phase* and *two phase trip* only).
- *yout_C* associated by default to any protective element trip trigs a phase C trip (*single phase* and *two phase trip* only).