



POWERFACTORY

PowerFactory 2021

Technical Reference

ABB RED 670

POWER SYSTEM SOLUTIONS
MADE IN GERMANY

F2021

Publisher:

DlgSILENT GmbH
Heinrich-Hertz-Straße 9
72810 Gomaringen / Germany
Tel.: +49 (0) 7072-9168-0
Fax: +49 (0) 7072-9168-88
info@digsilent.de

Please visit our homepage at:
<https://www.digsilent.de>

Copyright © 2021 DlgSILENT GmbH

All rights reserved. No part of this
publication may be reproduced or
distributed in any form without written
permission of DlgSILENT GmbH.

November 15, 2019
PowerFactory 2021
Revision 924

Contents

1	Model information	1
2	General description	1
3	Supported features	2
3.1	Measurement and acquisition	2
3.1.1	Available Units and Input Signals	2
3.1.2	Functionality	3
3.1.3	Data input	3
3.2	Main Relay protective elements	4
3.2.1	Available Units	4
3.2.2	Functionality	4
3.2.3	Data input	4
3.3	PDIF 87 sub relay	6
3.3.1	Available Units	6
3.3.2	Functionality	7
3.3.3	Data input	8
3.4	PIOC sub relay	11
3.4.1	Available Units	11
3.4.2	Functionality	11
3.4.3	Data input	11
3.5	PTOC 51N67N sub relay	12
3.5.1	Available Units	12
3.5.2	Functionality	12
3.5.3	Data input	13
3.6	PTOC 51_67 sub relay	14
3.6.1	Available Units	14
3.6.2	Functionality	14
3.6.3	Data input	15
3.7	PTOF PTUF PFRC 81 sub relay	16

3.7.1	Available Units	16
3.7.2	Functionality	16
3.7.3	Data input	16
3.8	PTUV 27 PTOV 59/59N sub relay	18
3.8.1	Available Units	18
3.8.2	Functionality	18
3.8.3	Data input	19
3.9	RPSB 78 sub relay	20
3.9.1	Available Units	20
3.9.2	Functionality	20
3.9.3	Data input	20
3.10	SC Dir-Z sub relay	21
3.10.1	Available Units	21
3.10.2	Functionality	21
3.10.3	Data input	21
3.11	ZMCPDIS sub relay	23
3.11.1	Available Units	23
3.11.2	Functionality	23
3.11.3	Data input	23
3.12	ZMHPDIS sub relay	25
3.12.1	Available Units	25
3.12.2	Functionality	25
3.12.3	Data input	25
3.13	ZMQPDIS sub relay	27
3.13.1	Available Units	27
3.13.2	Functionality	27
3.13.3	Data input	27
3.14	Output logic	29
3.14.1	Available Units	29
3.14.2	Functionality	29
3.14.3	Data input	29

4	Features not supported	30
4.1	Main features	30
4.2	PTOC 51N67N sub relay	30
4.3	PTOC 51_67 sub relay	30
4.4	PTUV 27 PTOV 59/59N sub relay	31
4.5	SC Dir-Z sub relay	31
4.6	ZMHPDIS sub relay	31
4.7	ZMQPDIS sub relay	31
5	References	32

1 Model information

Manufacturer ABB

Model RED 670

Variants The ABB RED 670 PowerFactory relay model can be used to simulate any version of the ABB RED 670 relay. However please consider that the model has been implemented with the features available in the V1.1 firmware version.

2 General description

The ABB RED 670 line distance protection terminal is a protective relay for HV and EHV line distance protection applications with additional differential functions. Special features to protect series compensated lines are also available. Additional protection functionality includes phase overcurrent, residual current, frequency and voltage functions.

The ABB RED 670 PowerFactory relay model consists of a main relay model and the following eleven sub relays:

- PDIF 87 (low and high impedance differential function)
- PIOC (instantaneous overcurrent functions)
- PTOC 51N67N (inverse time residual over current function)
- PTOC 51_67 (inverse time phase over current function)
- PTOF PTUF PFRC 81 (frequency function)
- PTUV 27 PTOV 59/59N (voltage function)
- RPSB 78 (power swing detection function)
- SC Dir-Z (directional logic for series compensated line elements)
- ZMCPDIS (polygonal distance function for series compensated line)
- ZMHPDIS (mho distance function)
- ZMQPDIS (polygonal distance function)

The ABB RED 670 PowerFactory relay model has been implemented trying to simulate the most commonly used protective functions.

The main relay contains the measurement and acquisition units, the starting element, the polarizing elements, the directional element for the distance elements for no distance compensated lines, the output logic and all other sub relays.

The model implementation has been based on the information available in the relay manual [1] .

3 Supported features

3.1 Measurement and acquisition

The voltage and the current are measured by one three phase current transformer ("Ct" block) and one three phase voltage transformer ("Vt" block).

Four measurement units ("Measure", "Delta Measure", "Measure Seq" and "2nd harm Measure" block) are fed by this CT and this VT.

The current values measured by the remote relay(s) are transferred to the relay by a set of input signals.

3.1.1 Available Units and Input Signals

- Two three phase current transformers ("Ct" and "Remote Ct" block).
- One three phase voltage transformer ("Vt" block).
- One three phase measurement block calculating both the current and voltage values ("Measure" block).
- One three phase measurement block calculating the 2nd harmonic current values ("2nd harm Measure" block).
- One three phase measurement block calculating the phase to phase currents and the phase to phase voltages ("Delta Measure" block).

The following relay input signals are available:

- ExtRel1_lphase (External relay 1 phase current)
- ExtRel2_lphase (External relay 2 phase current)
- ExtRel3_lphase (External relay 3 phase current)
- ExtRel4_lphase (External relay 4 phase current)
- ExtRel5_lphase (External relay 5 phase current)
- ExtRel1_I2 (External relay 1 negative sequence current)
- ExtRel2_I2 (External relay 2 negative sequence current)
- ExtRel3_I2 (External relay 3 negative sequence current)
- ExtRel4_I2 (External relay 4 negative sequence current)
- ExtRel5_I2 (External relay 5 negative sequence current)

3.1.2 Functionality

The input current and voltage values are sampled at 40 samples/cycle; for each signal the average values are calculated using groups of 2 samples. The average values are processed by a DFT filter, operating over a cycle, which then calculates the voltage and current values used by the protective elements.

The "Delta Measure" block calculates the current and voltage ph-ph values used by the phase-phase loop distance elements.

3.1.3 Data input

The nominal current and the nominal voltage values MUST be entered in all the measurement blocks.

3.2 Main Relay protective elements

The starting element, the polarizing elements, the load encroachment element and the directional element for the lines without series compensation are working together to simulate the ABB RED 670 distance functionalities.

3.2.1 Available Units

- One starting unit implementing the phase selection logic ("Phase Selector" block).
- One load encroachment element ("PHS Load Area" block).
- One directional element ("Dir-Z" block).
- Two polarizing blocks ("Polarizing" and "Polarizing20" block). Please note that no user input is usually needed in these blocks.

3.2.2 Functionality

Starting element The ABB RED 670 relay model starting element ("Phase Selector" block) simulates the relay *FDPSPDIS* phase selection logic function which follows the impedance fault detection criteria. Moreover the phase preference setting is available ('Phase Preference Logic' tab page).

Load encroachment element The relay model load encroachment element ("PHS Load Area" block) reproduces the load encroachment characteristics which in the relay are part of the *FDPSPDIS* phase selection logic function. Please notice that the relationship between the load encroachment relay settings and the model load encroachment element parameters is showed together.

Directional element The directional element ("Dir-Z" block) is based on the use of a positive-sequence voltage for the respective fault loop. The polarizing voltage is the sum of 80% of the actual positive sequence voltage and of 20% of the positive voltage calculated 100 ms before. It simulates the *ZDRDIR* relay function. This directional characteristic is not used by the distance elements present inside the "ZMCPDIS" sub relay but is used by the "ZMQPDIS" sub relay distance elements.

Polarizing elements The polarizing elements are calculating the voltage vectors used by the directional element. Two elements are available: "Polarizing" is calculating the actual positive sequence voltage, "Polarizing20" is working as a circular buffer storing the positive sequence voltage calculated during the last 100 ms and returning as output the positive voltage calculated 100 ms before.

3.2.3 Data input

The relationships between the relay settings and the model parameters can be found in the following tables (the relay model parameter names are listed between brackets):

Starting element :

Address	Relay Setting	Model block	Model setting	Note
	INBlockPP	Starting	INBlockPP (INBlockPP)	"Phase/ground fault conditions" tab page
	INReleasePE	Starting	INReleasePE (INReleasePE)	"Phase/ground fault conditions" tab page
	RLdFw	PHS Load Area	RLdFw (Rloadfw)	
	RLdRv	PHS Load Area	RLdRv (Rloadrev)	
	ArgLd	PHS Load Area	ARGLd (philoal)	
	Operation Z<	Starting	Impedance Z(iimped)	"Basic Data" tab page
	X1	Starting	X1PP (X1PP)	"Impedance Z" tab page
	X0	Starting	X0PE (X0PE)	"Impedance Z" tab page
	RFFwPP	Starting	RFPP (RFPP)	"Impedance Z" tab page
	RFRvPP	Starting	RFRvPP (RFRvPP)	"Impedance Z" tab page
	RFFwPE	Starting	RFPE (RFPE)	"Impedance Z" tab page
	RFRvPE	Starting	RFRvPE (RFRvPE)	"Impedance Z" tab page
	IMinOpPP	Starting	IMinOpPP (IMinOpPP)	"Impedance Z" tab page
	IMinOpPE	Starting	IMinOpPE (IMinOpPE)	"Impedance Z" tab page

Directional element :

Address	Relay Setting	Model block	Model setting	Note
	ArgDir	Dir-Z	Directional Angle, alpha (alpha)	
	ArgNegRes	Dir-Z	Directional Angle, phi (phi)	

Polarizing element :

No user input is required.

3.3 PDIF 87 sub relay

The "PDIF 87" sub relay implements one low impedance line differential protection 6 CT sets (*L6CPDIF* function block), one low impedance line differential protection 6 CT sets with in-zone transformers (*LT6CPDIF* function block), and a 3 phase high impedance differential protection (*HZPDIF* function block).

3.3.1 Available Units

L6CPDIF

- One 3 phase current magnitude differential element("L6CPDIF" block).
- One negative sequence current angle comparison differential element("NegSeqDiffEn L" block).
- One 3 phase definite time overcurrent element ("L6CPDIF IdiffAlarm" block).
- One 3 phase inverse time overcurrent element ("L6CPDIF IMaxAddDelay" block).
- Three 3 phase measurement elements ("L6CPDIF H1 Diff Measure", "L6CPDIF H2 Diff Measure", and "L6CPDIF H5 Diff Measure" block).
- One single phase measurement element ("NegSeqDiffEn L H1 Diff Measure" block).
- One 3 channel delayed reset element ("L6CPDIF tIdMinHigh" block).
- Three logic blocks ("L6CPDIF IdMinHigh", "L6CPDIF trip logic", and "L6CPDIF AddDelay" block).

LT6CPDIF

- One 3 phase current magnitude differential element("LT6CPDIF" block).
- One negative sequence current angle comparison differential element("NegSeqDiffEn LT" block).
- One 3 phase definite time overcurrent element ("LT6CPDIF IdiffAlarm" block).
- One 3 phase inverse time overcurrent element ("LT6CPDIF IMaxAddDelay" block).
- Six 3 phase adapters ("LT6CPDIF Adapter 1", "LT6CPDIF Adapter 2", "LT6CPDIF Adapter 3", "LT6CPDIF Adapter 4", "LT6CPDIF Adapter 5", "LT6CPDIF Adapter 6" block).
- Three 3 phase measurement elements ("LT6CPDIF H1 Diff Measure", "LT6CPDIF H2 Diff Measure", and "LT6CPDIF H5 Diff Measure" block).
- One single phase measurement element ("NegSeqDiffEn LT H1 Diff Measure" block).
- One 3 channel delayed reset element ("LT6CPDIF tIdMinHigh" block).
- Three logic blocks ("LT6CPDIF IdMinHigh", "LT6CPDIF trip logic", and "LT6CPDIF AddDelay" block).

HZPDIF

- Two three phase overvoltages element ("U> Alarm" and "U> Trip" block).
- One logic block ("Stabilizing R" block).

3.3.2 Functionality

L6CPDIF and LT6CPDIF *L6CPDIF* and *LT6CPDIF* are identical except for the "Adapters" present only in the *LT6CPDIF* protection function block. Up to 6 current inputs are supported and the relay model elements simulating *L6CPDIF* and *LT6CPDIF* can be used to model the *L3CPDIF* and the *LT3CPDIF* function block.

The current inputs are represented by a local CT and by 5 sets of relay input signals which must be connected to other instances of the ABB RED 670 relay model using a connection relay. In the RED 670 folder the "RED 670 Connection scheme" relay type can be used to create an instance of the connection relay.

The elements simulating *L6CPDIF* and *LT6CPDIF* implement two 3 phase (phase segregated) current magnitude differentials ("L6CPDIF" and "LT6CPDIF" block) each of them with double slope bias current restraint and with 2nd and 5th harmonic restraint. Two unrestrained high set differential threshold are also available in the differential block; two differential alarm thresholds can be defined in the "L6CPDIF IdiffAlarm" and in the "LT6CPDIF IdiffAlarm" block.

In each differential element the trip can be delayed using an inverse time trip characteristic set in the "L6CPDIF IMaxAddDelay" and in the "LT6CPDIF IMaxAddDelay" block; the inverse trip characteristic is activated when the current is below a user configurable threshold defined in the "L6CPDIF IMaxAddDelay" and in the "LT6CPDIF IMaxAddDelay" block.

Two fault discriminators based on the negative sequence current analysis are available to distinguish between *external* and *internal faults* ("NegSeqDiffEn L" and "NegSeqDiffEn LT" block).

In each differential element, if the fault is declared as external, an additional user configurable differential threshold ("L6CPDIF IdMinHigh" and "LT6CPDIF IdMinHigh" block) is used to temporarily (time settable in the "L6CPDIF tIdMinHigh" block) decrease the sensitivity of the differential elements.

If the fault is declared as internal and the differential current is greater than an additional user configurable differential threshold ("L6CPDIF IdMinHigh" and "LT6CPDIF IdMinHigh" block), any harmonic blocking is then overridden and a trip is declared if the differential element has started.

If the fault is declared as internal and the differential current is smaller than an additional user configurable differential threshold ("L6CPDIF IdMinHigh" and "LT6CPDIF IdMinHigh" block), the harmonic blocking is active and a trip is declared if the differential current started (it means that the differential current is greater than the double slope bias current restraint differential characteristic) and the harmonic content of the differential current is smaller than the harmonic blocking trip threshold.

The elements simulating the *L6CPDIF* protection function include six adapters, one for each current input. The relay provides only two adapters which can be set freely on two of the 6 current inputs. In the relay model only two of the six available adapters must be set at the time.

HZPDIF "U> Trip" block implements the high impedance voltage threshold. The "U> Alarm" block is an additional alarm threshold; please notice that the associated output signal doesn't

trip the power breaker and is freely available for any control logic.
The "Stabilizing R" block simulates the series resistor. The external voltage dependent resistor is not modeled and must be simulated by a separate additional element not part of this relay model.

3.3.3 Data input

The relationships between the relay settings and the model parameters can be found in the following table (the relay model parameter names are listed between brackets):

L6CPDIF and LT6CPDIF :

Address	Relay Setting	Model block	Model setting	Note
	Operation	L6CPDIF (LT6CPDIF)	Out of Service (outserv)	
	IBase	L6CPDIF (LT6CPDIF)	Differential current (Itapr)	
	IdMin	L6CPDIF (LT6CPDIF)	Release Threshold (Idiffr2)	
	IdMinHigh	L6CPDIF IdMinHigh (LT6CPDIF IdMinHigh)	Pickup Current (Ipset)	
	tIdMinHigh	L6CPDIF tIdMinHigh (LT6CPDIF tIdMinHigh)	Time Setting (Tdelay)	
	IdUnre	L6CPDIF (LT6CPDIF)	Unrestrained Differential threshold (Idiffunrestr)	
	NegSeqDiffEn	NegSeqDiffEn L (NegSeqDiffEn LT)	Out of Service (outserv)	
	NegSeqROA	NegSeqDiffEn L (NegSeqDiffEn LT)	Restraint region Angle (RestrAngle)	Set RestrAngle = 360 - 2* NegSeqROA
	MinNegSeq	NegSeqDiffEn L (NegSeqDiffEn LT)	Current Threshold (IM)	
	CrossBlockEn	L6CPDIF (LT6CPDIF)	Interlocking (h2interblock) Interlocking (h5interblock)	"Harmonic blocking" tab page "Harmonic blocking" tab page in the "Logic" tab page
	AddDelay	L6CPDIF AddDelay (LT6CPDIF AddDelay)	AddDelay	
	IMaxAddDelay	L6CPDIF IMaxAddDe- lay (LT6CPDIF IMaxAd- dDelay)	Current Setting (Ipset)	
	tDefTime	L6CPDIF IMaxAddDe- lay (LT6CPDIF IMaxAd- dDelay)	Time Shift (Tshift)	
	tMinInv	L6CPDIF IMaxAddDe- lay (LT6CPDIF IMaxAd- dDelay)	Min. Time (udeftmin)	
	CurveType	L6CPDIF IMaxAddDe- lay (LT6CPDIF IMaxAd- dDelay)	Characteristic (pcharac)	
	k	L6CPDIF IMaxAddDe- lay (LT6CPDIF IMaxAd- dDelay)	Time Dial (Tpset)	
	IdiffAlarm	L6CPDIF IdiffAlarm (LT6CPDIF IdiffAlarm)	Pickup Current (Ipset)	
	tAlarmdelay	L6CPDIF IdiffAlarm (LT6CPDIF IdiffAlarm)	Time Setting (Tset)	
	EndSection1	L6CPDIF (LT6CPDIF)	Restraint Current 1st thresh- old (Ipset1r2)	
	EndSection2	L6CPDIF (LT6CPDIF)	Restraint Current 2nd threshold (Ipset2r2)	
	SlopeSection2	L6CPDIF (LT6CPDIF)	Restrain percentage 1 (Ire- strpercent1)	
	SlopeSection3	L6CPDIF (LT6CPDIF)	Restrain percentage 2 (Ire- strpercent2)	

3 Supported features

Address	Relay Setting	Model block	Model setting	Note
	I2/I1 Ratio	L6CPDIF (LT6CPDIF)	2nd Harmonic blocking threshold (H2threshold)	"Harmonic blocking" tab page
	I5/I1 Ratio	L6CPDIF (LT6CPDIF)	5th Harmonic blocking threshold (H5threshold)	"Harmonic blocking" tab page

LT6CPDIF only :

Address	Relay Setting	Model block	Model setting	Note
	TraAOnInpCh		x ¹	Index of the adapter where to insert "RatVoltW2TraA" and "ClockNumTransA"
	RatVoltW1TraA	LT6CPDIF Adapter 1	Nominal Terminal Line-Line Voltage(LLVolt)	
	RatVoltW2TraA	LT6CPDIF Adapter x ¹	Nominal Terminal Line-Line Voltage(LLVolt)	
	ClockNumTransA	LT6CPDIF Adapter x ¹	Transformer Group(trasfgroup)	
	TraBOnInpCh		y ²	Index of the adapter where to insert "RatVoltW2TraB" and "ClockNumTransB"
	RatVoltW1TraB	LT6CPDIF Adapter 1	Nominal Terminal Line-Line Voltage(LLVolt)	Must be equal to "Rat-VoltW1TraA"
	RatVoltW2TraB	LT6CPDIF Adapter y ²	Nominal Terminal Line-Line Voltage(LLVolt)	
	ClockNumTrans	LT6CPDIF Adapter y ²	Transformer Group(trasfgroup)	

HZPDIF :

Address	Relay Setting	Model block	Model setting	Note
	Operation	Stabilizing R	Out of Service (outserv)	
	U>Alarm	U> Alarm	Pickup Voltage (Usetr)	
	tAlarm	U> Alarm	Time Delay (Tdel)	
	U>Trip	U> Trip	Pickup Voltage (Usetr)	
	SeriesResistor	Stabilizing R	R	Define the variable in the "Logic" tab page

¹x = 1,2,3,4,5,6

²y = 1,2,3,4,5,6

3.4 PIOC sub relay

The "PIOC" sub relay protective functions operate on the basis of the phase current and of the residual current. An instantaneous phase overcurrent protection and an instantaneous residual overcurrent protection can be used to clear close-in faults and for fast back-up earth fault protection. This sub relay simulates the *Instantaneous phase overcurrent protection, PHPIOC* and the *Instantaneous residual overcurrent protection EFPIOC* relay function.

3.4.1 Available Units

- One time defined phase overcurrent element ("PIOC 50" block).
- One time defined residual overcurrent element ("PIOC 50N" block).
- One output element ("PIOC Output Logic" block).

3.4.2 Functionality

The model is simulating the two instantaneous elements present in the relay protective function.

The output block is collecting the element trip signals but isn't operating the power breaker.

3.4.3 Data input

The relationships between the relay settings and the model parameters can be found in the following table (the relay model parameter names are listed between brackets):

Address	Relay Setting	Model block	Model setting	Note
	IP>>	loc Phase	Pickup Current (Ipset)	
	IN>>	loc Residual	Pickup Current (Ipset)	

3.5 PTOC 51N67N sub relay

The "PTOC 51N67N" sub relay consists of four inverse and definite time delayed residual over current functions with directional feature and 2nd harmonic blocking which can be used in solidly earthed systems to get a sensitive and fast fault clearance of phase to earth faults. This sub relay simulates the four step residual over current protection EF4PTOC relay function.

3.5.1 Available Units

- Four directional inverse characteristic zero sequence over current element ("PTOC 51N_67N 1", "PTOC 51N_67N 2", "PTOC 51N_67N 3" and "PTOC 51N_67N 4" block).
- One directional element ("Dir PTOC N" block).
- One 2nd harmonic current restrain element ("2nd harmonic Stab" block).
- One logic block ("PTOC Output Logic" block).

3.5.2 Functionality

Each inverse time element can be set as non directional, forward directional or reverse directional. The directional settings are unique and are stored in the "Dir PTOC N" block which implements a zero sequence voltage and current phase comparison direction detection logic. Each inverse time element can be configured to be controlled by the 2nd harmonic current restrain. The "PTOC 51N_67N n³" blocks include the following inverse time characteristics:

- ANSI Extremely Inverse
- ANSI Inverse.TypChatoc
- ANSI Long time Extremely Inverse.TypChatoc
- ANSI Long time Inverse.TypChatoc
- ANSI Long time Very Inverse.TypChatoc
- ANSI Moderately Inverse.TypChatoc
- ANSI Very Inverse.TypChatoc
- Definite time TCC.TypChatoc
- IEC Extremely inverse.TypChatoc
- IEC Inverse.TypChatoc
- IEC Long time inverse.TypChatoc
- IEC Normal inverse.TypChatoc
- IEC Short time inverse.TypChatoc
- IEC Very inverse.TypChatoc
- Logarithmic inverse.TypChatoc
- RI inverse.TypChatoc

³n = 1,2,3,4

The inverse time element trip characteristic equations comply with the IEC 60255-3 and the ANSI standards.

The output logic block is used only to combine the logic signals and is not operating the breaker.

3.5.3 Data input

The relationships between the relay settings and the model parameters can be found in the following table (the relay model parameter names are listed between brackets):

Address	Relay Setting	Model block	Model setting	Note
	Operation	PTOC 51N67N	Out of Service (outserv)	
	AngleRCA	Dir PTOC N	Max. Torque Angle (mtau)	In the "Voltage Polarizing " tab page
	UPolMin	Dir PTOC N	Polarizing Voltage (upolu)	In the "Voltage Polarizing " tab page
	IPolMin	Dir PTOC N	Operating Current (curopu)	In the "Voltage Polarizing " tab page
	2ndHarmStab	2nd harmonic Stab	Pickup Current (Ipset)	
	DirModen ⁴	PTOC 51N_67N n ⁴	Tripping Direction (idir)	
	Characteristn ⁴	PTOC 51N_67N n ⁴	Characteristic (pcharac)	
	INn ⁴ >	PTOC 51N_67N n ⁴	Current Setting (Ipset)	
	t1	PTOC 51N_67N n ⁴	Time Dial (Tpset)	Relay definite time delay
	k1	PTOC 51N_67N n ⁴	Time Dial (Tpset)	Relay time multiplier for the inverse characteristics
	t1Min	PTOC 51N_67N n ⁴	Min. Time(udeftimin)	
	HarmRestrinn ⁴	PTOC 51N_67N n ⁴	Release Blocking Time (Trelblock)	

The inverse time element ability to be blocked by the 2nd harmonic current restrain can be disabled setting equal to zero the "Release Blocking Time" setting in the "Blocking" tab page of the inverse time element dialog. Set the setting equal to "oo" to enable the 2nd harmonic current restrain blocking feature. The harmonic blocking is enabled by default.

⁴n = 1,2,3,4

3.6 PTOC 51_67 sub relay

The "PTOC 51_67" sub relay consists of four inverse and definite time delayed residual over current functions with directional feature and 2nd harmonic blocking which can be used for backup short circuit protection. The sub relay simulates the four step phase over current protection OC4PTOC relay function.

3.6.1 Available Units

- Four directional inverse characteristic 3 phase overcurrent element ("PTOC 51_67 1", "PTOC 51_67 2", "PTOC 51_67 3" and "PTOC 51_67 4" block).
- One 3 phase directional element ("Dir PTOC " block).
- One 2nd harmonic current restrain element ("2nd harmonic Stab" block).
- One logic block ("PTOC Output Logic" block).

3.6.2 Functionality

Each inverse time element can be set as non directional, forward directional or reverse directional. The directional settings are unique and are stored in the "Dir PTOC" block. Each inverse time element can be configured to be controlled by the 2nd harmonic current restrain.

The "PTOC 51_67 n⁵" blocks include the following inverse time characteristics:

- ANSI Extremely Inverse
- ANSI Inverse.TypChatoc
- ANSI Long time Extremely Inverse.TypChatoc
- ANSI Long time Inverse.TypChatoc
- ANSI Long time Very Inverse.TypChatoc
- ANSI Moderately Inverse.TypChatoc
- ANSI Very Inverse.TypChatoc
- Definite time TCC.TypChatoc
- IEC Extremely inverse.TypChatoc
- IEC Inverse.TypChatoc
- IEC Long time inverse.TypChatoc
- IEC Normal inverse.TypChatoc
- IEC Short time inverse.TypChatoc
- IEC Very inverse.TypChatoc
- Logarithmic inverse.TypChatoc
- RI inverse.TypChatoc

⁵n = 1,2,3,4

The inverse time element trip characteristic equations comply with the IEC 60255-3 and the ANSI standards.

The output logic block is used only to combine the logic signals and is not operating the breaker.

3.6.3 Data input

The relationships between the relay settings and the model parameters can be found in the following table (the relay model parameter names are listed between brackets):

Address	Relay Setting	Model block	Model setting	Note
	Operation	PTOC 51_67	Out of Service (outserv)	
	AngleRCA	Dir PTOC	Max. Torque Angle (mtau)	In the "Voltage Polarizing " tab page
	UPolMin	Dir PTOC	Polarizing Voltage (upolu)	In the "Voltage Polarizing " tab page
	IPolMin	Dir PTOC	Operating Current (curopu)	In the "Voltage Polarizing " tab page
	2ndHarmStab	2nd harmonic Stab	Pickup Current (Ipset)	
	DirModen ⁶	PTOC 51_67 n ⁶	Tripping Direction (idir)	
	Characteristn ⁶	PTOC 51_67 n ⁶	Characteristic (pcharac)	
	In ⁶ >	PTOC 51_67 n ⁶	Current Setting (Ipset)	
	t1	PTOC 51_67 n ⁶	Time Dial (Tpset)	Relay definite time delay
	k1	PTOC 51_67 n ⁶	Time Dial (Tpset)	Relay time multiplier for the inverse characteristics
	t1Min	PTOC 51_67 n ⁶	Min. Time(udeftimin)	
	HarmRestrinn ⁶	PTOC 51_67 n ⁶	Release Blocking Time (Trelblock)	

The inverse time element ability to be blocked by the 2nd harmonic current restrain can be disabled setting equal to zero the "Release Blocking Time" setting in the "Blocking" tab page of the inverse time element dialog. Set the setting equal to "oo" to enable the 2nd harmonic current restrain blocking feature. The harmonic blocking is enabled by default.

⁶n = 1,2,3,4

3.7 PTOF PTUF PFRC 81 sub relay

The "PTOF PTUF PFRC 81" sub relay consists of two under frequency, one over frequency and two rate of change frequency elements. This sub relay simulates two *SAPTUF*, one *SAPTOF* and two *SAPFRC* relay functions.

3.7.1 Available Units

- One frequency measurement element ("Meas Freq" block).
- Two under frequency elements ("TUF 1" and "TUF 2" block).
- Two minimum voltage elements controlling the under frequency elements("TUF1 intBlockLevel" and "TUF2 intBlockLevel" block).
- One over frequency elements ("TOF" block).
- One minimum voltage element controlling the over frequency element("TOF intBlockLevel" block).
- Two rate of change frequency elements ("FRC1" and "FRC1" block).
- Two minimum voltage elements controlling the rate of change frequency elements("FRC1 intBlockLevel" and "FRC1 intBlockLevel" block).
- One logic block ("Frequency Output Logic" block).

3.7.2 Functionality

Each frequency and rate of change frequency element is controlled by a minimum voltage threshold element

The output logic block is used only to combine the logic signals and is not operating the breaker.

3.7.3 Data input

The relationships between the relay settings and the model parameters can be found in the following table (the relay model parameter names are listed between brackets):

Address	Relay Setting	Model block	Model setting	Note
	SAPTUF Operation	TUF 1	Out of Service (outserv)	
	SAPTUF Start Frequency	TUF 1	Frequency (Fset)	
	SAPTUF IntBlockLevel	TUF1 intBlockLevel	Pickup Voltage (Uset)	
	SAPTUF TimeDlyOperate	TUF 1	Time Delay (Tdel)	
	SAPTUF Operation	TUF 2	Out of Service (outserv)	
	SAPTUF Start Frequency	TUF 2	Frequency (Fset)	
	SAPTUF IntBlockLevel	TUF2 intBlockLevel	Pickup Voltage (Uset)	
	SAPTUF TimeDlyOperate	TUF 2	Time Delay (Tdel)	
	SAPTOF Operation	TOF 1	Out of Service (outserv)	
	SAPTOF Start Frequency	TOF 1	Frequency (Fset)	
	SAPTOF IntBlockLevel	TOF1 intBlockLevel	Pickup Voltage (Uset)	
	SAPTOF TimeDlyOperate	TOF 1	Time Delay (Tdel)	
	SAPFRC Operation	TUF 1	Out of Service (outserv)	
	SAPFRC StartFreqGrad	FRC1 1	Frequency (Fset)	

3 Supported features

Address	Relay Setting	Model block	Model setting	Note
	SAPFRC IntBlockLevel	FRC1 intBlockLevel	Pickup Voltage (Uset)	
	SAPFRC tTrip	FRC1 1	Time Delay (Tdel)	
	SAPFRC Operation	TUF 1	Out of Service (outserv)	
	SAPFRC StartFreqGrad	FRC2 1	Frequency (Fset)	
	SAPFRC IntBlockLevel	FRC2 intBlockLevel	Pickup Voltage (Uset)	
	SAPFRC tTrip	FRC2 1	Time Delay (Tdel)	

3.8 PTUV 27 PTOV 59/59N sub relay

The "PTUV 27 PTOV 59/59N" sub relay consists of two inverse time 3 phase under voltage, two inverse time 3 phase over voltage and two inverse time residual overvoltage elements. The sub relay simulates one *PTUV*, 27, one *PTOV*, 59 and two *SAPFRC* relay functions.

3.8.1 Available Units

- Two inverse time 3 phase under voltage elements ("U1<" and "U2<" block).
- Two inverse time 3 phase over voltage elements ("U1>" and "U2>" block).
- Two inverse time residual over voltage elements ("U1N>" and "U2N>" block).
- One logic block ("Voltage Output Logic" block).

3.8.2 Functionality

This sub relay is providing the basic features of the relay voltage functions.

The under voltage elements support the following inverse time trip characteristics:

- Definite time (27/59-2)
- Inverse curve A (59)
- Inverse curve B (27)
- Programmable curve B (27)

The "Programmable curve B" is an additional characteristic which can be defined by the user inserting a set of voltage versus time points. Please notice that an unique user programmable characteristic is available for the two under voltage elements.

The over voltage elements support the following inverse time trip characteristics:

- Definite time (27/59-1+)
- Inverse curve A (59)
- Inverse curve B (59)
- Inverse curve C (59)
- Programmable curve C (59)

The "Programmable curve C" is an additional characteristic which can be defined by the user inserting a set of voltage versus time points. Please notice that an unique user programmable characteristic is available for the two over voltage elements.

The output logic block is used only to combine the logic signals and is not operating the breaker.

3.8.3 Data input

The relationships between the relay settings and the model parameters can be found in the following table (the relay model parameter names are listed between brackets):

Address	Relay Setting	Model block	Model setting	Note
	PTUV, 27 Operation	U1<	Out of Service (outserv)	
		U2<	Out of Service (outserv)	
	PTUV, 27 OperationStep1	U1<	Out of Service (outserv)	
	PTUV, 27 Characterist1	U1<	Characteristic (pcharac)	
	PTUV, 27 U1<	U1<	Input Setting (lpset)	
	PTUV, 27 t1	U1<	Time Dial (Tpset)	Relay definite time delay
	PTUV, 27 k1	U1<	Time Dial (Tpset)	Relay time multiplier inverse time
	PTUV, 27 OperationStep2	U2<	Out of Service (outserv)	
	PTUV, 27 Characterist2	U2<	Characteristic (pcharac)	
	PTUV, 27 U2<	U2<	Input Setting (lpset)	
	PTUV, 27 t2	U2<	Time Dial (Tpset)	Relay definite time delay
	PTUV, 27 k2	U2<	Time Dial (Tpset)	Relay time multiplier inverse time
	PTUV, 59 Operation	U1>	Out of Service (outserv)	
		U2>	Out of Service (outserv)	
	PTUV, 59 OperationStep1	U1>	Out of Service (outserv)	
	PTUV, 59 Characterist1	U1>	Characteristic (pcharac)	
	PTUV, 59 U1>	U1>	Input Setting (lpset)	
	PTUV, 59 t1	U1>	Time Dial (Tpset)	Relay definite time delay
	PTUV, 59 k1	U1>	Time Dial (Tpset)	Relay time multiplier inverse time
	PTUV, 59 OperationStep2	U2>	Out of Service (outserv)	
	PTUV, 59 Characterist2	U2>	Characteristic (pcharac)	
	PTUV, 59 U2>	U2>	Input Setting (lpset)	
	PTUV, 59 t2	U2>	Time Dial (Tpset)	Relay definite time delay
	PTUV, 59 k2	U2>	Time Dial (Tpset)	Relay time multiplier inverse time
	PTOV, 59N Operation	U1N>	Out of Service (outserv)	
		U2N>	Out of Service (outserv)	
	PTOV, 59N OperationStep1	U1N>	Out of Service (outserv)	
	PTOV, 59N Characterist1	U1N>	Characteristic (pcharac)	
	PTOV, 59N U1>	U1N>	Input Setting (lpset)	
	PTOV, 59N t1	U1N>	Time Dial (Tpset)	Relay definite time delay
	PTOV, 59N k1	U1N>	Time Dial (Tpset)	Relay time multiplier inverse time
	PTOV, 59N OperationStep2	U2N>	Out of Service (outserv)	
	PTOV, 59N Characterist2	U2N>	Characteristic (pcharac)	
	PTOV, 59N U2>	U2N>	Input Setting (lpset)	
	PTOV, 59N t2	U2N>	Time Dial (Tpset)	Relay definite time delay
	PTOV, 59N k2	U2N>	Time Dial (Tpset)	Relay time multiplier inverse time

3.9 RPSB 78 sub relay

The "RPSB 78" sub relay simulates the *Power swing detection (RPSB, 78)* relay function.

3.9.1 Available Units

- Two polygonal distance zone elements ("Inner zone" and "Outer zone" block).
- Two load encroachment elements ("Inner Load Area" and "Outer Load Area" block).
- One power swing detection element ("Power Swing" block).
- One logic block ("outlogic" block).

3.9.2 Functionality

This sub relay is providing the basic features of the power swing detection function. The output signal is on when a power swing condition has been detected.

3.9.3 Data input

The relationships between the relay settings and the model parameters can be found in the following table (the relay model parameter names are listed between brackets):

Address	Relay Setting	Model block	Model setting	Note
	Operation	Power Swing	Out of Service (outserv)	
	X1InFw	Outer zone	X1PP (X1PP)	
	R1LIn	Outer zone	R1PP (R1PP)	
	R1FInFw	Outer zone	RFPP (RFPP)	
	X1InRv	Outer zone	X1RvPP (X1RvPP)	
	R1FRv	Outer zone	RFRvPP (RFRvPP)	
	OperationLdCh	Outer Load Area	Out of Service (outserv)	
	RLdOutFw	Outer Load Area	RLdFw (Rloadfw)	
	ArgLd	Outer Load Area	ARGLd (philoal)	
	RLdOutRv	Outer Load Area	RLdRv (Rloadrev)	
	kLdRFw	Inner Load Area	KRFw (KRFw)	
		Inner Zone	KR (KR)	
		Inner Zone	KX (KX)	
	kLdRRv	Inner Load Area	KRRv (KRRv)	
	tP1	Power Swing	tP1 (tP1)	in the Timers tab page
	tP2	Power Swing	tP2 (tP2)	in the Timers tab page
	tW	Power Swing	tW (tW)	in the Timers tab page
	tH	Power Swing	tH (tH)	in the Timers tab page

3.10 SC Dir-Z sub relay

The "SC Dir-Z" sub relay simulates the *directional impedance quadrilateral, including series compensation (ZDSRDIR)* relay function. The subrelay implements the special features which have implemented in the relay to allow the fault direction detection when the relay is protecting a series compensated line.

3.10.1 Available Units

- One polygonal zone element ("ZDS1" block).
- One load encroachment element ("Load Area ZDS1" block).
- One phase-phase current starting element ("ZDS1 IMinOpPP" block).
- One phase-ground current starting element ("ZDS1 IMinOpPE" block).
- One ancillary logic block ("ZDS1logicst" block).
- One polarizing block ("Polarizing" block).
- One distance directional block ("Dir-Z" block).

3.10.2 Functionality

The fault direction determination implemented in this sub relay consists of an overcurrent fault detector for the phase-phase loops ("ZDS1 IMinOpPP" block) and of an overcurrent fault detector for the phase-ground loops ("ZDS1 IMinOpPE" block) which control an impedance starting zone ("ZDS1" block) and a load encroachment zone ("Load Area ZDS1" block) which in turn are identifying the faulted loops. The faulted loops information is used by the polarization block to activate a voltage memory buffer and stabilize during the fault transitory the polarizing voltage vectors provided to the distance directional element ("Dir-Z" block) which is calculating the fault direction. The fault direction is used by the ZMQPDIS sub relay (see 3.13)

3.10.3 Data input

The relationships between the relay settings and the model parameters can be found in the following table (the relay model parameter names are listed between brackets):

Address	Relay Setting	Model block	Model setting	Note
	OperationSC	Dir-Z	Out of Service (outserv)	
	IMinOpPE	ZDS1 IMinOpPE	Current I>> (ip2)	
	IMinOpPP	ZDS1 IMinOpPP	Current I>> (ip2)	
	ArgNegRes	Dir-Z	Directional Angle, phi (phi)	
	ArgDir	Dir-Z	Directional Angle, Alpha (alpha)	
	OperationLdCh	Load Area ZDS1	Out of Service (outserv)	
	RLdFw	Load Area ZDS1	RLdFw (Rloadfw)	
	RLdRv	Load Area ZDS1	RLdRv (Rloadrev)	
	ArgLd	Load Area ZDS1	ARGLd (phiload)	
	X1FwPP	ZDS1	X1PP (X1PP)	
	R1PP	ZDS1	R1PP (R1PP)	

3 Supported features

Address	Relay Setting	Model block	Model setting	Note
	RFFwPP	ZDS1	RFPP (RFPP)	
	X1RvPP	ZDS1	X1RvPP (X1RvPP)	
	RFRvPP	ZDS1	RFRvPP (RFRvPP)	
	X1FwPE	ZDS1	X1PE (1:X1PE)	
	R1PE	ZDS1	R1PE (1:R1PE)	
	X0FwPE	ZDS1	X0PE (X0PE)	
	R0PE	ZDS1	R0PE (R0PE)	
	RFFwPE	ZDS1	RFPE (RFPE)	
	X1RvPE	ZDS1	X1RvPE (X1RvPE)	
	X0RvPE	ZDS1	X0RvPE (X0RvPE)	
	RFRvPE	ZDS1	RFRvPE (RFRvPE)	

No user input is required in the "Polarizing" and in the "ZDS1logicst" block.

3.11 ZMCPDIS sub relay

The "ZMCPDIS" sub relay simulates the *Distance measuring zone, quadrilateral characteristic for series compensated lines (ZMCAPDIS)* relay function.

3.11.1 Available Units

- One zero sequence starting element ("ZMC1 IMinOpN" block).
- Five phase-phase current starting elements ("ZMC1 IMinOpPP", "ZMC2 IMinOpPP", "ZMC3 IMinOpPP", "ZMC4 IMinOpPP" and "ZMC5 IMinOpPP" block).
- Five phase current starting elements ("ZMC1 IMinOpPE", "ZMC2 IMinOpPE", "ZMC3 IMinOpPE", "ZMC4 IMinOpPE" and "ZMC5 IMinOpPE" block).
- Five phase-phase and phase-ground loop polygonal distance zones elements ("ZMC1", "ZMC2", "ZMC3", "ZMC4" and "ZMC5" block).
- Five timer element for the phase-phase loops starting signals ("ZMC1 tPP", "ZMC2 tPP", "ZMC3 tPP", "ZMC4 tPP" and "ZMC5 tPP" block).
- Five timer element for the phase-ground loops starting signals ("ZMC1 tPE", "ZMC2 tPE", "ZMC3 tPE", "ZMC4 tPE" and "ZMC5 tPE" block).
- Ten ancillary logic elements ("ZMC1logic", "ZMC2logic", "ZMC3logic", "ZMC4logic", "ZMC5logic", "ZMC1 logic", "ZMC2 logic", "ZMC3 logic", "ZMC4 logic" and "ZMC5 logic" block).

3.11.2 Functionality

This sub relay simulate the behavior of the ABB RED 670 polygonal distance zones used to protect series compensated lines.

Each polygonal distance zone is calculating both the phase-phase and the phase-ground loop impedances. The phase-phase loop and the phase-ground loop have separated over current starting elements ("ZMCn⁷IMinOpPP" for the phase-phase loops and "ZMCn⁷IMinOpPE" for the phase-ground loops). The first polygonal zone have also an additional zero sequence overcurrent starting element ("ZMC1 IMinOpN" block) to achieve better sensitivity. Separated timers are connected to the phase-phase loops and to the phase-ground loops distance zones starting signals.

3.11.3 Data input

The relationships between the relay settings and the model parameters can be found in the following table (the relay model parameter names are listed between brackets):

Address	Relay Setting	Model block	Model setting	Note
	ZMCPDIS Operation	ZMC1	Out of Service (outserv)	To set from the command line
	ZMCPDIS OperationDir	ZMC1	Tripping Direction (idir)	
	ZMCPDIS OperationPP	ZMC1 IMinOpPP	Out of Service (outserv)	
	ZMCPDIS X1FwPP	ZMC1	X1PP (X1PP)	
	ZMCPDIS R1PP	ZMC1	R1PP (R1PP)	
	ZMCPDIS RFFwPP	ZMC1	RFPP (RFPP)	

⁷n = 1,2,3,4,5

3 Supported features

Address	Relay Setting	Model block	Model setting	Note
	ZMCPDIS X1RvPP	ZMC1	X1RvPP (X1RvPP)	To set from the command line
	ZMCPDIS RFRvPP	ZMC1	RFRvPP (RFRvPP)	
	ZMCPDIS Timer tPP	ZMC1 tPP	Out of Service (outserv)	
	ZMCPDIS tPP	ZMC1 tPP	Time Setting (Tdelay)	
	ZMCPDIS OperationPE	ZMC1 IMinOpPE	Out of Service (outserv)	
		ZMC1 IMinOpIN	Out of Service (outserv)	
	ZMCPDIS X1FwPE	ZMC1	X1PE (X1PE)	
	ZMCPDIS R1PE	ZMC1	R1PE (R1PE)	
	ZMCPDIS X0PE	ZMC1	X0PE (X0PE)	
	ZMCPDIS R0PE	ZMC1	R0PE (R0PE)	
	ZMCPDIS RFFwPE	ZMC1	RFPE (RFPE)	To set from the command line
	ZMCPDIS X1RvPE	ZMC1	X1RvPE (X1RvPE)	
	ZMCPDIS RFRvPE	ZMC1	RFRvPE (RFRvPE)	
	ZMCPDIS Timer tPE	ZMC1 tPE	Out of Service (outserv)	
	ZMCPDIS tPE	ZMC1 tPE	Time Setting (Tdelay)	
	ZMCPDIS IMinOpPP	ZMC1 IMinOpPP	Current I>> (ip2)	
	ZMCPDIS IMinOpPE	ZMC1 IMinOpPE	Current I>> (ip2)	
	ZMCPDIS IMinOpIN	ZMC1 IMinOpIN	Current, 3*I0 (ie)	
	ZMCAPDIS Operation	ZMCn ⁸	Out of Service (outserv)	
	ZMCAPDIS OperationDir	ZMCn ⁸	Tripping Direction (idir)	To set from the command line
	ZMCAPDIS OperationPP	ZMCn ⁸ IMinOpPP	Out of Service (outserv)	
	ZMCAPDIS X1FwPP	ZMCn ⁸	X1PP (X1PP)	
	ZMCAPDIS R1PP	ZMCn ⁸	R1PP (R1PP)	
	ZMCAPDIS RFFwPP	ZMCn ⁸	RFPP (RFPP)	
	ZMCAPDIS X1RvPP	ZMCn ⁸	X1RvPP (X1RvPP)	
	ZMCAPDIS RFRvPP	ZMCn ⁸	RFRvPP (RFRvPP)	
	ZMCAPDIS Timer tPP	ZMCn ⁸ tPP	Out of Service (outserv)	
	ZMCAPDIS tPP	ZMCn ⁸ tPP	Time Setting (Tdelay)	
	ZMCAPDIS OperationPE	ZMCn ⁸ IMinOpPE	Out of Service (outserv)	To set from the command line
		ZMCn ⁸ IMinOpIN	Out of Service (outserv)	
	ZMCAPDIS X1FwPE	ZMCn ⁸	X1PE (X1PE)	
	ZMCAPDIS R1PE	ZMCn ⁸	R1PE (R1PE)	
	ZMCAPDIS X0PE	ZMCn ⁸	X0PE (X0PE)	
	ZMCAPDIS R0PE	ZMCn ⁸	R0PE (R0PE)	
	ZMCAPDIS RFFwPE	ZMCn ⁸	RFPE (RFPE)	
	ZMCAPDIS X1RvPE	ZMCn ⁸	X1RvPE (X1RvPE)	
	ZMCAPDIS RFRvPE	ZMCn ⁸	RFRvPE (RFRvPE)	
	ZMCAPDIS Timer tPE	ZMCn ⁸ tPE	Out of Service (outserv)	
	ZMCAPDIS tPE	ZMCn ⁸ tPE	Time Setting (Tdelay)	
	ZMCAPDIS IMinOpPP	ZMCn ⁸ IMinOpPP	Current I>> (ip2)	
	ZMCAPDIS IMinOpPE	ZMCn ⁸ IMinOpPE	Current I>> (ip2)	

No user input is required in the "ZMCn⁸logic" and in the "ZMCn⁸ logic" block.

⁸n = 2,3,4,5

3.12 ZMHPDIS sub relay

The "ZMHPDIS" sub relay simulates the *Full-scheme distance measuring, Mho characteristic (ZMHPDIS)* relay function.

3.12.1 Available Units

- Five phase-phase current and phase current starting elements ("ZMH1 IMinOp", "ZMH2 IMinOp", "ZMH3 IMinOp", "ZMH4 IMinOp" and "ZMH5 IMinOp" block).
- Five phase-phase loop mho elements ("ZMH1 PP", "ZMH2 PP", "ZMH3 PP", "ZMH4 PP" and "ZMH5 PP" block).
- Five phase-ground loop mho elements ("ZMH1 PE", "ZMH2 PE", "ZMH3 PE", "ZMH4 PE" and "ZMH5 PE" block).
- Five polarizing elements ("ZMH1 KN", "ZMH2 KN", "ZMH3 KN", "ZMH4 KN" and "ZMH5 KN" block).
- Five timer element for the phase-phase loops mho starting signals ("ZMH1 tPP", "ZMH2 tPP", "ZMH3 tPP", "ZMH4 tPP" and "ZMH5 tPP" block).
- Five timer element for the phase-ground loops mho starting signals ("ZMH1 tPE", "ZMH2 tPE", "ZMH3 tPE", "ZMH4 tPE" and "ZMH5 tPE" block).
- Five ancillary logic elements ("ZMH1 logic", "ZMH2 logic", "ZMH3 logic", "ZMH4 logic" and "ZMH5 logic" block).

3.12.2 Functionality

This sub relay simulate the behavior of the mho used to protect transmission and sub-transmission lines.

Separate mho elements are calculating the phase-phase loop and the phase-ground loop impedances ("ZMHn⁹PP" and "ZMHn⁹PE" block). The phase-phase loop and the phase-ground loop currents are evaluated by over current starting elements ("ZMHn⁹IMinOp" blocks) which enable the mho elements impedance measurement. Each over current starting element controls a phase-phase loop mho element and a phase-ground loop mho element. Separated timers are connected to the phase-phase loops and to the phase-ground loops mho starting signals.

3.12.3 Data input

The relationships between the relay settings and the model parameters can be found in the following table (the relay model parameter names are listed between brackets):

Address	Relay Setting	Model block	Model setting	Note
	ZMHPDIS Operation	ZMHn ¹⁰ PP	Out of Service (outserv)	In the main relay. Unique for all mho zones
		ZMHn ¹⁰ PE	Out of Service (outserv)	
	ZMHPDIS Dir Mode	ZMHn ¹⁰	Tripping Direction (idir)	
	ZMHPDIS LoadEncMode	PHS Load Area	Out of Service (outserv)	

⁹n = 1,2,3,4,5

¹⁰n = 1,2,3,4

3 Supported features

Address	Relay Setting	Model block	Model setting	Note
	ZMHPDIS OpModePE	ZMHn ¹⁰ PE	Out of Service (outserv)	In the "Offset" frame
	ZMHPDIS ZPE	ZMHn ¹⁰ PE	Replica Impedance (Zm)	
	ZMHPDIS ZAngPE	ZMHn ¹⁰ PE	Relay Angle (phi)	
	ZMHPDIS KN	ZMHn ¹⁰ KN	k0 (k0)	
	ZMHPDIS KNAng	ZMHn ¹⁰ KN	Angle (phik0)	
	ZMHPDIS ZRevPE	ZMHn ¹⁰ PE	Impedance (Zoff)	
	ZMHPDIS tPE	ZMHn ¹⁰ tPE	Time Setting (Tdelay)	
	ZMHPDIS IMinOpPE	ZMHn ¹⁰ IMinOp	Current, 3*i0 (ie)	
	ZMHPDIS OpModePP	ZMHn ¹⁰ PP	Out of Service (outserv)	
	ZMHPDIS ZPP	ZMHn ¹⁰ PP	Replica Impedance (Zm)	In the "Offset" frame
	ZMHPDIS ZAngPP	ZMHn ¹⁰ PP	Relay Angle (phi)	
	ZMHPDIS ZRevPP	ZMHn ¹⁰ PP	Impedance (Zoff)	
	ZMHPDIS tPP	ZMHn ¹⁰ tPP	Time Setting (Tdelay)	
	ZMHPDIS IMinOpPP	ZMHn ¹⁰ IMinOp	Current I>> (ip2)	

No user input is required in the "ZMHn¹⁰logic" blocks.

3.13 ZMQPDIS sub relay

The "ZMQPDIS" sub relay simulates the *Distance measuring zones, quadrilateral characteristic (ZMQPDIS,ZMQAPDIS)* relay function.

3.13.1 Available Units

- One zero sequence starting element ("ZMQ1 IMinOpN" block).
- Five phase-phase current starting elements ("ZMQ1 IMinOpPP", "ZMQ2 IMinOpPP", "ZMQ3 IMinOpPP", "ZMQ4 IMinOpPP" and "ZMQ5 IMinOpPP" block).
- Five phase current starting elements ("ZMQ1 IMinOpPE", "ZMQ2 IMinOpPE", "ZMQ3 IMinOpPE", "ZMQ4 IMinOpPE" and "ZMQ5 IMinOpPE" block).
- Five phase-phase and phase-ground loop polygonal distance zones elements ("ZMQ1", "ZMQ2", "ZMQ3", "ZMQ4" and "ZMQ5" block).
- Five timer element for the phase-phase loops starting signals ("ZMQ1 tPP", "ZMQ2 tPP", "ZMQ3 tPP", "ZMQ4 tPP" and "ZMQ5 tPP" block).
- Five timer element for the phase-ground loops starting signals ("ZMQ1 tPE", "ZMQ2 tPE", "ZMQ3 tPE", "ZMQ4 tPE" and "ZMQ5 tPE" block).
- Ten ancillary logic elements ("ZMQ1logic", "ZMQ2logic", "ZMQ3logic", "ZMQ4logic", "ZMQ5logic", "ZMQ1 logic", "ZMQ2 logic", "ZMQ3 logic", "ZMQ4 logic" and "ZMQ5 logic" block).

3.13.2 Functionality

This sub relay simulate the behavior of the ABB RED 670 polygonal distance zones used to protect non compensated transmission and sub-transmission lines.

Each polygonal distance zone is calculating both the phase-phase and the phase-ground loop impedances. The phase-phase loop and the phase-ground loop have separated over current starting elements ("ZMQn¹¹IMinOpPP" for the phase-phase loops and "ZMQn¹¹IMinOpPE" for the phase-ground loops). The first polygonal zone have also an additional zero sequence overcurrent starting element ("ZMQ1 IMinOpN" block) to achieve better sensitivity. Separated timers are connected to the phase-phase loops and to the phase-ground loops distance zones starting signals.

3.13.3 Data input

The relationships between the relay settings and the model parameters can be found in the following table (the relay model parameter names are listed between brackets):

Address	Relay Setting	Model block	Model setting	Note
	ZMQPDIS Operation	ZMQ1	Out of Service (outserv)	To set from the command line
	ZMQPDIS OperationDir	ZMQ1	Tripping Direction (idir)	
	ZMQPDIS OperationPP	ZMQ1 IMinOpPP	Out of Service (outserv)	
	ZMQPDIS X1	ZMQ1	X1 (X1)	
	ZMQPDIS R1	ZMQ1	R1 (R1)	
	ZMQPDIS RFPP	ZMQ1	RFPP (RFPP)	

¹¹n = 1,2,3,4,5

3 Supported features

Address	Relay Setting	Model block	Model setting	Note
	ZMQPDIS Timer tPP	ZMQ1 tPP	Out of Service (outserv)	To set from the command line
	ZMQPDIS tPP	ZMQ1 tPP	Time Setting (Tdelay)	
	ZMQPDIS OperationPE	ZMQ1 IMinOpPE	Out of Service (outserv)	To set from the command line
		ZMQ1 IMinOpIN	Out of Service (outserv)	To set from the command line
	ZMQPDIS X0PE	ZMQ1	X0PE (X0PE)	
	ZMQPDIS R0PE	ZMQ1	R0PE (R0PE)	
	ZMQPDIS RFPE	ZMQ1	RFPE (RFPE)	
	ZMQPDIS Timer tPE	ZMQ1 tPE	Out of Service (outserv)	
	ZMQPDIS tPE	ZMQ1 tPE	Time Setting (Tdelay)	
	ZMQPDIS IMinOpPP	ZMQ1 IMinOpPP	Current I>> (ip2)	
	ZMQPDIS IMinOpPE	ZMQ1 IMinOpPE	Current I>> (ip2)	
	ZMQPDIS IMinOpIN	ZMQ1 IMinOpIN	Current, 3*i0 (ie)	
	ZMQAPDIS Operation	ZMQn ¹²	Out of Service (outserv)	
	ZMQAPDIS OperationDir	ZMQn ¹²	Tripping Direction (idir)	
	ZMQAPDIS OperationPP	ZMQn ¹² IMinOpPP	Out of Service (outserv)	To set from the command line
	ZMQAPDIS X1PP	ZMQn ¹²	X1PP (X1PP)	
	ZMQAPDIS R1PP	ZMQn ¹²	R1PP (R1PP)	
	ZMQAPDIS RFPP	ZMQn ¹²	RFPP (RFPP)	
	ZMQAPDIS Timer tPP	ZMQn ¹² tPP	Out of Service (outserv)	
	ZMQAPDIS tPP	ZMQn ¹² tPP	Time Setting (Tdelay)	
	ZMQAPDIS OperationPE	ZMQn ¹² IMinOpPE	Out of Service (outserv)	To set from the command line
		ZMQn ¹² IMinOpIN	Out of Service (outserv)	To set from the command line
	ZMQAPDIS X0PE	ZMQn ¹²	X0PE (X0PE)	
	ZMQAPDIS R0PE	ZMQn ¹²	R0PE (R0PE)	
	ZMQAPDIS RFPE	ZMQn ¹²	RFPE (RFPE)	
	ZMQAPDIS Timer tPE	ZMQn ¹² tPE	Out of Service (outserv)	
	ZMQAPDIS tPE	ZMQn ¹² tPE	Time Setting (Tdelay)	
	ZMQAPDIS IMinOpPP	ZMQn ¹² IMinOpPP	Current I>> (ip2)	
	ZMQAPDIS IMinOpPE	ZMQn ¹² IMinOpPE	Current I>> (ip2)	

No user input is required in the "ZMQn¹²logic" and in the "ZMQn¹² logic" block.

¹²n = 2,3,4,5

3.14 Output logic

3.14.1 Available Units

The output logic is implemented by a set of logic blocks located in the main relay.

Four logic blocks are available:

- "ZMCPDIS Output Logic" connected to the "ZMCPDIS" subrelay output signals.
- "ZMHPDIS Output Logic" connected to the "ZMHPDIS" subrelay output signals.
- "ZMQPDIS Output Logic" connected to the "ZMQPDIS" subrelay output signals.
- "I & V & f Output Logic" connected to the "PTOC 51_67", "PTOC 51N67N", "PTOF PTUF PFRC 81", "PTUV 27 PTOV 59/59N" and to the "PDIF 87" subrelay output signals.

3.14.2 Functionality

Each logic block located in the main relay can operate the power breaker.

The output signals which can be used to operate the breaker are "yout", "yout_A", "yout_B" and "yout_C". Please notice that "yout_A", "yout_B" and "yout_C" are not connected to any relay output signals.

The logic blocks implement the three phase, single phase and the two phases trip logic.

3.14.3 Data input

Please disable the "ZMCPDIS Output Logic", "ZMHPDIS Output Logic", "ZMQPDIS Output Logic" and "I & V & f Output Logic" block in the main relay to disable the relay model ability to open the power circuit.

The "yout", "yout_A", "yout_B" and "yout_C" relay output signals can be set to operate the breaker using the "Tripping signal" ("sTripsig") parameter in the "Basic Data" tab page of the logic block dialogs. By default all of them are operating the breaker.

The single phase trip logic can be activated setting equal to "TRIP" the "single_pole_trip" parameter in the "Logic" tab page of the logic block dialogs. The two phases trip logic can be activated setting equal to "TRIP" the "two_poles_trip" parameters. By default the three phase trip logic is enabled.

4 Features not supported

4.1 Main features

The following features are not supported:

- Automatic switch onto fault logic, voltage and current based, ZCVPSOF.
- Breaker failure protection, CCRBRF.
- Four step directional negative phase sequence overcurrent protection NS4PTOC.
- Pole slip protection, PSPPPAM.
- Scheme communication logic for distance protection, ZCOM.
- Stub protection, STBPTOC.
- Pole discordance protection, CCRPLD.
- Directional underpower protection, GUPPDUP.
- Directional overpower protection, GOPPDOP.
- Broken conductor check, BRCPTOC.
- General current and voltage protection, CVGAPC.
- Power system and secondary system supervision.
- Synchrocheck, energizing check, and synchronizing, SESRSYN.
- Autorecloser, SMBRREC.
- Current circuit supervision, CCSRDIF.
- Fuse failure supervision SDDRFUF.
- Interlocking logics.

4.2 PTOC 51N67N sub relay

The following features are not supported:

- Switch On To Fault.
- Sensitive directional residual overcurrent and power protection SDEPSDE.

4.3 PTOC 51_67 sub relay

The following features are not supported:

- Switch On To Fault.
- Thermal overload protection, one time constant LPTTR

4.4 PTUV 27 PTOV 59/59N sub relay

The following features are not supported:

- Overexcitation protection OEXPVPH
- Voltage differential protection VDCPTOV
- Loss of voltage check LOVPTUV

4.5 SC Dir-Z sub relay

The following features are not supported:

- INReleasePE/INBlockPP relay setting

4.6 ZMHPDIS sub relay

The following features are not supported:

- Mho impedance supervision logic, ZSMGAPC

4.7 ZMQPDIS sub relay

The following features are not supported:

- Full-scheme distance protection, quadrilateral for earth faults ZMMPDIS, ZMMAPDIS
- Additional distance protection directional function for earth faults, ZDARDIR
- Distance protection zone, quadrilateral characteristic, separate settings ZMRPDIS, ZMRAPDIS and ZDRDIR

5 References

- [1] ABB Automation Products AB, Substation Automation Products, SE-721 59 Vasteras, Sweden.
Line differential protection RED670 Technical Reference Manual Document ID: 1MRK 505 222-UEN Issued: September 2011 Revision: B Product version: 1.2, 2011.