
	APPLICATION NOTE 07, iMCP – HT32SX		iMCP, app note
	Application Note	02/04/2021	V 2.0

HT32SX P2P Demo



1 INTRODUCTION

The iMCP is a Multicomponent Integrated Circuit (MCO) built for the Internet of Things, it provides a ready-to-use connectivity solution for the SigFox™ network.

The system combines an ARM Cortex M0+ 32bit, a S2-LP high performance, ultra-low power and generic RF transceiver and a RF Power Amplifier with all of the advantages, integration and convenience found in a SiP (System In Package), which is one of the most advanced semiconductor packaging technology.

1.1 About this document

This document will explore a new HT32SX functionality. A simple way to exchange message Peer-to-Peer between two or more different iMCPs, using S2LP Basic Protocol.

Through this application, users will be able to create their own protocol and Wireless network.

1.2 Application description

P2P Demo Application starts initializing some necessary peripherals: USART1, GPIOs (button, led, radio IRQn...) and SPI (interface between MCU and transceiver).

The whole system was modeled on a Finite State Machine. All state changes are triggered by two external interruptions:

- User Button – PB0: Trigger FSM to “Send Data” state.
- Radio IT - PB2: Trigger FSM to “Data Received” state or finishes to transmit a data when FSM is waiting for a TX be done.

Finite State Machine Diagram.





Image 1 - FSM block diagram.

More code details can be found reading the comments written in all header files available in this application.

	APPLICATION NOTE 07, iMCP – HT32SX		iMCP, app note
	Application Note	02/04/2021	V 2.0

2 TEST SETUP

This section describes the basic test setup to running this application.

- Git (<https://git-scm.com/downloads>).
- STM32CubeIDE (<https://www.st.com/en/development-tools/stm32cubeide.html>).
- RS232 terminal (Termite is recommended). (https://www.compuphase.com/software_termite.htm).
- ST-Link Debugger (to flash a firmware) (<https://www.st.com/en/development-tools/st-link-v2.html>).
- Button (must be in PB0 pin).
- Led (PA5 pin).
- 2 or more HT32SX devices.
- 2 or more antennas (one for each device).
- 2 or more FTDI (usb-serial converter – one for each device).

3 EXECUTING

1. Clone the master branch related to the hardware version 2.2:

```
git clone --single-branch --branch master_2 https://github.com/htmicron/ht32sx.git
```

2. Open HT32SX_P2P_Demo directory and then, double click **.cproject** file to open STM32CubeIDE.
3. Click “Run” to compile and flash the new firmware into your device:



Image 2 – Flashing a new firmware.

4. Open Termite and reset your device to check if the initial string was printed on serial.





Image 3 – Termite showing initial string.

5. Do the same (steps 3 and 4) with other devices that is going to be part of this test.
6. Press the button of one of tested devices and check if the message “Hello, World!” will be shown in the other terminal:

	APPLICATION NOTE 07, iMCP – HT32SX		iMCP, app note
	Application Note	02/04/2021	V 2.0




Image 4 – Sending a message to another device.

7. Check if the user led is blinking after receiving any message.

3.1 CHANGING DESTINATION/SOURCE ADDRESS - BROADCAST/MULTICAST MESSAGES

- Changing destination or source address:
 1. Open *HT_P2P_app.h* file and change *MY_ADDRESS* or *DESTINATION_ADDRESS* constants to the new value wanted (value must be less or equal than 1 byte).
- Sending broadcast and multicast messages:
 1. Open *HT_P2P_app.c* file and change *S2LP_SetDestinationAddress* (located in *AppliSendBuff* function) argument to *BROADCAST_ADDRESS* or *MULTICAST_ADDRESS* defines. Example:

```
/* Destination address. It could be also changed to BROADCAST_ADDRESS or MULTICAST_ADDRESS. */
S2LP_SetDestinationAddress(BROADCAST_ADDRESS);
```

4 EXTRA DOCUMENTATION


Datasheets and application notes can be found at the HT32SX Repository (<https://github.com/htmicron/ht32sx>).

5 REFERENCES

For additional information about S2LP or even more applications developed with this transceiver, check S2LP datasheet (<https://www.st.com/resource/en/datasheet/s2-lp.pdf>) and the UM1904 user manual written by STMicroelectronics.

6 CONTACT INFORMATION

Head Office – São Leopoldo, RS
 HT Micron Semiconductors
 Unisinos Avenue, 1550
 São Leopoldo - RS
 ZIP 93022-750
 Brazil
 Tel: +55 51 3081-8650
 E-mail (Support): support_iot@htmicron.com.br
 E-mail (General Enquiries): htmicron@htmicron.com.br

	APPLICATION NOTE 07, iMCP – HT32SX		iMCP, app note
	Application Note	02/04/2021	V 2.0

Version Control:

1.0 – Aimed for the engineering samples of iMCP

Legal note: Copyright 2020 HT Micron Semicondutores S.A.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.