

Internal PSK modulation (inpsk)

After selection, "HOP 180°" is displayed, and the cursor positions itself under 180°.

Set the phase shift between 0 and 360° using the thumbwheel switch [17], then press *Valid* [15].

A star is displayed between the frequency and function. From this time on, the output signal is shifted in phase by the set value at the modulation frequency (internal 800Hz).

To quit the modulation function, press *Modul. (Stop Mod.)* button [14].

External PSK modulation (extpsk)

After selection, "HOP 180°" is displayed, and the cursor positions itself under 180°.

Set the phase shift between 0 and 360° using the thumbwheel switch [17], then press *Valid* [15].

A star is displayed between the frequency and function. From this time on, the output signal is shifted in phase by the set value at the frequency of the VCF input signal [20] (TTL level).

To quit the modulation function, press *Modul. (Stop Mod.)* button [14].

The *IN/OUT VCF* BNC plug [20] is an input. The maximum allowable voltage before degradation is ± 60 V.

⚠ Electrical overload: Never apply a category II, III or IV measuring voltage to the inputs.

EXTERNAL FREQUENCY MEASUREMENT (counter)

When the generator is switched on, the cursor positions itself below the function.

Pressing the *Function Counter* button [9] selects the frequency counter.

If the cursor is not below the function, pressing the *Function Counter* button [9] twice selects the frequency counter.

After function selection, "Text 0-25 MHz" is displayed, and the cursor positions itself below *F*.

Select your range using the thumbwheel switch [17]: 0 - 25 MHz or 25 - 100MHz, then press *Valid* [15].

When a signal is present on the *INPUT COUNTER* BNC socket [19], the frequency counter shows its frequency.

The maximum allowable voltage at this input is ± 60 V.

The 0 - 25 MHz range is divided into 5 sub-ranges. The display is controlled automatically.

STORING A SETUP (Store)

Press % *Duty / Store* [13] twice. "Store (xx)" is displayed, and the cursor positions itself below (xx).

Select a memory location between 2 and 15 using the thumbwheel switch [17], then press *Valid* [15].

The setup (latest modification of all parameters) will be stored in the selected memory location.

RECALLING A SETUP (Recall)

Press *Offset / Recall* [12] twice. "Recall (xx)" is displayed, and the cursor positions itself below (xx).

Select the memory location to recall (1 to 15) using the thumbwheel switch [17], then press *Valid* [15].

The generator will use the setup stored in the selected memory location.

Note: Memory location (1) is programmed at the factory and cannot be modified.

Setup: sine, 1 kHz, 2 Vcc, calibrated offset and duty cycle.

PROTECTION AGAINST REVERSE POWER SURGES

The generator is protected against reverse power surges that may damage the output stages (50Ω OUTPUT and TTL OUTPUT).

When the current at one of outputs [21] or [22] exceeds the operating limit of the stage, the protection instantaneously disconnects these outputs.

outputs [21] and [22].

If the fault has not disappeared, the protection will trip immediately.

At outputs [21] and [22], the maximum allowable voltage is ± 60 V peak.

50W OUTPUT (Output50w)

The generator output signal is available on the female BNC socket [21].

This output can be subjected to a permanent short-circuit without damage to the unit.


The Zo impedance is equal to 50Ω (Fig. 10).

Zo and the Zi impedance of the connected stage form an attenuator with a ratio Zi / (Zo + Zi)

With Zi = 50Ω, we have:

Example: Vout measured at no load = Vg = 10 V peak to peak

Vout = 10x (50 / (50 + 50)) = 5 V peak to peak



4000-318-EN-04/04

4000-318-EN-04/04




fig. 11




fig. 12

[22] TTL OUTPUT (OutputTTL)

The TTL output signal from the generator is available on the BNC socket [21].

It is a square signal compatible with TTL logic gates. Its amplitude is fixed (5V), and its duty cycle is adjustable using the %Duty button [13]. Its frequency is identical to that of the output signal.

This output can be subjected to a permanent short-circuit without damage to the unit.

[23] RS-232 INTERFACE

You can control your generator via the RS-232 link (see 6-3 and table of codes).

Use a shielded NULL-MODEM cable 3 metres long maximum.

[25] MAINS SOCKET WITH FUSE-HOLDER

This socket receives the mains cable. The fuse-holder is fitted with a T200mA 5x20 fuse.

[24] 0 - 1 SWITCH

Switch depressed to 0: the generator is off.

Switch depressed to 1: the generator is on.

6 - INSTALLATION AND OPERATION

6-1 INSTALLATION

The generator must rest on its 2 rear rubber stops and on its 2 front feet (folded or fully unfolded).

Connect the mains cable to the socket [25] at the back of the unit.

Connect the other end of the cable to a 230V AC mains socket. Your generator is ready to operate.

6-2 OPERATION

Depress the on/off switch [24] to 1. The display lights up.

The generator uses the last setup used before switching off.

The signal is then available on the 50Ω BNC [22] and in a logic form on [21].

A 30-minute warm-up time is necessary to reach the specifications.

PRECAUTION: Set the signal amplitude so as to remain below the maximum allowable voltage.

6-3 RS-232 INTERFACE

Your GF 265 generator has an RS-232 interface, which is simple, user-friendly and comprehensive.

All functions are accessible via the RS-232 interface.

This interface enables you to control and monitor the GF 265 from a PC, as if you were next to the unit.

6-3-1 PREPARING FOR COMMUNICATION:

- Connect the generator to the serial port of the PC using a "null modem" RS-232 cable (cross-over).

Note: It is recommended to use a shielded cable in order to minimize the interference caused by the data conveyed between the unit and the PC. The cable length must not exceed 3 metres.

ACCES AUX MENUS ET PARAMETRES VIA RS 232												
Dizaines	Unités											
	COMMANDE	_0	_1	_2	_3	_4	_5	_6	_7	_8	_9	_A _B _C _D _E _F
0_	Function	Sinus	Square	Triangle	Ramp UP	Ramp DOWN	DC					
1_	Counter	0 à 25 MHz	25 à 100 MHz									
2_	Offset	Saisir la valeur numérique										
3_	Recall		1	2	3	4	5	6	7	8	9	10 11 12 13 14 15
4_	Frequency	Normal (4 digit) Saisir la valeur numérique	Etendu (10 digit) Saisir la valeur numérique									
5_	Modul	LIN SWP	LOG SWP	Int AM	ext AM	int FM	ext FM	int FSK	ext FSK	int PSK	ext PSK	
6_	Symétrie / Duty	Saisir la valeur numérique										
7_	Store			2	3	4	5	6	7	8	9	10 11 12 13 14 15
8_	Level	Saisir la valeur numérique										
9_	Atténuation	Directe										

TABLE OF CONTENTS

1 - PRELIMINARY INFORMATION	19
1-1 FOREWORD	19
1-2 SAFETY INSTRUCTIONS	19
1-3 SYMBOLS AND DEFINITIONS	19
1-4 TUTORIAL	20
2 - PRELIMINARY INSTRUCTIONS	23
2-1 UNPACKING AND REPACKING	23
2-2 SPECIFICATIONS	23
3 - GENERAL VIEW	25
3-1 CONTROLS	25
4 - FRONT PANEL OVERVIEW	25
5 - DESCRIPTION OF BASIC COMMANDS	25
6 - INSTALLATION AND OPERATION	29
6-1 INSTALLATION	29
6-2 OPERATION	29
6-3 RS-232 INTERFACE	29
7 - TYPICAL APPLICATIONS	32
7-1 AMPLIFIER FREQUENCY RESPONSE	32
7-2 TRANSISTOR AMPLIFIER WITHOUT EXTERNAL POWER SUPPLY (FIG. 18)	32
7-3 FREQUENCY RESPONSE:	32
7-4 SWITCHING LEVELS:	32
7-5 SYSTEM ANALYSIS:	32
8 - MAINTENANCE	32
9 - AFTER-SALE SERVICE	32
10 - DECLARATION OF CONFORMITY	33

1 - PRELIMINARY INFORMATION

1-1 FOREWORD

Thank you and congratulations on your choice of the GF 265 **CENTRAD*** FUNCTION GENERATOR. **elc's** offering also includes a wide variety of other electronic devices: POWER SUPPLIES, FREQUENCY COUNTER, PANEL INDICATORS, DECADE BOXES...

*CENTRAD is a registered trademark of **elc**.

Manufacturer : **elc** 59, avenue des Romains 74000 ANNECY - FRANCE
 Phone : +33 (0)4 50 57 30 46 Fax: +33 (0)4 50 57 45 19
 Instrument : **FUNCTIONGENERATOR**
 Trademark : **CENTRAD**
 Type : **GF 265**
 Power requirements : 230V AC 50/60 Hz

1-2 SAFETY INSTRUCTIONS

Do not carry repair or maintenance work within the unit.

Operate the unit in accordance with these instructions.

As the mains plug is used as a disconnecting device, connect the unit to an easily accessible mains socket (230V 50/60Hz) with an earth contact.

When the unit is to be supplied through an autotransformer for voltage reduction, ensure that the common terminal is connected to the earthed pole of the supply.



Electrical overload: Never apply a voltage in excess of the specified limits and category II, III or IV signals to the inputs.

1-3 SYMBOLS AND DEFINITIONS

You will find the following symbols on the unit:

**WARNING ! RISK OF
ELECTRIC SHOCK**



**CHASSIS GROUND
TERMINAL**



**CAUTION ! REFER TO
THE MANUAL**

