

## BC66-TE-B-Guide to flow test board processing

Test BC26 consumption using an external power supply instrument and bc26-te-b, The short circuit cap of J203 needs to be removed. Then connect the power cord to J201. "+" is 3.3v, "-" is GND.

In general, the USB of J301 needs to be plugged in.

