

CONFIDENTIAL

ADSP TDM Renderer/Capture Interface for Linux

RCG3AHIFL4101ZDP

Application Note - TDM Renderer/Capture -

RCG3AHIFL4101ZDPE_AN_RDR

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Electronics Corp. website (<http://www.renesas.com>).

Rev. 2.00 Dec, 2018

CONFIDENTIAL

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
 2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
 3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
 4. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
 5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.
"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.
"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.
Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.
 6. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
 7. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
 8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
 9. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
 10. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
 11. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

CONFIDENTIAL

Trademarks

- Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.
- Arm is a registered trademark of Arm Limited (or its subsidiaries) in the US and/or elsewhere.
- Windows and Windows Media are registered trademarks of Microsoft Corporation in the United States and other countries.
- Android is a trademark of Google Inc. Use of this trademark is subject to Google permissions.
- All other company names and product names mentioned in this manual are registered trademarks or trademarks of their respective companies.
- The registered trademark symbol (®) and trademark symbol (™) are omitted in this manual.

How to Use This Manual

1. Purpose and Target Reader

This manual is designed to provide the user with an understanding of the interface specifications of the Software product. It is intended for users designing application systems incorporating the Software product. Please refer to the related documents with this product.

Use this Software after carefully reading the precautions. The precautions are stated in the main text of each section, at the end of each section, and in the usage precaution section.

The revision history summarizes major corrections and additions to the previous version. It does not cover all the changes. For details, refer to this manual.

2. Restrictions on the Use of this Middleware

Any customer who wishes to use this Software must obtain a software license from Renesas Electronics.

3. Related Manuals

4. Technical Terms and Abbreviation



- Table of Contents -

1	OVERVIEW	3
1.1	Overview of this document.	3
1.2	The architecture of the Software and scope of this document	3
1.3	Software necessary to be prepared in advance	4
1.4	Related documents	4
2	SOFTWARE SPECIFICATION	5
2.1	The list of functions	5
2.2	The list of structures	7
2.3	Function specification	8
2.3.1	IL Core method	8
2.3.1.1	OMX_Init	8
2.3.1.2	OMX_Deinit	9
2.3.1.3	OMX_GetHandle	10
2.3.1.4	OMX_FreeHandle	11
2.3.2	Component API	12
2.3.2.1	OMX_SendCommand	12
2.3.2.2	OMX_GetParameter	13
2.3.2.3	OMX_SetParameter	14
2.3.2.4	OMX_GetState	15
2.3.2.5	OMX_AllocateBuffer	16
2.3.2.6	OMX_FreeBuffer	17
2.3.2.7	OMX_EmptyThisBuffer	18
2.3.2.8	OMX_FillThisBuffer	19
2.4	Callback function specification	20
2.4.1	EventHandler	21
2.4.2	EmptyBufferDone	22
2.4.3	FillBufferDone	23
2.5	Structure specification	24
2.5.1	XAOMX_AUDIO_PARAM_TDM_RENDERER	24
2.5.2	XAOMX_AUDIO_PARAM_TDM_CAPTURE	26
3	PROCESS SEQUENCE	28
3.1	Initialize Component	28
3.2	Decoding sequence	29
3.3	De-initialize Component	30
4	NOTES	31
4.1	Function Call	31
4.2	Other notes	31
4.2.1	Allocation of memory	31
4.2.2	Out of range memory access	31
4.2.3	Combination with other applications	31
4.2.4	Monitoring on Performance	31

- List of Figures -

Figure 1-1	The software architecture	3
------------	---------------------------------	---



Figure 3-1 Initialize the Component and preparation phase	28
Figure 3-2 Decoding sequence.....	29
Figure 3-3 De-Initialize Component and OMX IL Core	30

- List of Tables -

Table 1-1 The list of related documents	4
Table 2-1 List of functions	5
Table 2-2 List of available functions between TDM Renderer and TDM Capture.....	6
Table 2-3 List of structures	7
Table 2-4 Parameters Structure of TDM Renderer.....	25
Table 2-5 Parameters Structure of TDM Capture	27

1 Overview

1.1 Overview of this document.

In this chapter, overview of TDM Renderer/Capture interface is explained.

1.2 The architecture of the Software and scope of this document

The architecture of ADSP TDM Renderer/Capture Interface for Linux is shown in Figure 1-1. ADSP TDM Renderer/Capture Interface for Linux is a user space library which provides the interface to control ADSP TDM Renderer Plugin and ADSP TDM Capture Plugin.




Figure 1-1 The software architecture

Note:



- TDM Renderer function is used to merge multiple raw Pulse Code Modulation (PCM) audio data stream and then output to the configured output device. The user can setup the data path before using TDM Renderer Interface or can setting the data path inside of TDM Renderer Interface.
- TDM Capture function is used to capture/record the raw Pulse Code Modulation (PCM) audio data from configured input device and then spitting the data into multiple output streams. The user can setup the data path before using TDM Capture Interface or can setting the data path inside of TDM Capture Interface.

1.3 Software necessary to be prepared in advance

ADSP Driver for Linux should be loaded in advance to use ADSP TDM Renderer/Capture Interface for Linux.

1.4 Related documents

Table 1-1 shows related documents.

Table 1-1 The list of related documents

No.	Name	Published by
[1]	R-Car Series, 3rd Generation User's Manual: Hardware	Renesas Electronics Corporation
[2]	OpenMAX IL Specification 1.1.2	Renesas Electronics Corporation

2 Software specification

2.1 The list of functions

Table 2-1 shows the functions provided by this software. See 2.3 for more detailed specification of the functions.

Table 2-1 List of functions

	Name	Outline
IL Core Method	OMX_Init	Initialize the OpenMAX™ IL core
	OMX_Deinit	De-initialize the OpenMAX™ IL core
	OMX_GetHandle	Load that component into memory, validate it and return the component handle via the output parameter
	OMX_FreeHandle	Free a component handle (allocated by the OMX_GetHandle)
Component API	OMX_SendCommand	Send the command from application (IL-client) to component
	OMX_GetParameter	Retrieve the parameter from the component
	OMX_SetParameter	Setup the parameter to the component
	OMX_GetState	Get the current state of the component
	OMX_AllocateBuffer	Allocate buffer on behalf of a component
	OMX_FreeBuffer	De-allocate buffer structure
	OMX_EmptyThisBuffer	Pass filled input buffer to the component
	OMX_FillThisBuffer	Pass the free output buffer to the component

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

Table 2-2 shows the different functions between TDM Renderer and TDM Capture Interface.

Table 2-2 List of available functions between TDM Renderer and TDM Capture

	Name	TDM Renderer Interface	TDM Capture Interface
IL Core Method	OMX_Init (*)	O	O
	OMX_Deinit (**)	O	O
	OMX_GetHandle	O	O
	OMX_FreeHandle	O	O
	OMX_SetupTunnel	X	X
	OMX_TearardownTunnel	X	X
Component API	SendCommand	O	O
	GetParameter	O	O
	SetParameter	O	O
	GetState	O	O
	UseBuffer	X	X
	AllocateBuffer	O	O
	FreeBuffer	O	O
	EmptyThisBuffer	O	O
	FillThisBuffer (***)	X	O

Implementation:

O: Supported.

X: Not supported.

Note:

(*) OMX_Init function will be called only one time for the using of all the OpenMAX Media component (OMX TDM Renderer, OMX TDM Capture).

(**) OMX_Deinit function will be called only one time for the using of all the OpenMAX Media component (OMX TDM Renderer, OMX TDM Capture).

(***) OMX_FillThisBuffer function is not supported for TDM Renderer Interface due to the output data will be output to speaker device.

TDM does not support routing function. Therefore, OMX_SetupTunnel, OMX_TearardownTunnel and UseBuffer are unsupported.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.2 The list of structures

Table 2-3 shows the list of structures which user should allocate memory in using the software. See 2.5 for more detailed specification of the structures.

Table 2-3 List of structures

Name	Outline
XAOMX_AUDIO_PARAM_TDM_RENDERER	The structure of parameters for OMX MC TDM Renderer
XAOMX_AUDIO_PARAM_TDM_CAPTURE	The structure of parameters for OMX MC TDM Capture

For more detail about OpenMAX IL Structures, please refer to OMX IL Specification 1.1.2, section 3.1 and section 4.1.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.3 Function specification

2.3.1 IL Core method

2.3.1.1 OMX_Init

OMX_Init		
Synopsis	Initialize the OpenMAX™ IL core, including memory allocation and preparation for loading components. The OpenMAX™ IL core functions are ready to be used when this function returns successfully. (*)	
Syntax	OMX_API OMX_ERRORTYPE OMX_APIENTRY OMX_Init();	
Parameter	None	
Return values	OMX_ErrorInsufficientResources	Failed to initialize due to not enough resource
	OMX_ErrorUndefined	Undefined error while processing command
	OMX_ErrorNone	Normal ends. Initialize successfully

(*) OMX_Init shall be the first call made into OpenMAX IL and should be executed only one time without an intervening OMX_Deinit call. It will be called only one time for the using of OMX MC TDM Renderer, OMX MC TDM Capture.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.3.1.2 OMX_Deinit

OMX_Deinit		
Synopsis	De-initializes OMX IL core, including its allocated memory and objects use to load/manage components. (*)	
Syntax	OMX_API OMX_ERRORTYPE OMX_APIENTRY OMX_Deinit();	
Parameter	None	
Return values	OMX_ErrorUndefined	Undefined error while processing command
	OMX_ErrorNone	Normal ends. De-initialize successfully

(*) OMX_Deinit should be the last call made into the OpenMAX IL core after all OpenMAX IL-related resources have been released. It will be called only one time for the using of OMX MC TDM Renderer, OMX MC TDM Capture.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.3.1.3 OMX_GetHandle

OMX_GetHandle		
Synopsis	Locate the component specified by the component name given, load that component into memory, validate it and return the component handle via the output parameter.	
Syntax	<pre>OMX_API OMX_ERRORTYPE OMX_APIENTRY OMX_GetHandle (OMX_OUT OMX_HANDLETYPE * pHandle, OMX_IN OMX_STRING cComponentName, OMX_IN OMX_PTR pAppData, OMX_IN OMX_CALLBACKTYPE * pCallbacks);</pre>	
Parameter	pHandle	A pointer to OMX_HANDLETYPE to be filled in by this method
	cComponentName	A pointer to a string specifies the component name. Supported names for TDM Renderer and TDM Capture respectively are: "OMX.RENESAS.AUDIO.DSP.TDMRENDERER" "OMX.RENESAS.AUDIO.DSP.TDMCAPTURE"
	pAppData	A pointer to an IL client-defined value that will be returned during callbacks so that the IL client can identify the source of the callback.
	pCallbacks	A pointer to an OMX_CALLBACKTYPE structure containing the callbacks that the component will use for this IL client.
Return values	OMX_ErrorInvalidState	The proxy is not initialized.
	OMX_ErrorInsufficientResources	Failed to locate the component due to not enough resource
	OMX_ErrorInvalidComponentName	The component name parameter is invalid.
	OMX_ErrorNone	Normal ends. Get handle successfully

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.3.1.4 OMX_FreeHandle

OMX_FreeHandle		
Synopsis	Free a handle allocated by the OMX_GetHandle method. The IL client should call OMX_FreeHandle only when the component is in the OMX_StateLoaded and all the ports are not connected via any tunnels.	
Syntax	OMX_API OMX_ERRORTYPE OMX_APIENTRY OMX_FreeHandle(OMX_IN OMX_HANDLETYPE hComponent);	
Parameter	hComponent	The handle of the component to be freed
Return values	OMX_ErrorBadParameter	hComponent points to an invalid memory area.
	OMX_ErrorNone	Normal ends. Free handle successfully

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.3.2 Component API

2.3.2.1 OMX_SendCommand

OMX_SendCommand		
Synopsis	Receive a command from the client and make a queue for serial execution in separated component thread	
Syntax	<pre>OMX_ERRORTYPE OMX_SendCommand(OMX_HANDLETYPE hComponent, OMX_COMMANDTYPE Cmd, OMX_U32 nParam1, OMX_PTR pCmdData);</pre>	
Parameter	hComponent	Pointer to memory area of component handle
	Cmd	Type of command. For more detail about type of command, please refer to OMX IL Specification 1.1.2, section 3.1.1.1.
	nParam1	Integer parameter for the command that is to be executed (represented for STATETYPE, number of ports).
	pCmdData	Pointer to a memory area contains specific parameters (mark buffer header).
Return value	OMX_ErrorBadParameter	Invalid command Invalid mark buffer area Invalid number of ports Destination state could not be recognized
	OMX_ErrorSameState	State transition is requested between same states.
	OMX_ErrorIncorrectStateTransition	The transition is invalid such as changing from OMX_StateExecuting to OMX_StatePause, etc.
	OMX_ErrorInvalidState	The current state is OMX_StateInvalid. The destination state is OMX_StateInvalid.
	OMX_ErrorNotImplemented	Don't support OMX_StatePause and OMX_StateWaitForResources
	OMX_ErrorInsufficientResources	Failed to initial codec setup due to not enough resource
	OMX_ErrorBadPortIndex	Port index is invalid.
	OMX_ErrorIncorrectStateOperation	Execution is invalid in the current state of component.
	OMX_ErrorUndefined	Undefined error while processing command
	OMX_ErrorNone	Normal end. Command sending succeeds.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.3.2.2 OMX_GetParameter

OMX_GetParameter		
Synopsis	Get the current parameter settings from the component	
Syntax	<pre>OMX_ERRORTYPE OMX_GetParameter(OMX_HANDLETYPE hComponent, OMX_INDEXTYPE nParamIndex, OMX_PTR pComponentParameterStructure);</pre>	
Parameter	hComponent	Pointer to memory area of component handle
	nParamIndex	<p>It indicates which structure is requested from the component. This value is from the OMX_INDEXTYPE enumeration. Supported index are:</p> <p>OMX_IndexParamPortDefinition OMX_IndexParamAudioPortFormat OMX_IndexParamPriorityMgmt OMX_IndexParamAudioPcm OMX_IndexParamCompBufferSupplier XAOMX_IndexParamAudioTDMRenderer XAOMX_IndexParamAudioTDMCapture</p>
	pComponentParameterStructure	<p>A pointer to the IL client-allocated structure that the component fills.</p> <p>For OpenMAX IL parameters setting structure please refer OMX IL Specification 1.1.2, section 3.1 and section 4.1.</p> <p>For TDM Renderer and TDM Capture parameters setting structure: XAOMX_AUDIO_PARAM_TDM_RENDERER XAOMX_AUDIO_PARAM_TDM_CAPTURE</p>
Return value	OMX_ErrorBadParameter	pParam points to invalid memory area.
	OMX_ErrorIncorrectStateOperation	Current state is OMX_StateInvalid.
	OMX_ErrorBadPortIndex	Port index of parameter is invalid.
	OMX_ErrorUnsupportedIndex	The index of parameter structure is not supported by component.
	OMX_ErrorNone	Normal ends. Getting parameter from component is successful.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.3.2.3 OMX_SetParameter

OMX_SetParameter		
Synopsis	Send a parameter structure to a component	
Syntax	<pre>OMX_ERRORTYPE OMX_SetParameter(OMX_HANDLETYPE hComponent, OMX_INDEXTYPE nIndex, OMX_PTR pComponentParameterStructure);</pre>	
Parameter	hComponent	Pointer to memory area of component handle
	nIndex	It indicates which structure is passed to the component. This value is from the OMX_INDEXTYPE enumeration. Supported index are: OMX_IndexParamPortDefinition OMX_IndexParamAudioPortFormat OMX_IndexParamPriorityMgmt OMX_IndexParamStandardComponentRole OMX_IndexParamAudioPcm OMX_IndexParamCompBufferSupplier XAOMX_IndexParamAudioTDMRenderer XAOMX_IndexParamAudioTDMCapture
	pComponentParameterStructure	A pointer to the IL client-allocated structure that the component fills. For OpenMAX IL parameters setting structure please refer OMX IL Specification 1.1.2, section 3.1 and section 4.1. For TDM Renderer and TDM Capture parameters setting structure: XAOMX_AUDIO_PARAM_TDM_RENDERER XAOMX_AUDIO_PARAM_TDM_CAPTURE
Return value	OMX_ErrorBadParameter	pParam points to invalid memory area.
	OMX_ErrorIncorrectStateOperation	Current state is OMX_StateInvalid. Port is locked. Current state is not OMX_StateLoaded. (for OMX_IndexParamPriorityMgmt and OMX_IndexParamStandardComponentRole)
	OMX_ErrorBadPortIndex	Port index of parameter is invalid.
	OMX_ErrorUnsupportedIndex	The index of parameter structure is not supported by component.
	OMX_ErrorNone	Normal ends. Setting parameter to component is successful.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.3.2.4 OMX_GetState

OMX_GetState		
Synopsis	Return the current state of the component	
Syntax	OMX_ERRORTYPE OMX_GetState(OMX_HANDLETYPE hComponent, OMX_STATETYPE *pState);	
Parameter	hComponent	Pointer to memory area of component handle
	*pState	Pointer to an allocated memory area used to store component state
Return value	OMX_ErrorBadParameter	pState points to an invalid memory area.
	OMX_ErrorNone	Normal end. Getting the state of the component is successful.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.3.2.5 OMX_AllocateBuffer

OMX_AllocateBuffer		
Synopsis	Allocate the buffer and the buffer header and return the pointer to the buffer header	
Syntax	<pre>OMX_ERRORTYPE OMX_AllocateBuffer(OMX_HANDLETYPE hComponent, OMX_BUFFERHEADERTYPE **ppBufHdr, OMX_U32 nPortIndex, OMX_PTR pAppPrivate, OMX_U32 nSizeBytes);</pre>	
Parameter	hComponent	Pointer to memory area of component handle
	**ppBufHdr	Pointer to OMX_BUFFERHEADERTYPE which contains meta-information about the buffer. It receives the pointer to the buffer header.
	nPortIndex	Target port (index into the port definition array of the component)
	pAppPrivate	Pointer to the private memory area of IL Client. It is used to initialize the pAppPrivate member of the buffer header structure.
	nSizeBytes	The size (byte) of the buffer to allocate
Return value	OMX_ErrorBadParameter	ppBufHdr points to an invalid memory area. Target port is invalid.
	OMX_ErrorInsufficientResources	Failed to allocate the buffer due to lack of needed resources
	OMX_ErrorIncorrectStateOperation	Port is not populated.
	OMX_ErrorUndefined	Undefined error while processing command
	OMX_ErrorNone	Normal end. Allocating the buffer is successful.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.3.2.6 OMX_FreeBuffer

OMX_FreeBuffer		
Synopsis	De-allocate buffer structure	
Syntax	<pre>OMX_ERRORTYPE OMX_FreeBuffer(OMX_HANDLETYPE hComponent, OMX_U32 nPortIndex, OMX_BUFFERHEADERTYPE *pBufHdr);</pre>	
Parameter	hComponent	Pointer to memory area of component handle
	nPortIndex	Target port (index into the port definition array of the component)
	*pBufHdr	Pointer to OMX_BUFFERHEADERTYPE structure which contains meta-information about the buffer. It specifies the index of the input port that receives the buffer.
Return value	OMX_ErrorBadParameter	pBufHdr points to an invalid memory area. Target port is invalid.
	OMX_ErrorIncorrectStateOperation	The port is not unpopulated (all buffers of the port is active (being used), so cannot free the buffer).
	OMX_ErrorUndefined	Undefined error while processing command
	OMX_ErrorNone	Normal end. Transferring the buffer to the client is successful.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.3.2.7 OMX_EmptyThisBuffer

OMX_EmptyThisBuffer		
Synopsis	Send a filled buffer to an input port of a component (*)	
Syntax	<pre>OMX_ERRORTYPE OMX_EmptyThisBuffer(OMX_HANDLETYPE hComponent, OMX_BUFFERHEADERTYPE *pBufHdr);</pre>	
Parameter	hComponent	Pointer to memory area of component handle
	*pBufHdr	Pointer to OMX_BUFFERHEADERTYPE structure which contains meta-information about the buffer. It specifies the index of the input port that receives the buffer.
Return value	OMX_ErrorBadParameter	pBufHdr points to an invalid memory area. Input length is zero.
	OMX_ErrorVersionMismatch	OMX structure version is not compliance.
	OMX_ErrorBadPortIndex	Port index of buffer is invalid.
	OMX_ErrorIncorrectStateOperation	Input port is disable or busy. Component is not in OMX_StateExecuting. Receiving a buffer after end-of-stream has been reported.
	OMX_ErrorNone	Normal end. Buffer is transferred to the input port of a component successfully.

(*)This API only need to call once in TDM Capture Interface to start-up TDM Capture function.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.3.2.8 OMX_FillThisBuffer

OMX_FillThisBuffer		
Synopsis	Send an empty buffer to an output port of a component then fill it with appropriate output data. (*)	
Syntax	<pre>OMX_ERRORTYPE OMX_FillThisBuffer(OMX_HANDLETYPE hComponent, OMX_BUFFERHEADERTYPE* pBufHdr);</pre>	
Parameter	hComponent	Pointer to memory area of component handle
	*pBufHdr	Pointer to OMX_BUFFERHEADERTYPE which contains meta-information about the buffer. It specifies the index of the output port that receives the buffer.
Return value	OMX_ErrorBadParameter	pBufHdr points to an invalid memory area.
	OMX_ErrorVersionMismatch	OMX structure version is not compliance.
	OMX_ErrorBadPortIndex	Port index of buffer is invalid.
	OMX_ErrorIncorrectStateOperation	Output port is disable or busy. Component is not in OMX_StateExecuting. Sending a buffer after end-of-stream has been reported.
	OMX_ErrorNone	Normal ends. Transferring buffer to client is successful.

(*) This API supports only TDM Capture interface.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.4 Callback function specification

The OpenMAX IL includes a callback mechanism that allows a component to communicate the IL client. To accomplish a callback, the IL client has three callback functions defined: a generic event handler and two callbacks related to the dataflow (EmptyBufferDone and FillBufferDone).

The IL client is responsible for filling in an OMX_CALLBACKTYPE structure with its callback entry points and passing the structure to the OpenMAX IL core at initialization (init) time.

OMX_CALLBACKTYPE is defined as follows.

```
typedef struct OMX_CALLBACKTYPE {
    OMX_ERRORTYPE (*EventHandler)(
        OMX_IN OMX_HANDLETYPE hComponent,
        OMX_IN OMX_PTR pAppData,
        OMX_IN OMX_EVENTTYPE eEvent,
        OMX_IN OMX_U32 nData1,
        OMX_IN OMX_U32 nData2,
        OMX_IN OMX_PTR pEventData);
    OMX_ERRORTYPE (*EmptyBufferDone)(
        OMX_IN OMX_HANDLETYPE hComponent,
        OMX_IN OMX_PTR pAppData,
        OMX_IN OMX_BUFFERHEADERTYPE* pBuffer);
    OMX_ERRORTYPE (*FillBufferDone)(
        OMX_IN OMX_HANDLETYPE hComponent,
        OMX_IN OMX_PTR pAppData,
        OMX_IN OMX_BUFFERHEADERTYPE* pBuffer);
} OMX_CALLBACKTYPE;
```


ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.4.1 EventHandler

A component uses the EventHandler method to notify the IL client when an event of interest occurs within the component. The OMX_EVENTTYPE enumeration defines the set of OpenMAX IL events; refer to the definition of this enumeration for the meaning of each event.

The EventHandler method is defined as follows.

```
OMX_ERRORTYPE(* OMX_CALLBACKTYPE::EventHandler)(  
    OMX_IN OMX_HANDLETYPE hComponent,  
    OMX_IN OMX_PTR pAppData,  
    OMX_IN OMX_EVENTTYPE eEvent,  
    OMX_IN OMX_U32 nData1,  
    OMX_IN OMX_U32 nData2,  
    OMX_IN OMX_PTR pEventData)
```

The information carried within nData1, nData2 and pEventData varies depending on OMX_EVENTTYPE, refer to Table 3-11 of OMX IL Specification v1.1.2 for specific details.

During the processing, component may update some information of output port from default values to exact values. User should take into account the OMX_EventPortSettingsChanged to correct their configurations by getting parameters from component again. Note that, for output port, user has to perform necessary steps to reconfigure the port (see 3.4.5 of OMX IL Specification v1.1.2 for more detail of sequence). However, for input port, user just has to get the parameter again and must not process any further step.

For more detail, please refer to OMX IL Specification 1.1.2, section 3.1.3.9

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.4.2 EmptyBufferDone

A component uses the EmptyBufferDone callback to pass a buffer from an input port back to the IL client. A component updates the nOffset and nFilledLen values of the buffer header to reflect the portion of the buffer it consumed; for example, nFilledLen is set equal to 0 if completely consumed.

In addition to facilitating normal data flow between an executing component and the IL client, a component uses the EmptyBufferDone function to return input buffers to the IL client in the following cases:

- The IL client commands a transition from OMX_StateExecuting or OMX_StatePause to OMX_StateIdle.
- The IL client flushes or disables a port.

In these cases, a component may also return a partially consumed input buffer to the IL client. The EmptyBufferDone call is defined as follows.

```
OMX_ERRORTYPE(* OMX_CALLBACKTYPE::EmptyBufferDone)(  
    OMX_IN OMX_HANDLETYPE hComponent,  
    OMX_IN OMX_PTR pAppData,  
    OMX_IN OMX_BUFFERHEADERTYPE* pBuffer)
```

For more detail, please refer to OMX IL Specification 1.1.2, section 3.1.3.9.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.4.3 FillBufferDone

Component uses the FillBufferDone callback to pass a buffer from an output port back to the IL client. Component sets the nOffset and nFilledLen of the buffer header to reflect the portion of the buffer it filled; for example, nFilledLen is equal to 0 if it contains no data).

In addition to facilitating normal dataflow between an executing component and the IL client, a component uses this function to return output buffers to the IL client in the following cases:

- The IL client commands a transition from OMX_StateExecuting or OMX_StatePause to OMX_StateIdle.
- The IL client flushes or disables a port.

FillBufferDone is defined as follows.

```
OMX_ERRORTYPE(* OMX_CALLBACKTYPE::FillBufferDone)(  
    OMX_IN OMX_HANDLETYPE hComponent,  
    OMX_IN OMX_PTR pAppData,  
    OMX_IN OMX_BUFFERHEADERTYPE* pBuffer)
```

For more detail, please refer to OMX IL Specification 1.1.2, section 3.1.3.9.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.5 Structure specification

2.5.1 XAOMX_AUDIO_PARAM_TDM_RENDERER

To configure the input port of component, OMX MC TDM Renderer receives the XAOMX_AUDIO_PARAM_TDM_RENDERER structure from user (with the index param XAOMX_IndexParamAudioTDMRenderer). User can also obtain the information of input port by get this structure from the component.

```
typedef struct XAOMX_AUDIO_PARAM_TDM_RENDERER
{
    OMX_U32                nSize;
    OMX_VERSIONTYPE        nVersion;
    OMX_U32                nPCM_frame_size;
    OMX_U32                nPCM_channel_mode;
    OMX_U32                nPCM_in_sample_rate;
    OMX_U32                nPCM_out_sample_rate;
    OMX_U32                nPCM_output1;
    OMX_U32                nPCM_dma_channel1;
    OMX_U32                nPCM_output2;
    OMX_U32                nPCM_dma_channel2;
    OMX_U32                nPCM_volume_rate;
} XAOMX_AUDIO_PARAM_TDM_RENDERER;
```

For more detail about OMX_VERSIONTYPE please refer to OMX IL Specification 1.1.2, section 3.1.2.4.

Table 2-4 shows the detail explanations of this structure. I/O column indicates the element is input or output; Input Value column indicate the valid input value can be set from user.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

Table 2-4 Parameters Structure of TDM Renderer

Element	I/O	Input Value	Default	Description
nSize	O	None	The size of structure	Fixed by component
nVersion	O	None	1.1.2.0	OMX specification version information
nPCM_frame_size	I/O	512 / 1024 / 2048 (*)	1024	PCM frame size in sample
nPCM_channel_mode	I/O	0 (4 stereo stream), 1 (1 eight channel stream), 3 (3 stereo stream), 4 (1 six channel stream)	0	Set the channel mode of TDM plugin
nPCM_in_sample_rate	I/O	32,000/44,100/48,000 Hz	44100	Set the PCM input sampling rate
nPCM_out_sample_rate	I/O	0/48,000/44,100 Hz	0	Set the PCM output sampling rate. When SRC module is not used, this value should be 0
nPCM_output1	I/O	-SSI device: SSI00, SSI10, SSI20, SSI30, SSI40, SSI90 -SRC device: SCU_SRCI0, SCU_SRCI1, SCU_SRCI3, SCU_SRCI4 -No use: NONCONFIG	SSI00	Set the 1 st output destination device
nPCM_dma_channel1	I/O	(ADMACPP_CH00 to ADMACPP_CH28) or (ADMAC_CH00 to ADMAC_CH31)	ADMACPP_CH00	Set the data transfer method control for the 1 st output device
nPCM_output2	I/O	-SSI device: SSI00, SSI10, SSI20, SSI30, SSI40, SSI90 -SRC device: SCU_SRCI0, SCU_SRCI1, SCU_SRCI3, SCU_SRCI4 -No use: NONCONFIG	NONCONFIG	Set the 2 nd output destination device
nPCM_dma_channel2	I/O	(ADMACPP_CH00 to ADMACPP_CH28) or (ADMAC_CH00 to ADMAC_CH31)	ADMACPP_CH01	Set the data transfer method control for the 2 nd output device
nPCM_volume_rate	I/O	0xFFFFFFFF and (0 to 0x7FFFFFFF)	0xFFFFFFFF	Set the volume control value. To disable volume control, this value is set to FFFFFFFF

Note:

(*): Frame size is 1024 is the best performance. Frame size are 512 or 2048 not guarantee the performance of TDM Renderer plugin.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

2.5.2 XAOMX_AUDIO_PARAM_TDM_CAPTURE

To configure the output port of component, OMX MC TDM Capture receives the XAOMX_AUDIO_PARAM_TDM_CAPTURE structure from user (with the index param XAOMX_IndexParamAudioTDMCapture). User can also obtain the information of output port by get this structure from the component.

```
typedef struct XAOMX_AUDIO_PARAM_TDM_CAPTURE
{
    OMX_U32                      nSize;
    OMX_VERSIONTYPE              nVersion;
    OMX_U32                      nPCM_frame_size;
    OMX_U32                      nPCM_channel_mode;
    OMX_U32                      nPCM_in_sample_rate;
    OMX_U32                      nPCM_out_sample_rate;
    OMX_U32                      nPCM_input1;
    OMX_U32                      nPCM_dma_channel1;
    OMX_U32                      nPCM_input2;
    OMX_U32                      nPCM_dma_channel2;
    OMX_U32                      nPCM_volume_rate;
} XAOMX_AUDIO_PARAM_TDM_CAPTURE;
```

For more detail about OMX_VERSIONTYPE please refer to OMX IL Specification 1.1.2, section 3.1.2.4.

Table 2-6 shows the detail explanations of this structure. I/O column indicates the element is input or output; Input Value column indicate the valid input value can be set from user.

ADSP TDM Renderer/Capture Interface for Linux Application Note - TDM R enderer/Capture -

Table 2-5 Parameters Structure of TDM Capture

Element	I/O	Input Value	Default	Description
nSize	O	None	The size of structure	Fixed by component
nVersion	O	None	1.1.2.0	OMX specification version information
nPCM_frame_size	I/O	512 / 1024 / 2048 (*)	1024	PCM frame size in sample
nPCM_channel_mode	I/O	0 (4 stereo stream), 1 (1 eight channel stream), 3 (3 stereo stream), 4 (1 six channel stream)	0	Set the channel mode of TDM plugin
nPCM_in_sample_rate	I/O	0/48,000/44,100 Hz	0	Set the PCM input sampling rate. When SRC module is not used, this value should be 0
nPCM_out_sample_rate	I/O	32,000/44,100/48,000 Hz	44100	Set the PCM output sampling rate.
nPCM_input1	I/O	+SSI device: SSI00, SSI10, SSI20, SSI30, SSI40, SSI90 -SRC device: SCU_SRCI0, SCU_SRCI1, SCU_SRCI3, SCU_SRCI4 -No use: NONCONFIG	SSI10	Set the 1 st input destination device
nPCM_dma_channel1	I/O	(ADMACPP_CH00 to ADMACPP_CH28) or (ADMAC_CH00 to ADMAC_CH31)	ADMACPP_CH00	Set the data transfer method control for the 1 st input device
nPCM_input2	I/O	-SSI device: SSI00, SSI10, SSI20, SSI30, SSI40, SSI90 -SRC device: SCU_SRCI0, SCU_SRCI1, SCU_SRCI3, SCU_SRCI4 -No use: NONCONFIG	NONCONFIG	Set the 2 nd input destination device
nPCM_dma_channel2	I/O	(ADMACPP_CH00 to ADMACPP_CH28) or (ADMAC_CH00 to ADMAC_CH31)	ADMACPP_CH01	Set the data transfer method control for the 2 nd input device
nPCM_volume_rate	I/O	0xFFFFFFFF and (0 to 0x7FFFFFFF)	0xFFFFFFFF	Set the volume control value. To disable volume control, this value is set to FFFFFFFF

Note:

(*): Frame size is 1024 is the best performance. Frame size are 512 or 2048 not guarantee the performance of TDM Capture plugin.

3 Process sequence

3.1 Initialize Component




Figure 3-1 Initialize the Component and preparation phase

3.2 Decoding sequence




Figure 3-2 Decoding sequence

3.3 De-initialize Component




Figure 3-3 De-Initialize Component and OMX IL Core

Note: The order of 2: return (of SendCommand) and 3: EventCallback is not guaranteed. It depends on the current status of component.

4 Notes

This section describes the notice of developing user programs.

4.1 Function Call

User programs which calls the functions in this specification should obey the calling rules of compiler.

4.2 Other notes

4.2.1 Allocation of memory

Before calling the functions in this specification, allocate necessary memory area and each structure used for the parameters of each function.

4.2.2 Out of range memory access

The functions in this specification never access out of allocated memory or related I/O.

4.2.3 Combination with other applications

Take care not to duplicate symbol names when other applications are combined with other programs.

4.2.4 Monitoring on Performance

The products embedding this Software shall observe performance of the Software periodically with Watch Dog timer or such functions in order not to damage system performance.

CONFIDENTIAL

Revision History	ADSP Interface for Linux Application Note - TDM Renderer/Capture -
------------------	--

Rev.	Date	Description	
		Page	Summary
1.00	Jan. 29, 2018	-	New Create
1.01	Jun. 28, 2018	-	Style Modify
1.02	Oct. 29, 2018	28	Remove value 32kHz in range of output sample rate
2.00	Dec. 25, 2018	-	Official Release
		6	Add note the reason OMX_SetupTunnel, OMX_TeardownTunnel and UseBuffer unavailable(x) of TDM
		12, 13, 18	Remove OMX_SetupTunnel, OMX_TeardownTunnel, OMX_UseBuffer function
		12	Change details of "OMX_ErrorIncorrectStateTransition"
		28, 30	Update note

ADSP TDM Renderer/Capture Interface for Linux Application Note -
TDM Renderer/Capture -

Publication Date: Dec 25, 2018 Rev. 2.00

Published by: Renesas Electronics Corporation



SALES OFFICES

Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

Renesas Electronics Corporation

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061, Japan

Renesas Electronics America Inc.

1001 Murphy Ranch Road, Milpitas, CA 95035, U.S.A.

Tel: +1-408-432-8888, Fax: +1-408-434-5351

Renesas Electronics Canada Limited

9251 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3

Tel: +1-905-237-2004

Renesas Electronics Europe Limited

Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K

Tel: +44-1628-651-700

Renesas Electronics Europe GmbH

Arcadiastrasse 10, 40472 Düsseldorf, Germany

Tel: +49-211-6503-0, Fax: +49-211-6503-1327

Renesas Electronics (China) Co., Ltd.

Room 1709 Quantum Plaza, No.27 ZhichunLu, Haidian District, Beijing, 100191 P. R. China

Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

Renesas Electronics (Shanghai) Co., Ltd.

Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai, 200333 P. R. China

Tel: +86-21-2226-0888, Fax: +86-21-2226-0999

Renesas Electronics Hong Kong Limited

Unit 1601-1611, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong

Tel: +852-2265-6688, Fax: +852 2886-9022

Renesas Electronics Taiwan Co., Ltd.

13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan

Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

Renesas Electronics Singapore Pte. Ltd.

80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre, Singapore 339949

Tel: +65-6213-0200, Fax: +65-6213-0300

Renesas Electronics Malaysia Sdn.Bhd.

Unit 1207, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia

Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

Renesas Electronics India Pvt. Ltd.

No.777C, 100 Feet Road, HAL 2nd Stage, Indiranagar, Bangalore 560 038, India

Tel: +91-80-67208700, Fax: +91-80-67208777

Renesas Electronics Korea Co., Ltd.

17F, KAMCO Yangjae Tower, 262, Gangnam-daero, Gangnam-gu, Seoul, 06265 Korea

Tel: +82-2-558-3737, Fax: +82-2-558-5338



ルネサスエレクトロニクス株式会社

営業お問い合わせ窓口

<http://www.renesas.com>

営業お問い合わせ窓口の住所は変更になることがあります。最新情報につきましては、弊社ホームページをご覧ください。

ルネサス エレクトロニクス株式会社 〒135-0061 東京都江東区豊洲3-2-24 (豊洲フォレシア)

技術的なお問合せおよび資料のご請求は下記へどうぞ。
総合お問い合わせ窓口：<https://www.renesas.com/contact/>

ADSP TDM Renderer/Capture Interface for Linux

RCG3AHIFL4101ZDP