

CONFIDENTIAL

ADSP Interface for Android RCG3AHIFA9001ZDP

Application Note - Renderer/Capture -

RCG3AHIFA9001ZDPE_AN_RDR

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Electronics Corp. website (<http://www.renesas.com>).

Rev. 1.00 May, 2019

CONFIDENTIAL

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
 2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
 3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
 4. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
 5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.
"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.
"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.
Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.
 6. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
 7. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
 8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
 9. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
 10. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
 11. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

CONFIDENTIAL

Trademarks

- Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.
- Android™ is a trademark of Google LLC. Use of this trademark is subject to Google Permissions.
- Arm is a registered trademark of Arm Limited (or its subsidiaries) in the US and/or elsewhere.
- Windows and Windows Media are registered trademarks of Microsoft Corporation in the United States and other countries.
- Android is a trademark of Google Inc. Use of this trademark is subject to Google permissions.
- All other company names and product names mentioned in this manual are registered trademarks or trademarks of their respective companies.
- The registered trademark symbol (®) and trademark symbol (™) are omitted in this manual.

How to Use This Manual

1. Purpose and Target Reader

This manual is designed to provide the user with an understanding of the interface specifications of the Software product. It is intended for users designing application systems incorporating the Software product. Please refer to the related documents with this product.

Use this Software after carefully reading the precautions. The precautions are stated in the main text of each section, at the end of each section, and in the usage precaution section.

The revision history summarizes major corrections and additions to the previous version. It does not cover all the changes. For details, refer to this manual.

2. Restrictions on the Use of this Middleware

Any customer who wishes to use this Software must obtain a software license from Renesas Electronics.

3. Related Manuals

4. Technical Terms and Abbreviation



- Table of Contents -

| | | |
|----------|---|-----------|
| 1 | OVERVIEW | 3 |
| 1.1 | Overview of this document. | 3 |
| 1.2 | The architecture of the Software and scope of this document | 3 |
| 1.3 | Software necessary to be prepared in advance | 4 |
| 1.4 | Related documents | 4 |
| 2 | SOFTWARE SPECIFICATION | 5 |
| 2.1 | The list of functions | 5 |
| 2.2 | The list of structures | 7 |
| 2.3 | Function specification | 8 |
| 2.3.1 | IL Core method | 8 |
| 2.3.1.1 | OMX_Init | 8 |
| 2.3.1.2 | OMX_Deinit | 9 |
| 2.3.1.3 | OMX_GetHandle | 10 |
| 2.3.1.4 | OMX_FreeHandle | 11 |
| 2.3.1.5 | OMX_SetupTunnel | 12 |
| 2.3.1.6 | OMX_TeardownTunnel | 13 |
| 2.3.2 | Component API | 14 |
| 2.3.2.1 | OMX_SendCommand | 14 |
| 2.3.2.2 | OMX_GetParameter | 15 |
| 2.3.2.3 | OMX_SetParameter | 16 |
| 2.3.2.4 | OMX_GetState | 17 |
| 2.3.2.5 | OMX_UseBuffer | 18 |
| 2.3.2.6 | OMX_AllocateBuffer | 19 |
| 2.3.2.7 | OMX_FreeBuffer | 20 |
| 2.3.2.8 | OMX_EmptyThisBuffer | 21 |
| 2.3.2.9 | OMX_FillThisBuffer | 22 |
| 2.3.2.10 | OMX_SetConfig | 23 |
| 2.4 | Callback function specification | 24 |
| 2.4.1 | EventHandler | 25 |
| 2.4.2 | EmptyBufferDone | 26 |
| 2.4.3 | FillBufferDone | 27 |
| 2.5 | Structure specification | 28 |
| 2.5.1 | XAOMX_AUDIO_PARAM_RENDERER | 28 |
| 2.5.2 | XAOMX_AUDIO_PARAM_CAPTURE | 31 |
| 3 | PROCESS SEQUENCE | 34 |
| 3.1 | Initialize Component | 34 |
| 3.2 | Decoding sequence | 35 |
| 3.3 | De-initialize Component | 36 |
| 4 | NOTES | 37 |
| 4.1 | Function Call | 37 |
| 4.2 | Other notes | 37 |
| 4.2.1 | Allocation of memory | 37 |
| 4.2.2 | Out of range memory access | 37 |
| 4.2.3 | Combination with other applications | 37 |



| | | |
|-------|---------------------------------|----|
| 4.2.4 | Monitoring on Performance | 37 |
|-------|---------------------------------|----|

- List of Figures -

| | | |
|------------|--|----|
| Figure 1-1 | The software architecture | 3 |
| Figure 3-1 | Initialize the Component and preparation phase | 34 |
| Figure 3-2 | Decoding sequence | 35 |
| Figure 3-3 | De-Initialize Component and OMX IL Core | 36 |

- List of Tables -

| | | |
|-----------|--|----|
| Table 1-1 | Supported features for OMX Interface | 4 |
| Table 1-2 | The list of related documents | 4 |
| Table 2-1 | List of functions | 5 |
| Table 2-2 | List of available functions between Renderer and Capture | 6 |
| Table 2-3 | List of structures | 7 |
| Table 2-4 | Parameters Structure of Renderer | 29 |
| Table 2-5 | PCM stream setting of Renderer | 30 |
| Table 2-6 | Parameters Structure of Capture | 32 |
| Table 2-7 | PCM stream setting of Capture | 33 |

1 Overview

1.1 Overview of this document.

In this chapter, overview of Renderer/Capture interface is explained.

1.2 The architecture of the Software and scope of this document

The architecture of ADSP Interface for Android is shown in Figure 1-1. ADSP Interface for Android is a user space library which provides the interface to control ADSP Renderer Plugin and ADSP Capture Plugin.




Figure 1-1 The software architecture



Note:

- Renderer function is used to output the raw Pulse Code Modulation (PCM) audio data to the configured output device. The user can setup the data path before using Renderer Interface or can setting the data path inside of Renderer Interface.

- Capture function is used to capture/record the raw Pulse Code Modulation (PCM) audio data from configured input device. The user can setup the data path before using Capture Interface or can setting the data path inside of Capture Interface.

Table 1-1 shows supported features for OMX CAPTURE and OMX RENDERER

Table 1-1 Supported features for OMX Interface

| Name | Renderer Interface | Capture Interface |
|----------|--------------------|-------------------|
| ADMAC | O | O |
| ADMACPP | O | O |
| SSIU/SSI | O | O |
| SRC | O | O |
| DVC | O | O |
| CTU | O | X |
| MIX | O | X |

Implementation:

O: Supported.

X: Not supported.

Note: ADSP Capture Plugin does not support CTU and MIX functionalities.

1.3 Software necessary to be prepared in advance

ADSP Driver for Android should be loaded in advance to use ADSP Interface for Android.

1.4 Related documents

Table 1-2 shows related documents.

Table 1-2 The list of related documents

| No. | Name | Published by |
|-----|--|---------------------------------|
| [1] | R-Car Series, 3rd Generation User's Manual: Hardware | Renesas Electronics Corporation |
| [2] | OpenMAX IL Specification 1.1.2 | Renesas Electronics Corporation |

2 Software specification

2.1 The list of functions

Table 2-1 shows the functions provided by this software. See 2.3 for more detailed specification of the functions.

Table 2-1 List of functions

| | Name | Outline |
|----------------|----------------------|---|
| IL Core Method | OMX_Init | Initialize the OpenMAX™ IL core |
| | OMX_Deinit | De-initialize the OpenMAX™ IL core |
| | OMX_GetHandle | Load that component into memory, validate it and return the component handle via the output parameter |
| | OMX_FreeHandle | Free a component handle (allocated by the OMX_GetHandle) |
| | OMX_SetupTunnel | Establish a tunnel between components |
| | OMX_TearardownTunnel | Clears tunneled communication between components |
| Component API | OMX_SendCommand | Send the command from application (IL-client) to component |
| | OMX_GetParameter | Retrieve the parameter from the OMX component |
| | OMX_SetParameter | Setup the parameter to the OMX component |
| | OMX_GetState | Get the current state of the component |
| | OMX_UseBuffer | Pass the handle to the buffer allocated by application |
| | OMX_AllocateBuffer | Allocate buffer on behalf of a component |
| | OMX_FreeBuffer | De-allocate buffer structure |
| | OMX_EmptyThisBuffer | Pass filled input buffer to the component |
| | OMX_FillThisBuffer | Pass the free output buffer to the component |
| | OMX_SetConfig | Set ADSP Plugin-in configuration value |

ADSP Interface for Android Application Note - Renderer/Capture -

Table 2-2 shows the different functions between Renderer and Capture Interface.

Table 2-2 List of available functions between Renderer and Capture

| | Name | Renderer Interface | Capture Interface |
|----------------|--------------------------|--------------------|-------------------|
| IL Core Method | OMX_Init (*) | O | O |
| | OMX_Deinit (**) | O | O |
| | OMX_GetHandle | O | O |
| | OMX_FreeHandle | O | O |
| | OMX_SetupTunnel | O | O |
| | OMX_TeardownTunnel | O | O |
| Component API | OMX_SendCommand | O | O |
| | OMX_GetParameter | O | O |
| | OMX_SetParameter | O | O |
| | OMX_GetState | O | O |
| | OMX_UseBuffer | O | O |
| | OMX_AllocateBuffer | O | O |
| | OMX_FreeBuffer | O | O |
| | OMX_EmptyThisBuffer | O | O |
| | OMX_FillThisBuffer (***) | X | O |
| | OMX_SetConfig | O | O |

Implementation:

O: Supported.

X: Not supported.

Note:

(*) OMX_Init function will be called only one time for the using of all the OpenMAX Media component (OMX Equalizer, OMX Renderer, OMX Capture).

(**) OMX_Deinit function will be called only one time for the using of all the OpenMAX Media component (OMX Equalizer, OMX Renderer, OMX Capture).

(***) OMX_FillThisBuffer function is not supported for Renderer Interface due to the output data will be output to speaker device.

2.2 The list of structures

Table 2-3 shows the list of structures which user should allocate memory in using the software. See 2.5 for more detailed specification of the structures.

Table 2-3 List of structures

| Name | Outline |
|----------------------------|---|
| XAOMX_AUDIO_PARAM_RENDERER | The structure of parameters for OMX MC Renderer |
| XAOMX_AUDIO_PARAM_CAPTURE | The structure of parameters for OMX MC Capture |

For more detail about OpenMAX IL Structures, please refer to OMX IL Specification 1.1.2, section 3.1 and section 4.1.

2.3 Function specification

2.3.1 IL Core method

2.3.1.1 OMX_Init

| OMX_Init | | |
|---------------|---|---|
| Synopsis | Initialize the OpenMAX™ IL core, including memory allocation and preparation for loading components. The OpenMAX™ IL core functions are ready to be used when this function returns successfully. (*) | |
| Syntax | OMX_API OMX_ERRORTYPE OMX_APIENTRY OMX_Init(); | |
| Parameter | None | |
| Return values | OMX_ErrorInsufficientResources | Failed to initialize due to not enough resource |
| | OMX_ErrorUndefined | Undefined error while processing command |
| | OMX_ErrorNone | Normal ends. Initialize successfully |

(*) OMX_Init shall be the first call made into OpenMAX IL and should be executed only one time without an intervening OMX_Deinit call. It will be called only one time for the using of OMX MC Equalizer, OMX MC Renderer and OMX MC Capture.

2.3.1.2 OMX_Deinit

| OMX_Deinit | | |
|---------------|---|--|
| Synopsis | De-initializes OMX IL core, including its allocated memory and objects use to load/manage components. (*) | |
| Syntax | OMX_API OMX_ERRORTYPE OMX_APIENTRY OMX_Deinit(); | |
| Parameter | None | |
| Return values | OMX_ErrorUndefined | Undefined error while processing command |
| | OMX_ErrorNone | Normal ends. De-initialize successfully |

(*) OMX_Deinit should be the last call made into the OpenMAX IL core after all OpenMAX IL-related resources have been released. It will be called only one time for the using of OMX MC Equalizer, OMX MC Renderer and OMX MC Capture.

2.3.1.3 OMX_GetHandle

| OMX_GetHandle | | |
|---------------|--|--|
| Synopsis | Locate the component specified by the component name given, load that component into memory, validate it and return the component handle via the output parameter. | |
| Syntax | <pre>OMX_API OMX_ERRORTYPE OMX_APIENTRY OMX_GetHandle (OMX_OUT OMX_HANDLETYPE * pHandle, OMX_IN OMX_STRING cComponentName, OMX_IN OMX_PTR pAppData, OMX_IN OMX_CALLBACKTYPE * pCallbacks);</pre> | |
| Parameter | pHandle | A pointer to OMX_HANDLETYPE to be filled in by this method |
| | cComponentName | A pointer to a string specifies the component name. Supported names for Renderer and Capture respectively are: "OMX.RENESAS.AUDIO.DSP.RENDERER" "OMX.RENESAS.AUDIO.DSP.CAPTURE" |
| | pAppData | A pointer to an IL client-defined value that will be returned during callbacks so that the IL client can identify the source of the callback. |
| | pCallbacks | A pointer to an OMX_CALLBACKTYPE structure containing the callbacks that the component will use for this IL client. |
| Return values | OMX_ErrorInvalidState | The proxy is not initialized. |
| | OMX_ErrorInsufficientResources | Failed to locate the component due to not enough resource |
| | OMX_ErrorInvalidComponentName | The component name parameter is invalid. |
| | OMX_ErrorNone | Normal ends. Get handle successfully |

2.3.1.4 OMX_FreeHandle

| OMX_FreeHandle | | |
|----------------|--|--|
| Synopsis | Free a handle allocated by the OMX_GetHandle method. The IL client should call OMX_FreeHandle only when the component is in the OMX_StateLoaded and all the ports are not connected via any tunnels. | |
| Syntax | OMX_API OMX_ERRORTYPE OMX_APIENTRY OMX_FreeHandle(OMX_IN OMX_HANDLETYPE hComponent); | |
| Parameter | hComponent | The handle of the component to be freed |
| Return values | OMX_ErrorBadParameter | hComponent points to an invalid memory area. |
| | OMX_ErrorNone | Normal ends. Free handle successfully |

2.3.1.5 OMX_SetupTunnel

| OMX_SetupTunnel | | |
|-----------------|---|---|
| Synopsis | Handle the necessary calls to the components to setup the specified tunnel the two components. This method shall not be called unless the component is in the OMX_StateLoaded state except when the ports used for the tunnel are disabled (OMX_StateExecuting, OMX_StatePause, or OMX_StateIdle states). | |
| Syntax | <pre>OMX_API OMX_ERRORTYPE OMX_APIENTRY OMX_SetupTunnel(OMX_IN OMX_HANDLETYPE hOutput, OMX_IN OMX_U32 nPortOutput, OMX_IN OMX_HANDLETYPE hInput, OMX_IN OMX_U32 nPortInput);</pre> | |
| Parameter | hOutput | Handle of the component whose port, specified in the nPortOutput parameter will be used as the source for the tunnel. |
| | nPortOutput | Select the source port on component to be used in the tunnel |
| | hInput | Handle of the component whose port, specified in the nPortInput parameter will be used as the destination for the tunnel. |
| | nPortInput | Select the destination port on component to be used in the tunnel |
| Return value | OMX_ErrorBadParameter | Both hOutput and hInput component point to are invalid memory area. |
| | OMX_ErrorUndefined | Undefined error while processing command |
| | OMX_ErrorPortsNotCompatible | One or both components is a non-interop component and does not support tunneling. |
| | OMX_ErrorBadPortIndex | Port index is invalid. |
| | OMX_ErrorIncorrectStateOperation | Component is not in OMX_StateLoaded. |
| | OMX_ErrorNone | Normal ends. Setup tunnel successfully |

2.3.1.6 OMX_TeardownTunnel

| OMX_TeardownTunnel | | |
|--------------------|--|---|
| Synopsis | Clear tunneled communication between an output port and an input port. After OMX_TeardownTunnel returns successfully, these ports are no longer connected together. | |
| Syntax | <pre>OMX_API OMX_ERRORTYPE OMX_APIENTRY OMX_TeardownTunnel(OMX_IN OMX_HANDLETYPE hOutput, OMX_IN OMX_U32 nPortOutput, OMX_IN OMX_HANDLETYPE hInput, OMX_IN OMX_U32 nPortInput);</pre> | |
| Parameter | hOutput | Handle of the component whose port, specified in the nPortOutput parameter are being used as the source for the tunnel. |
| | nPortOutput | Select the source port on component being used in the tunnel |
| | hInput | Handle of the component whose port, specified in the nPortInput parameter are being used as the destination for the tunnel. |
| | nPortInput | Select the destination port on component being used in the tunnel |
| Return value | OMX_ErrorBadParameter | hOutput or hInput component points to invalid memory area. |
| | OMX_ErrorBadPortIndex | Port index is invalid. |
| | OMX_ErrorIncorrectStateOperation | Component is not in OMX_StateLoaded. |
| | OMX_ErrorNone | Normal ends. Teardown tunnel successfully |

2.3.2 Component API

2.3.2.1 OMX_SendCommand

| OMX_SendCommand | | |
|-----------------|---|--|
| Synopsis | Receive a command from the client and make a queue for serial execution in separated component thread | |
| Syntax | <pre>OMX_ERRORTYPE OMX_SendCommand(OMX_IN OMX_HANDLETYPE hComponent, OMX_IN OMX_COMMANDTYPE Cmd, OMX_IN OMX_U32 nParam1, OMX_IN OMX_PTR pCmdData);</pre> | |
| Parameter | hComponent | Pointer to memory area of component handle |
| | Cmd | Type of command. For more detail about type of command, please refer to OMX IL Specification 1.1.2, section 3.1.1.1. |
| | nParam1 | Integer parameter for the command that is to be executed (represented for STATETYPE, number of ports). |
| | pCmdData | Pointer to a memory area contains specific parameters (mark buffer header). |
| Return value | OMX_ErrorBadParameter | Invalid command Invalid mark buffer area Invalid number of ports Destination state could not be recognized |
| | OMX_ErrorSameState | State transition is requested between same states. |
| | OMX_ErrorIncorrectStateTransition | The transition is invalid such as changing from OMX_StateExecuting to OMX_StatePause, etc. |
| | OMX_ErrorInvalidState | The current state is OMX_StateInvalid. The destination state is OMX_StateInvalid. |
| | OMX_ErrorNotImplemented | Don't support OMX_StatePause and OMX_StateWaitForResources |
| | OMX_ErrorInsufficientResources | Failed to initial codec setup due to not enough resource |
| | OMX_ErrorBadPortIndex | Port index is invalid. |
| | OMX_ErrorIncorrectStateOperation | Execution is invalid in the current state of component. |
| | OMX_ErrorUndefined | Undefined error while processing command |
| | OMX_ErrorNone | Normal end. Command sending succeeds. |

2.3.2.2 OMX_GetParameter

| OMX_GetParameter | | |
|------------------|---|--|
| Synopsis | Get the current parameter settings from the OMX component | |
| Syntax | <pre>OMX_ERRORTYPE OMX_GetParameter(OMX_IN OMX_HANDLETYPE hComponent, OMX_IN OMX_INDEXTYPE nParamIndex, OMX_INOUT OMX_PTR pComponentParameterStructure);</pre> | |
| Parameter | hComponent | Pointer to memory area of component handle |
| | nParamIndex | It indicates which structure is requested from the component. This value is from the OMX_INDEXTYPE enumeration. Supported index are: OMX_IndexParamPortDefinition OMX_IndexParamAudioPortFormat OMX_IndexParamPriorityMgmt OMX_IndexParamAudioPcm XAOMX_IndexParamAudioRenderer XAOMX_IndexParamAudioCapture |
| | pComponentParameterStructure | A pointer to the IL client-allocated structure that the component fills. For OpenMAX IL parameters setting structure please refer OMX IL Specification 1.1.2, section 3.1 and section 4.1. For Renderer and Capture parameters setting structure: XAOMX_AUDIO_PARAM_RENDERER XAOMX_AUDIO_PARAM_CAPTURE |
| Return value | OMX_ErrorBadParameter | pComponentParameterStructure points to invalid memory area. |
| | OMX_ErrorIncorrectStateOperation | Current state is OMX_StateInvalid. |
| | OMX_ErrorBadPortIndex | Port index of parameter is invalid. |
| | OMX_ErrorUnsupportedIndex | The index of parameter structure is not supported by component. |
| | OMX_ErrorNone | Normal ends. Getting parameter from component is successful. |

2.3.2.3 OMX_SetParameter

| OMX_SetParameter | | |
|------------------|---|--|
| Synopsis | Send a parameter structure to a OMX component | |
| Syntax | <pre>OMX_ERRORTYPE OMX_SetParameter(OMX_IN OMX_HANDLETYPE hComponent, OMX_IN OMX_INDEXTYPE nIndex, OMX_IN OMX_PTR pComponentParameterStructure);</pre> | |
| Parameter | hComponent | Pointer to memory area of component handle |
| | nIndex | It indicates which structure is passed to the component. This value is from the OMX_INDEXTYPE enumeration. Supported index are: OMX_IndexParamPortDefinition OMX_IndexParamAudioPortFormat OMX_IndexParamPriorityMgmt OMX_IndexParamStandardComponentRole OMX_IndexParamAudioPcm XAOMX_IndexParamAudioRenderer XAOMX_IndexParamAudioCapture |
| | pComponentParameterStructure | A pointer to the IL client-allocated structure that the component fills. For OpenMAX IL parameters setting structure please refer OMX IL Specification 1.1.2, section 3.1 and section 4.1. For Renderer and Capture parameters setting structure: XAOMX_AUDIO_PARAM_RENDERER XAOMX_AUDIO_PARAM_CAPTURE |
| Return value | OMX_ErrorBadParameter | pComponentParameterStructure points to invalid memory area. |
| | OMX_ErrorIncorrectStateOperation | Current state is OMX_StateInvalid. Port is locked. Current state is not OMX_StateLoaded. (for OMX_IndexParamPriorityMgmt and OMX_IndexParamStandardComponentRole) |
| | OMX_ErrorBadPortIndex | Port index of parameter is invalid. |
| | OMX_ErrorUnsupportedIndex | The index of parameter structure is not supported by component. |
| | OMX_ErrorNone | Normal ends. Setting parameter to component is successful. |

2.3.2.4 OMX_GetState

| OMX_GetState | | |
|--------------|---|---|
| Synopsis | Return the current state of the component | |
| Syntax | OMX_ERRORTYPE OMX_GetState(OMX_IN OMX_HANDLETYPE hComponent, OMX_OUT OMX_STATETYPE *pState); | |
| Parameter | hComponent | Pointer to memory area of component handle |
| | *pState | Pointer to an allocated memory area used to store component state |
| Return value | OMX_ErrorBadParameter | pState points to an invalid memory area. |
| | OMX_ErrorNone | Normal end. Getting the state of the component is successful. |

2.3.2.5 OMX_UseBuffer

| OMX_UseBuffer | | |
|---------------|--|--|
| Synopsis | Use a buffer allocated by the IL Client to a port or supplied by a tunneling component | |
| Syntax | <pre>OMX_ERRORTYPE OMX_UseBuffer(OMX_IN OMX_HANDLETYPE hComponent, OMX_INOUT OMX_BUFFERHEADERTYPE **ppBufferHdr, OMX_IN OMX_U32 nPortIndex, OMX_IN OMX_PTR pAppPrivate, OMX_IN OMX_U32 nSizeBytes, OMX_IN OMX_U8 *pBuffer);</pre> | |
| Parameter | hComponent | Pointer to memory area of component handle |
| | **ppBufferHdr | Pointer to OMX_BUFFERHEADERTYPE which contains meta-information about the buffer. It receives the pointer to the buffer header. |
| | nPortIndex | Target port that uses the buffer (index into the port definition array of the component). |
| | pAppPrivate | Pointer to the private memory area of IL Client. It is used to initialize the pAppPrivate member of the buffer header structure. |
| | nSizeBytes | The size (byte) of the buffer to allocate |
| | *pBuffer | Pointer to the allocated buffer to be used |
| Return value | OMX_ErrorBadParameter | ppBufferHdr points to an invalid memory area. Target port is invalid. Buffer size is not suitable. |
| | OMX_ErrorIncorrectStateOperation | Port is not populated. |
| | OMX_ErrorUndefined | Undefined error while processing command |
| | OMX_ErrorNone | Normal end. Setting the buffer to the target port is successful. |

2.3.2.6 OMX_AllocateBuffer

| OMX_AllocateBuffer | | |
|--------------------|--|--|
| Synopsis | Allocate the buffer and the buffer header, request mapping the buffer with data buffer in ADSP and return the pointer to the buffer header | |
| Syntax | <pre>OMX_ERRORTYPE OMX_AllocateBuffer(OMX_IN OMX_HANDLETYPE hComponent, OMX_INOUT OMX_BUFFERHEADERTYPE **ppBuffer, OMX_IN OMX_U32 nPortIndex, OMX_IN OMX_PTR pAppPrivate, OMX_IN OMX_U32 nSizeBytes);</pre> | |
| Parameter | hComponent | Pointer to memory area of component handle |
| | **ppBuffer | Pointer to OMX_BUFFERHEADERTYPE which contains meta-information about the buffer. It receives the pointer to the buffer header. |
| | nPortIndex | Target port (index into the port definition array of the component) |
| | pAppPrivate | Pointer to the private memory area of IL Client. It is used to initialize the pAppPrivate member of the buffer header structure. |
| | nSizeBytes | The size (byte) of the buffer to allocate |
| Return value | OMX_ErrorBadParameter | ppBuffer points to an invalid memory area. Target port is invalid. |
| | OMX_ErrorInsufficientResources | Failed to allocate the buffer due to lack of needed resources |
| | OMX_ErrorIncorrectStateOperation | Port is not populated. |
| | OMX_ErrorUndefined | Undefined error while processing command |
| | OMX_ErrorNone | Normal end. Allocating the buffer is successful. |

2.3.2.7 OMX_FreeBuffer

| OMX_FreeBuffer | | |
|----------------|--|--|
| Synopsis | De-allocate buffer structure | |
| Syntax | OMX_ERRORTYPE OMX_FreeBuffer(OMX_IN OMX_HANDLETYPE hComponent, OMX_IN OMX_U32 nPortIndex, OMX_IN OMX_BUFFERHEADERTYPE *pBuffer); | |
| Parameter | hComponent | Pointer to memory area of component handle |
| | nPortIndex | Target port (index into the port definition array of the component) |
| | *pBuffer | Pointer to OMX_BUFFERHEADERTYPE structure which contains meta-information about the buffer. It specifies the index of the input port that receives the buffer. |
| Return value | OMX_ErrorBadParameter | pBuffer points to an invalid memory area. Target port is invalid. |
| | OMX_ErrorIncorrectStateOperation | The port is not unpopulated (all buffers of the port is active (being used), so cannot free the buffer). |
| | OMX_ErrorUndefined | Undefined error while processing command |
| | OMX_ErrorNone | Normal end. Transferring the buffer to the client is successful. |

2.3.2.8 OMX_EmptyThisBuffer

| OMX_EmptyThisBuffer | | |
|---------------------|--|--|
| Synopsis | Send a filled buffer to an input port of a component (*) | |
| Syntax | <pre>OMX_ERRORTYPE OMX_EmptyThisBuffer(OMX_IN OMX_HANDLETYPE hComponent, OMX_IN OMX_BUFFERHEADERTYPE *pBuffer);</pre> | |
| Parameter | hComponent | Pointer to memory area of component handle |
| | *pBuffer | Pointer to OMX_BUFFERHEADERTYPE structure which contains meta-information about the buffer. It specifies the index of the input port that receives the buffer. |
| Return value | OMX_ErrorBadParameter | pBuffer points to an invalid memory area. Input length is zero. |
| | OMX_ErrorBadPortIndex | Port index of buffer is invalid. |
| | OMX_ErrorIncorrectStateOperation | Input port is disable or busy. Component is not in OMX_StateExecuting. Receiving a buffer after end-of-stream has been reported. |
| | OMX_ErrorNone | Normal end. Buffer is transferred to the input port of a component successfully. |

(*)This API only need to call once in Capture Interface to start-up Capture function.

2.3.2.9 OMX_FillThisBuffer

| OMX_FillThisBuffer | | |
|--------------------|--|---|
| Synopsis | Send an empty buffer to an output port of a component then fill it with appropriate output data. (*) | |
| Syntax | OMX_ERRORTYPE OMX_FillThisBuffer(OMX_IN OMX_HANDLETYPE hComponent, OMX_IN OMX_BUFFERHEADERTYPE* pBuffer); | |
| Parameter | hComponent | Pointer to memory area of component handle |
| | *pBuffer | Pointer to OMX_BUFFERHEADERTYPE which contains meta-information about the buffer. It specifies the index of the output port that receives the buffer. |
| Return value | OMX_ErrorBadParameter | pBuffer points to an invalid memory area. |
| | OMX_ErrorBadPortIndex | Port index of buffer is invalid. |
| | OMX_ErrorIncorrectStateOperation | Output port is disable or busy. Component is not in OMX_StateExecuting. Sending a buffer after end-of-stream has been reported. |
| | OMX_ErrorNone | Normal ends. Transferring buffer to client is successful. |

(*) This API supports only Capture interface.

2.3.2.10 OMX_SetConfig

| OMX_SetConfig | | |
|---------------|---|--|
| Synopsis | Set parameter to ADSP Plugin when this command is called. This command can be called in any OMX_State except OMX_StateInvalid. This function is only support for setting volume rate parameter. | |
| Syntax | <pre>OMX_ERRORTYPE SetConfig(OMX_IN OMX_HANDLETYPE hComponent, OMX_IN OMX_INDEXTYPE nIndex, OMX_IN OMX_PTR pComponentConfigStructure)</pre> | |
| Parameter | hComponent | Pointer to memory area of component handle |
| | nIndex | It indicates which structure is passed to the component. This value is from the OMX_INDEXTYPE enumeration. Supported index are: XAOMX_IndexParamAudioRenderer XAOMX_IndexParamAudioCapture |
| | pComponentConfigStructure | A pointer to the IL client-allocated structure that the component fills. For Renderer and Capture parameters setting structure: XAOMX_AUDIO_PARAM_RENDERER XAOMX_AUDIO_PARAM_CAPTURE This function is only support for volume rate parameter in the setting structure. |
| Return value | OMX_ErrorBadParameter | pComponentConfigStructure points to an invalid memory area. |
| | OMX_ErrorIncorrectStateOperation | Component is in OMX_StateInvalid |
| | OMX_ErrorUnsupportedIndex | The index of parameter structure is not supported by component. |
| | OMX_ErrorNone | Normal ends. Transferring buffer to client is successful. |

2.4 Callback function specification

The OpenMAX IL includes a callback mechanism that allows a component to communicate the IL client. To accomplish a callback, the IL client has three callback functions defined: a generic event handler and two callbacks related to the dataflow (EmptyBufferDone and FillBufferDone).

The IL client is responsible for filling in an OMX_CALLBACKTYPE structure with its callback entry points and passing the structure to the OpenMAX IL core at initialization (init) time.

OMX_CALLBACKTYPE is defined as follows.

```
typedef struct OMX_CALLBACKTYPE {
    OMX_ERRORTYPE (*EventHandler)(
        OMX_IN OMX_HANDLETYPE hComponent,
        OMX_IN OMX_PTR pAppData,
        OMX_IN OMX_EVENTTYPE eEvent,
        OMX_IN OMX_U32 nData1,
        OMX_IN OMX_U32 nData2,
        OMX_IN OMX_PTR pEventData);
    OMX_ERRORTYPE (*EmptyBufferDone)(
        OMX_IN OMX_HANDLETYPE hComponent,
        OMX_IN OMX_PTR pAppData,
        OMX_IN OMX_BUFFERHEADERTYPE* pBuffer);
    OMX_ERRORTYPE (*FillBufferDone)(
        OMX_IN OMX_HANDLETYPE hComponent,
        OMX_IN OMX_PTR pAppData,
        OMX_IN OMX_BUFFERHEADERTYPE* pBuffer);
} OMX_CALLBACKTYPE;
```

2.4.1 EventHandler

A component uses the EventHandler method to notify the IL client when an event of interest occurs within the component. The OMX_EVENTTYPE enumeration defines the set of OpenMAX IL events; refer to the definition of this enumeration for the meaning of each event.

The EventHandler method is defined as follows.

```
OMX_ERRORTYPE(* OMX_CALLBACKTYPE::EventHandler)(  
    OMX_IN OMX_HANDLETYPE hComponent,  
    OMX_IN OMX_PTR pAppData,  
    OMX_IN OMX_EVENTTYPE eEvent,  
    OMX_IN OMX_U32 nData1,  
    OMX_IN OMX_U32 nData2,  
    OMX_IN OMX_PTR pEventData)
```

The information carried within nData1, nData2 and pEventData varies depending on OMX_EVENTTYPE, refer to Table 3-11 of OMX IL Specification v1.1.2 for specific details.

During the processing, component may update some information of output port from default values to exact values. User should take into account the OMX_EventPortSettingsChanged to correct their configurations by getting parameters from component again. Note that, for output port, user has to perform necessary steps to reconfigure the port (see 3.4.5 of OMX IL Specification v1.1.2 for more detail of sequence). However, for input port, user just has to get the parameter again and must not process any further step.

For more detail, please refer to OMX IL Specification 1.1.2, section 3.1.3.9

2.4.2 EmptyBufferDone

A component uses the EmptyBufferDone callback to pass a buffer from an input port back to the IL client. A component updates the nOffset and nFilledLen values of the buffer header to reflect the portion of the buffer it consumed; for example, nFilledLen is set equal to 0 if completely consumed.

In addition to facilitating normal data flow between an executing component and the IL client, a component uses the EmptyBufferDone function to return input buffers to the IL client in the following cases:

- The IL client commands a transition from OMX_StateExecuting or OMX_StatePause to OMX_StateIdle.
- The IL client flushes or disables a port.

In these cases, a component may also return a partially consumed input buffer to the IL client. The EmptyBufferDone call is defined as follows.

```
OMX_ERRORTYPE(* OMX_CALLBACKTYPE::EmptyBufferDone)(  
    OMX_IN OMX_HANDLETYPE hComponent,  
    OMX_IN OMX_PTR pAppData,  
    OMX_IN OMX_BUFFERHEADERTYPE* pBuffer)
```

For more detail, please refer to OMX IL Specification 1.1.2, section 3.1.3.9.

2.4.3 FillBufferDone

Component uses the FillBufferDone callback to pass a buffer from an output port back to the IL client. Component sets the nOffset and nFilledLen of the buffer header to reflect the portion of the buffer it filled; for example, nFilledLen is equal to 0 if it contains no data).

In addition to facilitating normal dataflow between an executing component and the IL client, a component uses this function to return output buffers to the IL client in the following cases:

- The IL client commands a transition from OMX_StateExecuting or OMX_StatePause to OMX_StateIdle.
- The IL client flushes or disables a port.

FillBufferDone is defined as follows.

```
OMX_ERRORTYPE(* OMX_CALLBACKTYPE::FillBufferDone)(  
    OMX_IN OMX_HANDLETYPE hComponent,  
    OMX_IN OMX_PTR pAppData,  
    OMX_IN OMX_BUFFERHEADERTYPE* pBuffer)
```

For more detail, please refer to OMX IL Specification 1.1.2, section 3.1.3.9.

2.5 Structure specification

2.5.1 XAOMX_AUDIO_PARAM_RENDERER

To configure the input port of component, OMX MC Renderer receives the XAOMX_AUDIO_PARAM_RENDERER structure from user (with the index param XAOMX_IndexParamAudioRenderer). User can also obtain the information of input port by get this structure from the component.

```
typedef struct XAOMX_AUDIO_PARAM_RENDERER
{
    OMX_U32                      nSize;
    OMX_VERSIONTYPE              nVersion;
    OMX_U32                      nPCM_frame_size;
    OMX_U32                      nPCM_output1;
    OMX_U32                      nPCM_DMAchannel1;
    OMX_U32                      nPCM_output2;
    OMX_U32                      nPCM_DMAchannel2;
    OMX_U32                      nPCM_in_sample_rate;
    OMX_U32                      nPCM_out_sample_rate;
    OMX_U32                      nPCM_volume_rate;
    OMX_U32                      nPCM_in_channel;
    OMX_U32                      nPCM_out_channel;
    OMX_U32                      nPCM_mix_control;
} XAOMX_AUDIO_PARAM_RENDERER;
```

For more detail about OMX_VERSIONTYPE please refer to OMX IL Specification 1.1.2, section 3.1.2.4.

Table 2-4 shows the detail explanations of this structure. I/O column indicates the element is input or output; Input Value column indicate the valid input value can be set from user.

ADSP Interface for Android Application Note - Renderer/Capture -

Table 2-4 Parameters Structure of Renderer

| Element | I/O | Input Value | Default | Description |
|---------------------------|-----|--|-----------------------|---|
| nSize | O | None | The size of structure | Fixed by component |
| nVersion | O | None | 1.1.2.0 | OMX specification version information |
| nPCM_frame_size (*) | I/O | 1024/2048 | 1024 | Set the PCM frame size |
| nPCM_output1 | I/O | Expected output device 1 | SSI00 | Set the expected output device 1: +SSI device: SSIx0, x from 0 to 9 +SCU_SRC device: SCU_SRCI0 to SCU_SRCI9 |
| nPCM_DMACHannel1 | I/O | ADMAC channel / ADMACPP channel | ADMACPP_CH00 | Set the data transfer method control for output device 1: +ADMACPP_CH00 to ADMACPP_CH28 +ADMAC_CH00 to ADMAC_CH31 |
| nPCM_output2 | I/O | Expected output device 2 | NONCONFIG | Set the expected output device 2: +No device: NONCONFIG (If output1 is SSI device) +SSI device: SSIx0, x from 0 to 9 (If output1 is SCU_SRC device) |
| nPCM_DMACHannel2 | I/O | ADMAC channel / ADMACPP channel | ADMACPP_CH01 | Set the data transfer method control for output device 2: +ADMACPP_CH00 to ADMACPP_CH28 +ADMAC_CH00 to ADMAC_CH31 |
| nPCM_in_sample_rate | I/O | Valid value: 32,000 / 44,100 / 48,000 Hz | 44100 | Set the PCM input sampling rate. |
| nPCM_out_sample_rate (**) | I/O | Valid value: 32,000 / 44,100 / 48,000 Hz | 44100 | Set the PCM output sampling rate. |
| nPCM_volume_rate (***) | I/O | 0x00000000 to 0x007FFFFFFF | 0xFFFFFFFF | Set the volume control value. To disable volume control, this value is set to 0xFFFFFFFF. |
| nPCM_in_channel | I/O | Valid value: 1/2/4/6/8 | 2 | Set the number of PCM input channels |
| nPCM_out_channel | I/O | Valid value: 1/2 | 2 | Set the number of PCM output channels |
| nPCM_mix_control (***) | I/O | Valid value: 0/1 | 0 | Set mixer control flag. (0: mixer disable, 1: mixer enable) |

ADSP Interface for Android Application Note - Renderer/Capture -

For detail about PCM stream structure of Renderer, the software supports the below settings in table 2-5.

The table 2-5 shows the detail explanations of PCM structure. I/O column indicates the element is input or output; Input Value column indicate the valid input value can be set from user.

Table 2-5 PCM stream setting of Renderer

| Element | I/O | Input Value | Default | Description |
|----------------|------------|--------------------|----------------|--|
| nBitPerSample | I/O | 16 or 24 bits | 16 | Set the PCM width of PCM stream. Supporting mode (nBitPerSample - nPCM_out_channel) is 24bit-2channel, 16bit-2channel, 16bit-1channel. |

Note:

(*) Frame size is 1024 is the best performance. The value 2048 does not guarantee the performance of Renderer plugin.

(**) When routing between Capture-Renderer and using SRC, In_fs of Capture and Out_fs of Renderer must be the same.

(***) Because hardware limitation has only two CMD modules. Therefore, user can only use volume control or mixing stream up to maximum two different SSI output.

2.5.2 XAOMX_AUDIO_PARAM_CAPTURE

To configure the output port of component, OMX MC Capture receives the XAOMX_AUDIO_PARAM_CAPTURE structure from user (with the index param XAOMX_IndexParamAudioCapture). User can also obtain the information of output port by get this structure from the component.

```
typedef struct XAOMX_AUDIO_PARAM_CAPTURE
{
    OMX_U32                      nSize;
    OMX_VERSIONTYPE              nVersion;
    OMX_U32                      nPCM_frame_size;
    OMX_U32                      nPCM_input1;
    OMX_U32                      nPCM_DMACHannel1;
    OMX_U32                      nPCM_input2;
    OMX_U32                      nPCM_DMACHannel2;
    OMX_U32                      nPCM_in_sample_rate;
    OMX_U32                      nPCM_out_sample_rate;
    OMX_U32                      nPCM_volume_rate;
} XAOMX_AUDIO_PARAM_CAPTURE;
```

For more detail about OMX_VERSIONTYPE please refer to OMX IL Specification 1.1.2, section 3.1.2.4.

Table 2-6 shows the detail explanations of this structure. I/O column indicates the element is input or output; Input Value column indicate the valid input value can be set from user.

ADSP Interface for Android Application Note - Renderer/Capture -

Table 2-6 Parameters Structure of Capture

| Element | I/O | Input Value | Default | Description |
|--------------------------|-----|--|-----------------------|--|
| nSize | O | None | The size of structure | Fixed by component |
| nVersion | O | None | 1.1.2.0 | OMX specification version information |
| nPCM_frame_size (*) | I/O | 1024/2048 | 1024 | Set the PCM frame size |
| nPCM_input1 | I/O | Expected input device 1 | SSI10 | Set the expected input device 1: +SSI device: SSIx0, x from 0 to 9 +SCU_SRC device: SCU_SRCI0-SCU_SRCI9 |
| nPCM_DMACHannel1 | I/O | ADMAC channel / ADMACPP channel | ADMACPP_CH10 | Set the data transfer method control for input device 1: +ADMACPP_CH00 to ADMACPP_CH28 +ADMAC_CH00 to ADMAC_CH31 |
| nPCM_input2 | I/O | Expected input device 2 | NONCONFIG | Set the expected input device 2: +No device: NONCONFIG (If input1 is SSI device) +SSI device: SSIx0, x form 0 to 9 (If input1 is SCU_SRC device) |
| nPCM_DMACHannel2 | I/O | ADMAC channel / ADMACPP channel | ADMACPP_CH02 | Set the data transfer method control for input device 2: +ADMACPP_CH00 to ADMACPP_CH28 +ADMAC_CH00 to ADMAC_CH31 |
| nPCM_in_sample_rate (**) | I/O | Valid value: 32,000 / 44,100 / 48,000 Hz | 44100 | Set the PCM input sampling rate. |
| nPCM_out_sample_rate | I/O | Valid value: 32,000 / 44,100 / 48,000 Hz | 44100 | Set the PCM output sampling rate. |
| nPCM_volume_rate (***) | I/O | 0x00000000 to 0x007FFFFF | 0xFFFFFFFF | Set the volume control value. To disable volume control, this value is set to 0xFFFFFFFF. |

ADSP Interface for Android Application Note - Renderer/Capture -

For detail about PCM stream structure of Capture, the software supports the below settings in table 2-7.

The table 2-7 shows the detail explanations of PCM structure. I/O column indicates the element is input or output; Input Value column indicate the valid input value can be set from user.

Table 2-7 PCM stream setting of Capture

| Element | I/O | Input Value | Default | Description |
|----------------|------------|--------------------|----------------|---|
| nChannels | I/O | 1 or 2 channels | 2 | Set channels of PCM stream. Supporting mode (nBitPerSample – nChannels) is 24bit-2channel, 16bit-2channel, 16bit-1channel |
| nBitPerSample | I/O | 16 or 24 bits | 16 | Set the PCM width of PCM stream. Supporting mode (nBitPerSample – nChannels) is 24bit-2channel, 16bit-2channel, 16bit-1channel |

Note:

(*) Frame size is 1024 is the best performance. The value 2048 does not guarantee the performance of Capture plugin.

(**) When routing between Capture-Renderer and using SRC, In_fs of Capture and Out_fs of Renderer must be the same.

(***) Because hardware limitation has only two CMD modules.
Therefore, user can only use volume control up to maximum two different SSI output.

3 Process sequence

3.1 Initialize Component




Figure 3-1 Initialize the Component and preparation phase

3.2 Decoding sequence




Figure 3-2 Decoding sequence

3.3 De-initialize Component




Figure 3-3 De-Initialize Component and OMX IL Core

Note: The order of 2: return (of SendCommand) and 3: EventCallback is not guaranteed. It depends on the current status of component.

4 Notes

This section describes the notice of developing user programs.

4.1 Function Call

User programs which calls the functions in this specification should obey the calling rules of compiler.

4.2 Other notes

4.2.1 Allocation of memory

Before calling the functions in this specification, allocate necessary memory area and each structure used for the parameters of each function.

4.2.2 Out of range memory access

The functions in this specification never access out of allocated memory or related I/O.

4.2.3 Combination with other applications

Take care not to duplicate symbol names when other applications are combined with other programs.

4.2.4 Monitoring on Performance

The products embedding this Software shall observe performance of the Software periodically with Watch Dog timer or such functions in order not to damage system performance.

CONFIDENTIAL

| | |
|------------------|--|
| Revision History | ADSP Interface for Android Application Note - Renderer/Capture - |
|------------------|--|

| Rev. | Date | Description | |
|------|---------------|-------------|------------|
| | | Page | Summary |
| 1.00 | May. 24, 2019 | - | New Create |

ADSP Interface for Android Application Note - Renderer/Capture -

Publication Date: May 24, 2019 Rev. 1.00

Published by: Renesas Electronics Corporation



SALES OFFICES

Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

Renesas Electronics Corporation

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061, Japan

Renesas Electronics America Inc.

1001 Murphy Ranch Road, Milpitas, CA 95035, U.S.A.

Tel: +1-408-432-8888, Fax: +1-408-434-5351

Renesas Electronics Canada Limited

9251 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3

Tel: +1-905-237-2004

Renesas Electronics Europe Limited

Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K

Tel: +44-1628-651-700

Renesas Electronics Europe GmbH

Arcadiastrasse 10, 40472 Düsseldorf, Germany

Tel: +49-211-6503-0, Fax: +49-211-6503-1327

Renesas Electronics (China) Co., Ltd.

Room 1709 Quantum Plaza, No.27 ZhichunLu, Haidian District, Beijing, 100191 P. R. China

Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

Renesas Electronics (Shanghai) Co., Ltd.

Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai, 200333 P. R. China

Tel: +86-21-2226-0888, Fax: +86-21-2226-0999

Renesas Electronics Hong Kong Limited

Unit 1601-1611, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong

Tel: +852-2265-6688, Fax: +852 2886-9022

Renesas Electronics Taiwan Co., Ltd.

13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan

Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

Renesas Electronics Singapore Pte. Ltd.

80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre, Singapore 339949

Tel: +65-6213-0200, Fax: +65-6213-0300

Renesas Electronics Malaysia Sdn.Bhd.

Unit 1207, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia

Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

Renesas Electronics India Pvt. Ltd.

No.777C, 100 Feet Road, HAL 2nd Stage, Indiranagar, Bangalore 560 038, India

Tel: +91-80-67208700, Fax: +91-80-67208777

Renesas Electronics Korea Co., Ltd.

17F, KAMCO Yangjae Tower, 262, Gangnam-daero, Gangnam-gu, Seoul, 06265 Korea

Tel: +82-2-558-3737, Fax: +82-2-558-5338



ルネサスエレクトロニクス株式会社

営業お問合せ窓口

<http://www.renesas.com>

営業お問合せ窓口の住所は変更になることがあります。最新情報につきましては、弊社ホームページをご覧ください。

ルネサス エレクトロニクス株式会社 〒135-0061 東京都江東区豊洲3-2-24 (豊洲フォレシア)

技術的なお問合せおよび資料のご請求は下記どうぞ。
総合お問合せ窓口：<https://www.renesas.com/contact/>

ADSP Interface for Android RCG3AHIFA9001ZDP