

17.10 Table: LOSSMODEL

17.10.1 LOSSMODEL

Name	LOSSMODEL
Comment	LOSSMODEL sets out segment breakpoints in loss model for each interconnector, used by LP Solver modelling of interconnector flows.

17.10.2 Description

LOSSMODEL data is public, so is available to all participants.

Source

LOSSMODEL only changes annually, when there is a change in the interconnector.

17.10.3 Notes

Name	Comment	Value
Visibility	Data in this table is:	Public

17.10.4 Primary Key Columns

Name
 EFFECTIVEDATE
 INTERCONNECTORID
 LOSSSEGMENT
 VERSIONNO

17.10.5 Index Columns

Name
 LASTCHANGED

17.10.6 Content

Name	Data Type	Mandatory	Comment
EFFECTIVEDATE	datetime	X	Calendar date data set is effective
VERSIONNO	numeric(3,0)	X	Version number within effective date
INTERCONNECTORID	varchar(10)	X	Interconnector identifier
PERIODID	varchar(20)		Not used
LOSSSEGMENT	numeric(6,0)	X	Segment Identifier (1 to 80 at present)
MWBREAKPOINT	numeric(6,0)		MW Value for segment
LOSSFACTOR	numeric(16,6)		Not used
LASTCHANGED	datetime		Last date and time record changed